

Apple® IIc Programmer's Guide to the 3.5 ROM

Apple® IIc Programmer's Guide
to the 3.5 ROM



Apple® IIc Programmer's Guide to the 3.5 ROM

030-1196-A

Reorder Apple Product #A2L4037

Contents

PREFACE

Read Me First	v
About This Manual	v
Where to Look for More Information	vi
Watch for These	vi

CHAPTER 1

Overview	1
Physical Changes	2
Machine Identification	2
Features Removed	3
Interrupt Handler Revision	3
Starting and Restarting	4
New Serial Port Commands	4
Monitor Enhancements	6
The Protocol Converter	6
The Protocol Converter Bus	7

CHAPTER 2

Monitor Enhancements	9
The Mini-Assembler	10
Starting the Mini-Assembler	10
Using the Mini-Assembler	11
Mini-Assembler Instruction Formats	14
STEP and TRACE	15
Cautions	17
ASCII Input Mode	17

CHAPTER 3

Calls to the Protocol Converter	19
Locating the Protocol Converter	20
How to Issue a Call to the Protocol Converter	20
Cautions	22
Descriptions of the Protocol Converter Calls	22
Format of Call Descriptions	24
STATUS	25
Parameter Descriptions	25
Possible Errors	29
READ BLOCK	30
Parameter Descriptions	30
Possible Errors	31
WRITE BLOCK	32
Parameter Descriptions	32
Possible Errors	33
FORMAT	34
Parameter Descriptions	34
Possible Errors	34
CONTROL	35
Parameter Descriptions	35
Possible Errors	38
INIT	39
Parameter Descriptions	39
Possible Errors	39
OPEN	40
Parameter Descriptions	40
Possible Errors	40

CLOSE	41
Parameter Descriptions	41
Possible Errors	41
READ	42
Parameter Descriptions	42
Possible Errors	43
WRITE	44
Parameter Descriptions	44
Possible Errors	45
An Example: Issuing a Protocol Converter Call	46
Summary of Commands and Parameters	50
Summary of Error Codes	51

APPENDIX A

Firmware Listing

53

Index

249

This reference manual is intended for experienced Apple® IIc assembly-language programmers and hardware designers. It is a supplement to the *Apple IIc Reference Manual*. If you're a beginning user, you should learn about your Apple IIc and some of the programs, languages, and devices that you intend to use before you start reading this manual. A list of some Apple manuals that will help you learn about the operation and function of Apple II family computers is given at the end of this preface.

This manual assumes that you have access to Apple manuals describing the programs, languages, and devices that you intend to use with your Apple IIc.

About This Manual

The Programmer's Guide that you are reading describes the differences between the original Apple IIc and the Apple IIc with 32-kilobyte (32K) ROM.

3.5 ROM

The name *3.5 ROM* refers to the ROM that is described in this book as the *32K ROM*.

Chapter 1 details the changes brought about by the ROM enhancement. It also refers to other sources of information about Apple IIc operation.

Chapter 2 describes Monitor enhancements, including the Mini-Assembler and the STEP and TRACE routines.

Chapter 3 describes the use of the Protocol Converter and Protocol Converter calls.

Appendix A is an assembly listing of the firmware for the 32K ROM.

Where to Look for More Information

The following manuals have information about the function and programming of Apple II-family computers and some important peripherals.

These books are available from your Apple dealer:

- About Your Enhanced Apple IIe: Programmer's Guide* (030-1143-A)
- Apple IIC Owner's Manual* (030-1030-A)
- Apple Pascal 1.2 Update Manual* (030-0602)
- Apple Pascal 1.3 Update Manual* (030-1206-A)
- Synertek Programming Manual* (A2L0003)

These books are available at your local bookstore:

- Apple IIC Reference Manual* (Addison-Wesley 17727-7)
- ProDOS Technical Reference Manual* (Addison-Wesley 17728-5)

Watch for These

Look for these throughout the manual:

By the Way: Text set off in this manner presents sidelights or interesting pieces of information.

Important Text set off in this manner—with a tag in the margin—presents important information.

▲Warning Warnings like this indicate potential problems or disasters.

Apple IIe Text set off in this manner—with the name of an Apple computer or peripheral device in the margin—applies specifically to that computer or device.

This chapter tells you about the operating differences between the original Apple® IIc and the Apple IIc with 32K ROM.

The following topics are discussed in this chapter:

- Physical changes in the Apple IIc
- Machine identification
- Features removed
- Interrupt handler revision
- Starting up from drives other than a Disk II
- New serial port commands
- Monitor enhancements, including the Mini-Assembler and the STEP and TRACE routines
- The Protocol Converter
- The Protocol Converter Bus

The Monitor enhancements and the Protocol Converter are described in detail in the following chapters.

Physical Changes

The 32K ROM for the Apple IIc replaces the original 16K ROM. The 32K ROM is organized into two 16K segments called the main and alternate banks. To toggle between banks, read address \$C028. A write to \$C028 toggles the line twice, leaving it unchanged.

Installing the new ROM involves cutting one trace and jumping another on the Apple IIc main logic board. Once the Apple IIc has been modified for the new ROM, the old ROM cannot be used in it.

▲Warning

Improperly done modifications can damage your Apple IIc. Modifications performed by anyone other than an authorized Apple dealer void your warranty.

Machine Identification

Your Apple II program can tell which member of the Apple II family it is running on by checking the values in four locations of ROM (the *identification bytes*). Table 1-1 lists the machines and their identification bytes.

Table 1-1. Apple II Family Identification Bytes

Machine	\$FBB3	\$FB1E	\$FBC0	\$FBBF
Apple II	\$38			
Apple II Plus	\$EA	\$AD		
Apple III (emulation)	\$EA	\$8A		
Apple IIe (original)	\$06		\$EA	
Apple IIe (enhanced)	\$06		\$E0	
Apple IIc (original)	\$06		\$00	\$FF
Apple IIc (32K ROM)	\$06		\$00	\$00

The only difference between the identification bytes for the original Apple IIc and the Apple IIc with 32K ROM is at \$FBBF. That location was \$FF in the original ROM and is \$00 in the current revision of the 32K ROM.

If you're not sure whether a particular Apple IIc has the 32K ROM installed, follow the instructions in Chapter 2 for starting the Mini-Assembler. If you are successful (the Monitor prompt character changes from * to !), then the 32K ROM is present.

Features Removed

PR#7 (from BASIC) or [7] [CONTROL]-[P] (from the Monitor) no longer causes the system to **boot** from the external Disk II drive because that ROM space is now used for new features.

Interrupt Handler Revision

If the alternate bank of the ROM is being used, the interrupt handler switches the ROM to the main bank before calling a user's interrupt routine, and restores the alternate bank before returning from the interrupt. The bank of ROM to be returned to is indicated by the least significant bit of the byte stored in address \$0044 after a break: 0 for the main bank, and 1 for the alternate bank of the ROM.

Programs written for the Apple II, II Plus, or IIe sometimes read \$C02x before a BRK instruction that attempts to jump to a monitor routine. Reading \$C02x toggles the cassette output signal in the Apple II, II Plus, and IIe, but switches between the main and alternate banks of ROM in the Apple IIc with 32K ROM. When the interrupt handler detects that a program

has tried to jump to a monitor routine while in the alternate bank of the ROM, it automatically switches to the main bank of ROM and attempts to restart the program at the point before the break occurred. Note that this feature does not work for programs that try to read monitor data after a \$C02x access because, in this case, no BRK instruction is executed.

Starting and Restarting

The Protocol Converter: see Chapter 3.

When the Apple IIc with 32K ROM is powered up, it attempts to boot from the built-in disk drive. If this fails, it attempts to boot from the first device attached to the Protocol Converter. If this fails too, the message **CHECK DISK DRIVE** is displayed and the system hangs.

The built-in Disk II can be booted with a **PR#6** command from BASIC, a **[6] [CONTROL]-[P]** from the Monitor, or **JMP \$C600** from a machine-language program.

An external UniDisk™ 3.5 can be booted with a **PR#5** command from BASIC, a **[5] [CONTROL]-[P]** from the Monitor, or **JUMP \$C500** from a machine-language program.

Important

External UniDisk 3.5 startup works with ProDOS®-based and Pascal 1.3 programs, but not with earlier versions of Pascal or with DOS.

New Serial Port Commands

The serial ports and the use of serial port commands are discussed in Chapters 7 and 8 of the *Apple IIc Reference Manual*.

Several new commands that can be used with serial ports 1 and 2 have been included in the 32K ROM. Each of these commands consists of two letters: the first letter identifies the command while the second letter enables (E) or disables (D) the function. You may separate the command and the letter with a space if you wish.

For example, to cause a line feed character to be output after every carriage return, use the command LE (or L E). To disable this function, use the command LD (or L D).

C D/E

(Column overflow)

When enabled, this command causes a carriage return character to be sent automatically any time the column count exceeds the printer line width. Default = enabled.

F D/E

(Find keyboard)

When enabled, this command causes your Apple IIc to accept signals coming from its keyboard as well as those coming over the serial port. You can use this command to disable the keyboard before receiving data or sending data to the printer, to prevent accidental keystrokes from disrupting the data flow. Be sure your program re-enables the keyboard when the data transfer is complete. This feature is available only in BASIC. Default = enabled.

L D/E

(Line feed after carriage return)

When enabled, this command causes a line feed character to be output automatically after each carriage return character. LD and LE have the same effects as commands L (enable line feed) and K (disable line feed), which still work. Default = disabled.

M D/E

(Mask line feeds)

When enabled, all incoming line feed characters are removed from the data stream. Default = enabled.

X D/E

(XON/XOFF protocol)

When enabled, XON/XOFF protocol is used: the Apple IIc looks for any XOFF character (ASCII character DC3, decimal 19), and responds by halting transmission until an XON character (ASCII character DC1, decimal 17) is received. Default = disabled.

Monitor Enhancements

The Apple IIc with 32K ROM includes the Mini-Assembler, which lets you enter machine-language programs directly from the keyboard; and the STEP and TRACE Monitor routines, which facilitate debugging of machine-language programs. The Mini-Assembler and the STEP and TRACE routines are discussed in detail in Chapter 2.

Important

Monitor commands can't be executed directly from the Mini-Assembler on an Apple IIc with 32K ROM.

The Protocol Converter

The Protocol Converter is a set of routines used to support I/O devices, such as the UniDisk 3.5, that connect to the external disk port. The routines begin at address \$C500 in ROM. ProDOS and Pascal 1.3 recognize the Protocol Converter as a block device. The Protocol Converter and calls to the Protocol Converter are described in detail in Chapter 3.

The Protocol Converter Bus

The Protocol Converter Bus (CBus) consists of hardware and software components that permit and control communications between the Apple IIc and intelligent I/O devices (such as UniDisk 3.5's) connected to its external disk port.

The software part of the CBus includes the Protocol Converter and the CBus communication protocol.

The hardware component of the CBus is a daisy chain made up of the following:

- The Apple IIc disk port, using the disk controller unit (IWM), see Chapter 11 in the *Apple IIc Reference Manual*.
- One or more intelligent I/O devices (*bus residents*).
- One Disk IIc (optional). If included, the Disk IIc must be the terminal member of the daisy chain, and remains dormant when a bus resident is addressed.

The maximum number of bus residents is limited by the Apple IIc's power supply and IWM drive capacity. The software can support up to 127 bus residents.

This chapter is about enhancements made to the Monitor, including the addition of the Mini-Assembler (which allows machine-language programs to be entered directly from the keyboard), and debugging routines for assembly-language programs. The following topics are discussed in this chapter:

- Procedures for using the Mini-Assembler
- The Mini-Assembler commands
- The STEP and TRACE debugging routines

The Mini-Assembler

Without an assembler, you have to write your machine-language program, take the hexadecimal values for the opcodes and operands, and store them in memory using the monitor commands described in Chapter 10 of the *Apple IIc Reference Manual*.

The Mini-Assembler lets you enter machine-language programs directly from the keyboard of your Apple. You can type ASCII characters in Mini-Assembler programs, exactly as you type them in the Monitor.

Important

The Mini-Assembler doesn't accept labels; you must use actual hexadecimal values and addresses.

Starting the Mini-Assembler

To start the Mini-Assembler, first call the Monitor by typing **CALL -151** and pressing **[RETURN]**. Then from the Monitor, type **!** and press **[RETURN]**. The Monitor prompt character then changes from ***** to **!**.

When you finish using the Mini-Assembler, press **[RETURN]** from a blank line to return to the Monitor.

To enter code into memory, type the address, a colon, and the instruction. For example, after entering the Mini-Assembler, type

!300:STA C030

You can enter a series of instructions by typing a space, then the instruction, followed by [RETURN]:

```
!300:STA C030
! LDA #A0
! INX
```

Each succeeding instruction is placed in the next consecutive memory location. As you type in instructions, each is replaced by the starting address of the instruction, the hexadecimal value(s) of the instruction, followed by mnemonics describing the instruction. For example, the sequence of instructions given above produces the following on your display screen:

0300-	8D 30 C0	STA \$C030
0303-	A9 A0	LDA #\$A0
0305-	E8	INX

When you're ready to execute your program, press [RETURN] to leave the Mini-Assembler and return to the Monitor.

Important Monitor commands can't be executed directly from the Mini-Assembler on an Apple IIc with 32K ROM.

Using the Mini-Assembler

The Mini-Assembler saves one address, that of the program counter. Before you start to type a program, you must set the program counter to point to the location where you want the Mini-Assembler to store your program. Do this by typing the address followed by a colon.

After the colon, type the mnemonic for the first instruction in your program, followed by a space and the operand of the instruction. Now press [RETURN]. The Mini-Assembler converts the line you typed into hexadecimal, stores it in memory beginning at the location of the program counter, and then disassembles it again and displays the disassembled line. It then displays a prompt character on the next line.

Now the Mini-Assembler is ready to accept the second instruction in your program. To tell it that you want the next instruction to follow the first, don't type an address or a colon; just type a space and the next instruction's mnemonic and operand, then press [RETURN]. The Mini-Assembler assembles that line and waits for another.

Formats for operands are listed in Table 2-1.

If the line you type has an error in it, the Mini-Assembler causes the Apple IIc to beep and display a caret (^) under or near the offending character in the input line. Most common errors are the result of typographical mistakes: misspelled mnemonics, missing parentheses, and so forth. The Mini-Assembler also rejects the input line if you forget the space before or after a mnemonic or include an extraneous character in a hexadecimal value or address. If the destination address of a branch instruction is out of the range of the branch (more than 127 locations distant from the address of the instruction), the Mini-Assembler flags this as an error.

Dollar Signs: In this book, dollar signs (\$) in addresses signify that the addresses are in hexadecimal notation. The dollar signs are ignored by the Mini-Assembler and may be omitted when typing programs.

```
!300:LDX #02
0300- A2 02      LDX    #$02
! LDA $0,X
0302- B5 00      LDA    $00,X
! STA $10,X
0304    95 10      STA    $10,X
! DEX
0306- CA          DEX
! STA $C030
0307- 8D 30 C0      STA    $C030
! BPL $302
030A- 10 F6      BPL    $0302
! BRK
030C- 00          BRK
!
```

To leave the Mini-Assembler and return to the Monitor, press [RETURN] at a blank line.

Your assembly-language program is now stored in memory. You can display it with the LIST command:

```
*300L
0300- A2 02      LDX    #$02
0302- B5 00      LDA    $00,X
0304- 95 10      STA    $10,X
0306- CA          DEX
0307- 8D 30 C0    STA    $C030
030A- 10 F6      BPL    $0302
030C- 00          BRK
030D- 00          BRK
030E- 00          BRK
030F- 00          BRK
0310- 00          BRK
0311- 00          BRK
0312- 00          BRK
0313- 00          BRK
0314- 00          BRK
0315- 00          BRK
0316- 00          BRK
0317- 00          BRK
0318- 00          BRK
0319- 00          BRK
*
```

Mini-Assembler Instruction Formats

The Apple IIc Mini-Assembler recognizes 66 mnemonics and 15 addressing formats. The mnemonics are standard, as used in the *Synertek Programming Manual*, but the addressing formats are somewhat different; see Table 2-1.

Table 2-1. Mini-Assembler Address Formats

Addressing Mode	Format
Accumulator	*
Implied	*
Immediate	#\${value}
Absolute	\${address}
Zero page	\${address}
Indexed zero page	\${address},X \${address},Y
Indexed absolute	\${address},X \${address},Y
Relative	\${address}
Indexed indirect	(\${address},X)
Indirect indexed	(\${address}),Y
Absolute indirect	(\${address})

* These instructions have no operands.

An address consists of one or more hexadecimal digits. The Mini-Assembler interprets addresses the same way the Monitor does: if an address has fewer than four digits, the Mini-Assembler adds leading zeros; if the address has more than four digits, then it uses only the last four.

There is no syntactical distinction between the absolute and zero page addressing modes. If you give an instruction to the Mini-Assembler that can be used in both absolute and zero page mode, the Mini-Assembler assembles that instruction in absolute mode if the operand for that instruction is greater than \$FF, and it assembles it in zero page mode if the operand is less than \$100.

Instructions in accumulator mode and implied addressing mode need no operands.

Branch instructions, which use the relative addressing mode, require the target address of the branch. The Mini-Assembler automatically calculates the relative distance to use in the instruction. If the target address is more than 127 locations distant from the instruction, the Mini-Assembler sounds a bell (beep), displays a caret (^) under the target address, and does not assemble the line.

If you give the Mini-Assembler the mnemonic for an instruction and an operand, and the addressing mode of the operand cannot be used with the instruction you entered, then the Mini-Assembler will not accept the line.

STEP and TRACE

STEP and TRACE are Monitor facilities for debugging assembly-language programs. The STEP command decodes, displays, and executes one instruction at a time, and the TRACE command steps continuously through a program, stopping when a BRK instruction is executed or [apple] is pressed. You can press [S] to slow down the trace to one step per second.

Each STEP command causes the Monitor to execute the instruction in memory pointed to by the Program Counter. The instruction is displayed in its disassembled form, then executed. The contents of the 65C02's internal registers are displayed after the instruction is executed. After execution, the Program Counter is incremented to point to the next instruction in the program.

Here is an example of the STEP command, using the following program:

```
$0300: LDX #02
$0302: LDA $00,X
$0304: STA $10,X
$0306: DEX
$0307: STA $C030
$030A: BPL $0302
$030C: BRK
```

To step through this program, first call the Monitor by typing **CALL - 151** and pressing [RETURN], and then from the Monitor, type **300S** (to start the STEP routine at address \$0300). Type [S] to advance each additional step

through the program. The Monitor keeps the Program Counter and the last opened address separate from one another, so you can examine or change the contents of memory while you are stepping through your program.

Here's what happens when you step through the program above, examining the contents of location \$0012 after the third step. Note that in this example, what you type appears just after the * prompt, and the information on the next two lines—that begin without the * prompt—is what the computer displays on the screen in response.

```
*300S
0300- A2 02      LDX #02
M=CA A=0A X=02 Y=D8 P=30 S=F8
*S

0302- B5 00      LDA $00,X
M=CA A=0C X=02 Y=D8 P=30 S=F8
*S

0304- 95 10      STA $10,X
M=CA A=0C X=02 Y=D8 P=30 S=F8
*12

0012- 0C
*S

0306- CA         DEX
M=CA A=0C X=01 Y=D8 P=30 S=F8
*S

0307- 8D 30 C0 STA $C030
M=CA A=0C X=01 Y=D8 P=30 S=F8
*S

030A- 10 F6      BPL $0302
M=CA A=0C X=01 Y=D8 P=30 S=F8
*S

0302- B5 00      LDA $00,X
M=CA A=0B X=01 Y=D8 P=30 S=F8
*S

0304- 95 10      STA $10,X
M=CA A=0B X=01 Y=D8 P=30 S=F8
*
```

The TRACE command is a continuous version of the STEP command; it will stop stepping through the program only when you press  or when it encounters a BRK instruction in the program. Press  to slow the trace to one step per second.

Cautions

Keep the following cautions in mind when using the STEP and TRACE Monitor commands:

- If the program ends with an RTS instruction, the TRACE routine will continue to run indefinitely until stopped with .
- You can't step or trace through routines that use the same zero page locations as the Monitor.

ASCII Input Mode

This mode lets you enter ASCII characters as well as their hexadecimal ASCII equivalents. This means that 'A' is the same as C1 and 'B' is the same as C2 to the Monitor. The ASCII value for *any* character following an apostrophe is used by the Monitor. For example, to enter the string "Hooray for sushi!" at \$300 in memory, type

```
*300:'H 'o 'o 'r 'a 'y ' 'f 'o 'r ' 's 'u 's 'h 'i '!
```

Note that each character to be placed in memory is delimited by a leading ' and a trailing space. The only exception to this rule is that the last character in the line is followed by a RETURN character instead of a space.

This chapter is about the Protocol Converter, which is a set of assembly-language routines used to support external I/O devices, such as UniDisk 3.5. To ProDOS and Pascal 1.3, the Protocol Converter appears to be a block device.

The following topics are discussed in this chapter:

- How to locate the Protocol Converter
- How to issue a call to the Protocol Converter
- The use of each call
- The parameters required for each call
- Possible errors codes returned for each call
- The possible causes of the errors

At the end of this chapter is an example of an assembly-language program that uses a Protocol Converter call.

Locating the Protocol Converter

The code for the Protocol Converter always begins at address \$C500 in the Apple IIc with 32K ROM. To ensure compatibility of your programs with the Apple IIe, however, your Protocol Converter routines should always begin with a search for the Protocol Converter by looking for the following bytes: CN01 = \$20, CN03 = \$00, CN05 = \$03, and \$CN07 = 00, where N can be from 1 to 7. The Protocol Converter entry point is then at address \$CN00 + (\$CNFF) + 3. The sample program at the end of this chapter illustrates such a search.

How to Issue a Call to the Protocol Converter

MLI calls: see the *ProDOS Technical Reference Manual*, Chapter 4.

Protocol Converter calls are coded in a manner similar to ProDOS Machine Language Interface (MLI) calls: The program executes a JSR (jump to subroutine) to a dispatch routine at address \$C500 + (\$C5FF) + 3, where (\$C5FF) refers to the value of the byte located at \$C5FF.

The number of the Protocol Converter call and a two-byte pointer to the call's parameter list must immediately follow the call. Here is an example of a call to the Protocol Converter:

```
IWMCALL JSR DISPATCH ;Call PC command dispatcher
DFB CMDNUM ;This specifies the command type
DW CMDLIST ;2-byte (low,high) pointer to parameter list
BCS ERROR ;Carry is set on an error
```

The command number determines the Protocol Converter call to be used. The length and contents of the parameter list depend on the call, as described in Section "Descriptions of the Protocol Converter Calls."

Upon completion of the call, the program resumes execution at the statement following the pointer to the parameter list. In this example, the DFB and DW statements are skipped, and execution resumes with the BCS statement. If the call is successful, the C flag (in the Processor Status register of the 65C02 microprocessor) is cleared (0), and the accumulator (the A register) is cleared to all zeros. If the call is unsuccessful, the C flag is set (1), and the error code is placed in the A register. After the Protocol Converter call, the contents of the 65C02's registers are as follows:

Register:	Processor Status	X	Y	A	PC	S
Bit:	N Z C D V I B					
Successful call:	x x 0 0 x u u x x 0				JSR+3	u
Unsuccessful call:	x x 1 0 x u u x x Error				JSR+3	u

x = undefined, except in cases where index information is returned in X and Y

u = unchanged

Most Protocol Converter calls include a two-byte pointer to a parameter list, which may contain information to be used by the call, or provide space for information to be returned by the call.

Cautions

You *must* observe the following cautions when using the Protocol Converter, or *your program will crash*:

- The Protocol Converter requires up to 35 bytes of stack space. Be sure you take this into account when calculating the stack space used by your program.
Failure to allow for the stack space used by the Protocol Converter can result in a stack overflow, causing your program to crash when it attempts to access the data that have been overwritten.
- Data cannot be read from the Protocol Converter into RAM that is not both read-enabled and write-enabled. The Protocol Converter must be able to read from the RAM after writing to it, to obtain a checksum. Failure to observe this rule results in an error (BUSERR \$06).
- Do not attempt to use the Protocol Converter to put anything into zero page locations. These locations are reserved for temporary storage of data by the Protocol Converter.

Reading and writing to RAM: see Section "Bank-Switched Memory" in the *Apple IIc Reference Manual*.

Descriptions of the Protocol Converter Calls

Calls to the Protocol Converter are used

- to obtain status information about a device
- to reset a device
- to format the medium in a device
- to read from a device
- to write to a device
- to send control information to a device.

The Protocol Converter calls, in command-number sequence, are:

STATUS (\$00)	Returns status information about a particular device, including general status (character or block device, read or write protection, format allowed, device on line); the device control block (set with the CONTROL call); the device newline status (character devices only); and device-specific information (number of blocks, ID string, device name, device type, device firmware version).
READ BLOCK (\$01)	Reads one 512-byte block from a disk device, and writes it to memory.
WRITE BLOCK (\$02)	Writes one 512-byte block from memory to a disk device.
FORMAT (\$03)	Prepares all blocks on a block device for reading and writing.
CONTROL (\$04)	Controls some device functions, including warm resets, setting the device control block (which controls global aspects of the device's operating environment), setting newline status (character devices only), and device interrupts. Several CONTROL calls are device-specific.
INIT (\$05)	Resets all resident devices. A global reset is done automatically on startup or system resets from the keyboard; an application should never have to reset all devices.
OPEN (\$06)	Prepares a character device for reading or writing.
CLOSE (\$07)	Tells a character device that a sequence of reads or writes is over.

READ (\$08)	Reads a specified number of bytes from a specified device.
WRITE (\$09)	Writes a specified number of bytes from memory to a specified device.

Format of Call Descriptions

The following sections describe each protocol converter call, including the command number, the parameter list, and error codes. The calls are discussed in command-number order. Each call is shown in this format:

Command Name The name used to identify the call for descriptive purposes.

Command Number The number, in hexadecimal, that specifies the call to the Protocol Converter.

Parameter List A list of the parameters required for the call.

General Description The purpose and use of the call.

Parameter Descriptions A description of each parameter, and descriptions of data bytes pointed to by parameters. When a parameter is a status or control code, the meaning of each code number is discussed.

Possible Errors A list of the error codes that can be returned by this call. A complete list of Protocol Converter error codes is included at the end of this chapter.

STATUS

Command Number	\$00
Parameter List	\$03 (parameter count) Unit number Status list pointer (low byte, high byte) Status code

The STATUS call returns status information about a particular device. The type of information returned is determined by the status-code parameter, and the location to which it is returned is determined by the status list pointer.

After a STATUS call has been executed, the 65C02's X and Y registers contain the number of bytes of status information returned (the low byte of this number is in the X register, and the high byte is in the Y register).

Parameter Descriptions

Parameter Count 1-byte value	3 for this call.
Unit Number 1-byte value	The Protocol Converter assigns each device a unique number during initialization (on startup and cold reset). The numbers are in the range \$01—\$7E, and are assigned according to the devices' positions in the chain.
Status List Pointer 2-byte value	Points to the buffer to which the status is to be returned. The length required for the buffer varies depending on the status request being made.
Status Code 1-byte value	Indicates what kind of status request is being made. Status codes are in the range \$00-\$FF, as follows:

Important

Use a unit number of \$00 and a status code of \$00 in a STATUS call to obtain the status of the Protocol Converter itself (see the discussion under Status Code = \$00, below).

Status List Pointer 2-byte value	Points to the buffer to which the status is to be returned. The length required for the buffer varies depending on the status request being made.
Status Code 1-byte value	Indicates what kind of status request is being made. Status codes are in the range \$00-\$FF, as follows:

Table 3-1. Status Codes

Code	Status Returned
\$00	Return device status
\$01	Return device control block (DCB)
\$02	Return newline status (character devices only)
\$03	Return device information block (DIB)
\$05	Return UniDisk 3.5 status

UniDisk 3.5

Status codes \$01 and \$02 are not supported by the UniDisk 3.5 and result in an error (BADCTL \$21). Device status for the UniDisk 3.5 can be obtained by using status code \$05.

Status Code = \$00, Return Device Status The device status consists of four bytes. The first is the general status byte:

Bit	Description
7	0 = character device, 1 = block device
6	1 = write allowed
5	1 = read allowed
4	1 = device on line or disk in drive
3	0 = format allowed
2	0 = medium write protected (block devices only)
1	1 = device currently interrupting
0	1 = device currently open (character devices only)

If the STATUS call is for a block device, the next three bytes (low byte first) are the size in 512-byte blocks. The maximum size is 16 million (\$FFFFFF) blocks (about 8 gigabytes). If the call is for a character device, these three bytes must be set to zero.

Unit Number \$00: A STATUS call with status code = \$00 and unit number = \$00 returns the status of the Protocol Converter itself. In this case, the status list consists of eight bytes, as follows:

```
STAT_LIST DFB Number_Devices ;Devices hooked to PC
DFB Interrupt_Status ;Bit 6 clear = interrupt sent
DFB ;Reserved
DFB ;Reserved
DFB ;Reserved
DFB ;Reserved
DFB ;Reserved
DFB ;Reserved
```

ACIA status register: see Section "Firmware Handling of Interrupts" in the *Apple IIc Reference Manual*.

The Number_Devices byte returns the total number of intelligent devices attached to the Protocol Converter. The Interrupt_Status byte is a copy of the Asynchronous Communications Interface Adapter (ACIA) status register at the time of the interrupt, and is used to indicate that a device requires interrupt servicing. If the sixth bit of this byte equals zero, one or more devices in the Protocol Converter Bus daisy chain must be serviced; your interrupt handler must poll each device on the chain to determine which ones.

About Interrupts: Devices that require interrupt servicing must use the EXTINT line on the external disk port connector of the Apple IIc to be supported by the Protocol Converter. UniDisk 3.5, for example, does not support this line, and so cannot generate interrupts to the Protocol Converter. See Section "CONTROL" for instructions on enabling Protocol Converter interrupts. See Appendix E in the *Apple IIc Reference Manual* for more information about programming with interrupts.

Status Code = \$01, Return Device Control Block The device control block (DCB) is used to control various operating characteristics of a device, and is device dependent. Each device has a default DCB, which can be altered with a CONTROL call. The first byte (the *count byte*) gives the number of bytes in the control block (*not* including the count byte), so the length never exceeds 256 bytes (257 including the count byte).

UniDisk 3.5

UniDisk 3.5 has no DCB, and returns an error (BADCTL \$21) in response to this call.

Newline read mode: see Chapter 4 in the *PRODOS Technical Reference Manual*.

Status Code = \$02, Return Newline Status Newline status applies only to character devices. Use of statcode = \$02 with a block device results in error BADCTL (\$21).

Status Code = \$03, Return Device Information Block The device's information block contains information identifying the device, its type, and various other attributes. The returned status list has the following form:

```
STAT_LIST DFB Device_StatusByte1 ;Same as byte 1 in Status Code=$0
DFB Device_Size_Lo    ;Number of blocks (block device)
DFB Device_Size_Med  ;Number of blocks (middle byte)
DFB Device_Size_Hi    ;Number of blocks (high byte)
DFB ID_String_Length ;Length in bytes (16 max.)
ASC '<device name>' ;7-bit ASCII, uppercase, padded
                      ;with spaces, eighth bit always=0
                      ;(16 bytes)
*
* DFB Device_Type_Code
DFB Device_Subtype_Code
DW   Version          ;Device firmware version number
```

Status Code = \$05, Return UniDisk 3.5 Status This call allows the diagnostic program to get more detailed information about the cause of a read or write error, and to examine the contents of the 65C02's registers after a CONTROL Protocol Converter call with control code = \$05 (see Section "CONTROL"). The returned status list has this form:

```
STAT_LIST DFB $00
DFB Error    ;Soft Error byte (see below)
DFB Retries  ;Number of retries (see below)
DFB $00
DFB A_Value  ;Acc value after a CONTROL EXECUTE call
DFB X_Value  ;X value after EXECUTE
DFB Y_Value  ;Y value after EXECUTE
DFB P_Value  ;Processor Status value after EXECUTE
```

The Error byte returned by a STATUS call with status code = \$05 (Return UniDisk 3.5 Status) contains the following bits:

Bit	Description
7	0
6	0
5	1 = address field mark or checksum error
4	1 = data field checksum error
3	1 = data field bitslip mark mismatch
2	1 = seek error; unexpected track value found in address field
1	0
0	0

The Retries byte returned by a STATUS call with status code = \$05 (Return UniDisk 3.5 Status) specifies the number of address fields that had to be passed before the operation was completed. This information could be used, for example, to determine the number of passes necessary to read a data field correctly: If Retries is found to be greater than the number of sectors on the target track, then more than one pass was required.

The last four bytes of the status list are set only after a CONTROL call with control code = \$05, and are zero after any other call (STATUS calls do not clear the status bytes).

Possible Errors

The following errors can be returned by the STATUS call:

\$01	BADCMD	An unimplemented command was issued
\$04	BADPCNT	Bad call parameter count
\$06	BUSERR	Communications error
\$21	BADCTL	Invalid status code
\$30-\$3F		Device-specific errors

READ BLOCK

Command Number	\$01
Parameter List	\$03 (parameter count) Unit number Data buffer (low byte, high byte) Block number (low byte, mid byte, high byte)

The READ BLOCK call reads one 512-byte block from the disk device specified by the unit-number parameter into memory starting at the address specified by the data-buffer parameter.

Parameter Descriptions

Parameter Count	3 for this call. 1-byte value
Unit Number	The Protocol Converter assigns each device a unique number during initialization (on startup and cold reset). The numbers are in the range \$01—\$7E, and are assigned according to the devices' positions in the chain. A unit number of \$00 in the STATUS call returns the number of devices connected to the Protocol Converter.
Data Buffer	Points to the buffer into which the data is read. The buffer must be 512 or more bytes in length.
Block Number	The logical address of a block of data to be read. There is no general connection between block numbers and the layout of tracks and sectors on the disk. The translation from logical to physical blocks is performed by the device. (The most significant byte is zero for all devices currently in use.)

Possible Errors

The following errors can be returned by the READ BLOCK call:

\$01	BADCMD	An unimplemented command was issued
\$04	BADPCNT	Bad call parameter count
\$06	BUSERR	Communications error
\$27	IOERROR	I/O error
\$28	NODRIVE	No device connected
\$2D	BADBLOCK	Invalid block number
\$2F	OFFLINE	Device off-line or no disk in drive

WRITE BLOCK

Command Number	\$02
Parameter List	\$03 (parameter count) Unit number Data buffer (low byte, high byte) Block number (low byte, mid byte, high byte)

The WRITE BLOCK call writes one 512-byte block from memory to the disk device specified by the unit-number parameter. The block in memory starts at the address specified by the data-buffer parameter.

Parameter Descriptions

Parameter	3 for this call.
Count	1-byte value
Unit Number	The Protocol Converter assigns each device a unique number during initialization (on startup and cold reset). The numbers are in the range \$01—\$7E, and are assigned according to the devices' positions in the chain. A unit number of \$00 in the STATUS call returns the number of devices connected to the Protocol Converter.
Data Buffer	Points to the buffer from which the data is to be written.
Block Number	The logical address of a block of data to be written. There is no general connection between block numbers and the layout of tracks and sectors on the disk. The translation from logical to physical blocks is performed by the device. (The most significant byte is zero for all devices currently in use.)
2-byte value	
3-byte value	

Possible Errors

The following errors can be returned by the WRITE BLOCK call:

\$01	BADCMD	An unimplemented command was issued
\$04	BADPCNT	Bad call parameter count
\$06	BUSERR	Communications error
\$27	IOERROR	I/O error
\$28	NODRIVE	No device connected
\$2B	NOWRITE	Disk write protected
\$2D	BADBLOCK	Invalid block number
\$2F	OFFLINE	Device off-line or no disk in drive

FORMAT

Command Number	\$03
Parameter List	\$01 (parameter count) Unit number

The FORMAT call prepares all blocks on the recording medium of a block device for reading and writing. The formatting done by this call is not linked to any operating system; for example, bitmaps and catalogs are not written by this call.

Parameter Descriptions

Parameter	1 for this call.
Count	1-byte value
Unit Number	The Protocol Converter assigns each device a unique number during initialization (on startup and cold reset). The numbers are in the range \$01—\$7E, and are assigned according to the devices' positions in the chain. A unit number of \$00 in the STATUS call returns the number of devices connected to the Protocol Converter.

Possible Errors

The following errors can be returned by the FORMAT call:

\$01	BADCMD	An unimplemented command was issued
\$04	BADPCNT	Bad call parameter count
\$06	BUSERR	Communications error
\$27	IOERROR	I/O error
\$28	NODRIVE	No device connected
\$2B	NOWRITE	Disk write protected
\$2F	OFFLINE	Device off-line or no disk in drive

CONTROL

Command Number	\$04
Parameter List	\$03 (parameter count)
	Unit number
	Control list (low byte, high byte)
	Control code

The CONTROL call sends control information to the device. The information can be of a general nature (such as resets or interrupts), or device-specific (such as Download to UniDisk 3.5 RAM).

Important

A CONTROL call to unit number \$00 sends control information to the Protocol Converter itself. See the discussions under Control Code = \$00 and Control Code = \$01, below.

Parameter Descriptions

Parameter Count 1-byte value	3 for this call.
Unit Number 1-byte value	The Protocol Converter assigns each device a unique number during initialization (on startup and cold reset). The numbers are in the range \$01—\$7E, and are assigned according to the devices' positions in the chain. A unit number of \$00 in the STATUS call returns the number of devices connected to the Protocol Converter. Use a unit number of \$00 in the CONTROL call to send control information to the Protocol Converter itself.
Control List 2-byte value	Points to the buffer from which the control information is read. The first two bytes (the <i>count bytes</i> , low byte first) of the control list specify the number of bytes in the list (<i>not</i> including the count bytes); the remainder of the list contains the control information passed to the device.

Important

Every CONTROL call must have a control list; if no control information is being passed, then the control list consists of the count bytes only:

```
CTRL_LIST DW $00
```

Control Code

1-byte value

The number of the control request being made.

Control codes are in the range \$00—\$FF. The following requests are not device-specific:

Code**Control Function**

\$00

Reset the device

\$01

Set device control block (DCB)

\$02

Set newline status (character devices only)

\$03

Service device interrupt

Control requests to unit number \$00 are sent to the Protocol Converter itself:

Code**Control Function**

\$00

Enable interrupts from Protocol Converter

\$01

Disable interrupts from Protocol Converter

Specific devices may respond to some or all of these additional control requests:

Code**Control Function**

\$04

Eject disk

\$05

Run a 65C02 subroutine

\$06

Set download address

\$07

Download to device RAM

Control Code = \$00, Reset the Device Performs a warm reset of the device. Generally returns “housekeeping” values to some reset value. The control list for this call is device dependent.

UniDisk 3.5

The control list for this call for UniDisk 3.5 devices is:

```
CTRL_LIST DW $00 ;No parameters are passed
```

Unit Number \$00: A CONTROL call with control code = \$00 and unit number = \$00 enables interrupts from the Protocol Converter. This call informs the firmware that external interrupts are possible, and directs it to call the user's interrupt handler if an interrupt occurs. It also turns on the Asynchronous Communications Interface Adapter (ACIA) for port 1.

When the user's interrupt handler identifies an external interrupt, you can determine if it came from the Protocol Converter by making a STATUS call with unit number = \$00 and control code = \$00 (see Section "STATUS"). See Appendix E in the *Apple IIc Reference Manual* for more information on handling interrupts.

Control Code = \$01, Set Device Control Block Alters the contents of the device control block (DCB). The DCB is usually used to set global aspects of a device's operating environment. Each device has a default setting for the DCB, set on initialization. Since the length of the DCB is device dependent, you should first read in the DCB with the STATUS call, then alter the bits of interest, and finally, use the same byte string as the control block for the CONTROL call. The first byte (the *count byte*) of the DCB gives the number of bytes in the control block (*not* including the count byte), so the length never exceeds 257 bytes, including the count byte.

UniDisk 3.5

UniDisk 3.5 has no DCB; a Set DCB CONTROL call to UniDisk 3.5 returns an error (BADCTL \$21).

Unit Number = \$00: A CONTROL call with control code = \$01 and unit number = \$00 disables interrupts from the Protocol Converter. This call turns off the ACIA for port 1 and sets the least significant bit of the ACIA control register to zero.

Control Code = \$02, Set Newline Status Sets a character device to newline enabled or newline disabled.

Control Code = \$03, Device Service Interrupt To be used as needed for interrupt-driven devices.

Control Code = \$04, Eject Disk To be used for devices that support an auto-eject feature.

UniDisk 3.5

Causes UniDisk 3.5 to auto-eject a disk. There are no parameters in the control list, and no errors are returned if the disk ejected correctly or there was no disk in the drive. Error code \$27 (I/O error) is returned if the eject failed, that is, a disk is still in the drive. The control list for UniDisk 3.5 is:

```
CTRL_LIST DW $00 ;No parameters are passed
```

▲Warning

Control codes \$05 and higher are reserved; use of some of these codes can cause your system to crash.

Possible Errors

The following errors can be returned by the CONTROL call:

\$01	BADCMD	An unimplemented command was issued
\$04	BADPCNT	Bad call parameter count
\$06	BUSERR	Communications error
\$21	BADCTL	Invalid control code
\$22	BADCTLPARM	Invalid parameter list
\$30-\$3F		Device-specific errors

INIT

Command Number	\$05
Parameter List	\$01 (parameter count) \$00 (unit number)

The INIT call resets all intelligent devices attached to the Protocol Converter. The Protocol Converter goes through an initialization sequence, cold-resetting all devices and sending each its unit number. This call is made automatically on startup; an application should never have to make this call.

Parameter Descriptions

Parameter Count	1 for this call. 1-byte value
Unit Number	The unit number used in this call is always \$00. 1-byte value

Possible Errors

The following errors can be returned by the INIT call:

\$01	BADCMD	An unimplemented command was issued
\$04	BADPCNT	Bad call parameter count
\$06	BUSERR	Communications error
\$28	NODRIVE	No device connected

OPEN

Command Number	\$06
Parameter List	\$01 (parameter count) Unit number

The OPEN call prepares a character device for reading or writing.

UniDisk 3.5

Since UniDisk 3.5 is a block device, it does not accept this call. An attempt to use an OPEN call with UniDisk 3.5 will result in an error (BADCMD \$01).

Parameter Descriptions

Parameter Count	1 for this call. 1-byte value
Unit Number	The Protocol Converter assigns each device a unique number during initialization (on startup and cold reset). The numbers are in the range \$01—\$7E, and are assigned according to the devices' positions in the chain. A unit number of \$00 in the STATUS call returns the number of devices connected to the Protocol Converter.

Possible Errors

The following errors can be returned by the OPEN call:

\$01	BADCMD	An unimplemented command was issued
\$04	BADPCNT	Bad call parameter count
\$06	BUSERR	Communications error
\$28	NODRIVE	No device connected
\$2F	OFFLINE	Device off-line or no disk in drive

CLOSE

Command Number	\$07
Parameter List	\$01 (parameter count) Unit number
The CLOSE call tells a character device that a sequence of reads or writes is over.	

UniDisk 3.5

Since UniDisk 3.5 is a block device, it does not accept this call. An attempt to use a CLOSE call with UniDisk 3.5 will result in an error (BADCMD \$01).

Parameter Descriptions

Parameter Count	1 for this call. 1-byte value
Unit Number	The Protocol Converter assigns each device a unique number during initialization (on startup and cold reset). The numbers are in the range \$01—\$7E, and are assigned according to the devices' positions in the chain. A unit number of \$00 in the STATUS call returns the number of devices connected to the Protocol Converter.

Possible Errors

The following errors can be returned by the CLOSE call:

\$01	BADCMD	An unimplemented command was issued
\$04	BADPCNT	Bad call parameter count
\$06	BUSERR	Communications error
\$28	NODRIVE	No device connected
\$2F	OFFLINE	Device off-line or no disk in drive

READ

Command Number	\$08
Parameter List	\$04 (parameter count) Unit number Buffer pointer (low byte, high byte) Byte count (low byte, high byte) Address pointer (low byte, mid byte, high byte)

The READ call reads the number of bytes specified by the byte-count parameter into memory starting at the address specified by the buffer-pointer parameter.

Macintosh: This call can be used by UniDisk 3.5 devices to read 524-byte data blocks written by an Apple Macintosh™ Computer.

Parameter Descriptions

Parameter Count 1-byte value	4 for this call.
Unit Number 1-byte value	The Protocol Converter assigns each device a unique number during initialization (on startup and cold reset). The numbers are in the range \$01—\$7E, and are assigned according to the devices' positions in the chain. A unit number of \$00 in the STATUS call returns the number of devices connected to the Protocol Converter.
Buffer Pointer 2-byte value	Points to the buffer into which the data is read. The buffer must be large enough to contain the number of bytes requested by the byte-count parameter.
Byte Count 2-byte value	Specifies the number of bytes to be transferred.

Macintosh: The byte count used to read Macintosh disks with a UniDisk 3.5 is always 524 bytes (\$020C).

Address Specifies the address to start reading from. The
Pointer meaning of this parameter depends on the device
3-byte value being read.

Macintosh: When using a UniDisk 3.5 to read Macintosh disks, the address pointer specifies the number of the 524-byte Macintosh block to be read (from \$00 to \$031F for a single-sided disk).

Possible Errors

The following errors can be returned by the READ call:

\$01	BADCMD	An unimplemented command was issued
\$04	BADPCNT	Bad call parameter count
\$06	BUSERR	Communications error
\$27	IOERROR	I/O error
\$28	NODRIVE	No device connected
\$2D	BADBLOCK	Invalid block number
\$2F	OFFLINE	Device off-line or no disk in drive

WRITE

Command Number	\$09
Parameter List	\$04 (parameter count) Unit number Buffer pointer (low byte, high byte) Byte count (low byte, high byte) Address pointer (low byte, mid byte, high byte)

The WRITE call writes the number of bytes specified by the byte-count parameter to the specified unit from memory starting at the address indicated by the buffer-pointer parameter. The meaning of the address pointer depends on the type of device (see the parameter descriptions, below).

| **Macintosh:** This call can be used by UniDisk 3.5 devices to write 524-byte blocks for use by an Apple Macintosh computer.

Parameter Descriptions

Parameter Count	4 for this call. 1-byte value
Unit Number	The Protocol Converter assigns each device a unique number during initialization (on startup and cold reset). The numbers are in the range \$01—\$7E, and are assigned according to the devices' positions in the chain. A unit number of \$00 in the STATUS call returns the number of devices connected to the Protocol Converter.
Buffer Pointer	Points to the buffer from which the data is to be written. 2-byte value
Byte Count	Specifies the number of bytes to be transferred. 2-byte value

Macintosh: The byte count used to write Macintosh disks with a UniDisk 3.5 is always 524 bytes (\$020C).

Address Specifies the address to start writing from. The
Pointer meaning of this parameter depends on the device
3-byte value being written to.

Macintosh: When using a UniDisk 3.5 to write Macintosh disks, the address pointer specifies the number of the 524-byte Macintosh block to be written (from \$00 to \$031F for a single-sided disk).

Possible Errors

The following errors can be returned by the WRITE call:

\$01	BADCMD	An unimplemented command was issued
\$04	BADPCNT	Bad call parameter count
\$06	BUSERR	Communications error
\$27	IOERROR	I/O error
\$28	NODRIVE	No device connected
\$2D	BADBLOCK	Invalid block number
\$2F	OFFLINE	Device off-line or no disk in drive

An Example: Issuing a Protocol Converter Call

Here is an example of a program that issues a STATUS call to the Protocol Converter to obtain information about a device.

Apple IIe

The code for the Protocol Converter in the Apple IIc with 32K ROM always begins at address \$C500; however, to ensure compatibility with the Apple IIe, your programs should always do a search for the Protocol Converter, as in the following example.

```
0000:          1 *
0000:          2 *
0000:          3 *
0000:          4 * This example shows how to find
0000:          5 * and use a PC interface. A search
0000:          6 * is made for a PC, and when one is
0000:          7 * found, a vector is set up which
0000:          8 * points to the PC entry. Then a
0000:          9 * Device Information Block STATUS call
0000:         10 * is made, and if successful, the name
0000:         11 * string embedded in the DIB is output
0000:         12 * to the screen. Only the first device
0000:         13 * in the chain is accessed.
0000:         14 *
0000:         15 *
0000:          16           MSB    ON
0000:          17 *
0000:          18 *
0000: 0006 19 ZPTempL equ $0006 ;Temporary zero
0000:          20 * page storage
0000: 0007 21 ZPTempH equ $0007
0000:          22 *
0000: FDED 23 COut    equ $FDED ;Console output
0000: FD8E 24 CROut   equ $FD8E ;Carriage return
0000:          25 *
0000: 0000 26 StatusCmd equ 0
0000:          27 *
0000:          28 *
0300: 0300 29 org $300
0300:          30 *
0300:          31 * Find a Protocol Converter in one of the
0300:          32 * slots.
0300:          33 *
0300:20 43 03 34 jsr FindPC
0303:B0 1C 0321 35 bcs Error
0305:          36 *
0305:          37 * Now make the DIB call to the first guy
0305:          38 *
```

```

0305:20 67 03      39          jsr    Dispatch
0308:00            40          dfb    StatusCmd
0309:6A 03          41          dw     DParms
030B:B0 14  0321    42          bcs    Error
030D:              43  *
030D:              44 * Got the DIB; now print the name string
030D:              45  *
030D:A2 00          46          ldx    #0
030F: 030F          47 morechars equ   *
030F:BD 74 03          48          lda    DIBName,x
0312:09 80          49          ora    #$80      ;COut wants high
0314:              50  *           Bit set
0314:              51  *
0314:20 ED FD          52          jsr    COut
0317:E8            53          inx
0318:EC 73 03          54          cpx    DIBNameLen
031B:90 F2  030F        55          blt    morechars
031D:              56  *
031D:20 8E FD          57          jsr    CROut    ;Finish it off
0320:              58  *           with a return
0320:              59  *
0320:60            60          rts
0321:              61  *
0321:              62  *
0321: 0321          63 Error    equ   *
0321:              64  *
0321:              65 * There's either no PC around, or there
0321:              66 * was no Unit #1... give message
0321:              67  *
0321:A2 00          68          ldx    #0
0323: 0323          69 err1    equ   *
0323:BD 2F 03          70          lda    Message,x
0326:F0 06  032E        71          beq    errout
0328:20 ED FD          72          jsr    COut
032B:E8            73          inx
032C:D0 F5  0323        74          bne    err1
032E:              75  *
032E: 032E          76 errout  equ   *
032E:60            77          rts
032F:              78  *
032F:CE CF A0 D0        79 Message  asc   'NO PC OR NO DEVICE'
0341:8D 00          80          dfb   $8D,0
0343:              81  *
0343:              82  *
0343: 0343          83 FindPC  equ   *
0343:              84  *
0343:              85 * Search slot 7 to slot 1 looking for
0343:              86 * signature bytes
0343:              87  *
0343:A2 07          88          ldx    #7      ;Do for seven
0345:              89  *           slots
0345:A9 C7          90          lda    #$C7

```

```

0347:85 07      91      sta    ZPTempH
0349:A9 00      92      lda    #$00
034B:85 06      93      sta    ZPTempL
034D:             94      *
034D:     034D  95 newslot  equ   *
034D:A0 07      96      ldy    #7
034F:             97      *
034F:     034F  98 again   equ   *
034F:B1 06      99      lda    (ZPTempL),y
0351:D9 70 03    100     cmp    sigtab,y ;One of four
0354:             101     *                   byte signature
0354:F0 07  035D 102     beq    maybe   ;Found one
0356:             103     *                   signature byte
0356:C6 07      104     dec    ZPTempH
0358:CA          105     dex
0359:D0 F2  034D 106     bne    newslot
035B:             107     *
035B:             108     * If we get here, it's because we couldn't
035B:             109     * find a Protocol Converter.
035B:             110     * Exit with the carry set.
035B:             111     *
035B:38          112     sec
035C:60          113     rts
035D:             114     *
035D:             115     * If we get here, it means that one or
035D:             116     * more of the signature bytes
035D:             117     * for this card are what we're looking
035D:             118     * for. Decrement the byte
035D:             119     * counter and branch back to verify any
035D:             120     * remaining bytes.
035D:             121     *
035D:     035D  122 maybe   equ   *
035D:88          123     dey
035E:88          124     dey   ;If N=1 then
035F:             125     *                   all sig bytes okay
035F:10 EE  034F 126     bpl    again
0361:             127     *
0361:             128     * Found a Protocol Converter interface.
0361:             129     * Set up the call address.
0361:             130     * We already have the high byte ($CN);
0361:             131     * we just need the low byte.
0361:             132     *
0361:     0361  133 foundPC equ   *
0361:A9 FF          134     lda    #$FF
0363:85 06          135     sta    ZPTempL
0365:A0 00          136     ldy    #0 ;For
0367:             137     *                   indirect load
0367:B1 06          138     lda    (ZPTempL),y ;Get the
0369:             139     *                   byte
0369:             140     *
0369:             141     * Now the Acc has the low order ProDOS
0369:             142     * entry point. The PC entry is

```

```

0369:           143 * three locations past this...
0369:           144 *
0369:18           145     clc
036A:69 03       146     adc #3
036C:85 06       147     sta ZPTempL
036E:           148 *
036E:           149 * Now ZPTempL has the PC entry point.
036E:           150 * Return with carry clear.
036E:           151 *
036E:18           152     clc
036F:60           153     rts
0370:           154 *
0370:           155 *
0370:           156 * These are the PC signature bytes in
0370:           157 * their relative order.
0370:           158 * The $FF bytes are filler bytes and
0370:           159 * are not compared.
0370:           160 *
0370:FF 20 FF 00   161 sigtab    dfb $FF,$20,$FF,$00
0374:FF 03 FF 00 162             dfb $FF,$03,$FF,$00
0378:           163 *
0378:           164 *
0378:     0378   165 Dispatch  equ  *
0378:6C 06 00     166     jmp  (ZPTempL) ;Simulate
037B:           167 *               an indirect JSR to PC
037B:           168 *
037B:           169 *
037B:     037B   170 DParms   equ  *
037B:03           171 DPParmCt dfb 3      ;Status
037C:           172 *               calls have three parameters
037C:01           173 DPUnit    dfb 1
037D:80 03       174 DPBuffer  dw   DIB
037F:03           175 DPStatCode dfb 3
0380:           176 *
0380:           177 *
0380:     0380   178 DIB     equ  *
0380:00           179 DIBStatByte1 dfb 0
0381:00 00 00     180 DIBDevSize dfb 0,0,0
0384:00           181 DIBNameLen dfb 0
0385:     0010   182 DIBName   ds   16,0
0395:00           183 DIBType   dfb 0
0396:00           184 DIBSubType dfb 0
0397:00 00     185 DIBVersion dw   0
0399:           186 *
0399:           187 *

```

Summary of Commands and Parameters

This is a summary of Protocol Converter calls. In each case, byte 0 of the command parameter list (CMDLST) specifies the number of parameters in the command list (not including byte 0). Parameters that require more than one byte (the status list pointer, for example) are entered low byte first. The meaning of the address-pointer parameter is device specific. See the sections on the individual calls in this chapter for a discussion of each parameter.

Figure 3-1. Summary of Protocol Converter Commands and Parameters

Command	STATUS	READBLOCK	WRITEBLOCK	FORMAT	CONTROL
CmdNum	\$00	\$01	\$02	\$03	\$04
CmdList Byte 0	\$03	\$03	\$03	\$01	\$03
1	Unit Num	Unit Num	Unit Num	Unit Num	Unit Num
2	Stat List Ptr	Buffer Ptr	Buffer Ptr		Ctl List Ptr
3					
4	Stat Code				Ctl Code
5		Block Num	Block Num		
6					

Command	INIT	OPEN	CLOSE	READ	WRITE
CmdNum	\$05	\$06	\$07	\$08	\$09
CmdList Byte 0	\$01	\$01	\$01	\$04	\$04
1	\$00	Unit Num	Unit Num	Unit Num	Unit Num
2				Buffer Ptr	Buffer Ptr
3					
4				Byte Count	Byte Count
5					
6					
7				Address Ptr	Address Ptr
8					

Unused bytes 

Summary of Error Codes

This is a summary of Protocol Converter call error codes, including a brief description of the possible causes for each. If there is no error, the C flag (in the Processor Status register of the 65C02 microprocessor) is cleared (0), and the accumulator (the A register) contains zeros. If the call was unsuccessful, the C flag is set (1), and the A register contains the error code.

\$00		No error.
\$01	BADCMD	A nonexistent command was issued. Check the command number in the Protocol Converter call.
\$04	BADPCNT	Bad call parameter count. The call parameter list was not properly constructed. Make sure the parameter list has the correct number of parameters.
\$06	BUSERR	A communications error between the device controller and the host. Make sure that RAM is both read-enabled and write-enabled. Check the hardware (cables and connectors) between the device and the host. Check for noise sources; make sure the cable is properly shielded.
\$11	BADUNIT	Unit number \$00 was used in a call other than STATUS, CONTROL, or INIT.
\$21	BADCTL	The control or status code is not supported by the device.
\$22	BADCTLPARM	The control parameter list contains invalid information. Make sure each value is within the range allowed for that parameter.
\$27	IOERROR	The device encountered an I/O error when trying to read or write to the recording medium. Make sure that the medium in the device is formatted and not defective. Make sure the device is operating correctly.
\$28	NODRIVE	The device is not connected. This can occur if the device is not connected but its controller is, or if there is no device with the unit number specified.

\$2B	NOWRITE	The medium in the device is write protected.
\$2D	BADBLOCK	The block number is outside the range allowed for the medium in the device. Note that this range depends on the type of device and the type of medium in the device (single-sided vs. double-sided disk, for example).
\$2F	OFFLINE	Device off-line or no disk in drive. Check the cables and connections; make sure the medium is present in the drive, and that the drive is functioning correctly.
\$30-\$3F	DEVSPEC	Errors which differ from device to device. See the technical manual for the device in question for details.
\$40-\$4F		Reserved for future expansion.
\$50-\$7F	NONFATAL	A device-specific <i>soft</i> error. The operation completed successfully, but some <i>exception</i> condition was detected. See the technical manual for the device in question for details.

Appendix A

Firmware Listing

```
SOURCE FILE #01 =>FIRM
INCLUDE FILE #02 =>NAMES
INCLUDE FILE #03 =>EQUATES
INCLUDE FILE #04 =>SERIAL
INCLUDE FILE #05 =>SER
INCLUDE FILE #06 =>COMM
INCLUDE FILE #07 =>C3SPACE
INCLUDE FILE #08 =>MOUSE
INCLUDE FILE #09 =>MCODE
INCLUDE FILE #10 =>MISC
INCLUDE FILE #11 =>BOOT
INCLUDE FILE #12 =>SWITCHER
INCLUDE FILE #13 =>IRQBUF
INCLUDE FILE #14 =>MINI
INCLUDE FILE #15 =>SCROLLING
INCLUDE FILE #16 =>ESCAPE
INCLUDE FILE #17 =>PASCAL
INCLUDE FILE #18 =>MOREMISC
INCLUDE FILE #19 =>AUTOST1
INCLUDE FILE #20 =>AUTOST2
INCLUDE FILE #21 =>BANK2
INCLUDE FILE #22 =>MINT
INCLUDE FILE #23 =>AUXSTUFF
INCLUDE FILE #24 =>BANGER2
INCLUDE FILE #25 =>SWITCHER2
INCLUDE FILE #26 =>COMMAND
INCLUDE FILE #27 =>MBASIC
INCLUDE FILE #28 =>BANGER
INCLUDE FILE #29 =>VECTORS2
```

```
0000:    0000    2      x6502
0000:    3 ****
0000:    4 *
0000:    5 * Firmware for the Apple //c
0000:    6 *
0000:    7 * December, 1983
0000:    8 *
0000:    9 *
0000:   10 * Rich Williams
0000:   11 * Ernie Beernink
0000:   12 * James R Huston
0000:   13 *
0000:   14 * Revision 2 May, 1985
0000:   15 * rom expanded to 32K in 2 16K banks
0000:   16 * new features added:
0000:   17 *   Protocol converter slot 5
0000:   18 *   AppleTalk slot 7
0000:   19 *   //e diagnostics
0000:   20 *   Enhanced serial port commands
0000:   21 *   Mini assembler
0000:   22 *   Step and trace
0000:   23 *   most $F8 rom changes marked with a +
0000:   24 *
0000:   25 ****
0000: F800    26 F80RG    EQU    $F800

INCLUDE FILE #02 ->NAMES
C100:    29      lst    on
C100:    30      include equates ;Equates for Video & Monitor ROM
```

```

C100:      2 ****
C100:      3 *
C100:      4 * Apple //c
C100:      5 * Video Firmware and
C100:      6 * Monitor ROM Source
C100:      7 *
C100:      8 * COPYRIGHT 1977-1983 BY
C100:      9 * APPLE COMPUTER, INC.
C100:     10 *
C100:     11 * ALL RIGHTS RESERVED
C100:     12 *
C100:     13 * S. WOZNIAK      1977
C100:     14 * A. BAUM        1977
C100:     15 * JOHN A          NOV 1978
C100:     16 * R. AURICCHIO    SEP 1981
C100:     17 * E. BEERNINK    1983
C100:     18 *
C100:     19 ****
C100:     20 *
C100:     21 * ZERO PAGE EQUATES
C100:     22 *
C100: 0000 23 LOC0    EQU $00      ;vector for autostart from disk
C100: 0001 24 LOC1    EQU $01
C100: 0020 25 WNDLFT   EQU $20      ;left edge of text window
C100: 0021 26 WNDWDTH  EQU $21      ;width of text window
C100: 0022 27 WNDTOP   EQU $22      ;top of text window
C100: 0023 28 WNDBTM   EQU $23      ;bottom+1 of text window
C100: 0024 29 CH       EQU $24      ;cursor horizontal position
C100: 0025 30 CV       EQU $25      ;cursor vertical position
C100: 0026 31 GBASL   EQU $26      ;lo-res graphics base addr.
C100: 0027 32 GBASH   EQU $27
C100: 0028 33 BASL    EQU $28      ;text base address
C100: 0029 34 BASH    EQU $29
C100: 002A 35 BAS2L   EQU $2A      ;temp base for scrolling
C100: 002B 36 BAS2H   EQU $2B
C100: 002C 37 H2       EQU $2C      ;temp for lo-res graphics
C100: 002C 38 LMNEM   EQU $2C      ;temp for mnemonic decoding
C100: 002C 39 RTNL    equ $2C      ;Step return address
C100: 002D 40 V2       EQU $2D      ;temp for lo-res graphics
C100: 002D 41 RMNEM   EQU $2D      ;temp for mnemonic decoding
C100: 002D 42 rtnh    equ $2D      ;Step return address
C100: 002E 43 MASK    EQU $2E      ;color mask for lo-res gr.
C100: 002E 44 FORMAT  EQU $2E      ;temp for opcode decode
C100: 002F 45 LENGTH  EQU $2F      ;temp for opcode decode
C100: 0030 46 COLOR   EQU $30      ;color for lo-res graphics
C100: 0031 47 MODE    EQU $31      ;Monitor mode
C100: 0032 48 INVFLG  EQU $32      ;normal/inverse{/flash}
C100: 0033 49 PROMPT  EQU $33      ;prompt character
C100: 0034 50 YSAV   EQU $34      ;position in Monitor command
C100: 0035 51 YSAV1  EQU $35
C100: 0036 52 CSWL   EQU $36      ;temp for Y register
C100: 0037 53 CSWH   EQU $37      ;character output hook
C100: 0038 54 KSWL   EQU $38      ;character input hook
C100: 0039 55 KSWH   EQU $39
C100: 003A 56 PCL    EQU $3A      ;temp for program counter
C100: 003B 57 PCH    EQU $3B
C100: 003C 58 XQT    EQU $3C      ;Step and trace execute area
C100: 003C 59 A1L    EQU $3C      ;Monitor temp

```

```

C100: 003D 60 A1H    EQU $3D      ;Monitor temp
C100: 003E 61 A2L    EQU $3E      ;Monitor temp
C100: 003F 62 A2H    EQU $3F      ;Monitor temp
C100: 0040 63 A3L    EQU $40      ;Monitor temp
C100: 0041 64 A3H    EQU $41      ;Monitor temp
C100: 0042 65 A4L    EQU $42      ;Monitor temp
C100: 0043 66 A4H    EQU $43      ;Monitor temp
C100: 0044 67 A5L    EQU $44      ;Monitor temp
C100: 0045 68 A5H    EQU $45      ;Monitor temp
C100: 69 *
C100: 70 * Note: In Apple II, //e, both interrupts and BRK destroyed
C100: 71 * location $45. Now only BRK destroys $45 (ACC) and it
C100: 72 * also destroys $44 (MACSTAT).
C100: 73 *
C100: 0044 74 MACSTAT  EQU $44      ;Machine state after BRK
C100: 0045 75 ACC     EQU $45      ;Acc after BRK
C100: 76 *
C100: 0046 77 XREG    EQU $46      ;X reg after break
C100: 0047 78 YREG    EQU $47      ;Y reg after break
C100: 0048 79 STATUS   EQU $48      ;P reg after break
C100: 0049 80 SPNT    EQU $49      ;SP after break
C100: 004E 81 RNDL    EQU $4E      ;random counter low
C100: 004F 82 RNDH    EQU $4F      ;random counter high
C100: 83 *
C100: 84 * Value equates
C100: 85 *
C100: 0006 86 GOODF8  EQU $06      ;value of //e, lolly ID byte
C100: 0095 87 PICK    EQU $95      ;CONTROL-U character
C100: 009B 88 ESC     EQU $9B      ;what ESC generates
C100: 89 *
C100: 90 * Characters read by GETLN are placed in
C100: 91 * IN, terminated by a carriage return.
C100: 92 *
C100: 0200 93 IN     EQU $0200      ;input buffer for GETLN
C100: 94 *
C100: 95 * Page 3 vectors
C100: 96 *
C100: 03F0 97 BRKV    EQU $03F0      ;vectors here after break
C100: 03F2 98 SOFTEV   EQU $03F2      ;vector for warm start
C100: 03F4 99 PWREDUP  EQU $03F4      ;THIS MUST = EDR #$A5 OF SOFTEV+1
C100: 03F5 100 AMPERV   EQU $03F5      ;APPLESOFT & EXIT VECTOR
C100: 03F8 101 USRADR   EQU $03F8      ;APPLESOFT USR function vector
C100: 03FB 102 NMI     EQU $03FB      ;NMI vector
C100: 03FE 103 IRQLOC   EQU $03FE      ;Maskable interrupt vector
C100: 0400 104 LINE1    EQU $0400      ;first line of text screen
C100: 07F8 105 MSLOT    EQU $07F8      ;owner of $C8 space
C100: 106 *
C100: 107 * HARDWARE EQUATES
C100: 108 *
C100: C000 109 IOADR    EQU $C000      ;for IN#, PR# vector
C100: C000 110 KBD     EQU $C000      ;>127 if keystroke
C100: C000 111 CLR80COL  EQU $C000      ;disable 80 column store
C100: C001 112 SET80COL  EQU $C001      ;enable 80 column store
C100: C002 113 RDMAINRAM EQU $C002      ;read from main 48K RAM
C100: C003 114 RDCARDRAM EQU $C003      ;read from alt. 48K RAM
C100: C004 115 WRMAINRAM EQU $C004      ;write to main 48K RAM
C100: C005 116 WRCARDRAM EQU $C005      ;write to alt. 48K RAM
C100: C008 117 SETSTDZP  EQU $C008      ;use main zero page/stack

```

```

C100:    C009  118 SETALTZP  EQU   $C009      ;use alt. zero page/stack
C100:    C00C  119 CLR80VID  EQU   $C00C      ;disable 80 column hardware
C100:    C00D  120 SET80VID  EQU   $C00D      ;enable 80 column hardware
C100:    C00E  121 CLRALTCHAR EQU   $C00E      ;normal LC, flashing UC
C100:    C00F  122 SETALTCHAR EQU   $C00F      ;normal inverse, LC; no flash
C100:    C010  123 KBDSTRB  EQU   $C010      ;turn off key pressed flag
C100:    C011  124 RDLCBNK2 EQU   $C011      ;>127 if LC bank 2 is in
C100:    C012  125 RDLCRAM  EQU   $C012      ;>127 if LC RAM read enabled
C100:    C013  126 RDRAMRD  EQU   $C013      ;>127 if reading main 48K
C100:    C014  127 RDRAMWRT EQU   $C014      ;>127 if writing main 48K
C100:    C016  128 RDALTZP  EQU   $C016      ;>127 if Alt ZP and LC switched in
C100:    C018  129 RD80COL  EQU   $C018      ;>127 if 80 column store
C100:    C019  130 RDVBLBAR EQU   $C019      ;>127 if not VBL
C100:    C01A  131 RDTEXT   EQU   $C01A      ;>127 if text (not graphics)
C100:    C01B  132 RDMIX    EQU   $C01B      ;>127 if mixed mode on
C100:    C01C  133 RDPAGE2   EQU   $C01C      ;>127 if TXTPAGE2 switched in
C100:    C01D  134 RDHIRES   EQU   $C01D      ;>127 if HIRES is on
C100:    C01E  135 ALTCHARSET EQU   $C01E      ;>127 if alternate char set in use
C100:    C01F  136 RD80VID  EQU   $C01F      ;>127 if 80 column hardware in
C100:    C028  137 ROMBANK   EQU   $C028      ;Switches rombanks
C100:    C030  138 SPKR     EQU   $C030      ;clicks the speaker
C100:    C050  139 TXTCLR   EQU   $C050      ;switch in graphics (not text)
C100:    C051  140 TXTSET   EQU   $C051      ;switch in text (not graphics)
C100:    C052  141 MIXCLR   EQU   $C052      ;clear mixed-mode
C100:    C053  142 MIXSET   EQU   $C053      ;set mixed-mode (4 lines text)
C100:    C054  143 TXTPAGE1  EQU   $C054      ;switch in text page 1
C100:    C055  144 TXTPAGE2  EQU   $C055      ;switch in text page 2
C100:    C056  145 LORES    EQU   $C056      ;low-resolution graphics
C100:    C057  146 HIRES    EQU   $C057      ;high-resolution graphics
C100:    C058  147 CLRAN0   EQU   $C058
C100:    C059  148 SETAN0   EQU   $C059
C100:    C05A  149 CLRAN1   EQU   $C05A
C100:    C05B  150 SETAN1   EQU   $C05B
C100:    C05C  151 CLRAN2   EQU   $C05C
C100:    C05D  152 SETAN2   EQU   $C05D
C100:    C05E  153 CLRAN3   EQU   $C05E
C100:    C05F  154 SETAN3   EQU   $C05F
C100:    C060  155 RD40SW   EQU   $C060      ;>127 if 40/80 switch in 40 pos
C100:    C061  156 BUTN0    EQU   $C061      ;open apple key
C100:    C062  157 BUTN1    EQU   $C062      ;closed apple key
C100:    C064  158 PADDL0   EQU   $C064      ;read paddle 0
C100:    C070  159 PTRIG    EQU   $C070      ;trigger the paddles
C100:    C081  160 ROMIN    EQU   $C081      ;switch in $D000-$FFFF ROM
C100:    C083  161 LCBANK2  EQU   $C083      ;switch in LC bank 2
C100:    C08B  162 LCBANK1  EQU   $C08B      ;switch in LC bank 1
C100:    CFFF  163 CLRRROM EQU   $CFFF      ;switch out $C8 ROMs
C100:    E000  164 BASIC    EQU   $E000      ;BASIC entry point
C100:    E003  165 BASIC2   EQU   $E003      ;BASIC warm entry point
C100:    166 *
C100:    04FB  167 VMODE   EQU   $4F8+3      ;OPERATING MODE
C100:    168 *
C100:    169 * BASIC VMODE BITS
C100:    170 *
C100:    171 * 1..... - BASIC active
C100:    172 * 0..... - Pascal active
C100:    173 * .0.....
C100:    174 * .1.....
C100:    175 * ..0.... - Print control characters

```

```

C100:    176 * ..1..... - Don't print ctrl chars
C100:    177 * ...0..... -
C100:    178 * ....1.... -
C100:    179 * ....0... - Print control characters
C100:    180 * ....1... - Don't print ctrl chars.
C100:    181 * .....0.. -
C100:    182 * .....1.. -
C100:    183 * .....0.. -
C100:    184 * .....1.. -
C100:    185 * .....0 - Print mouse characters
C100:    186 * .....1 - Don't print mouse characters
C100:    187 *
C100:    0040 188 M.40     EQU   $40
C100:    0020 189 M.CTL2   EQU   $20      ;Don't print controls
C100:    0008 190 M.CTL   EQU   $08      ;Don't print controls
C100:    0001 191 M.MOUSE  EQU   $01      ;Don't print mouse chars
C100:    192 *
C100:    193 * Pascal Mode Bits
C100:    194 *
C100:    195 * 1..... - BASIC active
C100:    196 * 0..... - Pascal active
C100:    197 * .0.....
C100:    198 * .1.....
C100:    199 * ..0.... -
C100:    200 * ..1.... -
C100:    201 * ....0.... - Cursor always on
C100:    202 * ....1.... - Cursor always off
C100:    203 * ....0... - GOTOXY n/a
C100:    204 * ....1... - GOTOXY in progress
C100:    205 * .....0.. - Normal Video
C100:    206 * .....1.. - Inverse Video
C100:    207 * .....0.. -
C100:    208 * .....1.. -
C100:    209 * .....0 - Print mouse chars
C100:    210 * .....1 - Don't print mouse chars
C100:    211 *
C100:    0080 212 M.PASCAL EQU   $80      ;Pascal active
C100:    0010 213 M.CURSOR EQU   $10      ;Don't print cursor
C100:    0008 214 M.GOXY   EQU   $08      ;GOTOXY IN PROGRESS
C100:    0004 215 M.VMODE  EQU   $04
C100:    216 *
C100:    0478 217 ROMSTATE EQU   $478      ;temp store of ROM state
C100:    04F8 218 TEMP1   EQU   $4F8      ;used by CTLCHAR
C100:    0578 219 TEMPA   EQU   $578      ;used by scroll
C100:    05F8 220 TEMPY   EQU   $5F8      ;used by scroll
C100:    221 *
C100:    047B 222 OLDCH   EQU   $478+3   ;last value of CH
C100:    057B 223 DURCH   EQU   $578+3   ;80-COL CH
C100:    05FB 224 DURCV   EQU   $5F8+3   ;CURSOR VERTICAL
C100:    067B 225 VFACTV  EQU   $678+3   ;Bit7=video firmware inactive
C100:    06FB 226 XCOORD  EQU   $6F8+3   ;X-COORD (GOTOXY)
C100:    077B 227 NXTCUR  EQU   $778+3   ;next cursor to display
C100:    07FB 228 CURSOR  EQU   $7F8+3   ;the current cursor char
C100:    229 *
C100:    230 * Disk II boot rom equates
C100:    231 *
C100:    0356 232 DNIBL   EQU   $356
C100:    0300 233 NBUF1  EQU   $300

```

```
C100:    002B  234 SLOTZ    EQU    $2B
C100:    003C  235 BOOTTMP   EQU    $3C
C100:    004F  236 BOOTDEV   EQU    $4F

C100:    238 ****
C100:    239 * Entry points for other modules
C100:    240 ****
C100:    C880  241 pcnv     equ    $C880
C100:    C5F5  242 bootfail  equ    $C5F5      ;Boot fails message
C100:    C5F8  243 pcnvrst  equ    $C5F8      ;Protocol converter reset
C100:    C580  244 atalk    equ    $C580      ;Apple talk
C100:    31      include serial      ;Equates for serial code
```

```

C100:      3 ****
C100:      4 *
C100:      5 * Apple Lolly communications driver
C100:      6 *
C100:      7 * By
C100:      8 * Rich Williams
C100:      9 * August 1983
C100:     10 * November 5 - j.r.huston
C100:     11 *
C100:     12 ****
C100:     13 *
C100:     14 * Command codes
C100:     15 *
C100:     16 * Default command char is ctrl-A (^A)
C100:     17 *
C100:     18 *      ^AnnB: Set baud rate to nn
C100:     19 *      ^AnnD: Set data format bits to nn
C100:     20 *      ^AI:   Enable video echo
C100:     21 *      ^AK:   Disable CRLF
C100:     22 *      ^AL:   Enable CRLF
C100:     23 *      ^AnnN: Disable video echo & set printer width
C100:     24 *      ^AnnP: Set parity bits to nn
C100:     25 *      ^AQ:   Quit terminal mode
C100:     26 *      ^AR:   Reset the ACIA, IN#0 PR#0
C100:     27 *      ^AS:   Send a 233 ms break character
C100:     28 *      ^AT:   Enter terminal mode
C100:     29 *      ^AZ:   Zap control commands
C100:     30 *      ^Ax:   Set command char to ^x
C100:     31 *      ^AnnCR: Set printer width (CR = carriage return)
C100:     32 *
C100:     33 * New commands added in rev 1 E = enable D = Disable
C100:     34 *
C100:     35 *      ^AC E/D Column overflow
C100:     36 *      ^AL E/D Linefeed same as L & K
C100:     37 *      ^AM E/D Mask incoming linefeeds
C100:     38 *      ^AX E/D Xon Xoff handshaking
C100:     39 *      ^AF E/D Find keyboard
C100:     40 *
C100:     41 ****
C100: C100 42 serslot    equ   $C100
C100: C200 43 comslot    equ   $C200
C100:      44 msb    ON
C100: 00BF 45 cmdcur    equ   '?'; Cursor while in command mode
C100: 00DF 46 termcur   equ   '_'; Cursor while in terminal mode
C100:      47 msb    OFF
C100: 008A 48 lfeed    equ   $8A; Linefeed
C100: 0091 49 xon      equ   $91; XON character
C100: 0093 50 xoff      equ   $93; XOFF character
C100: 03B8 51 sermode   equ   $3B8; D7=1 if in command D6=1 if terminal
C100:           $479 & $47A
C100: 0438 52 astat    equ   $438; Acia status from int 4F9 & 4FA
C100: 04B8 53 pwdth    equ   $4B8; Printer width 579 & 57A
C100: 0538 54 extint   equ   $538; extint & typhed enable 5F9 & 5FA
C100: 05F9 55 extint2  equ   $5F9
C100: 05FA 56 typhed   equ   $5FA
C100: 0679 57 oldcur   equ   $679; Saves cursor while in command
C100: 067A 58 oldcur2  equ   $67A; Saves cursor while in terminal mode
C100: 0638 59 eschar   equ   $638; Current escape character 6F9 & 6FA
C100: 06B8 60 flags    equ   $6B8; D7 = Video echo D6 = CRLF 779 & 77A

```

04 SERIAL

Serial & Communications equates

31-MAY-85

PAGE 9

C100:	0738	61 col	equ \$738	;Current printer column 7F9 & 7FA
C100:	047E	62 number	equ \$47E	;Number accumulated in command
C100:	04FF	63 aciabuf	equ \$4FF	;Owner of serial buffer
C100:	057F	64 twser	equ \$57F	;Storage pointer for serial buffer
C100:	05FF	65 twkey	equ \$5FF	;Storage pointer for type ahead buffer
C100:	067F	66 trser	equ \$67F	;Retrieve pointer for serial buffer
C100:	06FF	67 trkey	equ \$6FF	;Retrieve buffer for type ahead buffer
C100:	0800	68 thbuf	equ \$800	;Buffer in alt ram space
C100:	06F8	69 temp	equ \$6F8	;Temp storage
C100:	05FE	70 charbuf	equ \$5FE	;5FE, 67E are one byte character buffers
C100:	BFF8	71 sdata	equ \$BFF8	;+\$N0+\$90 is output port
C100:	BFF9	72 sstat	equ \$BFF9	;ACIA status register
C100:	BFFA	73 scomd	equ \$BFFA	;ACIA command register
C100:	BFFB	74 scntl	equ \$BFFB	;ACIA control register
C100:	32	include ser		;Printer port @ \$C100

05 SER

Serial output port routine

31-MAY-85

PAGE 10

```

C100:          3 *org serslot
C100:2C 89 C1  4     bit    serrts      ;Set V to indicate initial entry
C103:70 0C     C111  5     bvs    entr1      ;Always taken
C105:38         6     sec      ;Input entry point
C106:90         7     dfb    $90        ;BCC opcode
C107:18         8     clc
C108:B8         9     clv
C109:50 06     C111  10    bvc    entr1      ;V = 0 since not initial entry
                                         ;Always taken

C10B:01         12    dfb    $01        ;pascal signature byte
C10C:31         13    dfb    $31        ;device signature
C10D:9E         14    dfb    >p1init
C10E:A8         15    dfb    >p1read
C10F:B4         16    dfb    >p1write
C110:BB         17    dfb    >p1status

C111:DA         19    entr1    phx      ;Save the reg
C112:A2 C1     20    ldx    #<serslot   ;X = Cn
C114:4C 1C C2     21    jmp    setup      ;Set mslot, etc
C117:90 03     C11C  22    serport   bcc      ;Only output allowed
C119:4C E5 C7     23    jmp    serisout   swzznm   ;Reset the hooks
C11C:0A         24    serisout  asl      A        ;A = flags
C11D:7A         25    ply
C11E:5A         26    phy
C11F:BD B8 04     27    lda    pwdth,x   ;Formatting enabled?
C122:F0 42     C166  28    beq    prnow
C124:A5 24         29    lda    ch        ;Get current horiz position
C126:B0 1C     C144  30    bcs    servid   bcs      ;Branch if video echo
C128:DD B8 04     31    cmp    pwdth,x   ;If CH >= PWIDTH, then CH = COL
C12B:90 03     C130  32    bcc    chok
C12D:BD 38 07     33    lda    col,x
C130:DD 38 07     34    chok   cmp    col,x   ;Must be > col for valid tab
C133:B0 0B     C140  35    bcs    fixch   bcs      ;Branch if ok
C135:C9 11         36    cmp    #$11      ;8 or 16?
C137:B0 11     C14A  37    bcs    prnt    ;If > forget it
C139:09 F0         38    ora    #$F0      ;Find next comma cheaply
C13B:3D 38 07     39    and    col,x   ;Don't blame me it's Dick's trick
C13E:65 24         40    adc    ch
C140:85 24         41    fixch  sta    ch        ;Save the new position
C142:80 06     C14A  42    bra    prnt
C144:C5 21         43    servid  cmp    wndwdth ;If ch>= wndwdth go back to start of
                                         ;line
C146:90 02     C14A  44    blt    prnt
C148:64 24         45    stz    ch        ;Go back to left edge

C14A:          47 * We have a char to print
C14A:7A         48    prnt   ply
C14B:5A         49    phy
C14C:BD 38 07     50    lda    col,x   ;Have we exceeded width?
C14F:DD B8 04     51    cmp    pwdth,x
C152:B0 08     C15C  52    bge    toofar   bge      ;Are we tabbing?
C154:C5 24         53    cmp    ch
C156:B0 0E     C166  54    bge    prnow   lda      #$40      ;Space * 2
C158:A9 40         55    lda    "#$40
C15A:80 02     C15E  56    bra    tab
C15C:A9 1A         57    toofar  lda    "#$1A      ;CR * 2
C15E:C0 80         58    tab    cpy    #$80      ;C = High bit

```

05 SER

Serial output port routine

31-MAY-85

PAGE 11

```
C160:6A      59       ror    A      ;Shift it into char
C161:20 9B C1  60       jsr    goser3 ;Out it goes
C164:80 E4   C14A  61       bra    prnt
C166:98      62       prnow  tya
C167:20 8A C1  63       jsr    serout ;Print the actual char
C16A:BD B8 04  64       lda    pwdth,x ;Formatting enabled
C16D:F0 17   C186  65       beq    done
C16F:30 B8 06  66       bit    flags,x ;In video echo?
C172:30 12   C186  67       bmi    done
C174:BD 38 07  68       lda    col,x ;Check if within 8 chars of right edge
C177:FD B8 04  69       sbc    pwidth,x ;So BASIC can format output
C17A:C9 F8   70       cmp    #$F8
C17C:90 04   C182  71       bcc    setch ;If not within 8, we're done
C17E:18      72       clc
C17F:65 21   73       adc    wndwdth
C181:AC      74       dfb    $AC   ;Dummy LDY to skip next two bytes
C182:A9 00   75       setch  lda    #0   ;Keep cursor at 0 if video off
C184:85 24   76       sta    ch
C186:68      77       done   pla
C187:7A      78       ply
C188:FA      79       plx
C189:60      80       serrts rts
```

```
C18A:        C18A  82       serout  equ   *      ;Serial output
C18A:20 A9 C7  83       jsr    swcmd  ;Check if command
C18D:90 FA   C189  84       bcc    serrts ;All done if it is
C18F:        C18F  85       serout2 equ   *      ;N=1 iff video on
C18F:3C B8 06  86       bit    flags,x
C192:10 07   C19B  87       bpl    goser3 ;Don't echo ^Q
C194:C9 91   88       cmp    #xon
C196:F0 03   C19B  89       beq    goser3 ;Echo it
C198:20 F0 FD  90       jsr    cout1 ;Go to serout3
C19B:4C CD C7  91       goser3 jmp   swser3
```

```
C19E:        93 * Pascal support stuff
C19E:5A      94 p1init  phy
C19F:48      95 pha
C1A0:20 B6 C2  96 jsr   default ;set defaults, enable acia
C1A3:9E B8 06  97 stz   flags,x
C1A6:80 07   C1AF  98 bra   p1read2 ;all done...
```

```
C1A8:5A      100 p1read   phy
C1A9:20 D9 C7  101 jsr   swread  ;read data from serial port (or buffer)
C1AC:90 FA   C1A8  102 bcc   p1read  ;Branch if data not ready
C1AE:90      103 dfb   $90   ;BCC to skip pla
C1AF:68      104 p1read2 pla
C1B0:7A      105 ply
C1B1:A2 00   106 ldx   #0
C1B3:60      107 rts
```



```
C1B4:5A      109 p1write  phy
C1B5:48      110 pha
C1B6:20 8A C1  111 jsr   serout ;Go output character
C1B9:80 F4   C1AF  112 bra   p1read2
```

05 SER

Serial output port routine

31-MAY-85

PAGE 12

```
C1BB:5A      113 p1status  phy
C1BC:48      114 pha
C1BD:4A      115 lsr   A          ;C = 0 output, 1 input
C1BE:D0 15   C1D5 116 bne   p1err    ;Branch if bad call
C1C0:08      117 php
C1C1:20 D3 C7 118 jsr   swgetst   ;Get status in A
C1C4:28      119 plp
C1C5:90 05   C1CC 120 bcc   p1stwr   ;Test DCD = 0 & rcvr full
C1C7:29 28      121 and   #$28
C1C9:0A      122 asl   A          ;$08 -> $10
C1CA:80 02   C1CE 123 bra   p1strd   ;Test DCD = 0 & xmit empty
C1CC:29 30      124 p1stwr   and   #$30
C1CE:C9 10   C1CE 125 p1strd   cmp   #$10
C1D0:F0 DD   C1AF 126 beq   p1read2  ;Is it what we want?
C1D2:18      127 clc
C1D3:80 DA   C1AF 128 bra   p1read2  ;C = 1 if equal
C1D5:A2 40      129 p1err    ldx   #$40
C1D7:68      130 pla
C1D8:7A      131 ply
C1D9:18      132 clc
C1DA:60      133 rts

C1DB: 0025 135 ds     comslot-$00
C200:          33 include comm      ;Communications port @ $C200
```

06 COMM		Communications port routine			31-MAY-85	PAGE 13
C200:2C	89 C1	3	bit	serrts	;Set V to indicate initial entry	
C203:70	14 C219	4	bvs	entr		
C205:38		5	sin	sec	;Input entry point	
C206:90		6		dfb	\$90	;BCC opcode to skip next byte
C207:18		7	sout	clc	;Output entry point	
C208:B8		8		clv	;Mark not initial entry	
C209:50	0E C219	9	bvc	entr	;Branch around pascal entry stuff	
C20B:01		11		dfb	\$01	;pascal signature byte
C20C:31		12		dfb	\$31	;device signature
C20D:11		13		dfb	>p2init	
C20E:13		14		dfb	>p2read	
C20F:15		15		dfb	>p2write	
C210:17		16		dfb	>p2status	
C211: 18 * Pascal support stuff						
C211:80	8B C19E	20	p2init	bra	p1init	
C213:80	93 C1A8	21	p2read	bra	p1read	
C215:80	9D C1B4	22	p2write	bra	p1write	
C217:80	A2 C1BB	23	p2status	bra	p1status	
C219:DA		25	entr	phx		
C21A:A2	C2	26		idx	#<comslot	;X = <CN00
C21C:	C21C	27	setup	equ	*	
C21C:5A		28		phy		
C21D:48		29		pha		
C21E:8E	F8 07	30		stx	mslot	
C221:50	22 C245	31		bvc	sudone	;First call?
C223:A5	36	32		lda	cswl	;If both hooks CN00 setup defaults
C225:45	38	33		eor	kswl	
C227:F0	06 C22F	34		beq	sudodef	
C229:A5	37	35		lda	cswh	;If both hooks CN then don't do def
C22B:C5	39	36		cmp	kswh	;since it has already been done
C22D:F0	03 C232	37		beq	sunodef	
C22F:20	B6 C2	38	sudodef	jsr	default	;Set up defaults
C232:8A		39	sunodef	txa		
C233:45	39	40		eor	kswh	;Input call?
C235:05	38	41		ora	kswl	
C237:D0	07 C240	42		bne	suout	;Must be Cn00
C239:A9	05	43		lda	#>sin	;Fix the input hook
C23B:85	38	44		sta	kswl	
C23D:38		45		sec		;C = 1 for input call
C23E:80	05 C245	46		bra	sudone	
C240:A9	07	47	suout	lda	#>sout	;Fix output hook
C242:85	36	48		sta	cswl	;Note C might not be 0
C244:13		49		clc		;C=0 for output
C245:BD	B8 06	50	sudone	lda	flags,x	;Check if serial or comm port
C248:89	01	51		bit	#1	;Leave flags in a for serport
C24A:D0	03 C24F	52		bne	comport	
C24C:4C	17 C1	53	comout	jmp	serport	
C24F:90	FB C24C	54	comport	bcc	comout	;Output?
C251:68		55		pla		;Get the char
C252:80	28 C27C	56		bra	term1	;Input
C254:3C	B8 03	57	noesc	bit	sermode,x	;In terminal mode?
C257:50	1C C275	58		bvc	exit1	;If not, return key
C259:20	8F C1	59		jsr	serout2	;Out it goes
C25C:80	1E C27C	60		bra	term1	

```

C25E:      C25E   61 testkbd  equ   *
C25E:68    62      pla
C25F:20 70 CC  63      jsr update ;Get current char
C262:10 1B   C27F   64      bpl serin ;Update cursor & check keyboard
C264:20 A9 C7  65      jsr swcmd ;N=0 if no new key
C267:B0 EB   C254   66      bcs noesc ;Test for command
C269:29 5F   67      and #$5f ;Branch if not
C26B:C9 51   68      cmp #'Q' ;$upshift for following tests
C26D:F0 04   C273   69      beq exitX ;Quit?
C26F:C9 52   70      cmp #'R' ;Reset?
C271:D0 09   C270   71      bne term1 ;Go check serial
C273:A9 98   72      exitX lda #$98 ;return a CTRL-X
C275:7A     73      exit1  ply
C276:FA     74      plx
C277:60     75      rts
C278:18     76      goreMOTE clc ;Into remote mode
C279:20 A3 C7  77      goterm jsr swsttm ;Into terminal mode
C27C:        C270   78      term1 equ *
C27C:20 4C CC  79      jsr showcur ;Get current char on screen
C27F:48     80      serin pha
C280:20 D9 C7  81      sinokbd jsr swread ;Is it ready?
C283:B0 09   C28E   82      bcs sidata ;Branch if we got data
C285:BD B8 06  83      lda flags,x ;Is keyboard enabled?
C288:29 10   84      and #$10
C28A:F0 D2   C25E   85      beq testkbd ;Branch if enabled
C28C:80 F2   C280   86      bra sinokbd ;Go test acia again
C28E:A8     87      sidata tay ;Save new input in y for now
C28F:68     88      pla
C290:5A     89      phy
C291:20 B8 C3  90      jsr storCh ;Save new char on stack
C294:68     91      pla
C295:BC 38 06  92      ldy eschar,x ;Fix the screen
C298:F0 12   C2AC   93      beq sinomod ;Get the new data
C29A:09 80   94      ora #$80 ;If 0, don't modify char
C29C:C9 91   95      cmp #xon ;Apple loves the high bit
C29E:F0 DC   C27C   96      beq term1 ;Ignore ^Q
C2A0:C9 FF   97      cmp #$FF ;Ignore FFs
C2A2:F0 D8   C27C   98      beq term1 ;^R for remote?
C2A4:C9 92   99      cmp #$92 ;^T for terminal mode?
C2A6:F0 D0   C278   100     beq goreMOTE
C2A8:C9 94   101     cmp #$94
C2AA:F0 CD   C279   102     beq goterm ;In terminal mode?
C2AC:3C B8 03  103     sinomod bit sermode,x ;Return to user if not A = char
C2AF:50 C4   C275   104     bvc exit1 ;Onto the screen with it
C2B1:20 ED FD  105     jsr cout
C2B4:80 C6   C27C   106     bra term1
C2B6:        C2B6   107     default equ *
C2B6:20 9A CF  108     jsr moveirq ;Set up the defaults
C2B9:BC 29 C2  109     ldy defidx-$C1,x ;make sure irq vectors ok
C2BC:20 7C C3  110     jsr getalt ;Index into alt screen. Table in command
C2BF:48     111     pha
C2C0:88     112     dey
C2C1:30 04   C2C7   113     bmi defff ;Done if minus
C2C3:C0 03   114     cpy #3
C2C5:D0 F5   C2BC   115     bne defloop ;Or if 2
C2C7:20 9A CF  116     deffff jsr moveirq ;Jam irq vector into LC
C2CA:68     117     pla ;Command, control & flags on stack
C2CB:BC 2B C2  118     ldy devno,x

```

06 COMM		Communications port routine	31-MAY-85	PAGE 15
C2CE:99 FB BF	119	sta scntl,y	;Set command reg	
C2D1:68	120	pla		
C2D2:99 FA BF	121	sta scomd,y		
C2D5:68	122	pla		
C2D6:9D B8 06	123	sta flags,x	;And the flags	
C2D9:29 01	124	and #1	;A = \$01 (^A) if comm mode	
C2DB:D0 02 C2DF	125	bne defcom		
C2DD:A9 09	126	lda #9	;^I for serial port	
C2DF:9D 38 06	127	defcom sta eschar,x	;Get printer width	
C2E2:68	128	pla		
C2E3:9D B8 04	129	sta pwdth,x		
C2E6:9E B8 03	130	stz sermode,x		
C2E9:60	131	rts		
C2EA:03 07	132	defidx dfb 3,7		
C2EC: 00C1	133	sltdmy equ <serslot	;Make table for hardware access	
C2EC: C22B	134	devno equ *-sltdmy		
C2EC:A0 B0	135	dfb \$A0,\$B0		
C2EE: 0012	136	ds \$C300-*,\$00		
C300:	34	include c3space	;80 column card @ \$C300	

```

C300:          2 ****
C300:          3 *
C300:          4 * THIS IS THE $C3XX ROM SPACE:
C300:          5 *
C300:          6 ****
C300:48          7 C3ENTRY PHA           ;save regs
C301:DA          8 PHX
C302:5A          9 PHY
C303:80 12  C317 10 BRA   BASICINIT    ;and init video firmware
C305:38          11 C3KEYIN SEC           ;Pascal 1.1 ID byte
C306:90          12 DFB   $90          ;BCC OPCODE (NEVER TAKEN)
C307:18          13 C3COUT1 CLC          ;Pascal 1.1 ID byte
C308:80 1A  C324 14 BRA   BASICENT     ;=>go print/read char
C30A:EA          15 NOP
C30B:
C30B:          16 *
C30B:          17 * PASCAL 1.1 FIRMWARE PROTOCOL TABLE:
C30B:          18 *
C30B:01          19 DFB   $01          ;GENERIC SIGNATURE BYTE
C30C:88          20 DFB   $88          ;DEVICE SIGNATURE BYTE
C30D:
C30D:2C          21 * ****
C30E:2F          22 DFB   >JPINIT      ;PASCAL INIT
C30F:32          23 DFB   >JPREAD      ;PASCAL READ
C310:35          24 DFB   >JPWRITE     ;PASCAL WRITE
C310:35          25 DFB   >JPSTAT      ;PASCAL STATUS
C311:
C311:          26 ****
C311:          27 *
C311:          28 * 128K SUPPORT ROUTINE ENTRIES:
C311:          29 *
C311:4C AF C7          30 JMP   SWAUX        ;MEMORY MOVE ACROSS BANKS
C314:4C B5 C7          31 JMP   SWXFER       ;TRANSFER ACROSS BANKS
C317:
C317:          32 ****
C317:          33 *
C317:          34 ****
C317:          35 * BASIC I/O ENTRY POINT:
C317:          36 ****
C317:          37 *
C317:20 20 CE          38 BASICINIT JSR   HOOKUP      ;COPYROM if needed, sethooks
C31A:20 BE CD          39 JSR   SET80       ;setup 80 columns
C31D:20 58 FC          40 JSR   HOME        ;clear screen
C320:7A          41 PLY
C321:FA          42 PLX          ;restore X
C322:68          43 PLA          ;restore char
C323:18          44 CLC          ;output a character
C324:
C324:B0 03  C329 46 BASICENT BCS   BINPUT      ;=>carry me to input
C326:4C F6 FD          47 BPRINT JMP   COUTZ       ;print a character
C329:4C 1B FD          48 BINPUT JMP   KEYIN      ;get a keystroke
C32C:
C32C:4C 41 CF          49 * ****
C32F:4C 35 CF          50 JPINIT JMP   PINIT      ;pascal init
C32F:4C 35 CF          51 JPREAD JMP   PASREAD    ;pascal read
C332:4C C2 CE          52 JPWRITE JMP   PWRITE     ;pascal write
C335:4C B1 CE          53 JPSTAT JMP   PSTATUS    ;pascal status call
C338:
C338:          54 * ****
C338:          55 * COPYROM is called when the video firmware is
C338:          56 * initialized. If the language card is switched
C338:          57 * in for reading, it copies the F8 ROM to the
C338:          58 * language card and restores the state of the
C338:          59 * language card.

```

```

C338:      60 *
C338:A9 06  61 COPYROM  LDA #G00DF8      ;get the ID byte
C33A:      62 *
C33A:      63 * Compare ID bytes to whatever is readable. If it
C33A:      64 * matches, all is ok. If not, need to copy.
C33A:      65 *
C33A:CD B3 FB  66      CMP F8VERSION    ;does it match?
C33D:F0 3C C37B 67      BEQ ROMOK
C33F:20 60 C3  68      JSR SETROM      ;read ROM, write RAM, save state
C342:A9 F8  69      LDA #$F8        ;from F800-FFFF
C344:85 37  70      STA CSWH
C346:64 36  71      STZ CSWL
C348:B2 36  72      COPYROM2 LDA (CSWL)   ;get a byte
C34A:92 36  73      STA (CSWL)   ;and save a byte
C34C:E6 36  74      INC CSWL
C34E:D0 F8  C348 75      BNE COPYROM2
C350:E6 37  76      INC CSWH
C352:D0 F4  C348 77      BNE COPYROM2   ;fall into RESETLC
C354:      78 *
C354:      79 * RESETLC resets the language card to the state
C354:      80 * determined by SETROM. It always leaves the card
C354:      81 * write enabled.
C354:      82 *
C354:DA  83      RESETLC PHX          ;save X
C355:AE 78 04  84      LDX ROMSTATE   ;get the state
C358:3C 81 C0  85      BIT ROMIN,X   ;set bank & ROM/RAM read
C35B:3C 81 C0  86      BIT ROMIN,X   ;set write enable
C35E:FA  87      PLX          ;restore X
C35F:60  88      RTS
C360:      89 *
C360:      90 * SETROM switches in the ROM for reading, the RAM
C360:      91 * for writing, and it saves the state of the
C360:      92 * language card. It does not save the write
C360:      93 * protect status of the card.
C360:      94 *
C360:DA  95      SETROM PHX          ;save x
C361:A2 00  96      LDX #0          ;assume write enable,bank2,ROMRD
C363:2C 11 C0  97      BIT RDLCBNK2  ;is bank 2 switched in?
C366:30 02 C36A 98      BMI NOT1     ;=>yes
C368:A2 08  99      LDX #$8        ;indicate bank 1
C36A:2C 12 C0 100     NOT1        ;RDLCRAM   ;is LC RAM readable?
C36D:10 02 C371 101     BPL NORREAD  ;=>no
C36F:E8  102      INX          ;indicate RAM read
C370:E8  103      INX
C371:2C 81 C0 104     NORREAD    ;BIT $C081    ;ROM read
C374:2C 81 C0 105     BIT $C081    ;RAM write
C377:8E 78 04 106     STX ROMSTATE  ;save state
C37A:FA  107      PLX          ;restore X
C37B:60  108      ROMOK RTS
C37C:      109 *
C37C:      110 * GETALT reads a byte from aux memory screenholes.
C37C:      111 * Y is the index to the byte (0-7) indexed off of
C37C:      112 * address $478.
C37C:      113 *
C37C:AD 13 C0 114     GETALT LDA RDRAMRD  ;save state of aux memory
C37F:0A  115      ASL A
C380:AD 18 C0 116     LDA RD80COL  ;and of the 80STORE switch
C383:08  117      PHP

```

07 C3SPACE

Communications port routine

31-MAY-85

PAGE 18

```

C384:8D 00 C0      118      STA CLR80COL      ;no 80STORE to get page 1
C387:8D 03 C0      119      STA RDCARDRAM    ;pop in the other half of RAM
C38A:B9 78 04      120      LDA $478,Y       ;read the desired byte
C38D:28            121      PLP                 ;and restore memory
C38E:B0 03 C393    122      BCS GETALT1
C390:8D 02 C0      123      STA RDMAINRAM
C393:10 03 C398    124      BPL GETALT2
C395:8D 01 C0      125      STA SET80COL
C398:60            126      GETALT2 RTS
C399:              127      *
C399:09 80          128      UPSHIFT0 DRA #\$80      ;set high bit for execs
C39B:C9 FB          129      UPSHIFT CMP #\$FB
C39D:B0 06 C3A5    130      BCS X.UPSHIFT
C39F:C9 E1          131      CMP #\$E1
C3A1:90 02 C3A5    132      BCC X.UPSHIFT
C3A3:29 DF          133      AND #\$DF
C3A5:60            134      X.UPSHIFT RTS
C3A6:              135      *
C3A6:              136 * GETCOUT performs COUT for GETLN. It disables the
C3A6:              137 * echoing of control characters by clearing the
C3A6:              138 * M.CTL mode bit, prints the char, then restores
C3A6:              139 * M.CTL. NOESC is used by the RDKEY routine to
C3A6:              140 * disable escape sequences.
C3A6:              141 *
C3A6:48            142      GETCOUT PHA           ;save char to print
C3A7:A9 08          143      LDA #M.CTL        ;disable control chars
C3A9:1C FB 04          144      TRB VMODE        ;by clearing M.CTL
C3AC:68            145      PLA               ;restore character
C3AD:20 ED FD          146      JSR COUT         ;and print it
C3B0:4C 44 FD          147      JMP NOESCAPE   ;enable control chars
C3B3:              148      *
C3B3:              149 * STORCH determines loads the current cursor position,
C3B3:              150 * inverts the character, and displays it
C3B3:              151 * STORCHAR inverts the character and displays it at the
C3B3:              152 * position stored in Y
C3B3:              153 * STORY determines the current cursor position, and
C3B3:              154 * displays the character without inverting it
C3B3:              155 * STORE displays the char at the position in Y
C3B3:              156 *
C3B3:              157 * If mouse characters are enabled (VMODE bit 0 = 0)
C3B3:              158 * then mouse characters ($40-$5F) are displayed when
C3B3:              159 * the alternate character set is switched in. Normally
C3B3:              160 * values $40-$5F are shifted to $0-$1F before display.
C3B3:              161 *
C3B3:              162 * Calls to GETCUR trash Y
C3B3:              163 *
C3B3:20 9D CC          164      STORY JSR GETCUR     ;get newest cursor into Y
C3B6:80 09 C3C1        165      BRA STORE
C3B8:              166      *
C3B8:20 9D CC          167      STORCH JSR GETCUR     ;first, get cursor position
C3BB:24 32            168      BIT INVFLG        ;normal or inverse?
C3BD:30 02 C3C1        169      BMI STORE        ;=>normal, store it
C3BF:29 7F            170      AND #\$7F        ;inverse it
C3C1:5A            171      STORE PHY           ;save real Y
C3C2:09 00            172      ORA #0           ;does char have high bit set?
C3C4:30 15 C3DB        173      BMI STORE1      ;=>yes, don't do mouse check
C3C6:48            174      PHA               ;save char
C3C7:AD FB 04          175      LDA VMODE        ;is mouse bit set?

```

07 C3SPACE	Communications port routine		31-MAY-85	PAGE 19
C3CA:6A	176	ROR	A	
C3CB:68	177	PLA		:restore char
C3CC:90 0D C0	178	BCC	STORE1	;=>no, don't do mouse shift
C3CE:2C 1E C0	179	BIT	ALTCHARSET	;no shift if 11 char set
C3D1:10 08 C0	180	BPL	STORE1	;=> it is!
C3D3:49 40	181	EOR	#\$40	;\$40-\$5F=>0-\$1f
C3D5:89 60	182	BIT	#\$60	
C3D7:F0 02	183	BEQ	STORE1	
C3D9:49 40	184	EOR	#\$40	
C3DB:2C 1F C0	185	STORE1	BIT	;80 columns?
C3DE:10 19 C3F9	186	BPL	STORES	;=>no, store char
C3E0:48	187	PHA		;save (shifted) char
C3E1:8D 01 C0	188	STA	SET80COL	;hit 80 store
C3E4:98	189	TYA		;get proper Y
C3E5:45 20	190	EOR	WNDLFT	C=1 if char in main ram
C3E7:4A	191	LSR	A	
C3E8:B0 04 C3EE	192	BCS	STORE2	;=>yes, main RAM
C3EA:AD 55 C0	193	LDA	TXTPAGE2	;else flip in aux RAM
C3ED:C8	194	INY		;do this for odd left, aux bytes
C3EE:98	195	STORE2	TYA	;divide pos'n by 2
C3EF:4A	196	LSR	A	
C3F0:A8	197	TAY		
C3F1:68	198	PLA		:get (shifted) char
C3F2:91 28	199	STORE3	STA (BASL),Y	;stuff it
C3F4:20 54 C0	200	BIT	TXTPAGE1	;else restore page1
C3F7:7A	201	STORE4	PLY	;restore real Y
C3F8:60	202	RTS		;und exit
C3F9:	203 *			
C3F9:91 28	204	STORE5	STA (BASL),Y	;do 40 column store
C3FB:7A	205	PLY		;restore Y
C3FC:60	206	RTS		;and exit
C3FD:	0003	207	DS \$C400-*,\$00	
C400:	35		include mouse	;Equates for the mouse

```

C400:      2      msb    ON
C400:      3 ****
C400:      4 *
C400:      5 * Mouse firmware for the Chels
C400:      6 *
C400:      7 * by Rich Williams
C400:      8 * July, 1983
C400:      9 *
C400:     10 ****

C400:     12 ****
C400:     13 *
C400:     14 * Equates
C400:     15 *
C400:     16 ****

C400:     18 * Input bounds are in scratch area
C400: 0478 19 moutemp   equ   $478           ;Temporary storage
C400: 0478 20 mini      equ   $478
C400: 04F8 21 maxl      equ   $4F8
C400: 0578 22 minh      equ   $578
C400: 05F8 23 maxh      equ   $5F8
C400:     24 * Mouse bounds in slot 5 screen area
C400: 047D 25 minxl     equ   $47D
C400: 04FD 26 minyl     equ   $4FD
C400: 057D 27 minxh     equ   $57D
C400: 05FD 28 minyh     equ   $5FD
C400: 067D 29 maxxl     equ   $67D
C400: 06FD 30 maxyl     equ   $6FD
C400: 077D 31 maxxh     equ   $77D
C400: 07FD 32 maxyh     equ   $7FD
C400:     33 * Mouse holes in slot 4 screen area
C400: 047C 34 mouxl     equ   $47C           ;X position low byte
C400: 04FC 35 mouyl     equ   $4FC           ;Y position low byte
C400: 057C 36 mouxh     equ   $57C           ;X position high byte
C400: 05FC 37 mouyh     equ   $5FC           ;Y position high byte
C400: 067C 38 mouarm    equ   $67C           ;Arm interrupts from movement or button
C400: 077C 39 mousstat   equ   $77C           ;Mouse status
C400:     40 * Mousstat provides the following
C400: 41 * D7= Button pressed
C400: 42 * D6= Status of button on last read
C400: 43 * D5= Moved since last read
C400: 44 * D4= Reserved
C400: 45 * D3= Interrupt from VBL
C400: 46 * D2= Interrupt from button
C400: 47 * D1= Interrupt from movement
C400: 48 * D0= Reserved
C400: 07FC 49 mouemode   equ   $7FC           ;Mouse mode
C400: 50 * D7 = 1 if user wants control of mouse interrupts
C400: 51 * D6-D4= Unused
C400: 52 * D3= VBL active
C400: 53 * D2= VBL interrupt on button
C400: 54 * D1= VBL interrupt on movement
C400: 55 * D0= Mouse active

```

```

C400:    0020  56 movarm   equ   $20
C400:    000C  57 vblmode  equ   $0C
C400:    0004  58 butmode   equ   $04      ;D2 mask
C400:    0002  59 movmode   equ   $02      ;D1 mask

C400:    61 * Hardware addresses
C400:    C015  62 mouxint  equ   $C015      ;D7 = x interrupt
C400:    C017  63 moyint   equ   $C017      ;D7 = y interrupt
C400:    C019  64 vblint   equ   $C019      ;D7 = vbl interrupt
C400:    C078  65 ioudsbl  equ   $C078      ;Disable iou access
C400:    C079  66 iouenbl  equ   $C079      ;Enable iou access
C400:    C048  67 mouclr   equ   $C048      ;Clear mouse interrupt
C400:    C058  68 iou    equ   $C058      ;IOU interrupt switches
C400:    C058  69 moudsbl  equ   $C058      ;Disable mouse interrupts
C400:    C059  70 mouenbl  equ   $C059      ;Enable mouse interrupts
C400:    C063  71 moubut   equ   $C063      ;D7 = Mouse button
C400:    C066  72 moux1   equ   $C066      ;D7 = X1
C400:    C067  73 moy1    equ   $C067      ;D7 = Y1
C400:    C070  74 vblclr   equ   $C070      ;Clear VBL interrupt
C400:    75 *
C400:    76 * Other addresses
C400:    77 *
C400:    0200  78 inbuf   equ   $200      ;Input buffer
C400:    0214  79 binl    equ   inbuf+20  ;Temp for binary conversion
C400:    0215  80 binh    equ   inbuf+21
C400:    36     include mcode      ;Mouse @ $C400

```

```
2 ****
3 *
4 * Entry points for mouse firmware
5 *
6 ****
C400:00 05 C407 7 mbasic bra outent
C402:A2 03 8 pnull ldx #3
C404:60 9 rts ;Null for pascal entry
C405:38 10 inent sec ;Signature bytes
C406:90 11 dfb $90
C407:18 12 outent clc
C408:4C CF C5 13 jmp xmbasic ;Go do basic entry
C40B:01 14 dfb $01 ;More signature stuff
C40C:20 15 dfb $20
C40D:02 16 dfb >pnull
C40E:02 17 dfb >pnull
C40F:02 18 dfb >pnull
C410:02 19 dfb >pnull
C411:00 20 dfb $0
C412:3B 21 dfb >xsetmou ;SETMOUSE
C413:DC 22 dfb >xmtstint ;SERVEMOUSE
C414:93 23 dfb >xmread ;READMOUSE
C415:82 24 dfb >xmclear ;CLEARMOUSE
C416:69 25 dfb >noerror ;POSMOUSE
C417:BD 26 dfb >xmclamp ;CLAMPMOUSE
C418:6B 27 dfb >xmhome ;HOMEMOUSE
C419:1A 28 dfb >initmouse ;INITMOUSE
C41A: 29 * dfb >pnull
C41A: 30 * dfb >goxmint
```

```

C41A:      32 ****
C41A:      33 *
C41A:      34 * Initmouse - resets the mouse
C41A:      35 * Also clears all of the mouse holes
C41A:      36 * note that iou access fires pdlstrb & makes mouse happy
C41A:      37 *
C41A:      38 ****
C41A: C41A 39 initmouse equ   *
C41A:9C 7C 07 40 stz mousstat ;Clear status
C41D:A2 80 41 ldx #$80
C41F:A0 01 42 ldy #1
C421:9E 7D 04 43 xrloop stz minxl,x ;Minimum = $0000
C424:9E 7D 05 44 stz minxh,x
C427:A9 FF 45 lda #$FF ;Maximum = $03FF
C429:9D 7D 06 46 sta maxx1,x
C42C:A9 03 47 lda #03
C42E:9D 7D 07 48 sta maxxh,x
C431:A2 00 49 ldx #0
C433:88 50 dey
C434:10 EB C421 51 bpl xrloop
C436:20 6B C4 52 jsr xmhome ;Clear the mouse holes
C439:A9 00 53 lda #0 ;Fall into SETMOU

```

```

C43B:      55 ****
C43B:      56 *
C43B:      57 * XSETMOU - Sets the mouse mode to A
C43B:      58 *
C43B:      59 ****
C43B: C43B 60 xsetmou equ   *
C43B:AA 61 tax
C43C:20 9A CF 62 jsr moveirq ;Make sure interrupt vector is right
C43F:8A 63 txa ;Only x preserved by moveirq
C440:8D 78 04 64 sta moutemp
C443:4A 65 lsr A ;D0 = 1 if mouse active
C444:0D 78 04 66 ora moutemp ;D2 = 1 if vbl active
C447:09 10 67 cmp #$10 ;If >=$10 then invalid mode
C449:B0 1F C46A 68 bcs sminvalid
C44B:29 05 69 and #5 ;Extract VBL & Mouse
C44D:F0 01 C450 70 beq xswoff ;Turning it off?
C44F:58 71 cli ;If not, ints active
C450:69 55 72 xswoff adc #$55 ;Make iou byte C=0

```

```

C452:      74 ****
C452:      75 *
C452:      76 * SETIOU - Sets the IOU interrupt modes to A
C452:      77 * Inputs: A = Bits to change
C452:      78 * D7 = Y int on falling edge
C452:      79 * D6 = Y int on rising edge
C452:      80 * D5 = X int on falling edge
C452:      81 * D4 = X int on rising edge
C452:      82 * D3 = Enable VBL int
C452:      83 * D2 = Disable VBL int
C452:      84 * D1 = Enable mouse int
C452:      85 * D0 = Disable mouse int

```

```

C452:          86 *
C452:          87 *
C452:          88 *****
C452: C452  89 setiou    equ   *
C452:08        90    php
C453:78        91    sei           ;Don't allow ints while iou enabled
C454:8E FC 07  92    stx  moumode
C457:8D 79 C0  93    sta  iouenbl   ;Enable iou access
C45A:A2 08     94    ldx  #8
C45C:CA        95    siloop   dex
C45D:0A        96    asl  A           ;Get a bit to check
C45E:90 03 C463 97    bcc  sinoch    ;No change if C=0
C460:9D 58 C0  98    sta  iou,x      ;Set it
C463:D0 F7 C45C 99    sinoch   bne  siloop    ;Any bits left in A?
C465:8D 78 C0 100    sta  ioudsbl   ;Turn off iou access
C468:28        101   plp
C469:18        102   noerror  clc
C46A:60        103   sminvalid rts

C46B:          105 *****
C46B:          106 *
C46B:          107 * XMHOME- Clears mouse position & status
C46B:          108 *
C46B:          109 *****
C46B: C46B  110 xmhome   equ   *
C46B:A2 80     111   ldx  #$80       ;Point mouse to upper left
C46D:80 02 C471 112   bra  xmh2
C46F:A2 00     113   ldx  #0
C471:BD 7D 04  114   xmh2    lda  minxl,x
C474:9D 7C 04  115   sta  mouxl,x
C477:BD 7D 05  116   lda  minxh,x
C47A:9D 7C 05  117   sta  mouxh,x
C47D:CA        118   dex
C47E:10 EF C46F 119   bpl  xmhloop
C480:80 0C C48E 120   bra  xmcdone

C482:          122 *****
C482:          123 *
C482:          124 * XMCLEAR - Sets the mouse to 0,0
C482:          125 *
C482:          126 *****
C482: C482  127 xmclear   equ   *
C482:9C 7C 04  128   stz  mouxl
C485:9C 7C 05  129   stz  mouxh
C488:9C FC 04  130   stz  mouyl
C48B:9C FC 05  131   stz  mouyh
C48E:9C 7C 06  132   xmcdone  stz  mouarm
C491:18        133   clc
C492:60        134   rts

```

```

C493:      136 ****
C493:      137 *
C493:      138 * XMREAD - Updates the screen holes
C493:      139 *
C493:      140 ****
C493: C493 141 xmread equ *
C493:A9 20 142 lda #movarm ;Has mouse moved?
C495:10 7C 07 143 trb mousstat ;Clear moved bit in stat
C498:2D 7C 06 144 and mouarm
C49B:1C 7C 06 145 trb mouarm ;Clear arm bit
C49E:2C FC 07 146 bit mouemode ;If D7 = 1 leave buttons alone
C4A1:30 13 C4B6 147 bmi xmrd2
C4A3:2C 63 C0 148 bit moubut ;Button pressed?
C4A6:30 02 C4AA 149 bmi xrbut
C4A8:09 80 150 ora #$80
C4AA:2C 7C 07 151 xrbut bit mousstat ;Pressed last time?
C4AD:10 02 C4B1 152 bpl xrbut2
C4AF:09 40 153 ora #$40
C4B1:8D 7C 07 154 xrbut2 sta mousstat
C4B4:18 155 clc
C4B5:60 156 rts
C4B6: C4B6 157 xmrd2 equ * ;Leave button bits alone
C4B6:0D 7C 07 158 ora mousstat
C4B9:29 E0 159 and #$E0 ;Button bits
C4BB:80 F4 C4B1 160 bra xrbut2

```

```

C4BD:      162 ****
C4BD:      163 *
C4BD:      164 * XMCLAMP - Store new bounds
C4BD:      165 * Inputs A = 1 for Y, 0 for X axis
C4BD:      166 * minl, minh, maxl, maxh = new bounds
C4BD:      167 *
C4BD:      168 ****
C4BD: C4BD 169 xmclamp equ *
C4BD:6A 170 ror A ;1 -> 80
C4BE:6A 171 ror A
C4BF:29 80 172 and #$80
C4C1:AA 173 tax
C4C2:AD 78 04 174 lda minl
C4C5:9D 7D 04 175 sta minxl,x
C4C8:AD 78 05 176 lda minh
C4CB:9D 7D 05 177 sta minxh,x
C4CE:AD F8 04 178 lda maxl
C4D1:9D 7D 06 179 sta maxx1,x
C4D4:AD F8 05 180 lda maxh
C4D7:9D 7D 07 181 sta maxxh,x
C4DA:18 182 clc ;No error
C4DB:60 183 rts

```

```

C4DC:      185 ****
C4DC:      186 * XMTSTINT - Checks mouse status bits
C4DC:      187 * Used for user mouse interrupt
C4DC:      188 ****
C4DC: C4DC 189 xmtstint equ *

```

09 MCODE

Mouse firmware

31-MAY-85

PAGE 26

```
C4DC:48      190      pha
C4DD:18      191      clc
C4DE:A9 0E    192      lda  #$0E
C4E0:2D 7C 07  193      and  mousstat
C4E3:D0 01    C4E6    194      bne  nstat2
C4E5:38      195      sec
C4E6:68      196      nstat2  pla
C4E7:60      197      rts
C4E8: 0013    198      ds   $C4FB-*,$0
C4FB:D6      199      dfb  $D6      ;Signature byte
C4FC: 0004    200      ds   $C500-*,$00
C500:        37       include misc ;Miscellaneous junk
C500:        008E    1       ds   $C58E-*,$0
```

```

C58E:
C58E:      3 ****
C58E:      4 *
C58E:      5 * MAKTBL - Makes a deniblizing table for the disk II boot
C58E:      6 *
C58E:      7 ****
C58E:A2 03   8 MAKTBL    LDX    #$03
C590:A0 00   9 LDY    #0
C592:86 3C  10 TBLLOOP   STX    BOOTTMP
C594:8A   11 TXA
C595:0A   12 ASL    A
C596:24 3C  13 BIT    BOOTTMP
C598:F0 10  C5AA  14 BEQ    NOPATRN
C59A:05 3C  15 ORA    BOOTTMP
C59C:49 FF  16 EOR    #$FF
C59E:29 7E  17 AND    #$7E
C5A0:B0 08  C5AA  18 TBLLOOP2  BCS    NOPATRN
C5A2:4A   19 LSR    A
C5A3:D0 FB  C5A0  20 BNE    TBLLOOP2
C5A5:98   21 TYA
C5A6:9D 56 03  22 STA    DNIBL,X
C5A9:C8   23 INY
C5AA:E8   24 NOPATRN  INX
C5AB:10 E5  C592  25 BPL    TBLLOOP
C5AD:A9 08   26 LDA    #$08
C5AF:85 27   27 STA    $27
C5B1:A0 7F   28 LDY    #$7F
C5B3:60   29 RTS

```

```

C5B4:
C5B4:      31 ****
C5B4:      32 *
C5B4:      33 * GETUP - Get char from input buffer
C5B4:      34 * iny and upshift it
C5B4:      35 *
C5B4:      36 ****
C5B4:      37 setup    equ    *
C5B4:B9 00 02  38 lda    in,y           ;Get character
C5B7:C8   39 iny
C5B8:4C 99 C3  40 jmp    upshift0

```

```

C5BB:
C5BB:      42 ****
C5BB:      43 *
C5BB:      44 * This is who we are 9 letters
C5BB:      45 *
C5BB:      46 ****
C5BB:C1 F0 F0 EC  47 apple2c  asc    'Apple' //c'

```

```

C5C4:
C5C4:      49 ****
C5C4:      50 *
C5C4:      51 * SHDWINST - Disassemble an instruction and adjust the PC
C5C4:      52 *
C5C4:      53 ****
C5C4:      54 showinst equ    *

```

```

C5C4:20 D0 F8      55      jsr    instdsp
C5C7:20 53 F9      56      jsr    poadj
C5CA:85 3A          57      sta    pcl
C5CC:84 3B          58      sty    pch
C5CE:60              59      rts

61 ****
62 *
63 * XMBASIC - Basic call to the mouse
64 *
65 ****
C5CF:   C5CF  66 xmbasic  equ   *
C5CF:5A  67 phy
C5D0:B0 1C  C5EE 68 bcs  gobasicin ;Input?
C5D2:A0 C4          69 ldy  #<xmbasic ;Input from $C400?
C5D4:C4 39          70 cpy  kswh
C5D6:D0 04  C5DC 71 bne  xmbout
C5D8:A4 38          72 ldy  kswl
C5DA:F0 12  C5EE 73 beq  gobasicin
C5DC:DA          74 xmbout phx   ;Save X too
C5DD:48          75 pha
C5DE:29 7F          76 and  #$7F ;We don't care about high bit
C5E0:C9 02          77 cmp  #2
C5E2:B0 06  C5EA 78 bge  mbbad ;Only 0,1 valid
C5E4:20 3B C4          79 jsr  xsetmou
C5E7:20 6B C4          80 jsr  xmhome
C5EA:68          81 mbbad pla
C5EB:FA          82 plx
C5EC:7A          83 ply
C5ED:60          84 rts
C5EE:4C 9D C7          85 gobasicin jmp   swbasicin ;Go to input routine
C5F1: 0004          86 ds    $C5F5-* ,0 ;More disk stuff
C5F5:            38 include_boot ;Disk II boot @$C600
C5F5: 000B          1      ds    $C600-* ,0 ;Disk II in slot 6

```

```

C600:          4 ****
C600:          5 *
C600:          6 * Disk II boot stuff
C600:          7 * jumps to slot 5 if boot fails
C600:          8 *
C600:          9 ****
C600:A2 20    10      LDX    #$20
C602:A0 00    11      LDY    #$00
C604:64 03    12      STZ    $03
C606:64 3C    13      STZ    $3C
C608:A9 60    14      LDA    #$60
C60A:AA      15      TAX
C60B:86 2B    16      DRV2ENT STX    SLOTZ
C60D:85 4F    17      STA    BOOTDEV
C60F:5A      18      PHY
C610:BD 8E C0 19      LDA    $C08E,X ;Y=1 IF DRIVE 2 BOOT, ELSE Y=0
C613:BD 8C C0 20      LDA    $C08C,X
C616:7A      21      PLY
C617:B9 EA C0 22      LDA    $C0EA,Y ;SELECT DRIVE 1 OR 2
C61A:BD 89 C0 23      LDA    $C089,X
C61D:A0 50    24      LDY    #$50
C61F:BD 80 C0 25      SEEKZERO LDA    $C080,X
C622:98      26      TYA
C623:29 03    27      AND    #$03
C625:0A      28      ASL    A
C626:05 2B    29      ORA    SLOTZ
C628:AA      30      TAX
C629:BD 81 C0 31      LDA    $C081,X
C62C:A9 56    32      LDA    #$56
C62E:20 A8 FC 33      JSR    WAIT
C631:88      34      DEY
C632:10 EB    C61F 35      BPL    SEEKZERO
C634:85 26    36      STA    $26
C636:85 3D    37      STA    $3D
C638:85 41    38      STA    $41
C63A:20 8E C5 39      JSR    MAKtbl
C63D:64 03    40      EXTENT1 STZ    $03
C63F:18      41      RDADR  CLC
C640:08      42      PHP
C641:28      43      RETRY1 PLP
C642:A6 2B    44      RDDHDR LDX    SLOTZ ;RESTORE X TO $60
C644:C6 03    45      DEC    $03 ;UPDATE RETRY COUNT
C646:D0 0E    C656 46      BNE    RDHD0 ;BRANCH IF NOT OUT OF RETRIES
C648:BD 88 C0 47      FUGIT   LDA    $C088,X ;SHUT OFF DISK AND QUIT!
C64B:A5 01    48      LDA    LOC1 ;Auto boot from slot6?
C64D:C9 C6    49      CMP    #$C6
C64F:D0 A4    C5F5 50      BNE    BOOTFAIL
C651:4C 00 C5 51      JMP    $C500 ;Maybe slot 5 will talk to us
C654:        0002 52      ds    $C656-* ,0 ;Keep alignment
C656:08      53      RDHD0 PHP
C657:88      54      RETRY  DEY
C658:D0 04    C65E 55      BNE    RDHD1
C65A:F0 E5    C641 56      BEQ    RETRY1
C65C:80 DF    C63D 57      EXTENT  BRA    EXTENT1 ;Blows up if this is moved too
C65E:          58      * * * * * * * * * * * * * * * * * *
C65E:          59      * The following code is sacred in it's *
C65E:          60      * present form. To change it would *
C65E:          61      * cause volcanos to erupt, the ground *

```

```

C65E:          62 * to shake, and ProDOS not to boot! *
C65E:          63 * * * * * * * * * * * * * * * * * *
C65E:BD 8C C0  64 RDHD1   LDA   $C08C,X
C661:10 FB    C65E  65 BPL   RDHD1
C663:49 D5    66 ISMRK1  EOR   #$D5
C665:D0 F0    C657  67 BNE   RETRY
C667:BD 8C C0  68 RDHD2   LDA   $C08C,X
C66A:10 FB    C667  69 BPL   RDHD2
C66C:C9 AA    70      CMP   #$AA
C66E:D0 F3    C663  71 BNE   ISMRK1
C670:EA      72      NOP
C671:BD 8C C0  73 RDHD3   LDA   $C08C,X
C674:10 FB    C671  74 BPL   RDHD3
C676:C9 96    75      CMP   #$96
C678:F0 09    C683  76 BEQ   RDSECT
C67A:28      77      PLP
C67B:90 C2    C63F  78 BCC   RDADR
C67D:49 AD    79      EOR   #$AD
C67F:F0 25    C6A6  80 BEQ   RDATA
C681:D0 BC    C63F  81 BNE   RDADR
C683:A0 03    82 RDSECT  LDY   #$03
C685:85 40    83 RDSEC1  STA   $40
C687:BD 8C C0  84 RDSEC2  LDA   $C08C,X
C68A:10 FB    C687  85 BPL   RDSEC2
C68C:2A      86      ROL   A
C68D:85 3C    87      STA   BOOTTMP
C68F:BD 8C C0  88 RDSEC3  LDA   $C08C,X
C692:10 FB    C68F  89 BPL   RDSEC3
C694:25 3C    90      AND   BOOTTMP
C696:88      91      DEY
C697:D0 EC    C685  92 BNE   RDSEC1
C699:28      93      PLP
C69A:C5 3D    94      CMP   $3D
C69C:D0 A1    C63F  95 BNE   RDADR
C69E:A5 40    96      LDA   $40
C6A0:C5 41    97      CMP   $41
C6A2:D0 9B    C63F  98 BADRD1 BNE   RDADR
C6A4:B0 9C    C642  99 BCS   RDDHDR
C6A6:A0 56    100 RDATA  LDY   #$56
C6A8:84 3C    101 RDAT0  STY   BOOTTMP
C6AA:BC 8C C0  102 RDAT1  LDY   $C08C,X
C6AD:10 FB    C6AA  103 BPL   RDAT1
C6AF:59 D6 02  104 EOR   DNIBL-$80,Y
C6B2:A4 3C    105 LDY   BOOTTMP
C6B4:88      106      DEY
C6B5:99 00 03  107 STA   NBUF1,Y
C6B8:D0 EE    C6A8  108 BNE   RDAT0
C6BA:84 3C    109 RDATA2 STY   BOOTTMP
C6BC:BC 8C C0  110 RDAT3 LDY   $C08C,X
C6BF:10 FB    C6BC  111 BPL   RDAT3
C6C1:59 D6 02  112 EOR   DNIBL-$80,Y
C6C4:A4 3C    113 LDY   BOOTTMP
C6C6:91 26    114 STA   ($26),Y
C6C8:C8      115      INY
C6C9:D0 EF    C6BA  116 BNE   RDAT2
C6CB:BC 8C C0  117 RDATA4 LDY   $C08C,X
C6CE:10 FB    C6CB  118 BPL   RDAT4
C6D0:59 D6 02  119 EOR   DNIBL-$80,Y

```

11 BOOT

Disk II boot code

31-MAY-85

PAGE 31

C6D3:D0 CD	C6A2	120 BADREAD	BNE	BADRD1
C6D5:A0 00		121	LDY	\$00
C6D7:A2 56		122 DENIBL	LDX	\$56
C6D9:CA		123 DENIB1	DEX	
C6DA:30 FB	C6D7	124	BMI	DENIBL
C6DC:B1 26		125	LDA	(\$26),Y
C6DE:5E 00 03		126	LSR	NBUF1,X
C6E1:2A		127	ROL	A
C6E2:5E 00 03		128	LSR	NBUF1,X
C6E5:2A		129	ROL	A
C6E6:91 26		130	STA	(\$26),Y
C6E8:C8		131	INY	
C6E9:D0 EE	C6D9	132	BNE	DENIB1
C6EB:		133	*	*
C6EB:		134	*	Code beyond this point is not
C6EB:		135	*	sacred... It may be perverted
C6EB:		136	*	in any manner by any pervert.
C6EB:		137	*	*
C6EB:E6 27		138	INC	\$27
C6ED:E6 3D		139	INC	\$3D
C6EF:A5 3D		140	LDA	\$3D
C6F1:CD 00 08		141	CMP	\$0800
C6F4:A6 4F		142	LDX	BOOTDEV
C6F6:90 DB	C6D3	143	BCC	BADREAD
C6F8:4C 01 08		144	JMP	\$0801
C6FB: 0005		145	DS	\$C700-*,\$0 ;Last byte must be 0
C700:		39		include switcher ;Bank switcher @ \$C700

```

C780:      0080    2      ds    $C780-* ,0
C780:      3 ****
C780:      4 *
C780:      5 * Code for switching between banks
C780:      6 * This code appears in both banks of the rom
C780:      7 *
C780:      8 ****
C780:8D 28 C0  9 swrti   sta   rombank ;RTI to the other bank
C783:40     10     rti
C784:8D 28 C0  11 swrts   sta   rombank ;RTS to the other bank
C787:60     12 swrtsop  rts
C788:8D 28 C0  13 swreset  sta   rombank ;Reset routine
C78B:4C 62 FA  14 jmp    reset
C78E:8D 28 C0  15 sta    rombank ;Interrupt routine
C791:2C 87 C7  16 bit    swrtisop ;Set V = 1 for other bank
C794:4C 04 C8  17 jmp    irqent
C797:8D 28 C0  18 swpcnv  sta   rombank ;Protocol converter
C79A:4C F1 C7  19 jmp    swsthk3 ;Jump to sethooks from other side
C79D:8D 28 C0  20 swbasicin sta   rombank ;Mouse BASIC routines
C7A0:4C F6 C7  21 jmp    swzzqt3 ;Jump to zzquit from other side
C7A3:8D 28 C0  22 swsttm  sta   rombank ;Set terminal mode
C7A6:4C F1 C7  23 jmp    swsttm3
C7A9:8D 28 C0  24 swcmd   sta   rombank ;Serial port command processor
C7AC:4C 06 C8  25 jmp    swcmd3
C7AF:8D 28 C0  26 swaux   sta   rombank ;Moveaux
C7B2:4C 4E C3  27 jmp    moveaux
C7B5:8D 28 C0  28 swxfer  sta   rombank
C7B8:4C 97 C3  29 jmp    xfer
C7BB:8D 28 C0  30 swmint  sta   rombank ;Mouse interrupt handler
C7BE:4C 00 C1  31 jmp    mouseint
C7C1:8D 28 C0  32 banger  sta   rombank
C7C4:4C A9 D4  33 jmp    diags
C7C7:8D 28 C0  34 swatalk sta   rombank ;Jump to appletalk
C7CA:4C 80 C5  35 jmp    atalk
C7CD:8D 28 C0  36 swser3  sta   rombank ;Jump to serout3
C7D0:4C 4F C2  37 jmp    serout3
C7D3:8D 28 C0  38 swgetst sta   rombank ;Jump to getstat
C7D6:4C AC C2  39 jmp    getstat
C7D9:8D 28 C0  40 swread   sta   rombank ;Jump to xrdser
C7DC:4C C3 C2  41 jmp    xrdser
C7DF:8D 28 C0  42 swgetb  sta   rombank ;Jump to getbuf
C7E2:4C F7 C2  43 jmp    getbuf
C7E5:8D 28 C0  44 swzznm  sta   rombank
C7E8:4C E0 D4  45 jmp    zznm
C7EB:8D 28 C0  46 swxfgo  sta   rombank ;Jump to users xfer dest
C7EE:6C ED 03  47 jmp    ($3ED)
C7F1:20 23 CE  48 swsthk3 jsr    sethooks
C7F4:80 8E C784 49 bra    swrts
C7F6:20 4D CE  50 swzzqt3 jsr    zzquit
C7F9:80 89 C784 51 bra    swrts
C7FB:      0004  52 ds    $C7FF-* ,0
C7FF:00     53 dfb   0      ;Appletalk version number
C800:      40     include irqbuf ;Interrupt stuff @$C800

```

```

C800:
C800:      3 ****
C800:      4 *
C800:      5 * NEWIRQ - The main (only) IRQ handling routines
C800:      6 * IRQENT - Entry point from alternate rom bank
C800:      7 *
C800:      8 *
C800:      9 * This routine saves the memory state of the machine,
C800:     10 * checks for an internal interrupt, and then calls the user's
C800:     11 * interrupt handler at $3FE.
C800:     12 * The memory state is encoded as follows:
C800:     13 * D7 = 1 if Alternate zero page / stack
C800:     14 * D6 = 1 if 80 store and page 2
C800:     15 * D5 = 1 if Read aux
C800:     16 * D4 = 1 if Write Aux
C800:     17 * D3 = 1 if L.C. enabled
C800:     18 * D2 = 1 if L.C. and $D000 bank 1
C800:     19 * D1 = 1 if L.C. and $D000 bank 2
C800:     20 * D0 = 1 if Alternate rom bank
C800:     21 *
C800:     22 * New changes in the interrupt handler are marked with a +
C800:     23 *
C800:     24 ****
C800:4C 9E C1 25    jmp p1init      ;Pascal 1.0 Initialization
C803: C803 26 NEWIRQ EQU *          ;+
C803:B8 27 CLV             ;+ V=0 for main bank
C804: C804 28 IRQENT EQU *         ;+ Entry point from other bank assumes
C804:48 29    PHA             ;+ Save A on stack, not $45
C805:DA 30    PHX             ;+ X too
C806:BA 31    TSX             ;+ Save stack pointer
C807:68 32    PLA             ;+ Skip past X
C808:68 33    PLA             ;+ And A
C809:68 34    PLA             ;+ Here is the status Oh boy!
C80A:9A 35    TXS             ;+ Fix the stack pointer
C80B:5A 36    PHY             ;Save Y too
C80C:AE 66 C0 37   LDX MOUX1      ;Get mouse info
C80F:AC 67 C0 38   LDY MOUY1      ;As soon as we can
C812:D8 39    CLD             ;+ No decimal mode please
C813:29 10 40   AND #$10        ;+ Test break bit
C815:C9 10 41   CMP #$10        ;+ C=1 if break. V unchanged
C817:AD 18 C0 42   LDA RD80COL   ;TEST FOR 80-STORE WITH
C81A:2D 1C C0 43   AND RDPAGE2   ; PAGE 2 TEXT.
C81D:29 80 44   AND #$80        ; MAKE IT ZERO OR $80
C81F:F0 05 C826 45   BEQ IRQ2       ;SET PAGE 2 RESET BIT.
C821:8D 54 C0 46   STA TXTPAGE1  ;+ Which Rombank?
C824:A9 40 47   LDA #$40        ;+ Mark other bank
C826:50 02 C82A 48 IRQ2        BVC IRQ21
C828:09 01 49   ORA #01
C82A:2C 13 C0 50 IRQ21       BIT RDRAMRD
C82D:10 05 C834 51   BPL IRQ3       ;BRANCH IF MAIN RAM READ
C82F:8D 02 C0 52   STA RDMAINRAM ;ELSE, SWITCH IT IN
C832:09 20 53   ORA #$20        ;AND RECORD THE EVENT!
C834:2C 14 C0 54 IRQ3        BIT RDRAMWRT ;DO THE SAME FOR RAM WRITE.
C837:10 05 C83E 55   BPL IRQ4       ;Branch if break
C839:8D 04 C0 56   STA WRMAINRAM ;Save machine states so far...
C83C:09 10 57   ORA #$10
C83E:B0 08 C848 58 IRQ4        BCS IRQ5
C840:48 59   PHA             ;+ Go Test Mouse & ACIA
C841:20 BB C7 60   JSR SWMINT

```

13 IRQBUF	Serial & Keyboard buffering	31-MAY-85	PAGE 34
C844:90 3C C882	61 BCC IRQLCOK	;+ Branch if it was. LC unchanged!	
C846:68	62 PLA	;Restore states recorded so far	
C847:18	63 CLC	;Reset break/interrupt handler	
C848:2C 12 C0	64 IRQ5 BIT RDLCRAM	;DETERMINE IF LANGUAGE CARD ACTIVE	
C84B:80 03 C850	65 bra passkip1	;Skip around pascal 1.0 stuff	
C84D: 0000	66 ds \$C84D-*,\$00		
C84D:4C A8 C1	67 jmp p1read		
C850:	68 passkip1 equ *		
C850:10 0C C85E	69 BPL IRQ7		
C852:09 0C	70 ORA #\$C	;SET TWO BITS SO RESTORED	
C854:2C 11 C0	71 BIT RDLCBNK2	; LANGUAGE CARD IS WRITE ENABLED	
C857:10 02 C85B	72 BPL IRQ6	;BRANCH IF NOT PAGE 2 OF \$D000	
C859:49 06	73 EOR #\$6	;ENABLE READ FOR PAGE 2 ON EXIT	
C85B:8D 81 C0	74 IRQ6 STA ROMIN		
C85E:2C 16 C0	75 IRQ7 BIT RDALTZP	;LAST...AND VERY IMPORTANT!	
C861:10 0D C870	76 BPL IRQ8	; UNLESS IT IS NOT ENABLED	
C863:BA	77 TSX	;SAVE CURRENT STACK POINTER	
C864:8E 01 01	78 STX \$101	;AT BOTTOM OF STACK	
C867:AE 00 01	79 LDX \$100	;GET MAIN STACK POINTER	
C86A:9A	80 TXS		
C86B:8D 08 C0	81 STA SETSTDZP		
C86E:09 80	82 ORA #\$80		
C870:B0 35 C8A7	83 IRQ8 BCS GOBREAK		
C872:48	84 PHA		
C873:A9 C8	85 LDA #<IRQDONE		
C875:48	86 PHA		
C876:A9 7F	87 LDA #>IRQDONE	;SAVE RETURN IRQ ADDR	
C878:48	88 PHA		
C879:A9 04	89 LDA #4	; SO WHEN INTERRUPT DOES RTI	
C87B:48	90 PHA	; IT RETURNS TO IRQDONE.	
C87C:6C FE 03	91 JMP (\$3FE)	;PROCESS EXTERNAL INTERRUPT	
 ;87F:	93 * The user's RTI returns here		
C87F:	94 * BEWARE		
C87F:	95 * The rom must be reenabled with a LDA romin		
C87F:	96 * This way if the LC was write protected, it still is		
C87F:	97 * if it was write enabled, it still is		
C87F:	98 * if it was being write enabled (2 ldas), it still will be		
C87F:	99 * The restore loop uses an INC because some of the switches are read		
C87F:	100 * and some are write. It must be an INC abs,x since both the 6502 and		
C87F:	101 * the 65C02 do two reads before the write (for different reasons).		
C87F:AD 81 C0	102 IRQDONE LDA ROMIN	;+ Did some clown bank out the rom?	
C882:68	103 IRQLCOK PLA	;Recover machine state	
C883:10 07 C88C	104 BPL IRQDN1	;Branch if main zp was active	
C885:8D 09 C0	105 STA SETALTZP		
C888:AE 01 01	106 LDX \$101	;Restore alternate stack pointer	
C88B:9A	107 TXS		
C88C:A0 06	108 IRQDN1 LDY #\$06	;+ Y = index into table of switches	
C88E:10 06 C896	109 IRQDN2 BPL IRQDN3	;+ Branch if no change	
C890:BE 86 CF	110 LDX IRQTBLE,Y	;+ Get soft switch address	
C893:FE 00 C0	111 INC \$C000,X	;+ Hit the switch. No page cross!!!	
C896:88	112 IRQDN3 DEY		
C897:30 03 C89C	113 BMI IRQDN4	;+ Branch if all done	
C899:0A	114 ASL A	;Get next bit to check	
C89A:D0 F2 C88E	115 BNE IRQDN2	;+ Fall through if all done	
C89C:0A	116 IRQDN4 ASL A	;+ C = 1 if other rom bank	
C89D:0A	117 ASL A	;+	

```
C89E:7A      118      PLY
C89F:FA      119      PLX      ;RESTORE ALL REGISTERS
C8A0:68      120      PLA
C8A1:B0 01   C8A4      121      BCS  IRQDNS  ;+ Which rom bank?
C8A3:40      122      RTI      ;DO THE REAL RTI!
C8A4:4C 80 C7      123      JMP  SWRTI  ;+ Go back to the other bank
```

```
C8A7:          125 ****
C8A7:          126 *
C8A7:          127 * GOBREAK- If a braek instruction has occurred, we check
C8A7:          128 * if the BRK happened in the alternate rom bank. If it has,
C8A7:          129 * some fool may have hit the rom switch by accident and the PC is
C8A7:          130 * decremented by two, the main rom is switched in and we resume
C8A7:          131 * where we think he wanted to go
C8A7:          132 *
C8A7:          133 ****
C8A7:          C8A7 134 GOBREAK EQU *
C8A7:30 20   C8C9 135 BMI GBBRK  ;Give up if alt zp
C8A9:89 09   136 BIT #9    ;From alt rom and no lang card?
C8AB:F0 1C   C8C9 137 BEQ GBBRK  ;If not then break
C8AD:29 FE   138 AND #$FE  ;Force main rom
C8AF:48      139 PHA      ;Save state
C8B0:BA      140 TSX      ;Save stack pointer
C8B1:68      141 PLA      ;Skip State
C8B2:68      142 PLA      ;Skip Y
C8B3:68      143 PLA      ;Skip X
C8B4:68      144 PLA      ;Skip A
C8B5:68      145 PLA      ;Skip P
C8B6:68      146 PLA      ;> address
C8B7:7A      147 PLY      ;< address
C8B8:C0 C1   148 CPY #$C1  ;In the ROM?
C8B9:90 0B   C8C7 149 BCC GBNOTROM ;Branch if not
C8B9:E9 02   150 SBC #2    ;PC = PC - 2
C8BE:B0 01   C8C1 151 BCS GBNOC
C8C9:88      152 DEY      ;Borrow from high byte
C8C1:5A      153 GBNOC  PHY  ;Push new address
C8C2:48      154 PHA
C8C3:9A      155 TXS      ;Fix stack pointer
C8C4:4C 7F C8   156 JMP  IRQDONE
C8C7:9A      157 GBNOTROM TXS  ;Fix stack pointer
C8C8:68      158 PLA      ;Get state back
C8C9:4C 47 FA   159 GBBRK  JMP  NEWBRK ;Go do the break
```

```

C8CC:          162 *   The following routine is for reading key-
C8CC:          163 *   board from buffers or directly.
C8CC:          164 *   Type-ahead buffering only occurs for non auto-
C8CC:          165 *   repeat keypresses. When a key is pressed for
C8CC:          166 *   auto-repeat the buffer is first emptied, then the
C8CC:          167 *   repeated characters are returned.
C8CC:          168 *   The minus flag is used to indicate if a keystroke
C8CC:          169 *   is being returned.
C8CC:          170 *

C8CC:AD 00 C0 172 XRKBD1    LDA   KBD      ;test keyboard directly
C8CF:10 04 C8D5 173 BPL   XRDKBD   ;loop if buffered since test.
C8D1:8D 10 C0 174 STA   KBDSTRB  ;Clear keyboard strobe.
C8D4:60          175 XNOKEY   RTS   ;Minus flag indicates valid character

C8D5:20 E6 C8 177 XRDKBD   JSR   XBITKBD  ;is keyboard input ready?
C8D8:10 FA C8D4 178 BPL   XNOKEY   ;Branch if not.
C8DA:90 F0 C8CC 179 BCC   XRKBD1   ;Branch if direct KBD input.
C8DC:5A          180 PHY
C8DD:A0 80 181 LDY   #$80     ;Y=$80 for keyboard buffer
C8DF:20 DF C7 182 JSR   SWGETB   ;Get data from buffer
C8E2:7A          183 PLY
C8E3:09 00 184 ORA   #0       ;Set minus flag
C8E5:60          185 RTS

C8E6:2C FA 05 187 XBITKBD  BIT   TYPHED  ;This routine replaces "BIT KBD"
                                                ;instructions
C8E9:10 10 C8FB 188 BPL   XBKB2   ;so as to function with type-ahead.
C8EB:38          189 SEC
C8EC:08          190 PHP
C8ED:48          191 PHA
C8EE:AD FF 06 192 LDA   TRKEY   ;is there data to be read?
C8F1:CD FF 05 193 CMP   TWKEY   ;branch if type-ahead buffer empty
C8F4:F0 03 C8F9 194 BEQ   XBKB1   ;branch if type-ahead buffer empty
C8F6:68          195 PLA
C8F7:28          196 PLP
C8F8:60          197 RTS
C8F9:          198 *   ;Carry and minus flag already set.
C8F9:68          199 XBKB1   PLA
C8FA:28          200 PLP
C8FB:2C 00 C0 201 XBKB2   BIT   KBD      ;restore ACC and Status
C8FE:18          202 CLC
C8FF:60          203 RTS      ;test KBD Directly
                                ;indicate direct test

C900:          205 ****
C900:          206 *
C900:          207 * PADDLE patch
C900:          208 * This routine returns the mouse position instead of
C900:          209 * the paddle if the mouse is on
C900:          210 *
C900:          211 ****
C900:          C900 212 mpaddle equ   *
C900:AD FC 07 213 lda   moumode   ;Is the mouse active?
C903:C9 01 214 cmp   #01      ;Only transparent mode
C905:F0 06 C90D 215 beq   pdon
C907:AD 70 C0 216 lda   vbicir   ;Fire the strobe
C90A:4C 21 FB 217 jmp   $FB21

```

13 IRQBUF	Keyboard buffering	31-MAY-85	PAGE 37
C90D:	C90D	218 pdon	equ *
C90D:E0 01		219 cpx	#1 ;C=1 if X=1
C90F:6A		220 ror	A ;A=80 or 0
C910:A8		221 tay	
C911:B9 7C 05		222 lda	mouxh,y ;Get high byte
C914:F0 02 C918		223 beq	pdok
C916:A9 FF		224 lda	#\$FF
C918:19 7C 04		225 ora	mouxl,y
C91B:A8		226 tay	
C91C:60		227 rts	
C91D:		41 include	mini ;Mini assembler & step routines

```

C91D:          3 ****
C91D:          4 *
C91D:          5 * Apple //c Mini Assembler
C91D:          6 *
C91D:          7 * Got mnemonic, check address mode
C91D:          8 *
C91D:          9 ****
C91D:20 3B CA 10 AMOD1   JSR    NNBL      ;get next non-blank
C920:84 34 11 STY     YSAV      ;save Y
C922:DD BA F9 12 CMP     CHAR1,X
C925:D0 13 C93A 13 BNE     AMOD2
C927:20 3B CA 14 JSR     NNBL      ;get next non-blank
C92A:DD B4 F9 15 CMP     CHAR2,X
C92D:F0 0D C93C 16 BEQ     AMOD3
C92F:BD B4 F9 17 LDA     CHAR2,X ;done yet?
C932:F0 07 C93B 18 BEQ     AMOD4
C934:C9 A4 19   CMP     #$A4      ;if "$" then done
C936:F0 03 C93B 20   BEQ     AMOD4
C938:A4 34 21   LDY     YSAV      ;restore Y
C93A:18        22 AMOD2   CLC
C93B:88        23 AMOD4   DEY
C93C:26 44 24 AMOD3   ROL     A5L      ;shift bit into format
C93E:E0 03 25 CPX     #$03
C940:D0 0D C94F 26 BNE     AMOD6
C942:20 A7 FF 27 JSR     GETNUM
C945:A5 3F 28 LDA     A2H      ;get high byte of address
C947:F0 01 C94A 29 BEQ     AMOD5
C949:E8 30   INX
C94A:86 35 31 AMOD5   STX     YSAV1
C94C:A2 03 32 LDX     #$03
C94E:88 33   DEY
C94F:86 3D 34 AMOD6   STX     A1H
C951:CA 35   DEX
C952:10 C9 36 BPL     AMOD1
C954:60 37   RTS

```

```

C955:          39 *
C955:          40 *
C955:          41 * Calculate offset byte for relative addresses
C955:          42 *
C955:E9 81 43 REL    SBC     #$81      ;calc relative address
C957:4A 44   LSR     A
C958:D0 14 C96E 45   BNE     GOERR    ;bad branch
C95A:A4 3F 46   LDY     A2H
C95C:46 3E 47   LDX     A2L
C95E:D0 01 C961 48   BNE     REL1
C960:88 49   DEY
C961:CA 50   REL1   DEX      ;point to offset
C962:8A 51   TXA      ;displacement - 1
C963:18 52   CLC
C964:E5 3A 53   SBC     PCL      ;subtract current PCL
C966:85 3E 54   STA     A2L      ;and save as displacement
C968:10 01 C96B 55   BPL     REL2    ;check page
C96A:C8 56   INY
C96B:98 57   REL2   TYA      ;get page
C96C:E5 3B 58   SBC     PCH      ;check page

```

```

C96E:D0 57 C9C7 59 GOERR     BNE    MINIERR      ;display error
C970:          60 *
C970:          61 * Move instruction to memory
C970:          62 *
C970:A4 2F    63 MOVINST   LDY    LENGTH      ;get instruction length
C972:B9 3D 00  64 MOV1      LDA    A1H,Y      ;get a byte
C975:91 3A    65 STA       (PCL),Y    ;and move it
C977:88        66 DEY
C978:10 F8    C972 67 BPL     MOV1
C97A:          68 *
C97A:          69 * Display instruction
C97A:          70 *
C97A:20 48 F9  71 JSR      PRBLNK    ;print blanks to make ProDOS work
C97D:20 1A FC  72 JSR      UP         ;move up 2 lines
C980:20 1A FC  73 JSR      UP
C983:          C983 74 DISLIN    EQU    *
C983:20 C4 C5  75 JSR      SHOWINST   ;Display line & get next instruction
C986:          C986 76 GETINST1 EQU    *
C986:A9 A1    77 LDA      #$A1      ;! for prompt
C988:85 33    78 STA      PROMPT
C98A:20 67 FD  79 JSR      GETLNZ    ;Get a line
C98D:80 49    C9D8 80 BRA     DOINST    ;Go do the instruction
C98F:          81 *
C98F:          82 * Compare disassembly of all known opcodes with
C98F:          83 * the one typed in until a match is found
C98F:          84 *
C98F:A5 3D    85 GETOP    LDA    A1H      ;get opcode
C991:20 8E F8  86 JSR      INSDS2    ;determine mnemonic index
C994:AA        87 TAX
C995:BD 00 FA  88 LDA      MNEMR,X  ;get right half of index
C998:C5 42    89 CMP      A4L      ;does it match entry?
C99A:D0 21    C9BD 90 BNE      NXTOP    ;=>try next opcode
C99C:BD C0 F9  91 LDA      MNEML,X  ;get left half of index
C99F:80 0C    C9AD 93 bra     p1skip   ;Skip past pascal stuff
C9A1:          0009 94 ds      $C9AA-* ,0 ;Hello I'm the pascal 1.0 entry point
C9AA:4C B4 C1  95 jmp     p1write  ;Just getting in the way
C9AD:          C9AD 96 equ     *
C9AD:C5 43    98 CMP      A4H      ;does it match entry?
C9AF:D0 0C    C9BD 99 BNE      NXTOP    ;=>no, try next opcode
C9B1:A5 44    100 LDA      ASL      ;found opcode, check address mode
C9B3:A4 2E    101 LDY      FORMAT   ;get addr. mode format for that opcode
C9B5:C0 9D    102 CPY      #$9D    ;is it relative?
C9B7:F0 9C    C955 103 BEQ      REL      ;=>yes, calc relative address
C9B9:C5 2E    104 CMP      FORMAT   ;does mode match?
C9BB:F0 B3    C970 105 BEQ      MOVINST ;=>yes, move instruction to memory
C9BD:C6 3D    106 NXTOP
C9BF:D0 CE    C98F 107 BNE      GETOP   ;else try next opcode
C9C1:E6 44    108 INC      A5L      ;=>go try it
C9C3:C6 35    109 DEC      YSAV1   ;else try next format
C9C5:F0 C8    C98F 110 BEQ      GETOP   ;=>go try next format
C9C7:          111 *
C9C7:          112 * Point to the error with a caret, beep, and fall
C9C7:          113 * into the mini-assembler.
C9C7:          114 *
C9C7:A4 34    115 MINIERR  LDY      YSAV   ;get position
C9C9:98        116 ERR2    TYA

```

```

C9CA:AA      117    TAX
C9CB:        C9CB  118  ERR3   EQU   *
C9CB:20 4A F9  119    JSR    PRBL2
C9CE:A9 DE    120    LDA    #$DE      ;^ to point to error
C9D0:20 ED FD  121    JSR    COUT
C9D3:20 3A FF  122    JSR    BELL     ;Beep cause we're mad
C9D6:80 AE C986  123    BRA    GETINST1
C9D8:        124    *
C9D8:        125    * Read a line of input. If prefaced with " ", decode
C9D8:        126    * mnemonic. If "$" do monitor command. Otherwise parse
C9D8:        127    * hex address before decoding mnemonic.
C9D8:        128    *
C9D8:20 C7 FF  129  DOINST   JSR    ZMODE      ;clear mode
C9DB:AD 00 02  130    LDA    $200
C9DE:C9 A0    131    CMP    #$A0      ;if blank,
C9E0:F0 12    C9F4  132    BEQ    DOLIN     ;=>go attempt disassembly
C9E2:C9 8D    133    CMP    #$8D      ;is it return?
C9E4:D0 01    C9E7  134    BNE    GETI1     ;=>no, continue
C9E6:60      135    RTS
C9E7:        136    *
C9E7:20 A7 FF  137  GETI1   JSR    GETNUM     ;parse hexadecimal input
C9EA:C9 93    138    CMP    #$93      ;look for "ADDR:"
C9EC:D0 DB    C9C9  139  GOERR2   BNE    ERR2      ;no ":" , display error
C9EE:8A      140    TXA
C9EF:F0 D8    C9C9  141    BEQ    ERR2      ;X nonzero if address entered
C9F1:        142    *
C9F1:20 78 FE  143    JSR    A1PCLP     ;move address to PC
C9F4:A9 03    144  DOLIN   LDA    #$03      ;get starting opcode
C9F6:85 3D    145    STA    A1H      ;and save
C9F8:20 3B CA  146  NXTCH   JSR    NNBL      ;get next non-blank
C9FB:0A      147    ASL    A         ;validate entry
C9FC:E9 BE    148    SBC    #$BE
C9FE:C9 C2    149    CMP    #$C2
CA00:90 C7    C9C9  150    BCC    ERR2      ;=>flag bad mnemonic
CA02:        151    *
CA02:        152    * Form mnemonic for later comparison
CA02:        153    *
CA02:0A      154    ASL    A
CA03:0A      155    ASL    A
CA04:A2 04    156    LDX    #$04
CA06:0A      157  NXTMN   ASL    A
CA07:26 42    158    ROL    A4L
CA09:26 43    159    ROL    A4H
CA0B:CA      160    DEX
CA0C:10 F8    CA06  161    BPL    NXTMN
CA0E:C6 3D    162    DEC    A1H      ;decrement mnemonic count
CA10:F0 F4    CA06  163    BEQ    NXTMN
CA12:10 E4    C9F8  164    BPL    NXTCH
CA14:A2 05    165    LDX    #$5      ;index into address mode tables
CA16:20 1D C9  166    JSR    AMOD1     ;do this elsewhere
CA19:A5 44    167    LDA    ASL      ;get format
CA1B:0A      168    ASL    A
CA1C:0A      169    ASL    A
CA1D:05 35    170    ORA    YSAV1
CA1F:C9 20    171    CMP    #$20
CA21:B0 06    CA29  172    BCS    AMOD7
CA23:A6 35    173    LDX    YSAV1
CA25:F0 02    CA29  174    BEQ    AMOD7

```

```

CA27:09 80      175    DRA    #$80
CA29:85 44      176    AMOD7   STA    ASL          ;update format
CA2B:84 34      177    STY    YSAV         ;update position
CA2D:B9 00 02    178    LDA    $0200,Y    ;get next character
CA30:C9 BB      179    CMP    #$BB        ;is it a ";"?
CA32:F0 04      CA38   180    BEQ    AMOD8       ;=>yes, skip comment
CA34:C9 8D      181    CMP    #$8D        ;is it carriage return
CA36:D0 B4      C9EC   182    BNE    GOERR2     ;get next opcode
CA38:4C 8F C9    183    AMOD8   JMP    GETOP

```

```

CA3B:           185 ****
CA3B:           186 *
CA3B:           187 * NNBL - Gets a non blank character for the mini assembler
CA3B:           188 *
CA3B:           189 ****
CA3B:           CA3B 190 nnbl    equ    *
CA3B:20 B4 05    191    jsr    getup      ;Get next upshifted character
CA3E:C9 A0      192    cmp    #$A0        ;Blank?
CA40:F0 F9      CA3B   193    beq    nnbl
CA42:60          194    rts

```

```

CA43:          196 ****
CA43:          197 *
CA43:          198 * Step and trace routines
CA43:          199 *
CA43:          200 ****
CA43:          CA43 201 step    equ   *
CA43:2C 61 C0 202     bit   butn0      ;Open apple = slow step
CA46:10 08 CA50 203     bpl   xqnobt0
CA48:A2 07 204     ldx   #7       ;Wait about a second
CA4A:20 A8 FC 205 xqwait   jsr   wait
CA4D:CA 206     dex
CA4E:D0 FA CA4A 207     bne   xqwait
CA50:2C 62 C0 208 xqnobt0 bit   butn1
CA53:30 51 CAA6 209     bmi   xbrk      ;Closed apple = break
CA55:20 75 FE 210     jsr   a1pc      ;If user specified an address, move it
CA58:18 211     clc
CA59:20 0D CB 212     jsr   godsp      ;Disassemble one instruction
CA5C:68 213     pla
CA5D:85 2C 214     sta   rtnl      ;Adjust to user stack
CA5F:68 215     pla
CA60:85 2D 216     sta   rtnh      ;Save return address
CA62:A2 08 217     ldx   #$08
CA64:BD 04 CB 218 xqinit   lda   initbl-1,x ;Init XEQ area
CA67:95 3C 219     sta   xqt,x
CA69:CA 220     dex
CA6A:D0 F8 CA64 221     bne   xqinit
CA6C:A1 3A 222     lda   (pcl,x)
CA6E:F0 36 CAA6 223     beq   xbrk      ;Special if break
CA70:A4 2F 224     ldy   length
CA72:C9 20 225     cmp   #$20
CA74:F0 4A CAC0 226     beq   xjsr      ;Do JSR, RTS, JMP, JMP (), JMP (,X), RTI
CA76:C9 60 227     cmp   #$60
CA78:F0 36 CAB0 228     beq   xrts
CA7A:C9 4C 229     cmp   #$4C
CA7C:F0 4A CAC8 230     beq   xjmp
CA7E:C9 6C 231     cmp   #$6C
CA80:F0 47 CAC9 232     beq   xjmpat
CA82:C9 7C 233     cmp   #$7C
CA84:F0 5D CAE3 234     beq   xjmpatx
CA86:C9 40 235     cmp   #$40
CA88:F0 22 CAAC 236     beq   xrti
CA8A:C9 80 237     cmp   #$80      ;Make bra turn into bpl
CA8C:D0 02 CA90 238     bne   xqntbra
CA8E:A9 10 239     lda   #$10
CA90:29 1F 240 xqntbra and   #$1F
CA92:49 14 241     eor   #$14
CA94:C9 04 242     cmp   #$04
CA96:F0 02 CA9A 243     beq   xq2      ;Copy user inst to xeq area
CA98:B1 3A 244 xq1     lda   (pcl),y ;Change rel branch
CA9A:99 3C 00 245 xq2     sta   xqt,y ;displacement to 4 for jmp to branch
CA9D:88 246     dey
CA9E:10 F8 CA98 247     bpl   xq1      ;or jump to nbranch
CAA0:20 3F FF 248     jsr   restore
CAA3:4C 3C 00 249     jmp   xqt      ;Restore user reg contents
CAA6:A9 64 250 xbrk   lda   #>mon-1 ;Xeq user op from ram
CAA8:A2 FF 251     ldx   #<mon-1 ;Print registers and go to monitor
CAAA:80 2D CAD9 252     bra   rtnjmp2 ;Display regs & go to monitor
CAAC:18 253 xrti    clc

```

```

CAAD:68      254      pla          ;Simulate rti by geting status from
CAAE:85 48   255      sta  status    stack
CAB0:68      256      xrts        ;Then doing rts
CAB1:85 3A   257      pla          ;Pop PC (not pc - 1) !
CAB3:68      258      pla
CAB4:85 3B   259      pcinc2     ;Update Pc by 1 (Len = 0)
CAB6:45 2F   260      pcinc3     ;Update pc by length
CAB8:20 56 F9 261      lda          pch
CABB:84 3B   262      jsr          pcadj3
CABD:18      263      sty          pch
CABE:90 11   CAD1    264      bcc          newpcl
CAC0:18      265      xjsr        clc
CAC1:20 54 F9 266      jsr          pcadj2
CAC4:5A      267      phy          ;Push pc onto stack for jsr
CAC5:48      268      pha
CAC6:A0 02   269      ldy          #$02
CAC8:18      270      xjmp        clc
CAC9:B1 3A   271      xjmpat     lda  (pcl),y
CACB:AA      272      tax          ;Load pc for jmp, (jmp) simulate
CACC:88      273      dey
CADC:B1 3A   274      lda  (pcl),y
CACF:86 3B   275      stx          pch
CAD1:85 3A   276      newpcl     sta  pcl
CAD3:B0 F3   CACB    277      bcs          xjmp
CAD5:A6 2D   278      rtnjmp     ldx  rtnh
CAD7:A5 2C   279      lda          rtnl
CAD9:DA      280      rtnjmp2    phx
CADA:48      281      pha
CADB:A9 27   282      lda  #39      ;Move over
CADD:85 24   283      sta          ch
CAF0:38      284      sec
CAE0:4C 0D CB 285      jmp          godsp
CAE3:18      286      xjmpatx   clc
CAE4:A5 3A   287      lda  (pcl),y
CAE6:65 46   288      adc          xreg
CAE8:85 3A   289      sta          pcl
CAEA:90 02   CAEE    290      bcc          xjxnoc
CAEC:E6 3B   291      inc          pch
CAEE:38      292      xjxnoc    sec
CAEF:80 D8   CACB    293      bra  xjmpat
CAF1:18      294      branch     clc
CAF2:A0 01   295      ldy  #$01      ;Branch taken
CAF4:B1 3A   296      lda  (pcl),y
CAF6:20 56 F9 297      jsr          pcadj3
CAF9:85 3A   298      sta          pcl
CAF9:98      299      tya
CAF0:38      300      sec
CAF0:B0 B5   CAB4    301      bcs          pcinc2
CAFF:20 4A FF 302      nbrnch    jsr  save
CB02:38      303      sec
CB03:B0 B1   CAB6    304      bcs          pcinc3
                                ;Go update PC

CB05:      306 ****
CB05:      307 *
CB05:      308 * This is the table that is moved into zero page
CB05:      309 * when stepping and tracing
CB05:      310 *
CB05:      311 ****

```

```

CB05:EA      312 initbl    nop
CB06:EA      313          nop
CB07:4C FF CA 314          jmp    nbrnch
CB0A:4C F1 CA 315          jmp    branch

CB0D:          317 ****
CB0D:          318 *
CB0D:          319 * GODSP - Saves hooks, calls display routine and fixes hooks
CB0D:          320 * C = 0 instruction display
CB0D:          321 * C = 1 register display
CB0D:          322 * used by step and trace
CB0D:          323 *
CB0D:          324 ****
CB0D: CB0D 325 godsp     equ    *
CB0D:A5 36    326 lda     cswl
CB0F:48      327 pha
CB10:A5 37    328 lda     cswh      ;Save output hook
CB12:48      329 pha
CB13:A9 F0    330 lda     #>cout1
CB15:85 36    331 sta     cswl
CB17:A9 FD    332 lda     #<cout1
CB19:85 37    333 sta     cswh
CB1B:B0 05 CB22 334 bcs     godreg    ;Which display?
CB1D:20 D0 F8 335 jsr     instdsp
CB20:80 03 CB25 336 bra     goddone
CB22:20 DA FA 337 godreg    jsr     rgdsp1
CB25:68      338 goddone   pla
CB26:85 37    339 sta     cswh
CB28:68      340 pla
CB29:85 36    341 sta     cswl
CB2B:60      342 rts
CB2C:          42      INCLUDE SCROLLING ;More Video stuff @$CB30

```

```

CB2C:    0004   3      ds    $CB30-* ,0      ;ALign for fools with illegal entry
Points
CB30:        4 *
CB30:        5 * SCROLLIT scrolls the screen either up or down, depending
CB30:        6 * on the value of X. It scrolls within windows with even
CB30:        7 * or odd edges for both 40 and 80 columns. It can scroll
CB30:        8 * windows down to 1 characters wide.
CB30:        9 *
CB30:DA     10 SCROLLDN PHX          ;save X
CB31:A2 00   11 LDX  #0            ;direction = down
CB33:80 03   CB38   12 BRA  SCROLLIT ;do scroll
CB35:        13 *
CB35:DA     14 SCROLLUP PHX          ;save X
CB36:A2 01   15 LDX  #1            ;direction = up
CB38:A4 21   16 SCROLLIT LDY  WNDWDTH ;get width of screen window
CB3A:2C 1F C0   17 BIT  RD80VID ;in 40 or 80 columns?
CB3D:10 18   CB57   18 BPL  GETST ;=>40, determine starting line
CB3F:8D 01   CB57   19 STA  SET80COL ;make sure this is enabled
CB42:98   20 TYA
CB43:4A   21 LSR  A          ;divide by 2 for 80 column index
CB44:A8   22 TAY
CB45:A5 20   23 LDA  WNDLFT ;test oddity of right edge
CB47:4A   24 LSR  A          ;by rotating low bit into carry
CB48:B8   25 CLV
CB49:90 03   CB4E   26 BCC  CHKRT ;=>check right edge
CB4B:2C C1 CB   27 BIT  SEV1 ;V=1 if left edge odd
CB4E:2A   28 CHKRT ROL  A          ;restore WNDLFT
CB4F:45 21   29 EOR  WNDWDTH ;get oddity of right edge
CB51:4A   30 LSR  A          ;C=1 if right edge even
CB52:70 03   CB57   31 BVS  GETST ;if odd left, don't DEY
CB54:B0 01   CB57   32 BCS  GETST ;if even right, don't DEY
CB56:88   33 DEY
CB57:8C F8 05   34 GETST STY  TEMPY ;save window width
CB5A:AD 1F C0   35 LDA  RD80VID ;N=1 if 80 columns
CB5D:08   36 PHP
CB5E:A5 22   37 LDA  WNDTOP ;assume scroll from top
CB60:E0 00   38 CPX  #0            ;up or down?
CB62:D0 03   CB67   39 BNE  SETDBAS ;=>up
CB64:A5 23   40 LDA  WNDBTM ;down, start scrolling at bottom
CB66:3A   41 DEC  A          ;really need one less
CB67:        42 *
CB67:8D 78 05   43 SETDBAS STA  TEMPA ;save current line
CB6A:20 24 FC   44 JSR  VTABZ ;calculate base with window width
CB6D:        45 *
CB6D:A5 28   46 SCRLIN LDA  BASL ;current line is destination
CB6F:85 2A   47 STA  BAS2L
CB71:A5 29   48 LDA  BASH
CB73:85 2B   49 STA  BAS2H
CB75:        50 *
CB75:AD 78 05   51 LDA  TEMPA ;get current line
CB78:E0 00   52 CPX  #0            ;going up?
CB7A:D0 07   CB83   53 BNE  SETUP2 ;=>up, inc current line
CB7C:C5 22   54 CMP  WNDTOP ;down. Reached top yet?
CB7E:F0 39   CBB9   55 BEQ  SCRL3 ;yes! clear top line, exit
CB80:3A   56 DEC  A          ;no, go up a line
CB81:80 05   CB88   57 BRA  SETSRC ;set source for scroll
CB83:1A   58 SETUP2 INC  A          ;up, inc current line
CB84:C5 23   59 CMP  WNDBTM ;at bottom yet?
CB86:B0 31   CBB9   60 BCS  SCRL3 ;yes! clear bottom line, exit

```

```

CB88:          61 *
CB88:8D 78 05 62 SETSRC   STA  TEMPA      ;save new current line
CB88:20 24 FC 63 JSR   VTABZ      ;get base for new current line
CB8E:AC F8 05 64 LDY   TEMPY      ;get width for scroll
CB91:28       65 PLP
CB92:08       66 PHP
CB93:10 1F CBB4 67 BPL   SKPRT      ;=>only do 40 columns
CB95:AD 55 C0 68 LDA   TXTPAGE2   ;scroll aux page first (even bytes)
CB98:98       69 TYA
CB99:F0 07 CBA2 70 BEQ   SCRLEFT    ;if Y=0, only scroll one byte
CB9B:B1 28   71 SCRLEVEN   LDA  (BASL),Y
CB9D:91 2A   72 STA  (BAS2L),Y
CB9F:88       73 DEY
CBA9:D0 F9 CB9B 74 BNE   SCRLEVEN   ;do all but last even byte
CBA2:70 04 CBA8 75 SCRLEFT    ;odd left edge, skip this byte
CBA4:B1 28   76 LDA  (BASL),Y
CBA6:91 2A   77 STA  (BAS2L),Y
CBA8:AD 54 C0 78 SKPLFT     LDA  TXTPAGE1  ;now do main page (odd bytes)
CBA9:AC F8 05 79 LDY   TEMPY      ;restore width
CBAE:B0 04 CBB4 80 BCS   SKPRT      ;even right edge, skip this byte
CBB0:B1 28   81 SCRLODD    LDA  (BASL),Y
CBB2:91 2A   82 STA  (BAS2L),Y
CBB4:88       83 SKPRT      DEY
CBBS:10 F9 CBB0 84 BPL   SCRLODD    ;scroll next line
CBB7:80 B4 CB6D 85 BRA   SCRLIN     ;clear current line
CBB9:          86 *
CBB9:20 A0 FC 87 SCRLOD     JSR  CLRLIN    ;restore original cursor line
CBB0:20 22 FC 88 JSR   VTAB      ;pull status off stack
CBBF:28       89 PLP
CBB0:FA       90 PLX
CBC1:60       91 SEV1      RTS  ;done!!!

```

```

CBC2:          93 *
CBC2:          94 * DOCLR is called by CLREOL. It decides whether
CBC2:          95 * to do a (quick) 40 or 80 column clear to end of line.
CBC2:          96 *
CBC2:2C 1F C0  97 DOCLR    BIT   RD80VID      ;40 or 80 column clear?
CBC5:30 13 CBDA 98 BMI     CLR80      ;=>clear 80 columns
CBC7:91 28     99 CLR40    STA   (BASL),Y
CBC9:C8        100 INY
CBCA:C4 21     101 CPY     WNDWDTH
CBCC:90 F9     102 BCC     CLR40
CBCE:60        103 RTS
CBCF:          104 *
CBDF:DA        105 CLRHALF PHX
CBD0:A2 D8     106 LDX   #$D8      ;clear right half of screen
CBD2:A0 14     107 LDY   #20
CBD4:A5 32     108 LDA   INVFLG
CBD6:29 A0     109 AND   #$A0
CBDF:80 17     110 BRA   CLR2      ;=>jump into middle
CBDA:          111 *
CBDA:DA        112 CLR80  PHX
CBDB:48        113 PHA
CBDC:98        114 TYA
CBDD:48        115 PHA
CBDE:38        116 SEC
CBDF:E5 21     117 SBC   WNDWDTH
CBE1:AA        118 TAX
CBE2:98        119 TYA
CBE3:4A        120 LSR   A
CBE4:A8        121 TAY
CBE5:68        122 PLA
CBE6:45 20     123 EOR   WNDLFT
CBE8:6A        124 ROR   A
CBE9:B0 03     125 BCS   CLR0
CBE9:10 01     126 BPL   CLR0
CBED:C8        127 INY
CBEF:B0 0B     128 CLR0  PLA
CBFC:          129 BCS   CLR1
CBF1:2C 55 C0  130 CLR2  BIT   TXTPAGE2
CBF4:91 28     131 STA   (BASL),Y
CBF6:2C 54 C0  132 BIT   TXTPAGE1
CBF9:E8        133 INX
CBFA:F0 06     134 BEQ   CLR3
CBFC:91 28     135 CLR1  STA   (BASL),Y
CBFE:C8        136 INY
CBFF:E8        137 INX
CC00:D0 EF     138 BNE   CLR2
CC02:FA        139 CLR3  PLX
CC03:60        140 RTS
CC04:          141 *
CC04:9C FA 05  142 CLRPORT STZ   TYPHED
CC07:9C F9 05  143 STZ   EXTINT2
CC0A:60        144 RTS

```

```

CC0B:          146 *
CC0B:          147 * PASINVERT is used by Pascal to display the cursor. Pascal
CC0B:          148 * normally leaves the cursor on the screen at all times. It
CC0B:          149 * is fleetingly removed while a character is displayed, then
CC0B:          150 * promptly redisplayed. CTL-F and CTL-E, respectively,
CC0B:          151 * disable and enable display of the cursor when printed using
CC0B:          152 * the Pascal 1.1 entry point (PWRITE). Screen I/O is
CC0B:          153 * significantly faster when the cursor is disabled. This
CC0B:          154 * feature is supported by Pascal 1.2 and later.
CC0B:          155 *

CC0B:AD FB 04 156 PASINVERT LDA VMODE      ;Called by pascal to
CC0E:29 10    157 AND #M.CURSOR        ;display cursor
CC10:D0 0A CC1C 158 BNE INVX           ;=>cursor off, don't invert
CC12: CC12   159 INVERT EQU *
CC12:20 1D CC 160 JSR PICKY          ;load Y and get char
CC15:48       161 PHA
CC16:49 80    162 EOR #$80           ;FLIP INVERSE/NORMAL
CC18:20 B3 C3  163 JSR STORY          ;stuff onto screen
CC1B:68       164 PLA              ;for RDCHAR
CC1C:60       165 INVX            RTS
CC1D:
CC1D:          166 *

CC1D:          167 * PICK lifts a character from the screen in either
CC1D:          168 * 40 or 80 columns from the current cursor position.
CC1D:          169 * If the alternate character set is switched in,
CC1D:          170 * character codes $0-$1F are returned as $40-$5F (which
CC1D:          171 * is what must have been originally printed to the location).
CC1D:          172 *

CC1D:5A       173 PICKY   PHY      ;save Y
CC1E:20 9D CC 174 JSR GETCUR        ;get newest cursor into Y
CC21:AD 1F C0  175 LDA RD80VID      ;80 columns?
CC24:10 17 CC3D 176 BPL PICK1         ;=>no
CC26:8D 01 C0  177 STA SET80COL     ;force 80STORE if 80 columns
CC29:98       178 TYA
CC2A:45 20    179 EOR WNDLFT        ;C=1 if char in main RAM
CC2C:6A       180 ROR A             ;get low bit into carry
CC2D:B0 04 CC33 181 BCS PICK2         ;=>store in main memory
CC2F:AD 55 C0  182 LDA TXTPAGE2      ;else switch in page 2
CC32:C8       183 INY              ;for odd left, aux bytes
CC33:98       184 PICK2   TYA      ;divide pos'n by 2
CC34:4A       185 LSR A
CC35:A8       186 TAY              ;and use as offset into line
CC36:B1 28    187 LDA (BASL),Y      ;pick character
CC38:8D 54 C0  188 STA TXTPAGE1      ;80 columns, switch in
CC3B:80 02 CC3F  189 BRA PICK3         ;skip 40 column pick
CC3D:B1 28    190 PICK1   LDA (BASL),Y      ;pick 40 column char
CC3F:2C 1E C0  191 PICK3   BIT ALTCHARSET    ;only allow if alt set
CC42:10 06 CC4A  192 BPL PICK4         ;restore real Y
CC44:C9 20    193 CMP #$20
CC46:B0 02 CC4A  194 BCS PICK4         ;$40
CC48:09 40    195 ORA
CC4A:7A       196 PICK4   PLY      ;restore real Y
CC4B:60       197 RTS
CC4C:
CC4C:          198 *
CC4C:          199 * SHOWCUR displays either a checkerboard cursor, a solid
CC4C:          200 * rectangle, or the current cursor character, depending
CC4C:          201 * on the value of the CURSOR location. 0=inverse cursor,
CC4C:          202 * $FF=checkerboard cursor, anything else is displayed
CC4C:          203 * after being anded with inverse mask.

```

```

CC4C:          204 *
CC4C:AC FB 07 205 SHOWCUR  LDY   CURSOR      ;what's my type?
CC4F:D0 02    CC53  206 BNE   NOTINV      ;=>not inverse
CC51:80 BF    CC12  207 BRA   INVERT      ;else invert the char (exit)
CC53:          208 *
CC53:          209 * Exit with char in accumulator
CC53:          210 *
CC53:20 1D CC 211 NOTINV  JSR   PICKY      ;get char on screen
CC56:48        212 PHA   PLY      ;preserve it
CC57:8D 7B 07  213 STA   NXTCUR      ;save for update
CC5A:98        214 TYA   INY      ;test for checkerboard
CC5B:C8        215
CC5C:F0 0D    CC6B  216 BEQ   NOTINV2     ;=>checkerboard, display it
CC5E:7A        217 PLY   PHY      ;test char
CC5F:5A        218
CC60:30 09    CC6B  219 BMI   NOTINV2     ;don't need inverse
CC62:AD 1E C0  220 LDA   ALTCHARSET   ;mask = $7F if alternate
CC65:09 7F    221 ORA   #$7F       ;character set,
CC67:4A        222 LSR   A         ;$3F if normal char set
CC68:2D FB 07  223 NOTINV1 AND   CURSOR      ;form char to display
CC6B:20 B3 C3  224 NOTINV2 JSR   STORY      ;and display it
CC6E:68        225 PLA   PLA      ;restore real char
CC6F:60        226 RTS   RTS      ;screen, and we return with BMI.
CC70:          227 *
CC70:          228 * The UPDATE routine increments the random seed.
CC70:          229 * If a certain value is reached and we are in Apple II
CC70:          230 * mode, the blinking check cursor is updated. If a
CC70:          231 * key has been pressed, the old char is replaced on the
CC70:          232 * screen, and we return with BMI.
CC70:          233 *
CC70:          234 * NOTE: this routine used by COMM firmware!!
CC70:          235 *
CC70:48        236 UPDATE  PHA   ;save char
CC71:E6 4E    237 INC   RNDL      ;update seed
CC73:D0 1E    CC93  238 BNE   UD2       ;check for key
CC75:A5 4F    239 LDA   RNDH      ;+
CC77:E6 4F    240 INC   RNDH      ;+
CC79:45 4F    241 EOR   RNDH      ;+
CC7B:29 10    242 AND   #$10       ;need to update cursor?
CC7D:F0 14    CC93  243 BEQ   UD2       ;=>no, check for key
CC7F:AD FB 07  244 LDA   CURSOR     ;what cursor are we using?
CC82:F0 0F    CC93  245 BEQ   UD2       ;=>/e cursor, leave alone
CC84:5A        246 PHY   PHY      ;+ Save Y
CC85:20 1D CC  247 JSR   PICKY      ;get the character into A
CC88:AC 7B 07  248 LDY   NXTCUR     ;get next character
CC8B:8D 7B 07  249 STA   NXTCUR     ;save next next character
CC8E:98        250 TYA   TYA      ;+
CC8F:20 B3 C3  251 JSR   STORY      ;and print it
CC92:7A        252 PLY   PLY      ;+
CC93:68        253 UD2       PLA   PLA      ;get real char
CC94:20 E6 C8  254 JSR   XBITKBD    ;was a key pressed?
CC97:10 26    CCBF  255 BPL   GETCURX   ;=>no key pressed
CC99:4C BD CF 256 CLRKBD  JMP   CLRKBD2   ;+ restore old key look for key and exit
CC9C:EA        257 NOP   NOP      ;+ Keep code alignedkey
CC9D:          258 *
CC9D:          259 * ON CURSORS. Whenever the horizontal cursor position is
CC9D:          260 * needed, a call to GETCUR is done. This is the equivalent
CC9D:          261 * of a LDY CH. This returns the current cursor for II and

```

```

CC9D:          262 * //e mode, which may have been poked as either CH or DURCH.
CC9D:          263 *
CC9D:          264 * It also forces CH and OLDCH to 0 if 80 column mode active.
CC9D:          265 * This prevents LDY CH, STA (BASL),Y from trashing non screen
CC9D:          266 * memory. It works just like the //e.
CC9D:          267 *
CC9D:          268 * All routines that update the cursor's horizontal position
CC9D:          269 * are here. This ensures that the newest value of the cursor
CC9D:          270 * is always used, and that 80 column CH is always 0.
CC9D:          271 *
CC9D:          272 * GETCUR only affects the Y register
CC9D:          273 *
CC9D:A4 24    274 GETCUR   LDY   CH           ;if CH=OLDCH, then
CC9F:CC 7B 04  275     CPY   OLDCH        ;DURCH is valid
CCA2:D0 03    CCA7  276     BNE   GETCUR1      ;=>else CH must have been changed
CCA4:AC 7B 05  277     LDY   DURCH        ;use DURCH
CCA7:C4 21    278 GETCUR1  CPY   WNDWDTH      ;is the value too big
CCA9:90 02    CCAD  279     BCC   GETCUR2      ;=>no, fits just fine
CCAB:A0 00    280     LDY   #0           ;else force CH to 0
CCAD:          281 *
CCAD:          282 * GETCUR2 is commonly used to set the current cursor
CCAD:          283 * position when Y can be used.
CCAD:          284 *
CCAD:8C 7B 05  285 GETCUR2 STY   DURCH        ;update real cursor
CCB0:2C 1F C0  286     BIT   RD80VID      ;80 columns?
CCB3:10 02    CCB7  287     BPL   GETCUR3      ;=>no, set all cursors
CCB5:A0 00    288     LDY   #0           ;yes, peg CH to 0
CCB7:84 24    289 GETCUR3 STY   CH
CCB9:8C 7B 04  290     STY   OLDCH        ;get cursor
CCBC:AC 7B 05  291     LDY   DURCH        ;and fly...
CCBF:60          292 GETCURX RTS
CCCC:          43     INCLUDE ESCAPE

```

```

CCC0:      2 * START AN ESCAPE SEQUENCE:
CCC0:      3 * WE HANDLE THE FOLLOWING ONES:
CCC0:      4 *   @ - HOME & CLEAR
CCC0:      5 *   A - Cursor right
CCC0:      6 *   B - Cursor left
CCC0:      7 *   C - Cursor down
CCC0:      8 *   D - Cursor up
CCC0:      9 *   E - CLR TO EOL
CCC0:     10 *   F - CLR TO EOS
CCC0:      11 *   I, Up Arrow - CURSOR UP (stay escape)
CCC0:      12 *   J, Lft Arrow - CURSOR LEFT (stay escape)
CCC0:      13 *   K, Rt Arrow - CURSOR RIGHT (stay escape)
CCC0:      14 *   M, Dn Arrow - CURSOR DOWN (stay escape)
CCC0:      15 *   4 - GOTO 40 COLUMN MODE
CCC0:      16 *   8 - GOTO 80 COLUMN MODE
CCC0:      17 * CTL-D- Disable the printing of control chars
CCC0:      18 * CTL-E- Enable the printing of control chars
CCC0:      19 * CTL-Q- QUIT (PR#0/IN#0)
CCC0:      20 *
CCC0:B9 0C CD  21 ESC3    LDA    ESCCHAR,Y ;GET CHAR TO "PRINT"
CCC3:5A          22 PHY     ;save index
CCC4:20 58 CD  23 JSR    CTLCHAR ;execute character
CCC7:7A          24 PLY     ;restore index
CCC8:C0 08          25 CPY    #YHI   ;If Y<YHI, stay escape
CCCA:BB 21  CCED  26 BCS    ESCRDKEY ;=>exit escape mode
CCCC:
CCCC:      27 *
CCCC:      28 * This is the entry point called by RDKEY iff escapes
CCCC:      29 * are enabled and an escape is encountered. The next
CCCC:      30 * keypress is read and processed. If it is a key that
CCCC:      31 * terminates escape mode, a new key is read by ESCRDKEY.
CCCC:      32 * If escape mode should not be terminated, NEWESC is
CCCC:      33 * called again.
CCCC:      34 *
CCCC:20 1D CC  35 NEWESC  JSR    PICKY   ;get current character
CCCF:48          36 PHA     ;and save it
CCD0:29 80          37 AND    #$80   ;save invert bit
CCD2:49 AB          38 EOR    #$AB   ;make it inverted "+"
CCD4:20 B3 C3          39 JSR    STORY   ;and pop it on the screen
CCD7:20 E6 C8          40 ESC0   JSR    XBITKBD ;check for keystroke
CCDA:10 FB  CCD7  41 BPL    ESC0   ;get old char
CCDC:68          42 PLA     ;restore char, get key
CCDD:20 99 CC  43 JSR    CLRKBD ;upshift esc char
CCE0:20 9B C3  44 JSR    UPSHIFT ;COUNT/INDEX
CCE3:A0 13          45 ESC1   LDY    #ESCNUM
CCE5:D9 F8 CC  46 ESC2   CMP    ESCTAB,Y ;IS IT A VALID ESCAPE?
CCE8:F0 D6  CCC0  47 BEQ    ESC3   =>yes
CCEA:88          48 DEY     ;TRY 'EM ALL...
CCEB:10 F8  CCE5  49 BPL    ESC2   ;read next character.
CCEC:          50 *
CCEC:      51 * End of escape sequence, read next character.
CCEC:      52 * This is initially called by RDCHAR which is usually called
CCEC:      53 * by GETLN to read characters with escapes enabled.
CCEC:      54 *
CCEC:      55 ESCRDKEY LDA    #M.CTL ;enable escape sequences
CCEF:1C FB 04  56 TRB    VMODE
CCF2:20 0C FD  57 JSR    RDKEY ;read char with escapes
CCF5:4C 44 FD  58 JMP    NOESCAPE ;got the key, disable escapes
CCF8:          59 *

```

```

CCF8:    60 * When in escape mode, the characters in ESCTAB (high)
CCF8:    61 * bits set), are mapped into the characters in ESCCHAR.
CCF8:    62 * These characters are then executed by a call to CTLCHAR.
CCF8:    63 *
CCF8:    64 * CTLCHAR looks up a character in the table starting at
CCF8:    65 * CTLTAB. It uses the current index as an index into the
CCF8:    66 * table of routine addresses, CTLADR. If the character is
CCF8:    67 * not in the table, a call to VIDOUT1 is done in case the
CCF8:    68 * character is BS, LF, CR, or BEL.
CCF8:    69 *
CCF8:    70 * NOTE: CTLON and CTLOFF are not accessible except through
CCF8:    71 * and escape sequence
CCF8:    72 *
CCF8:    73      MSB   ON          ;high bit on
CCF8:    CCF8  74 ESCTAB  EQU   *
CCF8:    CCA: 75 ASC   'J'        ;left (stay esc)
CCF9:88  76 DFB   $88       ;left arrow (stay esc)
CCFA:CD  77 ASC   'M'        ;down (stay esc)
CCFB:8B  78 DFB   $8B       ;up arrow (stay esc)
CCFC:95  79 DFB   $95       ;right arrow (stay esc)
CCFD:8A  80 DFB   $8A       ;down arrow (stay esc)
CCFE:C9  81 ASC   'I'        ;up (stay esc)
CCFF:CB  82 ASC   'K'        ;right (stay esc)
CD00:    0008 83 YHI    EQU   *-ESCTAB
CD00:02  84 ASC   'B'        ;left
CD01:03  85 ASC   'C'        ;down
CD02:04  86 ASC   'D'        ;up
CD03:01  87 ASC   'A'        ;right
CD04:00  88 ASC   '@'       ;formfeed
CD05:05  89 ASC   'E'        ;clear EOL
CD06:06  90 ASC   'F'        ;clear EOS
CD07:B4  91 ASC   '4'       ;40 column mode
CD08:B8  92 ASC   '8'       ;80 column mode
CD09:91  93 DFB   $91       ;CTL-Q = QUIT
CD0A:84  94 DFB   $84       ;CTL-D ;ctl char disable
CD0B:85  95 DFB   $85       ;CTL-E ;ctl char enable
CD0C:    96 *
CD0C:    0013 97 ESCNUM  EQU   *-ESCTAB-1
CD0C:    98 *
CD0C:    CD0C  99 ESCCHAR EQU   *
CD0C:88 100 DFB   $88       ;list of escape chars
CD0D:88 101 DFB   $88       ;J: BS (stay esc)
CD0E:8A 102 DFB   $8A       ;<:BS (stay esc)
CD0F:9F 103 DFB   $9F       ;M: LF (stay esc)
CD10:9C 104 DFB   $9C       ;UP:US (stay esc)
CD11:8A 105 DFB   $8A       ;->:FS (stay esc)
CD12:9F 106 DFB   $9F       ;DN: LF (stay esc)
CD13:9C 107 DFB   $9C       ;I: UP (stay esc)
CD14:88 108 DFB   $88       ;K: RT (stay esc)
CD15:    CD15 109 CTLTAB EQU   *
CD15:8A 110 DFB   $8A       ;ESC-B = BS
CD16:9F 111 DFB   $9F       ;list of control characters
CD17:9C 112 DFB   $9C       ;ESC-C = DN
CD18:8C 113 DFB   $8C       ;ESC-D = UP
CD19:9D 114 DFB   $9D       ;ESC-A = RT
CD1A:8B 115 DFB   $8B       ;@: Formfeed
CD1B:91 116 DFB   $91       ;E: CLREOL
CD1C:92 117 DFB   $92       ;F: CLREOP

```

```

CD1D:95      118      DFB  $95          ;QUIT
CD1E:04      119      DFB  $04          ;Disable controls (escape only)
CD1F:05      120      DFB  $05          ;Enable controls (escape only)
CD20:         121 * escape chars end here
CD20:85      122      DFB  $85          ;X.CUR.ON
CD21:86      123      DFB  $86          ;X.CUR.OFF
CD22:8E      124      DFB  $8E          ;Normal
CD23:8F      125      DFB  $8F          ;Inverse
CD24:96      126      DFB  $96          ;Scroll down
CD25:97      127      DFB  $97          ;Scroll up
CD26:98      128      DFB  $98          ;mouse chars off
CD27:99      129      DFB  $99          ;home cursor
CD28:9A      130      DFB  $9A          ;clear line
CD29:9B      131      DFB  $9B          ;mouse chars on
CD2A:         132 *
CD2A: 0014    133 CTLNUM   EQU  *-CTLTAB-1
CD2A:         134 *
CD2A: CD2A    135 CTLADR   EQU  *
CD2A:66 FC    136 DW   LF           ;move cursor down
CD2C:1A FC    137 DW   UP           ;move cursor up
CD2E:A0 FB    138 DW   NEWADV       ;forward a space
CD30:58 FC    139 DW   HOME         ;home cursor, clear screen
CD32:9C FC    140 DW   CLREOL       ;clear to end of line
CD34:42 FC    141 DW   CLREOP       ;clear to end of page
CD36:C0 CD    142 DW   SET40        ;set 40 column mode
CD38:BE CD    143 DW   SET80        ;set 80 column mode
CD3A:45 CE    144 DW   QUIT         ;Quit video firmware
CD3C:91 CD    145 DW   CTLOFF       ;disable //e control chars
CD3E:95 CD    146 DW   CTLON        ;enable //e control chars
CD40:89 CD    147 DW   X.CUR.ON    ;turn on cursor (pascal)
CD42:8D CD    148 DW   X.CUR.OFF   ;turn off cursor (pascal)
CD44:B0 CD    149 DW   X.SO          ;normal video
CD46:B7 CD    150 DW   X.SI          ;inverse video
CD48:30 CB    151 DW   SCROLLDN    ;scroll down a line
CD4A:35 CB    152 DW   SCROLLUP    ;scroll up a line
CD4C:9F CD    153 DW   MOUSOFF      ;disable mouse characters
CD4E:A5 CD    154 DW   HOMECUR     ;move cursor home
CD50:A0 FC    155 DW   CLR琳IN    ;clear current line
CD52:99 CD    156 DW   MOUSON       ;enable mouse characters
CD54:         157 *
CD54:         158      MSB  ON
CD54:         159 *
CD54:         160 * CTLCHAR executes the control character in the
CD54:         161 * accumulator. If it is called by Pascal, the character
CD54:         162 * is always executed. If it is called by the video
CD54:         163 * firmware, the character is executed if M.CTL is set
CD54:         164 * and M.CTL2 is clear.
CD54:         165 *
CD54:         166 * Note: This routine is only called if the video firmware
CD54:         167 * is active. The Monitor ROM calls VIDOUT1 if the video
CD54:         168 * firmware is inactive.
CD54:         169 *
CD54:2C C1 CB 170 CTLCHAR0 BIT   SEV1      ;set V (use M.CTL)
CD57:50      171      DFB  $50          ;BVC opcode (never taken)
CD58:         172 *
CD58:B8      173 CTLCHAR   CLV          ;Always do control character
CD59:DA      174      PHX          ;save X
CD5A:8D F8 04 175 STA   TEMP1      ;temp save of A

```

```

CD5D:20 04 FC      176      JSR     VIDOUT1    ;try to execute CR, LF, BS, or BEL
CD60:CD F8 04      177      CMP     TEMP1     ;if acc has changed
CD63:D0 0A CD6F    178      BNE     CTLDONE   ;then function done
CD65:A2 14          179      LDX     #CTLNUM  ;number of CTL chars
CD67:DD 15 CD      180      FNDCTL  CMP     CTLTAB,X ;is it in table
CD6A:F0 05 CD71    181      BEQ     CTLGO    ;=>yes, should we execute?
CD6C:CA          182      DEX     CTLGO    ;else check next
CD6D:10 F8 CD67    183      BPL     FNDCTL  ;=>try next one
CD6F:FA          184      CTLDONE PLX     FNDCTL  ;restore X
CD70:60          185      RTS     CTLGO    ;and return
CD71:             186      *
CD71:48          187      CTLGO   PHA     CTLGO1   ;save A
CD72:50 0C CD80    188      BVC     CTLGO1   ;V clear, always do (pascal,escape)
CD74:AD FB 04      189      LDA     VMODE    ;controls are enabled iff
CD77:29 28          190      AND     #M.CTL+M.CTL2 ; M.CTL = 1 and
CD79:49 08          191      EOR     #M.CTL    ; M.CTL2 = 0
CD7B:F0 03 CD80    192      BEQ     CTLGO1   ;=>they're enabled!!
CD7D:68          193      CGO     PLA     CTLGO1   ;restore A
CD7E:FA          194      PLX     CTLGO1   ;restore X
CD7F:60          195      RTS     CTLGO1   ;and return
CD80:             196      *
CD80:8A          197      CTLGO1 TXA     A        ;double X as index
CD81:0A          198      ASL     A        ;into address table
CD82:AA          199      TAX    A        ;restore A
CD83:68          200      PLA     CTLDO    ;execute the char
CD84:20 A4 FC      201      JSR     CTLDO    ;restore X
CD87:FA          202      PLX     CTLDO    ;and return
CD88:60          203      RTS     CTLDO    ;they have no effect on firmware operation.
CD89:             204      *
CD89:             205 * X.CUR.ON = Allow Pascal cursor display
CD89:             206 * X.CUR.OFF = Disable Pascal cursor display
CD89:             207 * Cursor is not displayed during call, so it will
CD89:             208 * be right when "redisplayed".
CD89:             209 * Note: Though these commands are executed from BASIC,
CD89:             210 * they have no effect on firmware operation.
CD89:             211 *
CD89:A9 10          212      X.CUR.ON LDA     #M.CURSOR ;clear cursor bit
CD8B:80 0E CD9B    213      BRA     CLRIT    ;set cursor bit
CD8D:             214 *
CD8D:A9 10          215      X.CUR.OFF LDA     #M.CURSOR ;enable control characters
CD8F:80 10 CDA1    216      BRA     SETIT    ;by setting M.CTL2
CD91:             217 *
CD91:             218 * The control characters other than CR,LF,BEL,BS
CD91:             219 * are normally enabled when video firmware is active.
CD91:             220 * They can be disabled and enabled using the ESC-D
CD91:             221 * and ESC-E escape sequences.
CD91:             222 *
CD91:A9 20          223      CTLOFF  LDA     #M.CTL2  ;disable control characters
CD93:80 0C CDA1    224      BRA     SETIT    ;by clearing M.CTL2
CD95:             225 *
CD95:A9 20          226      CTLON   LDA     #M.CTL2  ;enable control characters
CD97:80 02 CD9B    227      BRA     CLRIT    ;by clearing M.CTL2
CD99:             228 *
CD99:             229 * Enable mouse text by clearing M.MOUSE
CD99:             230 *
CD99:A9 01          231      MOUSON  LDA     #M.MOUSE
CD9B:1C FB 04      232      CLRIT   TRB     VMODE
CD9E:60          233      RTS     CTLGO    ;and return

```

```

CD9F:          234 *
CD9F:          235 * Disable mouse text by setting M.MOUSE
CD9F:          236 *
CDA5:A9 01    237 MOUSOFF  LDA #M.MOUSE
CDA1:0C FB 04 238 SETIT   TSB VMODE
CDA4:60        239 RTS
CDA5:          240 *
CDA5:          241 * EXECUTE HOME:
CDA5:          242 *
CDA5:20 E9 FE 243 HOMECUR JSR CLRCH      ;move cursors to far left
CDA8:A8        244 TAY             ;(probably not needed)
CDA9:A5 22    245 LDA WNDTOP      ;and to top of window
CDAB:85 25    246 STA CV
CDAE:4C 88 FC 247 JMP NEWVTABZ   ;then set base address, DURCV
CDB0:          248 *
CDB0:          249 * EXECUTE "NORMAL VIDEO"
CDB0:          250 *
CDB0:20 84 FE 251 X.SO   JSR SETNORM    ;set INVFLG to $FF
CDB3:A9 04    252 LDA #M.VMODE     ;then clear inverse mode bit
CDB5:80 E4    CDB0:          253 BRA CLRIT
CDB7:          254 *
CDB7:          255 * EXECUTE "INVERSE VIDEO"
CDB7:          256 *
CDB7:20 80 FE 257 X.SI   JSR SETINV    ;set INVFLG to $3F
CDBA:A9 04    258 LDA #M.VMODE     ;then set inverse mode bit
CDBC:80 E3    CDA1:          259 BRA SETIT
CDBE:          260 *
CDBE:          261 * EXECUTE '40COL MODE' or '80COL MODE':
CDBE:          262 *
CDBE:38        263 SET80   SEC           ;flag an 80 column window
CDBF:90        264 DFB $90          ;BCC opcode (never taken)
CDC0:18        265 SET40   CLC           ;flag a 40 column window
CDC1:2C FB 04  266 BIT VMODE         ;but...is it pascal?
CDC4:10 54    CE1A:          267 BPL SETX         ;=>yes, don't execute
CDC6:08        268 PHP             ;save window size
CDC7:20 1B CE  269 JSR HOOKITUP    ;COPYROM if needed, set I/O hooks
CDC8:28        270 PLP             ;and get 40/80
CDCB:80 08    CDD5:          271 BRA WIN0         ;=>set window
CDCD:          272 *
CDCD:          273 * CHK80 is called by PR#0 to convert to 40 if it was
CDCD:          274 * 80. Otherwise the window is left ajar.
CDCD:          275 *
CDCD:2C 1F C0  276 CHK80  BIT RD80VID    ;don't set 40 if
CDD0:10 48    CE1A:          277 BPL SETX         ;already 40
CDCD:          278 *
CDCD:18        279 WIN40  CLC           ;flag 40 column window
CDD3:B0        280 DFB $B0          ;BCC opcode (never taken)
CDC4:38        281 WIN80  SEC           ;flag 80 column window
CDC5:64 22    282 WIN0   STZ WNDTOP      ;set window top now
CDC7:2C 1A C0  283 BIT RDTEXT       ;for text or mixed
CDCD:30 04    CDE0:          284 BMI WIN1         ;=>text
CDCD:A9 14    285 LDA #20
CDCD:85 22    286 STA WNDTOP      ;used by 80<->40 conversion
CDCD:2C 1F C0  287 WIN1   BIT RD80VID    ;80 columns now?
CDCD:08        288 PHP             ;save 80 or 40
CDCD:B0 07    CDED:          289 BCS WIN2         ;=>80: convert if 40
CDCD:10 0A    CDF2:          290 BPL WIN3         ;=>40: no convert
CDCD:20 53    CE:            291 JSR SCRNR04    ;80: convert to 40

```

```

CDEB:80 05 CDF2 292 BRA WIN3 ;done converting
CDED:30 03 CDF2 293 WIN2 BMI WIN3 ;=>80: no convert
CDFE:20 80 CE 294 JSR SCR48 ;40: convert to 80
CDF2:20 9D CC 295 WIN3 JSR GETCUR ;determine absolute CH
CDF5:98 296 TYA ;in case the window setting
CDF6:18 297 CLC ;was different
CDF7:65 20 298 ADC WNDLFT
CDF9:28 299 PLP ;pin to right edge if
CDFA:B0 06 CE02 300 BCS WIN4 ;80 to 40 leaves cursor
CDFC:C9 28 301 CMP #40 ;off the screen
CDFE:90 02 CE02 302 BCC WIN4
CE00:A9 27 303 LDA #39
CE02:20 EC FE 304 WIN4 JSR SETCUR ;set new cursor
CE05:A5 25 305 LDA CV ;set new base address
CE07:20 C1 FB 306 JSR BASCALC ;for left = 0 (always)
CE0A: 307 *
CE0A:64 20 308 WNDREST STZ WNDLFT ;Called by INIT and Pascal
CE0C:A9 18 309 LDA #$18 ;and bottom
CE0E:85 23 310 STA WNDBTM
CE10:A9 28 311 LDA #$28 ;set left,width,bottom
CE12:2C 1F C0 312 BIT RD80VID ;set width to 80 if 80 columns
CE15:10 01 CE18 313 BPL WINS
CE17:0A 314 ASL A
CE18:85 21 315 WINS STA WNDWDTH ;set width
CE1A:60 316 SETX RTS ;exit used by SET40/80
CE1B: 317 *
CE1B: 318 * Turn on video firmware:
CE1B: 319 *
CE1B: 320 * This routine is used by BASIC init, ESC-4, ESC-8
CE1B: 321 * It copies the Monitor ROM to the language card
CE1B: 322 * if necessary; it sets the input and output hooks to
CE1B: 323 * $C30x; it sets all switches for video firmware operation
CE1B: 324 *
CE1B:2C 7B 06 325 HOOKITUP BIT VFACTV ;don't touch hooks
CE1E:10 11 CE31 326 BPL VIDMODE ;if video firmware already active
CE20:20 38 C3 327 HOOKUP JSR COPYROM ;Copy ROM to LC?
CE23:A9 05 328 SETHOOKS LDA #>C3KEYIN ;set up $C300 hooks
CE25:85 38 329 STA KSWL
CE27:A9 07 330 LDA #>C3COUT1
CE29:85 36 331 STA CSWL
CE2B:A9 C3 332 LDA #<C3COUT1
CE2D:85 39 333 STA KSWH
CE2F:85 37 334 STA CSWH
CE31: 335 *
CE31: 336 * Now set the video firmware active
CE31: 337 *
CE31:9C FB 07 338 VIDMODE STZ CURSOR ;set a solid inverse cursor
CE34:A9 08 339 LDA #M.CTL ;preserve M.CTL bit
CE36:2D FB 04 340 AND VMODE
CE39:09 81 341 ORA #M.PASCAL+M.MOUSE ;no pascal,mouse
CE3B: 342 *
CE3B: 343 * Pascal calls here to set its mode
CE3B: 344 *
CE3B:8D FB 04 345 PVMODE STA VMODE ;set mode bits
CE3E:9C 7B 06 346 STZ VFACTV ;say video firmware active
CE41:8D 0F C0 347 STA SETALTCHAR ;and set alternate char set
CE44:60 348 QX RTS
CE45: 349 *

```

```
CE45:      350 * QUIT converts the screen from 80 to 40 if necessary,  
CE45:      351 * sets a 40 column window, and restores the normal I/O  
CE45:      352 * hooks (COUT1 and KEYIN).  
CE45:      353 *  
CE45:2C FB 04 354 QUIT     BIT    VMODE      ;no quitting from pascal  
CE48:10 FA CE44 355       BPL    QX  
CE4A:20 D2 CD 356       JSR    WIN40      ;first, do an escape 4  
CE4D:20 89 FE 357 ZZQUIT  JSR    SETKBD    ;do a IN#0 (used by COMM)  
CE50:4C 93 FE 358       JMP    SETVID    ;and a PR#0
```

```

CE53:      360 *
CE53:      361 * SCRNN84 and SCRNN48 convert screens between 40 & 80 cols.
CE53:      362 * WNDTOP must be set up to indicate the last line to
CE53:      363 * be done. All registers are trashed.
CE53:      364 *
CE53:A2 17 365 SCRNN84   LDX #23      ;start at bottom of screen
CE55:8D 01 C0 366 STA SET80COL    ;allow page 2 access
CE58:8A    367 SCR1      TXA          ;calc base for line
CE59:20 C1 FB 368 JSR BASCALC
CE5C:A0 27 369 LDY #39      ;start at right of screen
CE5E:5A    370 SCR2      PHY          ;save 40 index
CE5F:98    371 TYA      ;div by 2 for 80 column index
CE60:4A    372 LSR A
CE61:B0 03 CE66 373 BCS SCR3
CE63:2C 55 C0 374 BIT TXTPAGE2  ;even column, do page 2
CE66:A8    375 SCR3      TAY          ;get 80 index
CE67:B1 28 376 LDA (BASL),Y  ;get 80 char
CE69:2C 54 C0 377 BIT TXTPAGE1 ;restore page1
CE6C:7A    378 PLY      ;get 40 index
CE6D:91 28 379 STA (BASL),Y
CE6F:88    380 DEY
CE70:10 EC  CE5E 381 BPL SCR2      ;do next 40 byte
CE72:CA    382 DEX      ;do next line
CE73:30 04 CE79 383 BMI SCR4      ;=>done with setup
CE75:E4 22 384 CPX WNDTOP
CE77:B0 DF  CE58 385 BCS SCR1
CE79:8D 00 C0 386 SCR4      STA CLR80COL ;clear 80STORE for 40 columns
CE7C:8D 0C C0 387 STA CLR80VID ;clear 80VID for 40 columns
CE7F:60    388 RTS
CE80:      389 *
CE80:A2 17 390 SCRNN48   LDX #23      ;start at bottom of screen
CE82:8A    391 SCR5      TXA          ;set base for current line
CE83:20 C1 FB 392 JSR BASCALC
CE86:A0 00  393 LDY #0       ;start at left of screen
CE88:8D 01 C0 394 STA SET80COL    ;enable page2 store
CE8B:B1 28 395 SCR6      LDA (BASL),Y ;get 40 column char
CE8D:5A    396 SCR8      PHY          ;save 40 column index
CE8E:48    397 PHA
CE8F:98    398 TYA      ;save char
CE90:4A    399 LSR A      ;div 2 for 80 column index
CE91:B0 03 CE96 400 BCS SCR7      ;save on page1
CE93:8D 55 C0 401 STA TXTPAGE2
CE96:A8    402 SCR7      TAY          ;get 80 column index
CE97:68    403 PLA      ;now save character
CE98:91 28 404 STA (BASL),Y
CE9A:8D 54 C0 405 STA TXTPAGE1 ;flip page1
CE9D:7A    406 PLY      ;restore 40 column index
CE9E:C8    407 INY      ;move to the right
CE9F:C0 28 408 CPY #40     ;at right yet?
CEA1:90 E8  CE8B 409 BCC SCR6      ;=>no, do next column
CEA3:20 CF CB 410 JSR CLRHALF ;clear half of screen
CEA6:CA    411 DEX
CEA7:30 04 CEAD 412 BMI SCR9      ;else do next line of screen
CEA9:E4 22 413 CPX WNDTOP
CEAB:B0 D5  CE82 414 BCS SCR5
CEAD:8D 0D C0 415 SCR9      STA SET80VID ;convert to 80 columns
CEB0:60    416 RTS
CEB1:      44  INCLUDE PASCAL ;Pascal support stuff

```

```

CEB1:AA      3 PSTATUS   TAX      ;is request code = 0?
CEB2:F0 08  CEB0      4 BEQ     PIORDY  ;=>yes, ready for output
CEB4:CA      5 DEX      ;check for any input
CEB5:D0 07  CEBE      6 BNE     PSTERR  ;=>bad request, return error
CEB7:20 E6 C8  7 JSR     XBITKBD ;test keyboard
CEBA:10 04  CEC0      8 BPL     PNOTRDY ;=>no keystroked
CEBC:38      9 PIORDY   SEC      ;good return
CEBD:60      10 RTS
CEBE:A2 03    11 PSTERR   LDX #3   ;else flag error
CEC0:18      12 PNOTRDY CLC
CEC1:60      13 RTS
CEC2:        14 *
CEC2:        15 * PASCAL OUTPUT:
CEC2:        16 *
CEC2:        17 PWRITE   EQU    *
CEC2:09 80    18 ORA    #$80   ;turn on high bit
CEC4:AA      19 TAX
CEC5:20 54 CF  20 JSR    PSETUP2 ;SETUP ZP STUFF, don't set ROM
CEC8:A9 08    21 LDA    #M.GOXY ;ARE WE DOING GOTOXY?
CECA:2C FB 04  22 BIT    VMODE
CECD:D0 2B  CEF0      23 BNE    GETX   ;=>Doing X or Y?
CECF:8A      24 TXA
CED0:89 60    25 BIT    #$60   ;is it control?
CED2:F0 45  CF19    26 BEQ    PCTL   ;=>yes, do control
CED4:AC 7B 05  27 LDY    DURCH  ;get horizontal position
CED7:24 32    28 BIT    INVFLG ;check for inverse
CED9:30 02  CEDD    29 BMI    PWR1   ;normal, go store it
CEDB:29 7F    30 AND    #$7F
CDDD:20 01 C3  31 PWR1    JSR    STORE  ;now store it (erasing cursor)
CEE0:C8      32 INY
CEE1:8C 7B 05  33 STY    DURCH
CEE4:C4 21    34 CPY    WNDWDTH
CEE6:90 0C  CEF4    35 BCC    PWRET
CEE8:20 60 C3  36 JSR    SETROM
CEE9:20 E9 FE  37 JSR    CLRCH   ;set cursor position to 0
CEE9:20 66 FC  38 JSR    LF
CEF1:20 54 C3  39 PWRITERET JSR    RESETLC
CEF4:20 0B CC  40 PWRET   JSR    PASINVERT ;display new cursor
CEF7:A2 00    41 PRET    LDX #0   ;return with no error
CEF9:60      42 RTS
CEFA:        43 *
CEFA:        44 * HANDLE GOTOXY STUFF:
CEFA:        45 *
CEFA:        46 GETX   EQU    *
CEFA:20 0B CC  47 JSR    PASINVERT ;turn off cursor
CEFD:8A      48 TXA
CEFE:38      49 SEC
CEFF:E9 A0    50 SBC    #160   ;MAKE BINARY
CF01:2C FB 06  51 BIT    XCOORD ;doing X?
CF04:30 2A  CF30    52 BMI    PSETX ;=>yes, set it
CF06:        53 *
CF06:        54 * Set Y and do the GOTOXY
CF06:        55 *
CF06:        56 GETY   EQU    *
CF06:8D FB 05  57 STA    DURCV
CF09:20 71 CF  58 JSR    PASCALC ;calc base addr
CF0C:AC FB 06  59 LDY    XCOORD
CF0F:20 AD CC  60 JSR    GETCUR2 ;set proper cursors

```

17 PASCAL	Video firmware Pascal stuff	31-MAY-85	PAGE 60
CF12:A9 08	61 LDA #M.GOXY	;turn off gotoxy	
CF14:1C FB 04	62 TRB VMODE		
CF17:80 DB CEF4	63 BRA PWRET	;=>DONE (ALWAYS TAKEN)	
CF19:	64 *		
CF19:20 0B CC	65 PCTL JSR PASINVERT	;turn off cursor	
CF1C:8A	66 TXA	;get char	
CF1D:C9 9E	67 CMP #\$9E	;is it gotoXY?	
CF1F:F0 08 CF29	68 BEQ STARTXY	;=>yes, start it up	
CF21:20 60 C3	69 JSR SETROM	;must switch in ROM for controls	
CF24:20 58 CD	70 JSR CTLCHAR	;EXECUTE IT IF POSSIBLE	
CF27:80 C8 CEF1	71 BRA PWRITERET	;=>display new cursor, exit	
CF29:	72 *		
CF29:	73 * START THE GOTOXY SEQUENCE:		
CF29:	74 *		
CF29: CF29	75 STARTXY EQU *		
CF29:A9 08	76 LDA #M.GOXY		
CF2B:0C FB 04	77 TSB VMODE	;turn on gotoxy	
CF2E:A9 FF	78 LDA #\$FF	;set XCOORD to -1	
CF30:8D FB 06	79 PSETX STA XCOORD	;set X	
CF33:80 BF CEF4	80 BRA PWRET	;=>display cursor and exit	
CF35:	81 *		
CF35:	82 * PASCAL INPUT:		
CF35:	83 *		
CF35:20 54 CF	84 PASREAD JSR PSETUP2	;SETUP ZP STUFF	
CF38:20 D5 C8	85 GKEY JSR XRDKBD	;key pressed?	
CF3B:10 FB CF38	86 BPL GKEY	;=>not yet	
CF3D:29 7F	87 AND #\$7F	;DROP HI BIT	
CF3F:80 B6 CEF7	88 BRA PRET	;good exit	
CF41:	89 *		
CF41:	90 * PASCAL INITIALIZATION:		
CF41:	91 *		
CF41: CF41	92 PINIT EQU *		
CF41:A9 01	93 LDA #M.MOUSE	;Set mode to pascal	
CF43:20 3B CE	94 JSR PVMODE	;without mouse characters	
CF46:20 51 CF	95 JSR PSETUP	;setup zero page for pascal	
CF49:20 D4 CD	96 JSR WIN80	;do 40->80 convert	
CF4C:20 58 FC	97 JSR HOME	;home and clear screen	
CF4F:80 A0 CEF1	98 BRA PWRITERET	;display cursor, set DURCH,DURCV...	
CF51:	99 *		
CF51: CF51	100 PSETUP EQU *		
CF51:20 60 C3	101 JSR SETROM	;save LC state, set ROM read	
CF54:64 22	102 PSETUP2 STZ WNDTOP	;set top to 0	
CF56:20 0A CE	103 JSR WNDREST	;init either 40 or 80 window	
CF59:A9 FF	104 LDA #\$FF	;assume normal text	
CF5B:85 32	105 STA INVFLG		
CF5D:A9 04	106 LDA #M.VMODE	;is it	
CF5F:20 FB 04	107 BIT VMODE		
CF62:F0 02 CF66	108 BEQ PS1	;=>yes	
CF64:46 32	109 LSR INVFLG	;no, make flag inverse	
CF66:AC 7B 05	110 PS1 LDY DURCH		
CF69:20 AD CC	111 JSR GETCUR2	;set all cursors	
CF6C:AD FB 05	112 LDA DURCV		
CF6F:85 25	113 STA CV		
CF71:	114 *		
CF71:	115 * Put BASCALC here so we don't have to switch		
CF71:	116 * in the ROMs for each character output.		
CF71:	117 *		
CF71:0A	118 PASCALC ASL A		

17 PASCAL

Video firmware Pascal stuff

31-MAY-85

PAGE 61

```
CF72:A8      119      TAY      ;calc base addr in BASL,H
CF73:4A      120      LSR A   ;for given line no.
CF74:4A      121      LSR A
CF75:29 03    122      AND #$03 ; 0<=line no.<=$17
CF77:09 04    123      ORA #$4  ; arg=000ABCDE, generate
CF79:85 29    124      STA BASH ; BASH=000001CD
CF7B:98      125      TYA      ;and
CF7C:6A      126      ROR A   ; BASL=EABAB000
CF7D:29 98    127      AND #$98
CF7F:85 28    128 PASCLC2 STA BASL
CF81:0A      129      ASL A
CF82:0A      130      ASL A
CF83:04 28    131      TSB BASL
CF85:60      132      RTS
CF86:          45       include moremisc ;More random junk
```

```

CF86:      2 ****
CF86:      3 *
CF86:      4 * Here are more miscellaneous routines
CF86:      5 * stuffed here in a valiant effort to make other code align
CF86:      6 * properly
CF86:      7 *
CF86:      8 ****

CF86:      10 * Various tables
CF86: 83 8B 8B 11 irqtbl   dfb    >lcbank2,>lcbank1,>lcbank1
CF89: 05 03 55 12          dfb    >wrccardram,>rdccardram,>txtpage2

CF8C: 9E 0B 40 50 14 comtbl   dfb    $9E,$0B,$40,$50,$16,$0B,$01,$00
CF94: CD C1 D8 D9 16 rtbl    asc    'MAXYPS'

CF9A:      18 ****
CF9A:      19 *
CF9A:      20 * MOVEIRQ - This routine transfers the roms interrupt vector into
CF9A:      21 * both language cards
CF9A:      22 *
CF9A:      23 ****
CF9A: CF9A 24 moveirq   equ    *
CF9A: 20 60 C3 25 JSR    SETROM      ;Read ROM and Write to RAM
CF9D: AD 16 C0 26 LDA    RDALTZP    ;Which language card?
CFA0: 0A 27 ASL    A           ;C=1 if alternate card
CFA1: A0 01 28 LDY    #1          ;Move two bytes
CFA3: B9 FE FF 29 MIRQLP   LDA    IRQVECT,Y   ;Get byte from ROM
CFA6: 8D 09 C0 30 STA    SETALTZP   ;Set alternate card
CFA9: 99 FE FF 31 STA    IRQVECT,Y   ;Store it in the RAM card
CFAC: 8D 08 C0 32 STA    SETSTDZP   ;Set main card
CFAF: 99 FE FF 33 STA    IRQVECT,Y
CFB2: 88 34 DEY
CFB3: 10 EE CFA3 35 BPL    MIRQLP   ;Go do the second byte
CFB5: 90 03 CFBA 36 BCC    MIRQSTD   ;Is the card set right?
CFB7: 8D 09 C0 37 STA    SETALTZP   ;No, it wasn't
CFBA: 4C 54 C3 38 MIRQSTD  JMP    RESETLC   ;Clean up & go home

CFBD:      40 ****
CFBD:      41 * CLRKB2 - Moved here from scrolling routines
CFBD:      42 ****
CFBD: CFBD 43 clrkb2   equ    *
CFBD: 5A 44 phy
CFBE: 20 B3 C3 45 jsr    story     ;Now preserves Y
CFC1: 7A 46 ply
CFC2: 4C D5 C8 47 jmp    xrdkbd

CFCS:      49 ****
CFCS:      50 *
CFCS:      51 * LOOKASC - addition to monitor input routine

```

```
CFC5:      52 * if a quote (') in input, the ascii of the next is input
CFC5:      53 * like a hex number
CFC5:      54 *
CFC5:      55 ****
CFC5:      CFC5 56 lookasc equ   *
CFC5:B0 11  CFD8 57 bcs   ladig      ;Was char a hex digit?
CFC7:C9 A0  58 cmp    #$A0       ;Is it a quote
CFC9:D0 13  CFDE 59 bne   ladone     ;Done if not
CFCB:B9 00  02 60 lda   inbuf,y   ;Get next char
CFCE:A2 07  61 ldx   #7        ;for shifting asc into A2L and A2H
CFD0:C9 8D  62 cmp    #$8D       ;Was it a cr?
CFD2:F0 07  CFDB 63 beq   lacr      ;Go handle cr
CFD4:C8  64 iny   rts      ;Advance index into inbuf
CFD5:4C 90  FF  65 jmp   nxtbit    ;Go shift it in
CFD8:4C 8A  FF  66 ladig   jmp   dig
CFDB:4C A7  FF  67 lacr    jmp   getnum
CFDE:60  68 ladone   rts
CFDF:      0021 46 ds    $D000-* ,0
--- NEXT OBJECT FILE NAME IS /BUILD/FIRM.1
F800:      F800  47 ORG   F80RG
F800:      48 INCLUDE AUTOST1 ;F8 monitor rom
```

19 AUTOST1

Apple //c F8 monitor firmware

31-MAY-85

PAGE 64

```

F800:4A      3 PLOT    LSR   A          ;Y-COORD/2
F801:08      4 PHP     JSR   GBASCALC  ;SAVE LSB IN CARRY
F802:20 47 F8  5          PLP   ;CALC BASE ADR IN GBASL,H
F805:28      6          LDA   #$0F      ;RESTORE LSB FROM CARRY
F806:A9 0F    7          ADC   #$E0      ;MASK $0F IF EVEN
F808:90 02  F80C  8          BCC   RTMASK
F80A:69 E0    9          ADC   #$E0      ;MASK $F0 IF ODD
F80C:85 2E    10         RTMASK  STA   MASK
F80E:B1 26    11         PLT1   LDA   (GBASL),Y ;DATA
F810:45 30    12         EOR   COLOR    ; XOR COLOR
F812:25 2E    13         AND   MASK     ; AND MASK
F814:51 26    14         EOR   (GBASL),Y ; XOR DATA
F816:91 26    15         STA   (GBASL),Y ; TO DATA
F818:60      16         RTS
F819:        17         *
F819:20 00 F8  18 HLINE   JSR   PLOT    ;PLOT SQUARE
F81C:C4 2C    19 HLINE1  CPY   H2      ;DONE?
F81E:B0 11  F831  20         BCS   RTS1    ; YES, RETURN
F826:C8      21         INY
F821:20 0E F8  22         JSR   PLOT1   ;NO, INCR INDEX (X-COORD)
F824:90 F6  F81C  23         BCC   HLINE1  ;PLOT NEXT SQUARE
F826:69 01    24 VLINEZ  ADC   #$01      ;ALWAYS TAKEN
F828:48      25 VLINE   PHA
F829:20 00 F8  26         JSR   PLOT    ; SAVE ON STACK
F82C:68      27         PLA
F82D:C5 2D    28         CMP   V2      ;PLOT SQUARE
F82F:90 F5  F826  29         BCC   VLINEZ  ;DONE?
F831:60      30         RTS1   RTS    ; NO, LOOP.
F832:        31         *
F832:A0 2F    32 CLRSQR  LDY   #$2F      ;MAX Y, FULL SCRN CLR
F834:D0 02  F838  33         BNE   CLRSC2  ;ALWAYS TAKEN
F836:A0 27    34 CLRTOP  LDY   #$27      ;MAX Y, TOP SCRN CLR
F838:84 2D    35 CLRSC2  STY   V2      ;STORE AS BOTTOM COORD
F83A:        36         ;
F83A:A0 27    37         LDY   #$27      ;RIGHTMOST X-COORD (COLUMN)
F83C:A9 00    38 CLRSC3  LDA   #$00      ;TOP COORD FOR VLINE CALLS
F83E:85 30    39         STA   COLOR    ;CLEAR COLOR (BLACK)
F840:20 28 F8  40         JSR   VLINE   ;DRAW VLINE
F843:88      41         DEY
F844:10 F6  F83C  42         BPL   CLRSC3  ;NEXT LEFTMOST X-COORD
F846:60      43         RTS    ;LOOP UNTIL DONE.
F847:        44         *
F847:48      45 GBASCALC PHA
F848:4A      46 LSR   A          ;FOR INPUT 00DEFGH
F849:29 03    47 AND   #$03
F84B:09 04    48 ORA   #$04      ;GENERATE GBASH=000001FG
F84D:85 27    49 STA   GBASH
F84F:68      50 PLA
F850:29 18    51 AND   #$18      ;AND GBASL=HDEDE000
F852:90 02  F856  52 BCC   GBCALC
F854:69 7F    53 ADC   #$7F
F856:85 26    54 GBCALC STA   GBASL
F858:0A      55 ASL   A
F859:0A      56 ASL   A
F85A:05 26    57 ORA   GBASL
F85C:85 26    58 STA   GBASL
F85E:60      59 RTS
F85F:        60         *

```

19 AUTOST1	Apple //c F8 monitor firmware	31-MAY-85	PAGE 65
F85F:A5 30	61 NXTCOL LDA COLOR	;INCREMENT COLOR BY 3	
F861:18	62 CLC		
F862:69 03	63 ADC #\$03		
F864:29 0F	64 SETCOL AND #\$0F	;SETS COLOR=17*A MOD 16	
F866:85 30	65 STA COLOR		
F868:0A	66 ASL A	;BOTH HALF BYTES OF COLOR EQUAL	
F869:0A	67 ASL A		
F86A:0A	68 ASL A		
F86B:0A	69 ASL A		
F86C:05 30	70 ORA COLOR		
F86E:85 30	71 STA COLOR		
F870:60	72 RTS		
F871:	73 *		
F871:4A	74 SCRN LSR A	;READ SCREEN Y-COORD/2	
F872:08	75 PHP	;SAVE LSB (CARRY)	
F873:20 47 F8	76 JSR GBASCALC	;CALC BASE ADDRESS	
F876:B1 26	77 LDA (GBASL),Y	;GET BYTE	
F878:28	78 PLP	;RESTORE LSB FROM CARRY	
F879:90 04 F87F	79 SCRN2 BCC RTMSKZ	;IF EVEN, USE LO H	
F87B:4A	80 LSR A		
F87C:4A	81 LSR A		
F87D:4A	82 LSR A	;SHIFT HIGH HALF BYTE DOWN	
F87E:4A	83 LSR A		
F87F:29 0F	84 RTMSKZ AND #\$0F	;MASK 4-BITS	
F881:60	85 RTS		
F882:	86 *		
F882:A6 3A	87 INSDS1 LDX PCL	;PRINT PCL,H	
F884:A4 3B	88 LDY PCH		
F886:20 96 FD	89 JSR PRYX2		
F889:20 48 F9	90 JSR PRBLNK	;FOLLOWED BY A BLANK	
F88C:A1 3A	91 LDA (PCL,X)	;GET OPCODE	
F88E:A8	92 INSDS2 TAY	;Label moved down 1	
F88F:4A	93 LSR A	;EVEN/ODD TEST	
F890:90 05 F897	94 BCC IEVEN		
F892:6A	95 ROR A	;BIT 1 TEST	
F893:B0 0C F8A1	96 BCS ERR	;XXXXXX11 INVALID OP	
F895:29 87	97 AND #\$87	;MASK BITS	
F897:4A	98 IEVEN LSR A	;LSB INTO CARRY FOR L/R TEST	
F898:AA	99 TAX		
F899:BD 62 F9	100 LDA FMT1,X	;GET FORMAT INDEX BYTE	
F89C:20 79 F8	101 JSR SCRN2	;R/L H-BYTE ON CARRY	
F89F:D0 04 F8A5	102 BNE GETFMT		
F8A1:A0 FC	103 ERR LDY #\$FC	;SUBSTITUTE \$FC FOR INVALID OPS	
F8A3:A9 00	104 LDA #\$00	;SET PRINT FORMAT INDEX TO 0	
F8A5:AA	105 GETFMT TAX		
F8A6:BD A6 F9	106 LDA FMT2,X	;INDEX INTO PRINT FORMAT TABLE	
F8A9:85 2E	107 STA FORMAT	;SAVE FOR ADR FIELD FORMATTING	
F8AB:29 03	108 AND #\$03	;MASK FOR 2-BIT LENGTH	
F8AD:	109 ; (0=1 BYTE, 1=2 BYTE, 2=3 BYTE)		
F8AD:85 2F	110 STA LENGTH		
F8AF:20 35 FC	111 JSR NEWOPS	;get index for new opcodes	
F8B2:F0 18 F8CC	112 BEQ GOTONE	;found a new op (or no op)	
F8B4:29 8F	113 AND #\$8F	;MASK FOR 1XXX1010 TEST	
F8B6:AA	114 TAX	; SAVE IT	
F8B7:98	115 TYA	;OPCODE TO A AGAIN	
F8B8:A0 03	116 LDY #\$03		
F8BA:E0 8A	117 CPX #\$8A		
F8BC:F0 0B F8C9	118 BEQ MNNDX3		

19 AUTOST1

Apple //c F8 monitor firmware

31-MAY-85

PAGE 66

```

F8BE:4A      119 MNNDX1    LSR   A
F8BF:08 08    F8C9 120 BCC   MNNDX3    ;FORM INDEX INTO MNEMONIC TABLE
F8C1:4A      121 LSR   A
F8C2:4A      122 MNNDX2    LSR   A
F8C3:09 20    123 ORA   #$20    ; 1) XXXX1010 => 00101XXX
F8C5:88      124 DEY   MNNDX2    ; 2) XXXYYY01 => 00111XXX
F8C6:D0 FA    F8C2 125 BNE   MNNDX2    ; 3) XXXYYY10 => 00110XXX
F8C8:08      126 INY   MNNDX3    ; 4) XXXYY100 => 00100XXX
F8C9:88      127 MNNDX3    DEY
F8CA:D0 F2    F8BE 128 BNE   MNNDX1
F8CC:60      129 GOTONE   RTS
F8CD:
F8CD:FF FF FF 130 *
F8D0:          131 DFB   $FFF,$FFF,$FF
F8D0:20 82 F8 132 *
F8D3:48      133 INSTDSP   JSR   INSDS1    ;GEN FMT, LEN BYTES
F8D4:B1 3A    134 PHA
F8D6:20 DA FD 135 PRNTOP   LDA   (PCL),Y
F8D9:A2 01    136 JSR   PRBYTE
F8DB:20 4A F9 137 LDX   #$01    ;PRINT 2 BLANKS
F8DE:C4 2F    138 PRNTBL   JSR   PRBL2
F8E0:C8      139 CPY   LENGTH   ;PRINT INST (1-3 BYTES)
F8E1:90 F1    F8D4 140 INY
F8E3:A2 03    141 BCC   PRNTOP
F8E5:C0 04    142 LDX   #$03    ;CHAR COUNT FOR MNEMONIC INDEX
F8E7:90 F2    F8DB 143 CPY   #$04
F8E9:68      144 BCC   PRNTBL
F8EA:A8      145 PLA
F8EB:B9 C0 F9 146 TAY    ;RECOVER MNEMONIC INDEX
F8EE:85 2C    147 LDA   MNEML,Y
F8F0:B9 00 FA 148 STA   LMNEM    ;FETCH 3-CHAR MNEMONIC
F8F3:85 2D    149 LDA   MNEMR,Y
F8F5:A9 00    150 STA   RMNEM    ;(PACKED INTO 2-BYTES)
F8F7:A0 05    151 PRMN1   LDA   #$00
F8F9:06 2D    152 LDY   #$05    ;SHIFT 5 BITS OF CHARACTER INTO A
F8FB:26 2C    153 PRMN2   ASL   RMNEM
F8FD:2A      154 ROL   LMNEM
F8FE:88      155 ROL   A        ; (CLEAR CARRY)
F8FF:D0 F8    F8F9 156 DEY
F901:69 BF    157 BNE   PRMN2
F903:20 ED FD 158 ADC   #$BF    ;ADD "?" OFFSET
F906:CA      159 JSR   COUT    ;OUTPUT A CHAR OF MNEM
F907:D0 EC    F8F5 160 DEX
F909:20 48 F9 161 BNE   PRMN1
F90C:A4 2F    162 JSR   PRBLNK   ;OUTPUT 3 BLANKS
F90E:A2 06    163 LDY   LENGTH
F910:E0 03    164 LDX   #$06    ;CNT FOR 6 FORMAT BITS
F912:F0 1C    F930 165 PRADR1   CPX   #$03
F914:06 2E    166 BEQ   PRADRS
F916:90 0E    F926 167 PRADR2   ASL   FORMAT
F918:BD B9 F9 168 BCC   PRADR3
F91B:20 ED FD 169 LDA   CHAR1-1,X
F91E:BD B3 F9 170 JSR   COUT
F921:F0 03    F926 171 LDA   CHAR2-1,X
F923:20 ED FD 172 BEQ   PRADR3
F926:CA      173 JSR   COUT
F927:D0 E7    F910 174 PRADR3   DEX
F929:60      175 BNE   PRADR1
F929:60      176 RTS

```

```

F92A:          177 *
F92A:88        178 PRADR4    DEY
F92B:30 E7    F914 179 BMI     PRADR2
F92D:20 DA FD 180 JSR     PRBYTE
F930:A5 2E      181 PRADRS  LDA     FORMAT
F932:C9 E8      182 CMP     #$E8   ;HANDLE REL ADR MODE
F934:B1 3A      183 LDA     (PCL),Y ;SPECIAL (PRINT TARGET,
F936:90 F2    F92A 184 BCC     PRADR4 ; NOT OFFSET)
F938:20 56 F9      185 RELADR JSR     PCADJ3
F93B:AA          186 TAX
F93C:E8          187 INX
F93D:D0 01    F940 188 BNE     PRNTYX ;+1 TO Y,X
F93F:C8          189 INY
F940:98          190 PRNTYX TYA
F941:20 DA FD 191 PRNTAX JSR     PRBYTE ;OUTPUT TARGET ADR
F944:8A          192 PRNTX  TXA     ; OF BRANCH AND RETURN
F945:4C DA FD 193 JMP     PRBYTE
F948:          194 *
F948:A2 03      195 PRBLNK LDX     #$03   ;BLANK COUNT
F94A:A9 A0      196 PRBL2  LDA     #$A0   ;LOAD A SPACE
F94C:20 ED FD 197 PRBL3  JSR     COUT   ;OUTPUT A BLANK
F94F:CA          198 DEX
F950:D0 F8    F94A 199 BNE     PRBL2 ;LOOP UNTIL COUNT=0
F952:60          200 RTS
F953:          201 *
F953:38          202 PCADJ  SEC
F954:A5 2F      203 PCADJ2 LDA     LENGTH ;0=1 BYTE, 1=2 BYTE,
F956:A4 3B      204 PCADJ3 LDY     PCH   ; 2=3 BYTE
F958:AA          205 TAX
F959:10 01    F95C 206 BPL     PCADJ4 ;TEST DISPLACEMENT SIGN
F95B:88          207 DEY
F95C:65 3A      208 PCADJ4 ADC     PCL   ;FOR REL BRANCH
F95E:90 01    F961 209 BCC     RTS2   ;EXTEND NEG BY DECR PCH
F960:C8          210 INY
F961:60          211 RTS2  RTS    ;PCL+LENGTH(OR DISPL)+1 TO A
F962:          212 *           ; CARRY INTO Y (PCH)
F962:          213 ; FMT1 BYTES: XXXXXXXY0 INSTRS
F962:          214 ; IF Y=0 THEN RIGHT HALF BYTE
F962:          215 ; IF Y=1 THEN LEFT HALF BYTE
F962:          216 ; (X=INDEX)
F962:          217 *
F962:0F          218 FMT1  DFB     $0F
F963:22          219 DFB     $22
F964:FF          220 DFB     $FF
F965:33          221 DFB     $33
F966:CB          222 DFB     $CB
F967:62          223 DFB     $62
F968:FF          224 DFB     $FF
F969:73          225 DFB     $73
F96A:03          226 DFB     $03
F96B:22          227 DFB     $22
F96C:FF          228 DFB     $FF
F96D:33          229 DFB     $33
F96E:CB          230 DFB     $CB
F96F:66          231 DFB     $66
F970:FF          232 DFB     $FF
F971:77          233 DFB     $77
F972:0F          234 DFB     $0F

```

```

F973:20      235      DFB   $20
F974:FF      236      DFB   $FF
F975:33      237      DFB   $33
F976:CB      238      DFB   $CB
F977:60      239      DFB   $60
F978:FF      240      DFB   $FF
F979:70      241      DFB   $70
F97A:0F      242      DFB   $0F
F97B:22      243      DFB   $22
F97C:FF      244      DFB   $FF
F97D:39      245      DFB   $39
F97E:CB      246      DFB   $CB
F97F:66      247      DFB   $66
F980:FF      248      DFB   $FF
F981:7D      249      DFB   $7D
F982:0B      250      DFB   $0B
F983:22      251      DFB   $22
F984:FF      252      DFB   $FF
F985:33      253      DFB   $33
F986:CB      254      DFB   $CB
F987:A6      255      DFB   $A6
F988:FF      256      DFB   $FF
F989:73      257      DFB   $73
F98A:11      258      DFB   $11
F98B:22      259      DFB   $22
F98C:FF      260      DFB   $FF
F98D:33      261      DFB   $33
F98E:CB      262      DFB   $CB
F98F:A6      263      DFB   $A6
F990:FF      264      DFB   $FF
F991:87      265      DFB   $87
F992:01      266      DFB   $01
F993:22      267      DFB   $22
F994:FF      268      DFB   $FF
F995:33      269      DFB   $33
F996:CB      270      DFB   $CB
F997:60      271      DFB   $60
F998:FF      272      DFB   $FF
F999:70      273      DFB   $70
F99A:01      274      DFB   $01
F99B:22      275      DFB   $22
F99C:FF      276      DFB   $FF
F99D:33      277      DFB   $33
F99E:CB      278      DFB   $CB
F99F:60      279      DFB   $60
F9A0:FF      280      DFB   $FF
F9A1:70      281      DFB   $70
F9A2:24      282      DFB   $24
F9A3:31      283      DFB   $31
F9A4:65      284      DFB   $65
F9A5:78      285      DFB   $78
F9A6:          286 ; ZZXXXX01 INSTR'S
F9A6:00      287 FMT2   DFB   $00      ;ERR
F9A7:21      288      DFB   $21      ;IMM
F9A8:81      289      DFB   $81      ;Z-PAGE
F9A9:82      290      DFB   $82      ;ABS
F9AA:59      291      DFB   $59      ;(ZPAG,X)
F9AB:4D      292      DFB   $4D      ;(ZPAG),Y

```

F9AC:91	293	DFB	\$91	;ZPAG,X
F9AD:92	294	DFB	\$92	;ABS,X
F9AE:86	295	DFB	\$86	;ABS,Y
F9AF:4A	296	DFB	\$4A	;CABS)
F9B0:85	297	DFB	\$85	;ZPAG,Y
F9B1:9D	298	DFB	\$9D	;RELATIVE
F9B2:49	299	DFB	\$49	;CZPAG) (new)
F9B3:5A	300	DFB	\$5A	;CABS,X) (new)
F9B4:	301 *			
F9B4:D9	302 CHAR2	DFB	\$D9	;`Y'
F9B5:00	303	DFB	\$00	;Cbyte F of FMT2)
F9B6:D8	304	DFB	\$D8	;`Y'
F9B7:A4	305	DFB	\$A4	;`\$'
F9B8:A4	306	DFB	\$A4	;`\$'
F9B9:00	307	DFB	\$00	
F9BA:	308 *			
F9BA:AC	309 CHAR1	DFB	\$AC	;`,'
F9BB:A9	310	DFB	\$A9	;`)'
F9BC:AC	311	DFB	\$AC	;`,'
F9BD:A3	312	DFB	\$A3	;`#'
F9BE:A8	313	DFB	\$A8	;`('
F9BF:A4	314	DFB	\$A4	;`\$'
F9C0:1C	315 MNEML	DFB	\$1C	
F9C1:8A	316	DFB	\$8A	
F9C2:1C	317	DFB	\$1C	
F9C3:23	318	DFB	\$23	
F9C4:5D	319	DFB	\$5D	
F9C5:8B	320	DFB	\$8B	
F9C6:1B	321	DFB	\$1B	
F9C7:A1	322	DFB	\$A1	
F9C8:9D	323	DFB	\$9D	
F9C9:8A	324	DFB	\$8A	
F9CA:1D	325	DFB	\$1D	
F9CB:23	326	DFB	\$23	
F9CC:9D	327	DFB	\$9D	
F9CD:8B	328	DFB	\$8B	
F9CE:1D	329	DFB	\$1D	
F9CF:A1	330	DFB	\$A1	
F9D0:1C	331	DFB	\$1C	;BRA
F9D1:29	332	DFB	\$29	
F9D2:19	333	DFB	\$19	
F9D3:AE	334	DFB	\$AE	
F9D4:69	335	DFB	\$69	
F9D5:A8	336	DFB	\$A8	
F9D6:19	337	DFB	\$19	
F9D7:23	338	DFB	\$23	
F9D8:24	339	DFB	\$24	
F9D9:53	340	DFB	\$53	
F9DA:1B	341	DFB	\$1B	
F9DB:23	342	DFB	\$23	
F9DC:24	343	DFB	\$24	
F9DD:53	344	DFB	\$53	
F9DE:19	345	DFB	\$19	
F9DF:A1	346	DFB	\$A1	; (A) FORMAT ABOVE
F9E0:AD	347	DFB	\$AD	; TSB
F9E1:1A	348	DFB	\$1A	
F9E2:5B	349	DFB	\$5B	
F9E3:5B	350	DFB	\$5B	

F9E4:A5	351	DFB	\$A5
F9E5:69	352	DFB	\$69
F9E6:24	353	DFB	\$24
F9E7:24	354	DFB	\$24
F9E8:AE	355	DFB	\$AE
F9E9:AE	356	DFB	\$AE
F9EA:A8	357	DFB	\$A8
F9EB:AD	358	DFB	\$AD
F9EC:29	359	DFB	\$29
F9ED:8A	360	DFB	\$8A
F9EE:7C	361	DFB	\$7C
F9EF:8B	362	DFB	\$8B
F9F0:15	363	DFB	\$15
F9F1:9C	364	DFB	\$9C
F9F2:6D	365	DFB	\$6D
F9F3:9C	366	DFB	\$9C
F9F4:A5	367	DFB	\$A5
F9F5:69	368	DFB	\$69
F9F6:29	369	DFB	\$29
F9F7:53	370	DFB	\$53
F9F8:84	371	DFB	\$84
F9F9:13	372	DFB	\$13
F9FA:34	373	DFB	\$34
F9FB:11	374	DFB	\$11
F9FC:A5	375	DFB	\$A5
F9FD:69	376	DFB	\$69
F9FE:23	377	DFB	\$23
F9FF:A0	378	DFB	\$A0
FA00:	379 *		
FA00:D8	380 MNEMR	DFB	\$D8
FA01:62	381	DFB	\$62
FA02:5A	382	DFB	\$5A
FA03:48	383	DFB	\$48
FA04:26	384	DFB	\$26
FA05:62	385	DFB	\$62
FA06:94	386	DFB	\$94
FA07:88	387	DFB	\$88
FA08:54	388	DFB	\$54
FA09:44	389	DFB	\$44
FA0A:C8	390	DFB	\$C8
FA0B:54	391	DFB	\$54
FA0C:68	392	DFB	\$68
FA0D:44	393	DFB	\$44
FA0E:E8	394	DFB	\$E8
FA0F:94	395	DFB	\$94
FA10:C4	396	DFB	\$C4
FA11:B4	397	DFB	\$B4
FA12:08	398	DFB	\$08
FA13:84	399	DFB	\$84
FA14:74	400	DFB	\$74
FA15:B4	401	DFB	\$B4
FA16:28	402	DFB	\$28
FA17:6E	403	DFB	\$6E
FA18:74	404	DFB	\$74
FA19:F4	405	DFB	\$F4
FA1A:CC	406	DFB	\$CC
FA1B:4A	407	DFB	\$4A
FA1C:72	408	DFB	\$72

```

FA1D:F2      409      DFB  $F2
FA1E:A4      410      DFB  $A4
FA1F:8A      411      DFB  $8A      ; (A) FORMAT
FA20:06      412      DFB  $06      ; TSB
FA21:AA      413      DFB  $AA
FA22:A2      414      DFB  $A2
FA23:A2      415      DFB  $A2
FA24:74      416      DFB  $74
FA25:74      417      DFB  $74
FA26:74      418      DFB  $74
FA27:72      419      DFB  $72      ; (B) FORMAT
FA28:44      420      DFB  $44
FA29:68      421      DFB  $68
FA2A:B2      422      DFB  $B2
FA2B:32      423      DFB  $32
FA2C:B2      424      DFB  $B2
FA2D:72      425      DFB  $72
FA2E:22      426      DFB  $22
FA2F:72      427      DFB  $72      ; (C) FORMAT
FA30:1A      428      DFB  $1A
FA31:1A      429      DFB  $1A
FA32:26      430      DFB  $26
FA33:26      431      DFB  $26
FA34:72      432      DFB  $72
FA35:72      433      DFB  $72
FA36:88      434      DFB  $88
FA37:C8      435      DFB  $C8      ; (D) FORMAT
FA38:C4      436      DFB  $C4
FA39:CA      437      DFB  $CA
FA3A:26      438      DFB  $26
FA3B:48      439      DFB  $48
FA3C:44      440      DFB  $44
FA3D:44      441      DFB  $44
FA3E:A2      442      DFB  $A2
FA3F:C8      443      DFB  $C8      ; (E) FORMAT
FA40:
444 *
FA40:85 45   445 IRQ    STA  $45      ;+ Trash $45 for those who want it
FA42:A5 45   446 LDA  $45      ;+
FA44:4C 03 C8 447 JMP  NEWIRQ    ;+
FA47:
448 *
FA47:
449 *
FA47:        450 * NEWBRK is called by the interrupt handler which has
FA47:        451 * set the hardware to its default state and encoded
FA47:        452 * the state in the accumulator. Software that wants
FA47:        453 * to do break processing using full system resources
FA47:        454 * can restore the machine state from this value.
FA47:
455 *
FA47:85 44   456 NEWBRK    STA  MACSTAT    ;save state of machine
FA49:7A      457 PLY       PLA  MACSTAT    ;restore registers for save
FA4A:FA      458 PLX       PLA  MACSTAT
FA4B:68      459 PLA       PLA  MACSTAT
FA4C:
460 *
FA4C:28      461 BREAK    PLP       ;Note: same as old BREAK routine!!
FA4D:20 4A FF 462 JSR  SAVE     ;save reg's on BRK
FA50:68      463 PLA       PLA  MACSTAT
FA51:85 3A   464 STA  PCL      ;including PC
FA53:68      465 PLA       PLA  MACSTAT
FA54:85 3B   466 STA  PCH

```

```

FA56:6C F0 03      467      JMP   (BRKV)      ;call BRK HANDLER
FA59:               468 *                               ;PRINT USER PC
FA59:20 82 F8      469 OLDBRK    JSR   INSDS1      ; AND REGS
FA50:20 DA FA      470           JSR   RGDSP1      ;GO TO MONITOR (NO PASS GO, NO $200!)
FA5F:4C 65 FF      471           JMP   MON
FA62:               472 *                               ;DO THIS FIRST THIS TIME
FA63:20 84 FE      473 RESET    CLD
FA66:20 2F FB      474           JSR   SETNORM
FA66:20 4D CE      475           JSR   INIT
FA69:20 1A C4      476           JSR   ZZQUIT
FA6C:20 04 CC      477           JSR   INITMOUSE
FA6F:20 04 C0      478           JSR   CLRPORT
FA72:9C FF 04      479           STZ   ACIABUF
FA75:AD 5F C0      480           LDA   SETAN3
FA78:20 BD FA      481           JSR   RESET.X
FA7B:2C 10 C0      482           BIT   KBDSTRB
FA7E:80 05 FA85      483           BRA   BEEP SKIP
FA80:EA             484           NOP
FA81:D8             485 NEWMON    CLD
FA82:20 3A FF      486           JSR   BELL
FA85:AD F3 03      487 BEEP SKIP LDA SOFTEV+1
FA88:49 A5             EDR #$A5
FA8A:CD F4 03      488           CMP   PWREDUP
FA8D:D0 17 FAA6      489           BNE   PWRUP
FA8F:AD F2 03      490           LDA   SOFTEV
FA92:D0 0F FAA3      491           BNE   NOFIX
FA94:A9 E0             492           LDA   #$E0
FA96:CD F3 03      493           CMP   SOFTEV+1
FA99:D0 08 FAA3      494           BNE   NOFIX
FA9B:A0 03             495           LDY   #3
FA9D:BC F2 03      496 FIXSEV   STY   SOFTEV
FAA0:4C 00 E0      497           JMP   BASIC
FAA3:               498           *     ; AND DO THE COLD START
FAA3:6C F2 03      499 *                               ; YES SO REENTER SYSTEM
FAA6:               500 NOFIX    JMP   (SOFTEV)
FAA6:               501 *                               ; NO SO POINT AT WARM START
FAA6:20 CA FC      502 PWRUP    JSR   COLDSTART
FAA9:               503 SETPG3    EQU   *
FAA9:A2 05             504           LDX   #5
FAAB:BD FC FA      505 SETPLP    LDA   PWRCON-1,X
FAAE:9D EF 03      506           STA   BRKV-1,X
FAB1:CA             507           DEX
FAB2:D0 F7 FAA8      508           BNE   SETPLP
FAB4:A9 C6             509           LDA   #$C6
FAB6:80 5A FB12      510           BRA   PWRUP2
FAB8:               511 *                               ;branch around mnemonics
FAB8:               512 * Extension to MNEML (left mnemonics)
FAB8:               513 *                               ; SET PAGE 3 VECTORS
FABB:8A             514 DFB   $8A      ;PHY
FABB:8B             515 DFB   $8B      ;PLY
FABA:A5             516 DFB   $A5      ;STZ
FABB:AC             517 DFB   $AC      ;TRB
FABC:00             518 DFB   $00      ;???
FABD:               519 *                               ;???
FABD:               520 * This extension to the monitor reset routine ($FA62)
FABD:               521 * checks for apple keys. If both are pressed, it goes
FABD:               522 * into an exerciser mode. If the open apple key only is
FABD:               523 * pressed, memory is selectively trashed and a cold start
FABD:               524 * is done.

```

```

FABD:      525 *
FABD:A9 FF 526 RESET.X   LDA  #$FF
FABF:8D FB 04 527 STA  VMODE    ;initialize mode
FAC2:20 3A FF 528 JSR  BELL     ;+ Need bell delay for 3.5" drive
FAC5:20 F8 C5 529 JSR  PCNVRST  ;+ Reset protocol converter
FAC8:0E 62 C0 530 ASL  BUTN1
FACB:2C 61 C0 531 BIT  BUTN0
FACE:10 5E FB2E 532 BPL  RTS2D
FAD0:90 D4 FAA6 533 BCC  PWRUP   ;open apple only, reboot
FAD2:4C C1 C7 534 JMP  BANGER   ;both apples, exercise 'er
FAD5:EA      535 NOP
FAD6:EA      536 NOP
FAD7:20 8E FD 537 REGDSP  JSR  CROUT  ;DISPLAY USER REG CONTENTS
FADA:A9 44 538 RGDSP1  LDA  #$44  ;WITH LABELS
FADC:85 40 539 STA  A3L      ;Memory state now printed
FADE:A9 00 540 LDA  #$00
FAE0:85 41 541 STA  A3H
FAE2:A2 FA 542 LDX  #$FA
FAE4:A9 A0 543 RDSP1  LDA  #$A0
FAE6:20 ED FD 544 JSR  COUT
FAE9:BD 9A CE 545 LDA  RTBL-$FA,X
FAEC:20 ED FD 546 JSR  COUT
FAEF:A9 BD 547 LDA  #$BD
FAF1:20 ED FD 548 JSR  COUT
FAF4:B5 4A 549 LDA  ACC+5,X
FAF6:80 0A FB02 550 BRA  RGDSP2  ;make room for mnemonics
FAF8:      551 *
FAF8:      552 * Right half of new mnemonics, indexed from MNEMR
FAF8:      553 *
FAF8:74 554 DFB  $74      ;PHY
FAF9:74 555 DFB  $74      ;PLY
FAFA:76 556 DFB  $76      ;STZ
FAFB:C6 557 DFB  $C6      ;TRB
FAFC:00 558 DFB  $00      ;???
FAFD:      559 *
FAFD:59 FA 560 PWRCON DW  OLDBRK
FAFF:00 E0 45 561 DFB  $00,$E0,$45
FB02:      562 *
FB02:20 DA FD 563 RGDSP2  JSR  PRBYTE
FB05:E8 564 INX
FB06:30 DC FAE4 565 BMI  RDSP1
FB08:60 566 RTS
FB09:      567 *
FB09:C1 F0 F0 EC 568 TITLE  ASC  'Apple  ]['
FB11:C4 569 DFB  $C4      ;optional filler
FB12:      570 *
FB12:86 00 571 PWRUP2 STX  LOC0    ; SETPG3 MUST RETURN X=0
FB14:85 01 572 STA  LOC1    ; SET PTR H
FB16:20 60 FB 573 JSR  APPLEII  ;Display our banner...
FB19:6C 00 00 574 JMP  (LOC0)  ;JUMP $C600
FB1C:00 575 BRK
FB1D:00 576 BRK
FB1E:      577 *
FB1E:4C 00 C9 578 PREAD  JMP  MPADDLE ;read mouse paddle
FB21:A0 00 579 LDY  #$00  ;INIT COUNT
FB23:EA 580 NOP
FB24:EA 581 NOP  ;COMPENSATE FOR 1ST COUNT
FB25:BD 64 C0 582 PREAD2 LDA  PADDL0,X  ;COUNT Y-REG EVERY 12 USEC.

```

19 AUTOST1 Apple //c F8 monitor firmware 31-MAY-85 PAGE 74

```
FB28:10 04 FB2E 583      BPL      RTS2D
FB2A:C8      584      INY
FB2B:D0 F8 FB25 585      BNE      PREAD2      ;EXIT AT 255 MAX
FB2D:88      586      DEY
FB2E:60      587 RTS2D      RTS
FB2F:      49      INCLUDE AUTOST2
```

```

FB2F:          2 *
FB2F:A9 00    3 INIT      LDA   #$00      ;CLR STATUS FOR DEBUG SOFTWARE
FB31:85 48    4 STA   STATUS
FB33:AD 56 C0  5 LDA   LORES
FB36:AD 54 C0  6 LDA   TXTPAGE1 ;INIT VIDEO MODE
FB39:AD 51 C0  7 SETTXT   LDA   TXTSET  ;SET FOR TEXT MODE
FB3C:A9 00    8 LDA   #$00      ;FULL SCREEN WINDOW
FB3E:F0 0B    FB4B  9 BEQ   SETWND
FB40:AD 50 C0 10 SETGR   LDA   TXTCLR ;SET FOR GRAPHICS MODE
FB43:AD 53 C0 11 LDA   MIXSET  ;LOWER 4 LINES AS TEXT WINDOW
FB46:20 36 F8 12 JSR   CLRTOP
FB49:A9 14    13 LDA   #$14
FB4B:85 22    14 SETWND   STA   WNDTOP ;SET WINDOW
FB4D:EA       15 NOP
FB4E:EA       16 NOP
FB4F:20 0A CE 17 JSR   WNDREST ;40/80 column width
FB52:80 05    FB59  18 BRA   VTAB23
FB54:          19 *
FB54:09 80    20 DOCTL    ORA   #$80      ;controls need high bit
FB56:4C 54 CD 21 JMP   CTLCHAR0 ;execute control char
FB59:          22 *
FB59:A9 17    23 VTAB23   LDA   #$17      ;VTAB TO ROW 23
FB5B:85 25    24 TABV     STA   CV        ;VTABS TO ROW IN A-REG
FB5D:4C 22 FC 25 JMP   VTAB    ;don't set DURCV!!
FB60:          26 *
FB60:20 58 FC 27 APPLEII  JSR   HOME     ;CLEAR THE SCRN
FB63:A0 09    28 LDY   #9
FB65:B9 BA C5 29 STITLE   LDA   APPLE2C-1,Y ;GET A CHAR
FB68:99 0D 04 30 STA   LINE1+13,Y ;PUT IT AT TOP CENTER OF SCREEN
FB6B:88    31 DEY
FB6C:D0 F7    FB65  32 BNE   STITLE
FB6E:60    33 RTS
FB6F:          34 *
FB6F:AD F3 03 35 SETPWRC  LDA   SOFTEV+1 ;ROUTINE TO CALCULATE THE 'FUNNY
FB72:49 A5    36 EOR   #$AS      ;COMPLEMENT' FOR THE RESET VECTOR
FB74:8D F4 03 37 STA   PWREDUP
FB77:60    38 RTS
FB78:          39 *
FB78:          FB78  40 VIDWAIT EQU   *      ;CHECK FOR A PAUSE (CONTROL-S).
FB78:C9 8D    41 CMP   #$8D      ;ONLY WHEN I HAVE A CR
FB7A:D0 18    FB94  42 BNE   NOWAIT  ;NOT SO, DO REGULAR
FB7C:AC 00 C0  43 LDY   KBD    ;IS KEY PRESSED?
FB7F:10 13    FB94  44 BPL   NOWAIT  ;NO.
FB81:C0 93    45 CPY   #$93      ;YES — IS IT CTRL-S?
FB83:D0 0F    FB94  46 BNE   NOWAIT  ;NOPE - IGNORE
FB85:2C 10 C0  47 BIT   KBDSTRB ;CLEAR STROBE
FB88:AC 00 C0  48 KBDWAIT LDY   KBD    ;WAIT TILL NEXT KEY TO RESUME
FB8B:10 FB    FB88  49 BPL   KBDWAIT ;WAIT FOR KEYPRESS
FB8D:C0 83    50 CPY   #$83      ;IS IT CONTROL-C?
FB8F:F0 03    FB94  51 BEQ   NOWAIT  ;YES, SO LEAVE IT
FB91:2C 10 C0  52 BIT   KBDSTRB ;CLR STROBE
FB94:2C 7B 06  53 NOWAIT BIT   VFACTV ;is video firmware active?
FB97:30 64    FBFD  54 BMI   VIDOUT ;=>no, do normal 40 column
FB99:89 60    55 BIT   #$60      ;is it a control?
FB9B:F0 B7    FB54  56 BEQ   DOCTL  ;=>yes, do it
FB9D:20 B8 C3  57 JSR   STORCH ;print w/inverse mask
FB9E:EE 7B 05  58 NEWADV INC   DURCH ;advance cursor
FB93:AD 7B 05  59 LDA   DURCH ;and update others

```

20 AUTOST2	Apple //c F8 monitor firmware	31-MAY-85	PAGE 76
FBA6:2C 1F C0	60	BIT RD80VID	;but only if not 80 columns
FBA9:30 05 FBB0	61	BMI NEWADV1	;=>80 columns, leav'em
FBA8:8D 7B 04	62	STA OLDCH	
FBAE:85 24	63	STA CH	
FBB0:80 46 FBF8	64	NEWADV1 BRA ADV2	;check for CR
FBB2:	65 *		
FBB2:EA	66	NOP	
FBB3:	67 *		
FBB3:06	68	F8VERSION DFB GOODF8	;//e, chels ID byte
FBB4:	69 *		
FBB4:10 06 FBBC	70	DOCOUT1 BPL DCX	;=>video firmware active, no mask
FBB6:C9 A0	71	CMP #\$A0	;is it control char?
FBB8:90 02 FBBC	72	BCC DCX	;=>yes, no mask
FBB8:25 32	73	AND INVFLG	;else apply inverse mask
FBBC:4C F6 FD	74	DCX JMP COUTZ	;and print character
FBBF:00	75	BRK	
FBC0:	76 *		
FBC0:00	77	DFB \$00	;chels ID byte
FBC1:	78 *		
FBC1:48	79	BASCALC PHA	;CALC BASE ADDR IN BASL,H
FBC2:4A	80	LSR A	;FOR GIVEN LINE NO.
FBC3:29 03	81	AND #\$03	;0<=LINE NO.<=\$17
FBC5:09 04	82	ORA #\$04	;ARG=000ABCDE, GENERATE
FBC7:85 29	83	STA BASH	;BASH=000001CD
FBC9:68	84	PLA	; AND
FBCA:29 18	85	AND #\$18	; BASL=EABAB000
FBCB:90 02 FBD0	86	BCC BASCLC2	
FBCE:69 7F	87	ADC #\$7F	
FBD0:85 28	88	BASCLC2 STA BASL	
FBD2:0A	89	ASL A	
FBD3:0A	90	ASL A	
FBD4:05 28	91	ORA BASL	
FBD6:85 28	92	STA BASL	
FBD8:60	93	RTS	
FBD9:	94 *		
FBD9:C9 87	95	CHKBELL CMP #\$87	;BELL CHAR? (CONTROL-G)
FBDB:D0 12 FBEF	96	BNE RTS2B	;NO, RETURN.
FBDD:A9 40	97	BELL1 LDA #\$40	;YES...
FBDF:20 A8 FC	98	JSR WAIT	;DELAY .01 SECONDS
FBE2:A0 C0	99	LDY #\$C0	
FBE4:A9 0C	100	BELL2 LDA #\$0C	;TOGGLE SPEAKER AT 1 KHZ
FBE6:20 A8 FC	101	JSR WAIT	;FOR .1 SEC.
FBE9:AD 30 C0	102	LDA SPKR	
FBECA:88	103	DEY	
FBED:D0 F5 FBE4	104	BNE BELL2	
FBEF:60	105	RTS2B RTS	
FBF0:	106 *		
FBF0:A4 24	107	STORADV LDY CH	;get 40 column position
FBF2:91 28	108	STA (BASL),Y	;and store
FBF4:E6 24	109	ADVANCE INC CH	;increment cursor
FBF6:A5 24	110	LDA CH	
FBF8:C5 21	111	ADV2 CMP WNDWDTH	;BEYOND WINDOW WIDTH?
FBFA:B0 66 FC62	112	BCS CR	;YES, CR TO NEXT LINE.
FBFC:60	113	RTS3 RTS	;NO, RETURN.
Fbfd:	114 *		
Fbfd:C9 A0	115	VIDOUT CMP #\$A0	;CONTROL CHAR?
FBFF:B0 EF FBF0	116	BCS STORADV	;NO, OUTPUT IT.
FC01:A8	117	TAY	;INVERSE VIDEO?

```

FC02:10 EC    FBF0   118      BPL    STORADV ; YES, OUTPUT IT.
FC04:C9 8D    FC73   119      VIDOUT1  CMP    #$8D ;CR?
FC06:F0 6B    FC73   120      BEQ    NEWCR  ;Yes, use new routine
FC08:C9 8A    FC66   121      CMP    #$8A ;LINE FEED?
FC0A:F0 5A    FC66   122      BEQ    LF     ; IF SO, DO IT.
FC0C:C9 88    FC66   123      CMP    #$88 ;BACK SPACE? (CONTROL-H)
FC0E:D0 C9    FBD9   124      BNE    CHKBELL ; NO, CHECK FOR BELL.
FC10:20 E2 FE  FC86   125 BS   JSR    DECCH  ;decrement all cursor H indices
FC13:10 E7 FBFC  126      BPL    RTS3   ;IF POSITIVE, OK; ELSE MOVE UP.
FC15:A5 21    FC86   127      LDA    WNDWDTH ;get window width,
FC17:20 EB FE  FC86   128      JSR    WDTCHC ;and set CH's to WNDWDTH-1
FC1A:A5 22    FC86   129 UP   LDA    WNDTOP ;CURSOR V INDEX
FC1C:C5 25    FC86   130      CMP    CV    ;
FC1E:B0 DC    FBFC   131      BCS    RTS3   ;top line, exit
FC20:C6 25    FC86   132      DEC    CV    ;not top, go up one
FC22:
FC22:80 62    FC86   133 *   RTS4   RTS   ;
FC24:20 C1 FB  FC86   134 VTAB  BRA   NEWVTAB ;go update DURCV
FC27:A5 20    FC86   135 VTABZ JSR   BASCALC ;calculate the base address
FC29:2C 1F C0  FC86   136 LDA   WNDLFT ;get the left window edge
FC2C:10 02    FC30   137 BIT   RD80VID ;80 columns?
FC2E:4A      138      BPL   VTAB40 ;=>no, left edge ok
FC2F:18      139      LSR   A    ;divide width by 2
FC30:65 28    FC86   140      CLC   CLC   ;prepare to add
FC32:85 28    FC86   141 VTAB40 ADC   BASL  ;add width to base
FC34:60      142      STA   BASL  ;
FC35:
FC35: 143      RTS4   RTS   ;
FC35: 144 *
FC35: 145 * NEWOPS translates the opcode in the Y register
FC35: 146 * to a mnemonic table index and returns with Z=1.
FC35: 147 * If Y is not a new opcode, Z=0.
FC35: 148 *
FC35: 149 NEWOPS  TYA   ;get the opcode
FC36:A2 16    150      LDX   #NUMOPS ;check through new opcodes
FC38:DD FE FE  151 NEWOP1 CMP   OPTBL,X ;does it match?
FC3B:F0 43    FC80   152      BEQ   GETINDX ;=>yes, get new index
FC3D:CA      153      DEX   ;
FC3E:10 F8    FC38   154      BPL   NEWOP1 ;else check next one
FC40:60      155      RTS   ;not found, exit with BNE
FC41:
FC41: 156 *
FC42:
FC42: 157      BRK   ;
FC42: 158 *
FC42:80 19    FC5D   159 CLREOP  BRA   CLREOP1 ;ESC F IS CLR TO END OF PAGE
FC44:A5 25    160 CLREOP2 LDA   CV   ;
FC46:48      161 CLLEOP1 PHA   ;
FC47:20 24 FC  162 JSR   VTABZ ;SAVE CURRENT LINE NO. ON STACK
FC4A:20 9E FC  163 JSR   CLEOLZ ;CALC BASE ADDRESS
FC4D:A0 00    164 LDY   #$00 ;CLEAR TO EOL. (SETS CARRY)
FC4F:68      165 PLA   ;
FC50:1A      166 INC   A    ;CLEAR FROM H INDEX=0 FOR REST
FC51:C5 23    167 CMP   WNDBTM ;INCREMENT CURRENT LINE NO.
FC53:90 F1    FC46   168 BCC   CLEOP1 ;DONE TO BOTTOM OF WINDOW?
FC55:B0 CB    FC22   169 BCS   VTAB  ; NO, KEEP CLEARING LINES.
FC57:00      170      BRK   ;
FC58: 171 *
FC58:20 A5 CD  172 HOME  JSR   HOMECUR ;YES, TAB TO CURRENT LINE
FC5B:80 E7    FC44   173 BRA   CLREOP2 ;move cursor home
FC5D: 174 *
FC5D:20 9D CC  175 CLREOP1 JSR   GETCUR ;then clear to end of page
FC5D: 176      JSR   GETCUR ;load Y with proper CH

```

20 AUTOST2		Apple //c F8 monitor firmware		31-MAY-85	PAGE 78
FC60:80 E2	FC44	176 BRA CLREOP2		;before clearing page	
FC62:		177 * LDA CV			
FC62:80 0F	FC73	178 CR BRA NEWCR		;only LF if not Pascal	
FC64:00		179 BRK			
FC65:00		180 BRK			
FC66:		181 * INC CV		;INCR CURSOR V. (DOWN 1 LINE)	
FC66:E6 25		182 LF INC CV			
FC68:A5 25		183 LDA CV		;OFF SCREEN?	
FC6A:C5 23		184 CMP WNDBTM			
FC6C:90 1A	FC88	185 BCC NEWVTABZ		;set base+WNDLFT	
FC6E:C6 25		186 DEC CV		;DECR CURSOR V. (BACK TO BOTTOM)	
FC70:		187 * BRA LF			
FC70:4C 35 CB		188 SCROLL JMP SCROLLUP		;scroll the screen	
FC73:		189 * INC CV			
FC73:20 E9 FE		190 NEWCR JSR CLRCH		;set CH's to 0	
FC76:2C FB 04		191 BIT VMODE		;is it Pascal?	
FC79:10 0A	FC85	192 BPL CRRTS		;pascal, no LF	
FC7B:20 44 FD		193 JSR NOESCAPE		;else clear escape mode	
FC7E:80 EG	FC66	194 BRA LF		;then do LF	
FC80:		195 * INC CV			
FC80:BD 15 FF		196 GETINDX LDA INDX,X		;lookup index for mnemonic	
FC83:A0 00		197 LDY #0		;exit with BEQ	
FC85:60		198 CRRTS RTS			
FC86:		199 * INC CV			
FC86:A5 25		200 NEWVTAB LDA CV		;update //e CV	
FC88:8D FB 05		201 NEWVTABZ STA DURCV			
FC8B:80 97	FC24	202 BRA VTABZ		;and calc base+WNDLFT	
FC8D:		203 * INC CV			
FC8D:20 9D CC		204 NEWCLREOL JSR GETCUR		;get current cursor	
FC90:A9 A0		205 NEWCLEOLZ LDA #\$A0		;get a blank	
FC92:2C 7B 06		206 BIT VFACTV		;if video firmware active,	
FC95:30 02	FC99	207 BMI NEWC1		;=>don't use inverse mask	
FC97:25 32		208 AND INVFLG			
FC99:4C C2 CB		209 NEWC1 JMP DOCLR		;go do clear	
FC9C:		210 * INC CV			
FC9C:80 EF	FC8D	211 CLREOL BRA NEWCLREOL		;get cursor and clear	
FC9E:80 F0	FC90	212 CLEOLZ BRA NEWCLEOLZ		;clear from Y	
FCA0:		213 * INC CV			
FCA0:A0 00		214 CLRLIN LDY #0		;clear entire line	
FCA2:80 EC	FC90	215 BRA NEWCLEOLZ			
FCA4:		216 * INC CV			
FCA4:7C 2A CD		217 CTLDO JMP (CTLADR,X)		;jump to proper routine	
FCA7:		218 * INC CV			
FCA7:EA		219 NOP			
FCA8:		220 * INC CV			
FCA8:38		221 WAIT SEC			
FCA9:48		222 WAIT2 PHA			
FCAA:E9 01		223 WAIT3 SBC #\$01			
FCAC:D0 FC	FCAA	224 BNE WAIT3		;1.0204 USEC	
FCAE:68		225 PLA		;(13+2712*A+512*A*A)	
FCAF:E9 01		226 SBC #\$01			
FCB1:D0 F6	FCA9	227 BNE WAIT2			
FCB3:60		228 RTS6 RTS			
FCB4:		229 * INC CV			
FCB4:E6 42		230 NXTA4 INC A4L		;INCR 2-BYTE A4	
FCB6:D0 02	FCBA	231 BNE NXTA1		; AND A1	
FCB8:E6 43		232 INC A4H			
FCBA:A5 3C		233 NXTA1 LDA A1L		;INCR 2-BYTE A1.	

20 AUTOST2	Apple //c F8 monitor firmware	31-MAY-85	PAGE 79
FCBC:C5 3E	234	CMP A2L	; AND COMPARE TO A2
FCBE:A5 3D	235	LDA A1H	; (CARRY SET IF >=)
FCC0:E5 3F	236	SBC A2H	
FCC2:E6 3C	237	INC A1L	
FCC4:D0 02	238	BNE RTS4B	
FCC6:E6 3D	239	INC A1H	
FCC8:60	240	RTS4B RTS	
FCC9:	241 *		
FCCA:	242	HEADR RTS	;don't do it
FCCA:A0 B0	243 *		
FCCC:64 3C	244	COLDSTART LDY #\$B0	;let it precess down
FCCE:A2 BF	245	STZ A1L	
FCD0:86 3D	246	LDX #\$BF	;start from BFXX down
FCD2:A9 A0	247	BLAST STX A1H	
FCD4:91 3C	248	LDA #\$A0	;store blanks
FCD6:88	249	STA (A1L),Y	
FCD7:91 3C	250	DEY	
FCD9:CA	251	STA (A1L),Y	
FCDA:E0 01	252	DEX	;back down to next page
FCDC:D0 F2	253	CPX #1	;stay away from stack
FCD0	254	BNE BLAST	;fall into COMINIT
FCDE:	255 *		
FCDE:8D 01 C0	256	STA SET80COL	;init ALT screen holes
FCE1:AD 55 C0	257	LDA TXTPAGE2	;for serial and comm ports
FCE4:A2 88	258	LDX #\$88	;C = 1 from CPX #1
FCE6:BD 8B CF	259	COM1 LDA COMTBL-1,X	;XFER from rom
FCE9:90 0A FCF5	260	BCC COM2	;branch if defaults ok
FCEB:DD 77 04	261	CMP \$477,X	;test for prior setup
FCEE:18	262	CLC	;branch if not valid
FCEF:D0 04 FCF5	263	BNE COM2	;if \$4F8 & \$4FF = TBL values
FCF1:E0 82	264	CPX #\$82	
FCF3:90 06 FCFB	265	BCC COM3	
FCF5:9D 77 04	266	COM2 STA \$477,X	
FCF8:CA	267	DEX	;move all 8...
FCF9:D0 EB FCE6	268	BNE COM1	
FCFB:AD 54 C0	269	COM3 LDA TXTPAGE1	;restore switches
FCFE:8D 00 C0	270	STA CLR80COL	;to default states
FD01:60	271	RTS	
FD02:EA	272	NOP	;*
FD03:EA	273	NOP	
FD04:EA	274	NOP	
FD05:EA	275	NOP	
FD06:EA	276	NOP	
FD07:EA	277	NOP	
FD08:EA	278	NOP	
FD09:EA	279	NOP	
FD0A:EA	280	NOP	
FD0B:EA	281	NOP	
FD0C:	282 *		
FD0C:A4 24	283	RDKEY LDY CH	;get char at current position
FD0E:B1 28	284	LDA (BASL),Y	;for those who restore it
FD10:EA	285	NOP	;if a program controls input
FD11:EA	286	NOP	;hooks, no cursor may be displayed
FD12:EA	287	NOP	
FD13:EA	288	NOP	
FD14:EA	289	NOP	
FD15:EA	290	NOP	
FD16:EA	291	NOP	

```

FD17:EA      292      NOP
FD18:          293 *    NOP
FD18:6C 38 00 294 KEYIN0  JMP  (KSWL)   ;GO TO USER KEY-IN
FD1B:          295 *    NOP
FD1B:91 28    296 KEYIN   STA  (BASL),Y ;erase false images
FD1D:20 4C CC 297 JSR  SHOWCUR ;display true cursor
FD20:20 70 CC 298 DONXTCUR JSR  UPDATE ;look for key, blink II cursor
FD23:10 FB FD20 299 BPL  DONXTCUR ;loop until keypress
FD25:48      300 GOTKEY  PHA
FD26:A9 08    301 LDA  #M.CTL ;save character
FD28:20 FB 04 302 BIT  VMODE ;were escapes enabled?
FD2B:D0 1D FD4A 303 BNE  NOESC2 ;=>no, there is no escape
FD2D:68      304 PLA
FD2E:C9 9B    305 CMP  #ESC ;yes, there may be a way out!!
FD30:D0 06 FD38 306 BNE  LOOKPICK ;escape?
FD32:4C CC CC 307 JMP  NEWESC ;=>no escape
FD35:          308 *    NOP
FD35:4C ED CC 309 RDCHAR  JMP  ESCRDKEY ;do RDKEY with escapes
FD38:          310 *    NOP
FD38:2C 7B 06 311 LOOKPICK BIT  VFACTV ;only process f.arrow
FD3B:30 07 FD44 312 BMI  NOESCAPE ;if video firmware is active
FD3D:C9 95    313 CMP  #PICK ;was it PICK? (-,CTL-U)
FD3F:D0 03 FD44 314 BNE  NOESCAPE ;no, just return
FD41:20 1D CC 315 JSR  PICKY ;yes, pick the character
FD44:          316 *    NOP
FD44:          317 * NOESCAPE is used by GETCOUT too.
FD44:          318 *    NOP
FD44:48      319 NOESCAPE PHA ;save it
FD45:A9 08    320 NOESC1  LDA  #M.CTL ;disable escape sequences
FD47:0C FB 04 321 TSB  VMODE ;and enable controls
FD4A:68      322 NOESC2  PLA ;by setting M.CTL
FD4B:60      323 RTS
FD4C:          324 *    NOP
FD4C:EA      325 NOP
FD4D:          326 *    NOP
FD4D:20 A6 C3 327 NOTCR  JSR  GETCOUT ;disable controls and print
FD50:C9 88    328 CMP  #$88 ;CHECK FOR EDIT KEYS
FD52:F0 1D FD71 329 BEQ  BCKSPC ; - BACKSPACE
FD54:C9 98    330 CMP  #$98
FD56:F0 0A FD62 331 BEQ  CANCEL ; - CONTROL-X
FD58:E0 F8    332 CPX  #$F8
FD5A:90 03 FD5F 333 BCC  NOTCR1 ;MARGIN?
FD5C:20 3A FF 334 JSR  BELL ; YES, SOUND BELL
FD5F:E8      335 NOTCR1 INX ;ADVANCE INPUT INDEX
FD60:D0 13 FD75 336 BNE  NXTCHAR
FD62:A9 DC    337 CANCEL LDA  #$DC ;BACKSLASH AFTER CANCELLED LINE
FD64:20 A6 C3 338 JSR  GETCOUT
FD67:20 8E FD  339 GETLNZ JSR  CROUT ;OUTPUT 'CR'
FD6A:A5 33    340 GETLN  LDA  PROMPT ;OUTPUT PROMPT CHAR
FD6C:20 ED FD 341 JSR  COUT
FD6F:A2 01    342 GETLN1 LDX  #$01 ;INIT INPUT INDEX
FD71:8A      343 BCKSPC TXA
FD72:F0 F3 FD67 344 BEQ  GETLNZ ;WILL BACKSPACE TO 0
FD74:CA      345 DEX
FD75:20 ED CC 346 NXTCHAR JSR  ESCRDKEY ;do new RDCHAR (allow escapes)
FD78:C9 95    347 CMP  #PICK ;USE SCREEN CHAR
FD7A:D0 08 FD84 348 BNE  ADDINP ; FOR CONTROL-U
FD7C:20 1D CC 349 JSR  PICKY ;lift char from screen

```

```

FD7F:EA      350      NOP
FD80:EA      351      NOP
FD81:EA      352      NOP
FD82:EA      353      NOP
FD83:EA      354      NOP
FD84:D0 00 02 355 ADDINP  STA IN,X      ;ADD TO INPUT BUFFER
FD87:C9 8D    356 CMP #$8D
FD89:D0 C2 FD4D 357 BNE NOTCR
FD8B:20 9C FC 358 CROUT1 JSR CLREOL
FD8E:A9 8D    359 CROUT  LDA #$8D
FD90:D0 5B FDDE 360 BNE COUT
FD92:          361 *
FD92:A4 3D    362 PRA1   LDY A1H      ;PRINT CR,A1 IN HEX
FD94:A6 3C    363 LDX A1L
FD96:20 8E FD 364 PRYX2  JSR CROUT
FD99:20 40 F9 365 JSR PRNTYX
FD9C:A0 00    366 LDY #$00
FD9E:A9 AD    367 LDA #$AD      ;PRINT '-'
FD9F:4C ED FD 368 JMP COUT
FDA3:          369 *
FDA3:A5 3C    370 XAMB   LDA A1L
FDA5:09 07    371 ORA #$07      ;SET TO FINISH AT
FDA7:85 3E    372 STA A2L      ; MOD 8=7
FDA9:A5 3D    373 LDA A1H
FDAB:85 3F    374 STA A2H
FDAD:A5 3C    375 MOD8CHK LDA A1L
FDAF:29 07    376 AND #$07
FDB1:D0 03 FD6 377 BNE DATAOUT
FDB3:20 92 FD 378 XAM   JSR PRA1
FDB6:A9 A0    379 DATAOUT LDA #$A0
FDB8:20 ED FD 380 JSR COUT      ;OUTPUT BLANK
FDBB:B1 3C    381 LDA (A1L),Y
FDBD:20 DA FD 382 JSR PRBYTE
FDC0:20 BA FC 383 JSR NXTA1
FDC3:90 E8 FDAD 384 BCC MOD8CHK
FDC5:60      385 RTS4C  RTS
FDC6:          386 *
FDC6:4A      387 XAMPM  LSR A      ;DETERMINE IF MONITOR MODE IS
FDC7:90 EA FD3 388 BCC XAM      ; EXAMINE, ADD OR SUBTRACT
FDC9:4A      389 LSR A
FDCA:4A      390 LSR A
FDCB:A5 3E    391 LDA A2L
FDCD:90 02 FDD1 392 BCC ADD
FDCF:49 FF    393 EOR #$FF      ;FORM 2'S COMPLEMENT FOR SUBTRACT.
FDD1:65 3C    394 ADD  ADC A1L
FDD3:48      395 PHA
FDD4:A9 BD    396 LDA #$BD      ;PRINT '=', THEN RESULT
FDD6:20 ED FD 397 JSR COUT
FDD9:68      398 PLA
FDDA:          399 *
FDDA:48      400 PRBYTE PHA      ;PRINT BYTE AS 2 HEX DIGITS
FDBB:4A      401 LSR A      ; (DESTROYS A-REG)
FDDC:4A      402 LSR A
FDDD:4A      403 LSR A
FDDE:4A      404 LSR A
FDFD:20 E5 FD 405 JSR PRHEXZ
FDE2:68      406 PLA
FDE3:          407 *

```

20 AUTOST2	Apple //c F8 monitor firmware	31-MAY-85	PAGE 82
FDE3:29 0F	408 PRHEX AND #\$0F	;PRINT HEX DIGIT IN A-REG	
FDE5:09 B0	409 PRHEXXZ ORA #\$B0	;LSBITS ONLY.	
FDE7:C9 BA	410 CMP #\$BA		
FDE9:90 02 FDED	411 BCC COUT		
FDEB:69 06	412 ADC #\$06		
FDED:	413 *		
FDED:6C 36 00	414 COUT JMP (CSWL)	;VECTOR TO USER OUTPUT ROUTINE	
FDF0:	415 *		
FDF0:2C 7B 06	416 COUT1 BIT VFACTV	;video firmware active?	
FDF3:4C B4 FB	417 JMP DOCOUT1	;mask II mode characters	
FDF6:84 35	418 COUTZ STY YSAV1	;SAVE Y-REG	
FDF8:48	419 PHA	;SAVE A -REG	
FDF9:20 78 FB	420 JSR VIDWAIT	;OUTPUT CHR AND CHECK FOR CTRL-S	
FDFC:68	421 PLA	;RESTORE A-REG	
FDFD:A4 35	422 LDY YSAV1	;AND Y-REG	
FDFE:60	423 RTS	;RETURN TO SENDER...	
FE00:	424 *		
FE00:C6 34	425 BL1 DEC YSAV		
FE02:F0 9F FDA3	426 BEQ XAM8		
FE04:	427 *		
FE04:CA	428 BLANK DEX	;BLANK TO MON	
FE05:D0 16 FE1D	429 BNE SETMDZ	;AFTER BLANK	
FE07:C9 BA	430 CMP #\$BA	;DATA STORE MODE?	
FE09:D0 BB FDC6	431 BNE XAMPM	; NO; XAM, ADD, OR SUBTRACT.	
FE0B:	432 *		
FE0B:85 31	433 STOR STA MODE	;KEEP IN STORE MODE	
FE0D:A5 3E	434 LDA A2L		
FE0F:91 40	435 STA (A3L),Y	;STORE AS LOW BYTE AT (A3)	
FE11:E6 40	436 INC A3L		
FE13:D0 02 FE17	437 BNE RTSS	;INCR A3, RETURN.	
FE15:E6 41	438 INC A3H		
FE17:60	439 RTSS RTS		
FE18:	440 *		
FE18:A4 34	441 SETMODE LDY YSAV	;SAVE CONVERTED ':', '+',	
FE1A:B9 FF 01	442 LDA IN-1,Y	;'-', '.' AS MODE	
FE1D:85 31	443 SETMDZ STA MODE		
FE1F:60	444 RTS		
FE20:	445 *		
FE20:A2 01	446 LT LDX #\$01		
FE22:B5 3E	447 LT2 LDA A2L,X	;COPY A2 (2 BYTES) TO	
FE24:95 42	448 STA A4L,X	; A4 AND A5	
FE26:95 44	449 STA A5L,X		
FE28:CA	450 DEX		
FE29:10 F7 FE22	451 BPL LT2		
FE2B:60	452 RTS		
FE2C:	453 *		
FE2C:B1 3C	454 MOVE LDA (A1L),Y	;MOVE (A1) THRU (A2) TO (A4)	
FE2E:91 42	455 STA (A4L),Y		
FE30:20 B4 FC	456 JSR NXTA4		
FE33:90 F7 FE2C	457 BCC MOVE		
FE35:60	458 RTS		
FE36:	459 *		
FE36:B1 3C	460 VERIFY LDA (A1L),Y	;VERIFY (A1) THRU (A2)	
FE38:D1 42	461 CMP (A4L),Y	; WITH (A4)	
FE3A:F0 1C FE58	462 BEQ VFYOK		
FE3C:20 92 FD	463 JSR PRA1		
FE3F:B1 3C	464 LDA (A1L),Y		
FE41:20 DA FD	465 JSR PRBYTE		

```

FE44:A9 A0      466     LDA    #$A0
FE46:20 ED FD   467     JSR    COUT
FE49:A9 A8      468     LDA    #$A8
FE4B:20 ED FD   469     JSR    COUT
FE4E:B1 42      470     LDA    (A4L),Y
FE50:20 DA FD   471     JSR    PRBYTE
FE53:A9 A9      472     LDA    #$A9
FE55:20 ED FD   473     JSR    COUT
FE58:20 B4 FC   474     VFYOK JSR    NXTA4
FE5B:90 D9      FE36   475     BCC    VERIFY
FE5D:60          476     RTS
FE5E:             477 * 
FE5E:20 75 FE   478 LIST   JSR    A1PC      ;MOVE A1 (2 BYTES) TO
FE61:A9 14      479     LDA    #$14      ; PC IF SPEC'D AND
FE63:48          480 LIST2  PHA
FE64:20 C4 C5   481     JSR    SHOWINST ;+DISASSEMBLE 20 INSTRUCTIONS.
FE67:68          482     PLA
FE68:3A          483     DEC    A        ;+Display a line
FE69:D0 F8      FE63   484     BNE    LIST2   ;+Count down
FE6B:60          485     RTS
FE6C:             486 * 
FE6C:4C 86 C9   487 MINI   JMP    GETINST1 ;Go to the mini assembler
FE6F:C6 34      488 TRACE  DEC    YSAV      ;+Stay on T for trace
FE71:4C 43 CA   489 STEPZ  JMP    STEP      ;+Off to the step routine
FE74: 0001       490     ds     $FE75-*,$0 ;+Extra bytes
FE75:             491 * 
FE75:8A          492 A1PC   TXA
FE76:F0 07      FE7F   493     BEQ    A1PCRTS ;IF USER SPECIFIED AN ADDRESS,
FE78:B5 3C      494 A1PCLP LDA    A1L,X    ; COPY IT FROM A1 TO PC.
FE7A:95 3A      495     STA    PCL,X    ;YEP, SO COPY IT.
FE7C:CA          496     DEX
FE7D:10 F9      FE78   497     BPL    A1PCLP
FE7F:60          498 A1PCRTS RTS
FE80:             499 * 
FE80:A0 3F      500 SETINV LDY    #$3F      ;SET FOR INVERSE VID
FE82:D0 02      FE86   501     BNE    SETIFLG ; VIA COUT1
FE84:A0 FF      502 SETNORM LDY    #$FF      ;SET FOR NORMAL VID
FE86:84 32      503 SETIFLG STY    INVFLG
FE88:60          504     RTS
FE89:             505 * 
FE89:A9 00      506 SETKBD LDA    #$00      ;DO 'IN#0'
FE8B:85 3E      507 IMPORT STA    A2L      ;DO 'IN#AREG'
FE8D:A2 38      508 INPRT  LDX    #KSWL
FE8F:A0 1B      509     LDY    #KEYIN
FE91:D0 08      FE9B   510     BNE    IOPRT
FE93:             511 * 
FE93:A9 00      512 SETVID LDY    #$0      ;DO 'PR#0'
FE95:85 3E      513 OUTPORT STA    A2L      ;DO 'PR#AREG'
FE97:A2 36      514 OUTPRT LDX    #CSWL
FE99:A0 F0      515     LDY    #COUT1
FE9B:A5 3E      516 IOPRT LDA    A2L
FE9D:29 0F      517     AND    #$0F
FE9F:D0 06      FEA7   518     BNE    NOTPRT0 ;not slot 0
FEA1:C0 1B      519     CPY    #KEYIN ;Continue if KEYIN
FEA3:F0 39      FEDE   520     BEQ    IOPRT1
FEA5:80 1B      FEC2   521     BRA    OPRT0  ;=>do PR#0
FEA7:09 C0      522 NOTPRT0 DRA    #<IOADR
FEA9:A0 00      523     LDY    #$00

```

20 AUTOST2	Apple //c F8 monitor firmware	31-MAY-85	PAGE 84
FEAB:94 00	524 IOPRT2	STY LOC0,X	
FEAD:95 01	525	STA LOC1,X	
FEAF:60	526	RTS	
FEB0:	527 *		
FEB0:4C 00 E0	528 XBASIC	JMP BASIC	;TO BASIC, COLD START
FEB3:	529 *		
FEB3:4C 03 E0	530 BASCONT	JMP BASIC2	;TO BASIC, WARM START
FEB6:	531 *		
FEB6:20 75 FE	532 GO	JSR A1PC	;ADDR TO PC IF SPECIFIED
FEB9:20 3F FF	533	JSR RESTORE	;RESTORE FAKE REGISTERS
FEBC:6C 3A 00	534	JMP (PC1)	; AND GO!
FEBF:	535 *		
FEBF:4C D7 FA	536 REGZ	JMP REGDSP	;GO DISPLAY REGISTERS
FEC2:	537 *		
FEC2:3A	538 OPRT0	DEC A	;Need \$FF
FEC3:8D FB 07	539	STA CURSOR	;set checkerboard cursor
FEC6:A9 F7	540	LDA #\$FF-M.CTL	;reset mode
FEC8:80 04 FECE	541	BRA DOPR0	
FECA:	542 *		
FECA:4C F8 03	543 USR	JMP USRADR	;JUMP TO CONTROL-Y VECTOR IN RAM
FECD:	544 *		
FECD:60	545 WRITE	RTS	;Tape write not needed
FECE:	546 *		
FECE:8D 7B 06	547 DOPR0	STA VFACTV	;say video firmware inactive
FED1:8D 0E C0	548	STA CLRALTCHAR	;switch in normal char set
FED4:0C FB 04	549	TSB VMODE	;don't change M.CTL
FED7:DA	550	PHX	;save X and Y
FED8:5A	551	PHY	;for rest of PR#0
FED9:20 CD CD	552	JSR CHK80	;convert to 40 if needed
FEDC:7A	553	PLY	
FEDE:FA	554	PLX	
FEDE:A9 FD	555 IOPRT1	LDA #<COUT1	;set I/O page
FEE0:80 C9 FEAB	556	BRA IOPRT2	;=>go set output hook
FEE2:	557 *		
FEE2:	558 * DECCH decrements the current cursor		
FEE2:	559 * CLRCH sets all cursors to 0		
FEE2:	560 * SETCUR sets cursors to value in Acc.		
FEE2:	561 * See explanatory note with GETCUR		
FEE2:	562 *		
FEE2:5A	563 DECCH	PHY	;from \$FC10)
FEE3:20 9D CC	564	JSR GETCUR	;get current CH
FEE6:88	565	DEY	;decrement it
FEE7:80 05 FEEE	566	BRA SETCUR1	;go update cursors
FEE9:	567 *		
FEE9:A9 01	568 CLRCH	LDA #1	;set all cursors to 0
FEEB:3A	569 WDTHCH	DEC A	;dec window width (from \$FC17)
FEEC:5A	570 SETCUR	PHY	;save Y
FEED:A8	571 TAY		;need value in Y
FEEE:20 AD CC	572 SETCUR1	JSR GETCUR2	;save new CH
FEF1:7A	573 PLY		;restore Y
FEF2:AD 7B 05	574 LDA DURCH		;and get new CH into acc
FEFS:60	575 RTS		;Need LDA to set flags
FEF6:	576 *		
FEF6:20 00 FE	577 CRMON	JSR BL1	;HANDLE CR AS BLANK
FEF9:68	578 PLA		; THEN POP STACK
FEFA:68	579 PLA		; AND RETURN TO MON
FEFB:D0 6C FF69	580 BNE MONZ		; (ALWAYS)
FEFD:	581 *		

```

      582 READ      RTS          ;Tape read not needed
      583 *
      584 * OPTBL is a table containing the new opcodes that
      585 * wouldn't fit into the existing lookup table.
      586 *
      587 OPTBL    DFB  $12      ;ORA (ZPAG)
      588       DFB  $14      ;TRB ZPAG
      589       DFB  $1A      ;INC A
      590       DFB  $1C      ;TRB ABS
      591       DFB  $32      ;AND (ZPAG)
      592       DFB  $34      ;BIT ZPAG,X
      593       DFB  $3A      ;DEC A
      594       DFB  $3C      ;BIT ABS,X
      595       DFB  $52      ;EDR (ZPAG)
      596       DFB  $5A      ;PHY
      597       DFB  $64      ;STZ ZPAG
      598       DFB  $72      ;ADC (ZPAG)
      599       DFB  $74      ;STZ ZPAG,X
      600       DFB  $7A      ;PLY
      601       DFB  $7C      ;JMP (ABS,X)
      602       DFB  $89      ;BIT IMM
      603       DFB  $92      ;STA (ZPAG)
      604       DFB  $9C      ;STZ ABS
      605       DFB  $9E      ;STZ ABS,X
      606       DFB  $B2      ;LDA (ZPAG)
      607       DFB  $D2      ;CMP (ZPAG)
      608       DFB  $F2      ;SBC (ZPAG)
      609       DFB  $FC      ;??? (the unknown opcode)
      610 NUMOPS   EQU  *-OPTBL-1 ;number of bytes to check
      611 *
      612 * INDX contains pointers to the mnemonics for each of
      613 * the opcodes in OPTBL. Pointers with BIT 7
      614 * set indicate extensions to MNEM1 or MNEMR.
      615 *
      616 INDX    DFB  $38
      617       DFB  $FB
      618       DFB  $37
      619       DFB  $FB
      620       DFB  $39
      621       DFB  $21
      622       DFB  $36
      623       DFB  $21
      624       DFB  $3A
      625       DFB  $F8
      626       DFB  $FA
      627       DFB  $3B
      628       DFB  $FA
      629       DFB  $F9
      630       DFB  $22
      631       DFB  $21
      632       DFB  $3C
      633       DFB  $FA
      634       DFB  $FA
      635       DFB  $3D
      636       DFB  $3E
      637       DFB  $3F
      638       DFB  $FC      ;???
      639       BRK

```

```

FF2D:          640 *
FF2D:A9 C5    641 PRERR   LDA #C5      ;PRINT 'ERR', THEN FALL INTO
FF2F:20 ED FD 642 JSR COUT    ; FWEAPER.
FF32:A9 D2    643 LDA #$D2
FF34:20 ED FD 644 JSR COUT
FF37:20 ED FD 645 JSR COUT
FF3A:          646 *
FF3A:A9 87    647 BELL    LDA #$87      ;MAKE A JOYFUL NOISE, THEN RETURN.
FF3C:4C ED FD 648 JMP COUT
FF3F:          649 *
FF3F:A5 48    650 RESTORE LDA STATUS   ;RESTORE 6502 REGISTER CONTENTS
FF41:48        651 PHA
FF42:A5 45    652 LDA ASH      ; USED BY DEBUG SOFTWARE
FF44:A6 46    653 RESTR1  LDX XREG
FF46:A4 47    654 LDY YREG
FF48:28        655 PLP
FF49:60        656 RTS
FF4A:          657 *
FF4A:85 45    658 SAVE    STA ASH      ;SAVE 6502 REGISTER CONTENTS
FF4C:86 46    659 SAV1    STX XREG    ; FOR DEBUG SOFTWARE
FF4E:84 47    660 STY YREG
FF50:08        661 PHP
FF51:68        662 PLA
FF52:85 48    663 STA STATUS
FF54:BA        664 TSX
FF55:86 49    665 STX SPNT
FF57:D8        666 CLD
FF58:60        667 RTS
FF59:          668 *
FF59:20 84 FE 669 OLDRST  JSR SETNORM ;SET SCREEN MODE
FF5C:20 2F FB 670 JSR INIT    ; AND INIT KBD/SCREEN
FF5F:20 93 FE 671 JSR SETVID ; AS I/O DEVS.
FF62:20 69 FE 672 JSR SETKBD
FF65:          673 *
FF65:D8        674 MON    CLD      ;MUST SET HEX MODE!
FF66:20 3A FF  675 JSR BELL    ;FWEAPER.
FF69:A9 AA    676 MONZ   LDA #$AA  ;**' PROMPT FOR MONITOR
FF6B:85 33    677 STA PROMPT
FF6D:20 67 FD 678 JSR GETLNZ ;READ A LINE OF INPUT
FF70:20 C7 FF  679 JSR ZMODE ;CLEAR MONITOR MODE, SCAN IDX
FF73:20 A7 FF  680 NXTITM JSR GETNUM ;GET ITEM, NON-HEX
FF76:84 34    681 STY YSAV    ; CHAR IN A-REG.
FF78:A0 17    682 LDY #SUBTBL-CHRTBL ; X-REG=0 IF NO HEX INPUT
FF7A:88        683 CHRSRCH DEY
FF7B:30 E8 FF65 684 BMI MON    ;COMMAND NOT FOUND, BEEP & TRY AGAIN.
FF7D:D9 CC FF  685 CMP CHRTBL,Y ;FIND COMMAND CHAR IN TABLE
FF80:D0 F8 FF7A 686 BNE CHRSRCH ;NOT THIS TIME
FF82:20 BE FF  687 JSR TOSUB ;GOT IT! CALL CORRESPONDING SUBROUTINE
FF85:A4 34    688 LDY YSAV    ;PROCESS NEXT ENTRY ON HIS LINE
FF87:4C 73 FF  689 JMP NXTITM
FF8A:          690 *
FF8A:A2 03    691 DIG    LDX #$03
FF8C:0A        692 ASL    A
FF8D:0A        693 ASL    A      ;GOT HEX DIGIT,
FF8E:0A        694 ASL    A      ; SHIFT INTO A2
FF8F:0A        695 ASL    A
FF90:0A        696 NXTBIT ASL    A
FF91:26 3E    697 ROL    A2L

```

```

FF93:26 3F      698      ROL    A2H
FF95:CA          699      DEX
FF96:10 F8      FF90  700      BPL    NXTBIT      ;LEAVE X=$FF IF DIG
FF98:A5 31      701      NXTBAS
FF9A:D0 06      FFA2  702      LDA    MODE
FF9C:B5 3F      703      BNE    NXTBS2      ;IF MODE IS ZERO,
FF9E:95 3D      704      LDA    A2H,X      ; THEN COPY A2 TO A1 AND A3
FFA0:95 41      705      STA    A1H,X
FFA2:E8          706      STA    A3H,X
FFA3:F0 F3      FF98  707      INX
FFA5:D0 06      FFAD  708      BEQ    NXTBAS
FFA7:A2 00      709      GETNUM
FFA9:86 3E      710      LDX    #$00      ;CLEAR A2
FFAB:86 3F      711      STX    A2L
FFAD:20 B4 C5      712      NXTCHR
FFB0:49 B0      713      JSR    GETUP      ;Get char, iny, upshift
FFB2:C9 0A      714      EOR    #$B0
FFB4:90 D4      FF8A  715      CMP    #$0A
FFB6:69 88      716      BCC    DIG      ;it's a digit
FFB8:C9 FA      717      ADC    #$88
FFBA:4C C5 CF      718      CMP    #$FA
FFBD:00          719      JMP    LOOKASC      ;+ Check for quote
FFBE:             720      BRK
FFBE:A9 FE      721      TOSUB
FFC0:48          722      LDA    #<GO      ;DISPATCH TO SUBROUTINE, BY
FFC1:B9 E3 FF      723      PHA
FFC4:48          724      SUBTBL,Y      ; PUSHING THE HI-ORDER SUBR ADDR,
FFC5:A5 31      725      LDA    MODE      ; THEN THE LO-ORDER SUBR ADDR
FFC7:A0 00      726      ZMODE
FFC9:84 31      727      LDY    #$00      ; (CLEARING THE MODE, SAVE THE OLD
FFCB:60          728      STY    MODE      ; MODE IN A-REG),
FFCC:             729      RTS
FFCC:BC          730      CHRTBL
FFCD:B2          731      DFB    $BC      ;^C (BASIC WARM START)
FFCE:BE          732      DFB    $B2      ;^Y (USER VECTOR)
FFCF:9A          733      DFB    $BE      ;^E (OPEN AND DISPLAY REGISTERS)
FFD0:EF          734      DFB    $9A      ;+! (Mini assembler)
FFD1:C4          735      DFB    $C4      ;^V (MEMORY VERIFY)
FFD2:A9          736      DFB    $A9      ;^K (IN#SLOT)
FFD3:BB          737      DFB    $BB      ;^P (PR#SLOT)
FFD4:A6          738      DFB    $A6      ;^B (BASIC COLD START)
FFD5:A4          739      DFB    $A4      ;'-' (SUBTRACTION)
FFD6:06          740      DFB    $06      ;'+ (ADDITION)
FFD7:95          741      DFB    $95      ;'< (DELIMITER FOR MOVE, VFY)
FFD8:07          742      DFB    $07      ;'N (SET NORMAL VIDEO)
FFD9:02          743      DFB    $02      ;'I (SET INVERSE VIDEO)
FFDA:05          744      DFB    $05      ;'L (DISASSEMBLE 20 INSTRS)
FFDB:00          745      DFB    $00      ;'G (EXECUTE PROGRAM)
FFDC:93          746      DFB    $93      ;': (MEMORY FILL)
FFDD:A7          747      DFB    $A7      ;',' (ADDRESS DELIMITER)
FFDE:C6          748      DFB    $C6      ;'CR' (END OF INPUT)
FFDF:99          749      DFB    $99      ;BLANK
FFE0:EC          750      DFB    $EC      ;+S (Step)
FFE1:ED          751      DFB    $ED      ;+T (Trace)
FFE2:EA          752      NOP
FFE3:             753      *
FFE3:             754 * Table of low order monitor routine
FFE3:             755 * dispatch addresses.

```

FFE3:	756 *		
FFE3:B2	757 SUBTBL	DFB	>BASCONT-1
FFE4:C9	758	DFB	>USR-1
FFE5:BE	759	DFB	>REGZ-1
FFE6:6B	760	DFB	>MINI-1
FFE7:35	761	DFB	>VERIFY-1
FFE8:8C	762	DFB	>INPRT-1
FFE9:96	763	DFB	>OUTPRT-1
FFEA:AF	764	DFB	>XBASIC-1
FFEB:17	765	DFB	>SETMODE-1
FFEC:17	766	DFB	>SETMODE-1
FFED:2B	767	DFB	>MOVE-1
FFEE:1F	768	DFB	>LT-1
FFFF:83	769	DFB	>SETNORM-1
FFF0:7F	770	DFB	>SETINV-1
FFF1:5D	771	DFB	>LIST-1
FFF2:B5	772	DFB	>GO-1
FFF3:17	773	DFB	>SETMODE-1
FFF4:17	774	DFB	>SETMODE-1
FFF5:F5	775	DFB	>CRMON-1
FFF6:03	776	DFB	>BLANK-1
FFF7:70	777	DFB	>STEPZ-1
FFF8:6E	778	DFB	>TRACE-1
FFF9:	779 *		
FFF9: 0001	780	ds	\$FFFFA-* ,0
FFFA:	781 *		
FFFA:FB 03	782	DW	NMI
FFFC:62 FA	783	DW	RESET
FFFE:03 C8	784 IRQVECT	DW	NEWIRQ
0000:	50	include bank2	

21 BANK2 Apple //c F8 monitor firmware 31-MAY-85 PAGE 89

0000: 2 ****
0000: 3 *
0000: 4 * Bank 2 of the roms
0000: 5 *
0000: 6 ****
---- NEXT OBJECT FILE NAME IS /BUILD/FIRM.2
C000: C000 7 org \$C000
C000: 51 include mint ;Mouse & acia interrupt handler
C000: 0100 1 ds \$C100-* ,0

```

C100:
C100:      4 ****
C100:      5 *
C100:      6 * Mouse interrupt handler
C100:      7 *
C100:      8 * MOUSEINT - Monitor's interrupt handler
C100:      9 *
C100:     10 * Returns C = 0 if interrupt handled
C100:     11 * If not mouse interrupt, Goes to acaint
C100:     12 * New in this rom:
C100:     13 * If D7 of moumode = 1, mouse X and Y interrupts are not processed
C100:     14 * and are passed on to the user.
C100:     15 *
C100:     16 ****
C100: C100 17 mouseint equ * ;Entry point if X & Y set up
C100:A9 0E 18 lda #$0E ;Clear status bits
C102:1C 7C 07 19 trb mousstat

C105:38
C106:      21 sec ;Assume interrupt not handled
C106:      22 * Check for vertical blanking interrupt
C106:AD 19 C0 23 lda vblint ;VBL interrupt?
C109:10 2B C136 24 bpl chkmou
C10B:8D 79 C0 25 sta iouenbl ;Enable iou access & clear VBL interrupt
C10E:A9 0C 26 lda #vblmode ;Should we leave vbl active?
C110:2C FC 07 27 bit moumode
C113:D0 03 C118 28 bne cvnovb1
C115:8D 5A C0 29 sta iou+2 ;Disable VBL
C118:09 02 30 cvnovb1 ora #movmode
C11A:8D 78 C0 31 sta ioudsbl
C11D:2C 7C 06 32 bit mouarm ;VBL bit in arm isn't used
C120:D0 02 C124 33 bne cvmoved
C122:A9 0C 34 lda #vblmode ;Didn't move
C124:2C 63 C0 35 cvmoved bit moubut ;Button pressed?
C127:10 02 C12B 36 bpl cvbut
C129:49 04 37 eor #butmode ;Clear the button bit
C12B:2D FC 07 38 cvbut and moumode ;Which bits were set in the mode
C12E:0C 7C 07 39 tsb mousstat
C131:1C 7C 06 40 trb mouarm
C134:69 FE 41 adc #$FE ;C=1 if int passes to user
C136:      42 * Check & update mouse movement
C136: C136 43 chkmou equ *
C136:AD FC 07 44 lda moumode ;If D7 = 1, user better handle it
C139:30 72 C1AD 45 bmi xmdone
C13B:AD 15 C0 46 lda mouxint ;Mouse interrupt?
C13C:0D 17 C0 47 ora mouyint
C141:10 6A C1AD 48 bpl xmdone ;If not return with C from vbl
C143:8A 49 txa ;Get X1 in A
C144:A2 00 50 ldx #0
C146:2C 15 C0 51 bit mouxint ;X movement?
C149:30 0A C155 52 bmi cmxmov
C14B:98 53 cmloop tya ;Get Y1 into A
C14C:49 80 54 eor #$80 ;Complement direction
C14E:A2 80 55 ldx #$80
C150:2C 17 C0 56 bit mouyint
C153:10 39 C18E 57 bpl cmnoy
C155:0A 58 cmxmov asl A
C156:BD 7C 04 59 lda mouxl,x ;A = current low byte

```

22 MINT

Mouse & serial interrupt stuff

31-MAY-85

PAGE 91

```

C159:B0 1A C175    60      bcs   cmrght      ;Which way?
C15B:DD 7D 04      61      cmp   minxl,x    ;Move left
C15E:D0 08 C168    62      bne   cmlok
C160:BD 7C 05      63      lda   mouxh,x
C163:DD 7D 05      64      cmp   minxh,x
C166:F0 22 C18A    65      beq   cmnoint
C168:BD 7C 04      66      lda   mouxl,x
C16B:D0 03 C170    67      bne   cmni0      ;Borrow from high byte?
C16D:DE 7C 05      68      dec   mouxh,x
C170:DE 7C 04      69      dec   mouxl,x
C173:80 15 C18A    70      bra   cmnoint
C175:DD 7D 06      71      cmp   maxx1,x    ;At high bound?
C178:D0 08 C182    72      bne   cmrok
C17A:BD 7C 05      73      lda   mouxh,x
C17D:DD 7D 07      74      cmp   maxxh,x
C180:F0 08 C18A    75      beq   cmnoint
C182:FE 7C 04      76      inc   mouxl,x    ;Move right
C185:D0 03 C18A    77      bne   cmnoint
C187:FE 7C 05      78      inc   mouxh,x
C18A:E0 00          79      cpx   #0
C18C:F0 BD C14B    80      beq   cmloop
C18E:8D 48 C0      81      sta   mouclr
C191:A9 02          82      lda   #movmode   ;Should we enable VBL?
C193:2D FC 07      83      and   moumode
C196:F0 09 C1A1    84      beq   cmnovbl   ;Branch if not
C198:8D 79 C0      85      sta   iouenbl
C19B:8D 5B C0      86      sta   iou+3     ;Enable VBL int
C19E:8D 78 C0      87      sta   ioudsbl
C1A1:09 20          88      ora   #movarm   ;Mark that we moved
C1A3:0C 7C 06      89      tsb   mouarm
C1A6:A9 0E          90      lda   #$0E
C1A8:2D 7C 07      91      and   mousstat
C1AB:69 FE          92      adc   #$FE
C1AD:B0 05 C1B4    93      bcs   aciaint   ;C=1 iff any bits were 1
C1AF:4C 84 C7      94      jmp   swrts2   ;If not handled, try acia
                                         ;If not handled, try acia
                                         ;Back we go

```

```

C1B2:      96 * This routine will determine if the source of
C1B2:      97 * is either of the built in ACIAs. If neither port
C1B2:      98 * generated the interrupt, or the interrupt was due
C1B2:      99 * to a transmit buffer empty, protocol converter, or
C1B2:     100 * 'unbuffered' receiver full, the carry is set indi-
C1B2:     101 * cating an externally serviced interrupt.
C1B2:     102 * If the interrupt source was keyboard, 'buffered'
C1B2:     103 * serial input, or the DCD, the interrupt is serviced
C1B2:     104 * and the carry is cleared indicating interrupt was
C1B2:     105 * serviced. (DCD handshake replaces CTS.)
C1B2:     106 * Location "ACIABUF" specifies which (if either) re-
C1B2:     107 * ceiver data is buffered. For port 1 it must contain
C1B2:     108 * $C1, for port 2 a $C2. Any other values are cause
C1B2:     109 * interrupts to pass to external (RAM based) routines.
C1B2:     110 * Location "TYPHED" specifies whether Keyboard in-
C1B2:     111 * put should be buffered, ignored, or processed by
C1B2:     112 * RAM based routines. If bit 7=1 and bit 6=0, key-
C1B2:     113 * board data is placed in the type-ahead buffer. If
C1B2:     114 * bit 6 is set the interrupt is cleared, but must
C1B2:     115 * be recognized and serviced by a RAM routine. If
C1B2:     116 * both bits = 0, the interrupt is serviced, but the
C1B2:     117 * keyboard data is ignored.
C1B2:     118 * While using type-ahead, Open-Apple CTRL-X will
C1B2:     119 * flush the buffer. No other code is recognized.
C1B2:     120 * if the source was an ACIA that has the transmit
C1B2:     121 * interrupt enabled, the original value of the ACIAs
C1B2:     122 * status registers is preserved. Automatic serial input
C1B2:     123 * buffering is not serviced from a port so configured.
C1B2:     124 * Interrupts originating from the protocol converter or
C1B2:     125 * keyboard (RAM serviced) do not inhibit serial buffering
C1B2:     126 * and are passed thru. The RAM service routine can rec-
C1B2:     127 *ognize the interrupt source by a 1 state in bit 6 of
C1B2:     128 * the ACIAs status register. The RAM service routine must
C1B2:     129 * cause the clearing of DSR (bit 6) AND make a second ac-
C1B2:     130 * cess to the status register before returning.
C1B2:
C1B2:     131 *
C1B2:     132 *
C1B2: 133 notacia sec ;Not acia int
C1B3:60
C1B4:      C1B4 134 acdone rts
C1B4:20 BA C1 135 aciaint equ *
C1B7:4C 84 C7 136 jsr aciaint2 ;Extra jsr since rest needs RTS
C1BA:      C1BA 137 jmp swrts2
C1BA: 138 aciaint2 equ *
C1BA:A2 C2 139 ldx #<comslot ;Test port 2 first
C1BC:20 C2 C1 140 jsr aciatst ;Check for interrupt
C1BF:90 F2 C1B3 141 bcc acdone ;Return if interrupt done
C1C1:CA 142 dex ;Try port 1
C1C2:BC 42 C1 143 aciatst ldy devno2,x ;Get index for acia
C1C5:A9 04 144 lda #$4 ;If xmit ints enabled pass to user
C1C7:59 FA BF 145 eor scomd,y ;Check if D<3>, D<2> = 01
C1CA:29 0C 146 and #$0C ;
C1CC:F0 E4 C1B2 147 beq notacia ;User better take it!
C1CE:B9 F9 BF 148 lda sstat,y ;Get status
C1D1:9D 38 04 149 sta astat,x ;Save it away
C1D4:10 DC C1B2 150 bpl notacia ;No interrupt
C1D6:E0 C2 151 aitst2 cpx #<comslot ;C=1 if com port. Called from serout3
C1D8:B0 02 C1DC 152 bcs aiport2 ;Invert DSR if port1
C1DA:49 40 153 eor #$40

```

```

C1DC:3C 38 05      154 aiport2   bit   extint,x    ;Is DSR enabled?
C1DF:70 29      C20A 155   bvs   aipass      ;Yes, user wants it
C1E1:10 25      C20B 156   bpl   aieatit   ;No, eat it
C1E3:90 23      C20B 157   bcc   aieatit   ;Yes but I don't want it for port 1
C1E5:89 40      C20B 158   bit   #$40      ;Is DSR 1?
C1E7:F0 21      C20A 159   beq   aipass      ;If not, skip it
C1E9:             160 * It's a keyboard interrupt
C1E9:AD 00 C0      161   lda   kbd       ;Get the key
C1EC:A0 80      162   ldy   #$80      ;Put it in the buffer
C1EE:20 28 C2      163   jsr   putbuf      ;Is it a ^x?
C1F1:C9 98      164   cmp   #$98      ;And the closed apple?
C1F3:D0 0B      C20B 165   bne   ainoflsh
C1F5:AD 62 C0      166   lda   butn1      ;Flush the type ahead buffer
C1F8:10 06      C20B 167   bpl   ainoflsh
C1FA:8E FF 05      168   stx   twkey      ;Clear the keyboard
C1FD:8E FF 06      169   stx   trkey
C200:AD 10 C0      170   ainoflsh  lda   kbdstrb
C203:             171 * $A0 $B0 table needed by serial firmware
C203:             C142 172 devno2   equ   *-sltdmy
C203:A0 B0      173   ldy   #$B0      ;Restore y
C205:B9 F9 BF      174   lda   sstat,y    ;Read status to clear int
C208:29 BF      175   aieatit  and   #$BF      ;Clear the DSR bit
C20A:0A      176   aipass   asl   A        ;Shift DSR into C
C20B:0A      177   asl   A        ;Is the receiver full?
C20C:29 20      178   and   #$20      ;If not, we're done
C20E:F0 3E      C24E 179   beq   aciadone
C210:B9 FA BF      180   lda   scmd,y    ;Are receive interrupts enabled?
C213:49 01      181   eor   #1        ;Check for D<1>,D<0> = 01
C215:29 03      182   and   #3        ;If not, were done
C217:D0 35      C24E 183   bne   aciadone
C219:8A      184   txa   aciabuf    ;Is this acia buffered?
C21A:4D FF 04      185   eor   aciabuf
C21D:D0 93      C1B2 186   bne   notacia
C21F:08      187   php   getdata    ;The user better handle it!
C220:20 22 C3      188   jsr   getdata    ;Save DSR status
C223:90 28      C24D 189   bcc   aieat
C225:A0 00      190   ldy   #0        ;Get char & check xon, etc
C227:D0      191   dfb   $D0      ;Don't put in buffer if eaten
C228:             C228 192 putbuf   equ   *
C228:08      193   php   phx
C229:DA      194   phx
C22A:48      195   pha
C22B:B9 7F 05      196   lda   twser,y    ;Get buffer pointer
C22E:AA      197   tax   twser,y    ;Save it for later
C22F:1A      198   inc   A        ;Bump it to next free byte
C230:89 7F      199   bit   #$7F      ;Overflow?
C232:D0 01      C235 200   bne   pbok
C234:98      201   tya   twser,y    ;Wrap pointer
C235:D9 7F 06      202 pbok   cmp   trser,y    ;Buffer full?
C238:F0 03      C23D 203   beq   pbfull
C23A:99 7F 05      204   sta   twser,y    ;Save the new pointer
C23D:68      205 pbfull  pla   twser,y    ;Get the data
C23E:2C 14 C0      206   bit   rdramwrt
C241:8D 05 C0      207   sta   wrcardram
C244:9D 00 08      208   sta   thbuf,x    ;It goes to aux ram
C247:30 03      C24C 209   bmi   aiaux
C249:8D 04 C0      210   sta   wrmainram
C24C:FA      211 aiaux  pld

```

22 MINT	Mouse & serial interrupt stuff	31-MAY-85	PAGE 94
C24D:28	212 aieat p1p	;Get DSR status back	
C24E:60	213 aciadone rts		

```

C24F:          215 ****
C24F:          216 *
C24F:          217 * SEROUT3 - Outputs a character to a acia
C24F:          218 * Inputs: A = char, X = Cn
C24F:          219 *
C24F:          220 ****
C24F:          C24F 221 serout3 equ *
C24F:20 55 C2 222 jsr serout4
C252:4C 84 C7 223 jmp swrt$2
C255:          C255 224 serout4 equ *
C255:48       225 pha      ;Entry point with rts
C256:2C AB C2 226 bit sorts   ;Save the char
C259:F0 03 C25E 227 beq sordy  ;Control char?
C25B:FE 38 07 228 inc col,x  ;Don't inc column if so
C25E:20 B2 C2 229 sordy  jsr getstat2 ;Get acia status
C261:29 30    230 and #$30  ;Y set by getstat
C263:C9 10    231 cmp #$10
C265:D0 F7 C25E 232 bne sordy
C267:BD B8 06 233 lda flags,x ;Is XON/XOFF enabled?
C26A:89 20    234 bit #$20
C26C:F0 1F C28D 235 beq sook  ;Branch if not
C26E:EC FF 04 236 cpx aciabuf ;Is port interrupt driven?
C271:F0 13 C286 237 beq sotst
C273:20 E9 C2 238 jsr xrdnobuf ;Get a char from the acia
C276:90 0E C286 239 bcc sotst ;Branch if no char
C278:BC 34 C2 240 ldy charptr,x ;Get pointer to charbuf
C27B:99 FE 05 241 sta charbuf,y ;Save the character
C27E:BD B8 06 242 lda flags,x ;Set bit for char in buffer
C281:09 04    243 ora #$04
C283:9D B8 06 244 sta flags,x
C286:BD B8 06 245 sotst lda flags,x ;Check if in xoff
C289:29 02    246 and #$02
C28B:D0 D1 C25E 247 bne sordy ;Loop if not ready
C28D:BC 42 C1 248 sook ldy devno2,x
C290:68       249 pla
C291:48       250 pha      ;Get char to XMIT
C292:99 F8 BF 251 sta sdata,y ;Out it goes
C295:3C B8 06 252 bit flags,x ;V=1 if LF after CR
C298:49 0D    253 eor #$0D ;check for CR.
C29A:0A       254 asl A    ;preserve bit 7
C29B:D0 0D C2AA 255 bne sodone ;branch if not CR.
C29D:50 06 C2A5 256 bvc clrcol ;branch if no LF after CR
C29F:A9 14    257 lda #$14 ;Get LF*2
C2A1:6A       258 ror A    ;no shift in high bit
C2A2:20 55 C2 259 jsr serout4 ;Output the LF but don't echo it
C2A5:64 24    260 clrcol stz ch  ;0 position & column
C2A7:9E 38 07 261 stz col,x
C2AA:68       262 sodone pla
C2AB:60       263 sorts  rts

```

```

22 MINT      Mouse & serial interrupt stuff      31-MAY-85      PAGE 96
C2AC:
C2AC:      265 ****
C2AC:      266 *
C2AC:      267 * GETSTAT - Gets the status from a scia
C2AC:      268 * GETSTAT2 - Call from this side
C2AC:      269 * If interrupt, aciatst is called
C2AC:      270 * note: external interrupts are lost
C2AC:      271 * inputs: X = Cn
C2AC:      272 * outputs: A = status, X = Cn, Y = devno
C2AC:      273 *
C2AC:      274 ****
C2AC:      C2AC 275 getstat    equ   *
C2AC:20 B2 C2 276      jsr    getstat2
C2AF:4C 84 C7 277      jmp    swrt52      ;Return to other side
C2B2:      C2B2 278 getstat2  equ   *
C2B2:08     279      php    ;Save interrupt status
C2B3:78     280      sei
C2B4:BC 42 C1 281 gstatst  ldy    devno2,x  ;Get index into hardware
C2B7:B9 F9 BF 282      lda    sstat,y  ;Get the status
C2BA:10 05 C2C1 283      bpl    gstatoint ;D7 = 1 if interrupt
C2BC:20 D6 C1 284      jsr    aitst2   ;Go service the interrupt
C2BF:80 F3 C2B4 285      bra    gstatst  ;Interrupt may have changed status
C2C1:28     286      plp    ;Restore interrupt status
C2C2:60
C2C2:60     287      rts

```

```

C2C3:          289 ****
C2C3:          290 * This is the serial input routine. Carry
C2C3:          291 * flag set indicates that returned data is
C2C3:          292 * valid.
C2C3:          293 *
C2C3:          294 ****
C2C3: C2C3 295 xrdser    equ   *
C2C3:20 C9 C2 296 jsr    xrdser2
C2C6:4C 84 C7 297 jmp    swrts
C2C9:          C2C9 298 xrdser2  equ   *
C2C9:EC FF 04 299 cpx    aciabuf ;is serial input buffered?
C2CC:D0 07 C2D5 300 bne    xnobuf ;(in english "NO SERIAL BUFFER")
C2CE:A0 00 301 ldy    #0      ;Y=0 for serial buffer
C2D0:20 FD C2 302 jsr    getbuf2 ;Any data in buffer?
C2D3:B0 1F C2F4 303 bcs    xrddone
C2D5:          304 *
C2D5:BD B8 06 305 xnobuf   lda    flags,x ;Is there a char in the onr byte buffer?
C2D8:89 04 306 bit    #$04
C2DA:F0 0D C2E9 307 beq    xrdnobuf ;Branch if not
C2DC:29 FB 308 and    #$FB  ;Clear the bit
C2DE:9D B8 06 309 sta    flags,x
C2E1:BC 34 C2 310 ldy    charptr,x
C2E4:B9 FE 05 311 lda    charbuf,y
C2E7:38       312 sec
C2E8:60       313 rts
C2E9:          314 *
C2E9:20 B2 C2 315 xrdnobuf jsr    getstat2 ;Get ACIA status
C2EC:29 08 316 and    #$8
C2EE:18       317 clc
C2EF:F0 03 C2F4 318 beq    xrddone ;Branch if no data!
C2F1:20 22 C3 319 jsr    getdata ;Get data and check xon, etc
C2F4:60       320 xrddone  rts
C2F5: C234 322 charptr equ   *-$C1 ;Pointer to character buffers
C2F5:00 80 323 dfb    $0,$80

```

```

C2F7:          325 ****
C2F7:          326 *
C2F7:          327 * GETBUF - Gets a byte from the input buffer
C2F7:          328 * Inputs: Y=0 for Serial buffer 80 for Keyboard buffer
C2F7:          329 * C = 0 if no data C = 1 if data valid A = Data
C2F7:          330 *
C2F7:          331 ****
C2F7: C2F7 332 getbuf   equ   *
C2F7:20 FD C2 333 jsr    getbuf2
C2FA:4C 84 C7 334 jmp    swrts
C2FD:          C2FD 335 getbuf2  equ   *
C2FD:B9 7F 06 336 lda    trser,Y ;Test for data in buffer
C300:D9 7F 05 337 cmp    twser,Y ;If = then no data
C303:18       338 clc
C304:F0 1B C321 339 beq    gbdone ;Branch if empty
C306:48       340 pha    ;Save current value
C307:1A       341 inc    A      ;Update the pointer
C308:89 7F 342 bit    #$7F  ;Overflow
C30A:D0 01 C30D 343 bne    gbnovr
C30C:98       344 tya

```

22 MINT

Mouse & serial interrupt stuff

31-MAY-85

PAGE 98

```
C30D:99 7F 06      345 gboovr   sta   trser,y      ;Store the updated pointer
C310:7A             346       ply   rdy           ;Get the old value of the pointer
C311:AD 13 C0      347       lda   rdramrd     ;Are we in main ram
C314:0A             348       asl   A            ;C=1 for Aux ram
C315:8D 03 C0      349       sta   rdcardram   ;Force Aux ram
C318:B9 00 08      350       lda   thbuf,Y    ;Get byte from buffer
C31B:B0 04 C321    351       bcs   gbdone      ;Branch if we were in aux bank
C31D:8D 02 C0      352       sta   rdmainram   ;Set back to main
C320:38             353       sec   rts          ;Mark data there
C321:60             354       gbdone      rts
```

```
C322:               356 ****
C322:               357 *
C322:               358 * GETDATA - Gets data from serial port
C322:               359 * and checks for LF, XON, XOFF
C322:               360 * inputs: Y = index to acia
C322:               361 * outputs: A = data, Y dest, C = 1 if data ok = 0 if eaten
C322:               362 *
C322:               363 ****
C322: C322      364 getdata  equ   *
C322:B9 F8 BF      365       lda   sdata,y      ;Save the data
C325:48             366       pha   rdy           ;Set D7 for compares
C326:09 80           367       ora   #$80
C328:A8             368       tay   rdy
C329:BD B8 06      369       lda   flags,x      ;Get options byte
C32C:89 08           370       bit   #$08      ;Eat linefeeds?
C32E:D0 04 C334    371       bne   gdnlkf
C330:C0 8A           372       cpy   #lfeed      ;Is it a LF?
C332:F0 12 C346    373       beq   gdeat      ;Eat it if it is
C334:89 20           374       gdnlkf      bit   #$20      ;Xon/XOFF enabled?
C336:F0 10 C348    375       beq   gdok
C338:C0 91           376       cpy   #xon        ;Is it an XON?
C33A:D0 04 C340    377       bne   gdnxon     and   #$FD      ;Clear xoff bit
C33C:29 FD           378       bra   gdeat      ;And eat it
C33E:80 06 C346    379       cpy   #xoff
C340:C0 93           380       gdnxon      bne   gdok
C342:D0 04 C348    381       ora   #$02      ;Set xoff bit
C344:09 02           382       clc   rdy
C346:18             383       gdeat      dfb   $B0      ;BCS opcode
C347:B0             384       gdok      sec   rts
C348:38             385       sta   flags,x      ;Auxillary move stuff
C349:9D B8 06      386       pla   rts
C34C:68             387       rts
C34D:60             388       rts
C34E:               52       include auxstuff ;Auxillary move stuff
```

```

C34E:          4 ****
C34E:          5 * NAME      : MOVEAUX
C34E:          6 * FUNCTION: PERFORM CROSSBANK MEMORY MOVE
C34E:          7 * INPUT     : A1=SOURCE ADDRESS
C34E:          8 *           : A2=SOURCE END
C34E:          9 *           : A4=DESTINATION START
C34E:         10 *          : CARRY SET=MAIN->CARD
C34E:          11 *          : CLR=CARD->MAIN
C34E:          12 * OUTPUT    : NONE
C34E:          13 * VOLATILE   : NOTHING
C34E:          14 * CALLS     : NOTHING
C34E:          15 ****
C34E: C34E 16 MOVEAUX EQU *
C34E:48 17 PHA           ;SAVE AC
C34F:AD 13 C0 18 LDA RDRAMRD ;SAVE STATE OF
C352:48 19 PHA           ;MEMORY FLAGS
C353:AD 14 C0 20 LDA RDRAMWRT
C356:48 21 PHA
C357: 22 *
C357: 23 * SET FLAGS FOR CROSSBANK MOVE:
C357: 24 *
C357:90 08 C361 25 BCC MOVEC2M ;=>CARD->MAIN
C359:8D 02 C0 26 STA RDMAINRAM ;SET FOR MAIN
C35C:8D 05 C0 27 STA WRCARDRAM ; TO CARD
C35F:B0 06 C367 28 BCS MOVESTRT ;=>(ALWAYS TAKEN)
C361:          29 *
C361: C361 30 MOVEC2M EQU *
C361:8D 04 C0 31 STA WRMAINRAM ;SET FOR CARD
C364:8D 03 C0 32 STA RDCARDRAM ; TO MAIN
C367:          33 *
C367: C367 34 MOVESTRT EQU *
C367:B2 3C 35 MOVELOOP LDA (A1L) ;get a byte
C369:92 42 36 STA (A4L) ;move it
C36B:E6 42 37 INC A4L
C36D:D0 02 C371 38 BNE NEXTA1
C36F:E6 43 39 INC A4H
C371:A5 3C 40 NEXTA1 LDA A1L
C373:C5 3E 41 CMP A2L
C375:A5 3D 42 LDA A1H
C377:E5 3F 43 SBC A2H
C379:E6 3C 44 INC A1L
C37B:D0 02 C37F 45 BNE C01
C37D:E6 3D 46 INC A1H
C37F:90 E6 C367 47 C01 BCC MOVELOOP ;=>more to move
C381:          48 *
C381:8D 04 C0 49 STA WRMAINRAM ;CLEAR FLAG2
C384:68 50 PLA           ;GET ORIGINAL STATE
C385:10 03 C38A 51 BPL C03 ;=>IT WAS OFF
C387:8D 05 C0 52 STA WRCARDRAM
C38A: C38A 53 C03 EQU *
C38A:8D 02 C0 54 STA RDMAINRAM ;CLEAR FLAG1
C38D:68 55 PLA           ;GET ORIGINAL STATE
C38E:10 03 C393 56 BPL MOVERET ;=>IT WAS OFF
C390:8D 03 C0 57 STA RDCARDRAM
C393: C393 58 MOVERET EQU *
C393:68 59 PLA           ;Restore AC
C394:4C 84 C7 60 JMP SWRTS2

```

```

C397:          62 ****
C397:          63 * NAME      : XFER
C397:          64 * FUNCTION: TRANSFER CONTROL CROSSBANK
C397:          65 * INPUT     : $03ED=TRANSFER ADDR
C397:          66 *           : CARRY SET=XFER TO CARD
C397:          67 *           : CLR=XFER TO MAIN
C397:          68 *           : VFLAG CLR=USE STD ZP/STK
C397:          69 *           : SET=USE ALT ZP/STK
C397:          70 * OUTPUT    : NONE
C397:          71 * VOLATILE: $03ED/03EE IN DEST BANK
C397:          72 * CALLS     : NOTHING
C397:          73 * NOTE      : ENTERED VIA JMP, NOT JSR
C397:          74 ****
C397:          75 *
C397:          C397 76 XFER    EQU   *
C397:48          77      PHA             ;SAVE AC ON CURRENT STACK
C398:          78 *
C398:          79 * COPY DESTINATION ADDRESS TO THE
C398:          80 * OTHER BANK SO THAT WE HAVE IT
C398:          81 * IN CASE WE DO A SWAP:
C398:          82 *
C398:AD ED 03  83      LDA    $03ED      ;GET XFERADDR LO
C398:48          84      PHA             ;SAVE ON CURRENT STACK
C39C:AD EE 03  85      LDA    $03EE      ;GET XFERADDR HI
C39F:48          86      PHA             ;SAVE IT TOO
C3A0:          87 *
C3A0:          88 * SWITCH TO APPROPRIATE BANK:
C3A0:          89 *
C3A0:90 08 C3AA 90      BCC    XFERC2M    ;=>CARD->MAIN
C3A2:8D 03 C0  91      STA    RDCARDRAM  ;SET FOR RUNNING
C3A5:8D 05 C0  92      STA    WRCARDRAM  ; IN CARD RAM
C3A8:B0 06 C3B0 93      BCS    XFERZP    ;=> always taken
C3AA:          94 XFERC2M  EQU   *
C3AA:8D 02 C0  95      STA    RDMAINRAM  ;SET FOR RUNNING
C3AD:8D 04 C0  96      STA    WRMAINRAM ; IN MAIN RAM
C3B0:          97 *
C3B0:          C3B0 98 XFERZP  EQU   *      ;SWITCH TO ALT ZP/STK
C3B0:68          99      PLA             ;STUFF XFERADDR
C3B1:8D EE 03 100      STA    $03EE      ; HI AND
C3B4:68          101     PLA             ;
C3B5:8D ED 03 102      STA    $03ED      ; LO
C3B8:68          103     PLA             ; RESTORE AC
C3B9:70 05 C3C0 104      BVS    XFERAZP   ;=>switch in alternate zp
C3BB:8D 08 C0  105     STA    SETSTDZP  ;else force standard zp
C3BE:50 03 C3C3 106      BVC    JMPDEST   ;=>always perform transfer
C3C0:8D 09 C0  107 XFERAZP  STA    SETALTZP  ;switch in alternate zp
C3C3:4C EB C7  108 JMPDEST  JMP    SWXFG02  ;Back we go
C3C6:          109 ****
C3C6:          53      include banger2 ;Diagnostic routines

```

```

C3C6:
C3C6:      3 ****
C3C6:      4 *
C3C6:      5 * Here is the rest of the diagnostic stuff
C3C6:      6 * the first part has been moved into the $D000 space
C3C6:      7 * to make desperately needed room
C3C6:      8 *
C3C6:      9 ****
C3C6: C3C6 10 TSTMEM equ *
C3C6:01      11 stx $01
C3C6:02      12 stx $02
C3C6:03      13 stx $03
C3C6:04      14 ldx #4      ;do RAM $100-$FFFF five times
C3C6:04      15 stx $04
C3D0:05      16 MEM1 STA $05      ;keep acc in a safe place
C3D2:A2 04    17 ldx #4
C3D4:64 01    18 stz $01
C3D6:E6 01    19 inc 1      ;point to page 1 first
C3D8:A8      20 mem2 tay      ;save ACC in Y for now
C3D9:8D 83 C0 21 sta lcbank2  ;anticipate not $C000 range...
C3DC:8D 83 C0 22 sta lcbank2
C3DF:A5 01    23 lda $01      ;get page address
C3E1:29 F0    24 and #$F0      ;test for $C0-$CF range
C3E3:C9 C0    25 cmp #$C0
C3E5:D0 0C  C3F3 26 bne mem3  ;branch if not...
C3E7:AD 8B C0 27 lda lcbank1
C3EA:AD 8B C0 28 lda lcbank1  ;select primary $D000 space
C3ED:A5 01    29 lda $01
C3EF:69 0F    30 adc #$F      ;Plus carry =+$10
C3F1:D0 02  C3F5 31 bne mem4  ;branch always taken
C3F3:A5 01    32 mem3 lda $01
C3F5:85 03    33 mem4 sta $03
C3F7:98      34 tya      ;restore pattern to ACC
C3F8:A0 00    35 ldy #$00      ;fill this page with the pattern
C3FA:18      36 mem5 clc
C3FB:7D 2A C8 37 adc ntbl,x
C3FE:91 02    38 sta ($02),y  ;keep x in the range 0-4
C400:CA      39 dex
C401:10 02  C405 40 bpl mem6
C403:A2 04    41 ldx #4
C405:C8      42 mem6 iny      ;all 256 filled yet?
C406:D0 F2  C3FA 43 bne mem5  ;branch if not
C408:EG 01    44 inc 1      ;bump page #
C40A:D0 CC  C3D8 45 bne mem2  ;loop through $0100 to $FF00
C40C:E6 01    47 inc $01      ;point to page 1 again
C40E:A2 04    48 LDX #4
C410:A5 05    49 LDA $05
C412:A8      50 mem7 tay      ;save ACC in Y for now
C413:AD 83 C0 51 lda lcbank2  ;anticipate not $C000 range...
C416:AD 83 C0 52 lda lcbank2
C419:A5 01    53 lda $01      ;get page address
C41B:29 F0    54 and #$F0      ;test for $C0-$CF range
C41D:C9 C0    55 cmp #$C0
C41F:D0 09  C42A 56 bne mem8  ;branch if not...
C421:AD 8B C0 57 lda lcbank1
C424:A5 01    58 lda $01      ;select primary $D000 space
C426:69 0F    59 adc #$F      ;Plus carry =+$10
C428:D0 02  C42C 60 bne mem9  ;branch always taken

```

```

C42A:A5 01      61 mem8    lda   $01
C42C:85 03      62 mem9    sta   $03
C42E:98          63 tya
C42F:A0 00      64 ldy   #$00 ;restore pattern to ACC
C431:18          65 memA   clc
C432:7D 2A C8    66 adc   ntbl,x
C435:51 02      67 eor   ($02),y
C437:D0 39 C472  68 bne   MEMERROR ;if any bits are different, give up!!!
C439:B1 02      69 lda   ($02),y ;restore correct pattern
C43B:CA          70 dex
C43C:10 02 C440  71 bpl   memB ;keep x in the range 0-4
C43E:A2 04      72 ldx   #4
C440:C8          73 memB   iny
C441:D0 EE C431  74 bne   memA ;all 256 filled yet?
C443:E6 01      75 inc   1 ;branch if not
C445:D0 CB C412  76 bne   mem7 ;bump page #
C447:6A          77 ror   a ;loop through $0100 to $FF00
C448:2C 19 C0    78 bit   rdvblbar ;change ACC for next pass
C44B:10 02 C44F  79 bpl   memC ;use RDVBL for a little randomness...
C44D:49 A5      80 eor   #$A5
C44F:C6 04      81 memC   dec   $04 ;have 5 passes been done yet?
C451:30 03 C456  82 bmi   memD ;skip if yes
C453:4C D0 C3    83 jmp   mem1 ;start next pass

C456:AA          85 memD   TAX   ;save acc
C457:2C 13 C0    86 BIT    rdramrd ;main or aux ram ?
C45A:30 10 C46C  87 BMI    MEMF   ;skip if aux ram
C45C:8A          88 txa
C45D:8D 05 C0    89 STA    wrcardram ;enable aux mem write
C460:8D 03 C0    90 STA    rdcardram ;enable aux mem read
C463:8D 09 C0    91 STA    setaltzp ;swap in alt zero page
C466:8D 81 C0    92 STA    ROMIN  ;Force rom enable
C469:4C B2 D4    93 jmp   TSTZPG ;and test it!

C46C:8D 08 C0    95 MEMF   STA    setstdzp ;swap in main zero page
C46F:4C EF C4    96 JMP    SWCHTST

```

```

C472:38      98 MEMERROR sec      ;indicate main ram failure
C473:AA      99 BADBITS tax     ;save bit pattern in x for now
C474:A0 13 C0 100 lda   rdramrd ;main or aux mem?
C477:B8      101 clv
C478:10 03 C47D 102 bpl   bbits1 ;with V-FLG
C47A:2C 2A C8 103 bit   setv
C47D:A0      104 bbits1 lda   #$A0 ;branch if primary bank
C47F:A0 06    105 ldy   #6
C481:99 FE BF 106 clrsts sta  ioadr-2,y
C484:99 06 C0 107 sta   ioadr+6,y
C487:88      108 dey
C488:88      109 dey
C489:D0 F6 C481 110 bne   clrsts
C48B:8D 51 C0 111 sta   txiset
C48E:8D 54 C0 112 sta   txtpage1
C491:99 00 04 113 clrs  sta  $400,y
C494:99 00 05 114 sta  $500,y
C497:99 00 06 115 sta  $600,y
C49A:99 00 07 116 sta  $700,y
C49D:C8      117 iny
C49E:D0 F1 C491 118 bne   clrs
C4A0:8A      119 txa
C4A1:F0 27 C4CA 120 beq   BADSWTCH ;test for switch test failure
C4A3:A0 03    121 ldy
C4A5:B0 02 C4A9 122 bcs   badmain ;branch if ZP ok
C4A7:A0 05    123 ldy   #5
C4A9:A9 AA    124 badmain lda  #$AA ;mark aux report with an asterisks
C4AB:50 03 C4B0 125 bvc   badprim
C4AD:8D B0 05 126 sta   screen-8
C4B0:B9 66 C8 127 badprim lda  rmess,y
C4B3:99 B1 05 128 sta   screen-7,y
C4B6:88      129 dey
C4B7:10 F7 C4B0 130 bpl   badprim ;message is either "RAM" or "RAM ZP"
C4B9:A0 10    131 ldy   #$10 ;print bits
C4BB:8A      132 bbits2 txa
C4BC:4A      133 lsr   a
C4BD:AA      134 tax
C4BE:A9 58    135 lda   #$58 ;bits are printed as ascii 0 or 1
C4C0:2A      136 rol   a
C4C1:99 B6 05 137 sta   screen-2,y
C4C4:88      138 dey
C4C5:88      139 dey
C4C6:D0 F3 C4BB 140 bne   bbits2
C4C8:F0 FE C4C8 141 hangx beq   hangx ;hang forever and ever

```

```

C4CA:A2 02      143 BADSWTCH  ldx   #2
C4CC:7A          144           ply
C4CD:08          145           php
C4CE:BD 6C C8    146 bswtch1  lda   smess,x    ;anticipate MMU error
C4D1:28          147           plp
C4D2:08          148           php
C4D3:90 03      C4D8 149           bcc bswtch2    ;branch if not IOU error
C4D5:BD 6F C8    150           lda   smess+3,x  ;anticipate IOU error
C4D8:C0 06      151 bswtch2  cpy   #6
C4DA:90 0B      C4E7 152           bcc bswtch3    ;compare with where we left off
C4DC:C0 08      153           cpy   #8
C4DE:90 04      C4E4 154           bcc bswtch2a   ;skip if GLU (ioudis or dhires failure)
C4E0:C0 11      155           cpy   #$11
C4E2:90 03      C4E7 156           bcc bswtch3    ;skip if IOU
C4E4:BD 72 C8    157 bswtch2a  lda   smess+6,x  ;GLU error (ioudis failure)
C4E7:9D B8 05    158 bswtch3  sta   screen,x
C4EA:CA          159           dex
C4EB:10 E1      C4CE 160           bpl bswtch1    ;print "MMU", "IOU" or "GLU"
C4ED:30 FE      C4ED 161 hangy  bmi   hangy      ;branch forever

C4EF:A0 01      163 SWCHTST  ldy   #MMUIDX
C4F1:A9 7F      164 swtst1  lda   #$7F
C4F3:6A          165 swtst2  ror   a
                                         ;set switches of the IOU/MMU to match
                                         Accumulator

C4F4:BE 2F C8    166           ldx   SWTBL0,y
C4F7:F0 0F      C508 167           beq   swtst4    ;branch if done setting switches
C4F9:90 03      C4FE 168           bcc   swtst3    ;branch if setting switch to 0-state
C4FB:BE 41 C8    169           ldx   SWTBL1,y
C4FE:9D FF BF    170 swtst3  sta   iaddr-1,x  ;else get index to set switch to 1
C501:C8          171           iny
C502:D0 EF      C4F3 172           bne   swtst2    ;set switch
C504:          173 *          ;branch always taken...
C504:AE 30 C0    174 click    ldx   spkr
C507:2A          175           rol   a
C508:88          176 swtst4  dey
C509:BE 53 C8    177           ldx   RSWTBL,y
C50C:F0 13      C521 178           beq   swtst6    ;now verify the settings just made
C50E:30 F4      C504 179           bmi   click     ;branch if done this pass
C50E:          verified.  ;branch if this switch no to be

C510:2A          180           rol   a
C511:90 07      C51A 181           bcc   swtst5
C513:1E 00 C0    182           asl   iaddr,x
C516:90 1F      C537 183           bcc   swerr
C518:B0 EE      C508 184           bcs   swtst4    ;branch always
C51A:1E 00 C0    185 swtst5  asl   iaddr,x
C51D:B0 18      C537 186           bcs   swerr
C51F:90 E7      C508 187           bcc   swtst4    ;branch always
C521:          188 *          ;branch always
C521:2A          189 swtst6  rol   a
                                         ;restore original value
                                         ;and IOU/MMU index
C522:C8          190           iny
C523:38          191           sec
C524:E9 01      192           sbc   #1
                                         ;try next pattern
C526:B0 CB      C4F3 193           bcs   swtst2
C528:88          194           dey
C529:F0 08      C533 195           beq   swtst7    ;was MMU just tested?
                                         ;yes, go test IOU
C52B:C0 08      196           cpy   #IOUIDX-1  ;was IOU just tested?
C52D:D0 10      C53F 197           bne   BIGLOOP   ;no, go loop again
C52F:A0 11      198           ldy   #GLUIDX
C531:D0 BE      C4F1 199           bne   swtst1    ;yes, go test IOUDIS switch
                                         ;branch always

```

24 BANGER2	Apple //c diagnostics	31-MAY-85	PAGE 105
C533:A0 09	200 swtst7 ldy #IOUIDX		
C535:D0 BA C4F1	201 bne swtst1	;branch always	
C537:	202 *		
C537:5A	203 swerr phy	;save y to distinguish from MMU or GLU failure	
C538:A2 00	204 ldx #0	;indicate switch error	
C53A:C0 0A	205 cpy #IOUIDX+1	;set carry if IOU was cause	
C53C:4C 7D C4	206 jmp bbits1		

```

C53F:46 80      208 BIGLOOP    lsr   $80
C541:D0 AC     C4EF  209       bne   SWCHTST
C543:A9 A0     210 blp2      lda   #$A0
C545:A0 00     211       ldy   #0
C547:99 00 04  212 blp3      sta   $400,y      ;clear screen for success message
C54A:99 00 05  213       sta   $500,y
C54D:99 00 06  214       sta   $600,y
C550:99 00 07  215       sta   $700,y
C553:C8       216       iny
C554:D0 F1     C547  217       bne   blp3
C556:AD 61 C0  218 blp4      LDA   butn0      ;test for both Open and Closed Apple
C559:2D 62 C0  219       AND   butn1      ; pressed
C55C:0A       220       asl   a          ;put result in carry
C55D:E6 FF     221       INC   $FF
C55F:A5 FF     222       LDA   $FF
C561:90 03     C566  223       bcc   dquit
C563:4C A9 D4  224       jmp   DIAGS
C566:           225 *      *
C566:AD 51 C0  226 dquit    lda   txtset      ;put success message on the screen
C569:A0 08     227       ldy   #8
C56B:B9 75 C8  228 suc2     lda   success,y
C56E:99 B8 05  229       sta   SCREEN,y
C571:88       230       dey
C572:10 F7     C56B  231       bpl   suc2
C574:30 E0     C556  232       bmi   blp4      ;loop forever
C576: 000A     54        ds   $C580-* ,0      ;Appletalk stuff
C580:           55        include switcher2 ;Bank switch stuff @ 2:C780

```

```

C580:      0200    2      ds    $C780-*,$00
C780:      3 ****
C780:      4 *
C780:      5 * SWITCHING ROUTINES
C780:      6 *
C780:      7 ****
C780:8D 28 C0   8 swrt12  sta rombank
C783:40     9       rti
C784:8D 28 C0   10 swrts2  sta rombank
C787:60    11       rts
C788:8D 28 C0   12 swreset2 sta rombank
C78B:4C 62 FA   13 jmp  reset
C78E:8D 28 C0   14 swirq2  sta rombank ;Irq entry
C791:2C 87 C7   15 bit  swrtstop
C794:4C 04 C8   16 jmp  irqent
C797:8D 28 C0   17 swsthk2 sta rombank
C79A:4C 80 C8   18 jmp  pcnv
C79D:8D 28 C0   19 swzzq12 sta rombank ;Mouse basic routines
C7A0:4C 00 D4   20 jmp  basicin
C7A3:8D 28 C0   21 sta rombank ;Set terminal mode
C7A6:4C F1 C7   22 jmp  swsttm3
C7A9:8D 28 C0   23 sta rombank ;Jump to command routine
C7AC:4C 06 C8   24 jmp  swcmd3
C7AF:8D 28 C0   25 sta rombank ;Aux move
C7B2:4C 4E C3   26 jmp  moveaux
C7B5:8D 28 C0   27 sta rombank ;XFER
C7B8:4C 97 C3   28 jmp  xfer
C7BB:8D 28 C0   29 sta rombank ;Mouse interrupt handler
C7BE:4C 00 C1   30 jmp  mouseint
C7C1:8D 28 C0   31 sta rombank ;Diagnostics
C7C4:4C A9 D4   32 jmp  diags
C7C7:8D 28 C0   33 sta rombank ;Appletalk
C7CA:4C 80 C5   34 jmp  atalk
C7CD:8D 28 C0   35 sta rombank ;Serial output
C7D0:4C 4F C2   36 jmp  serout3
C7D3:8D 28 C0   37 sta rombank ;Get status
C7D6:4C AC C2   38 jmp  getstat
C7D9:8D 28 C0   39 sta rombank ;Read from serial port
C7DC:4C C3 C2   40 jmp  xrdser
C7DF:8D 28 C0   41 sta rombank ;Get char from buffer
C7E2:4C F7 C2   42 jmp  getbuf
C7E5:8D 28 C0   43 sta rombank
C7E8:4C E0 D4   44 jmp  znnm
C7EB:8D 28 C0   45 swxfg02 sta rombank ;Go to users xfer dest
C7EE:6C ED 03   46 jmp  ($3ED)
C7F1:DA        47 swsttm3 phx      ;Save X
C7F2:20 16 C8   48 jsr  getlc
C7F5:5A        49 phy
C7F6:20 A0 D1   50 jsr  setterm
C7F9:80 13 C80E 51 bra  fixlc ;Fix Language card and return
C7FB:      0008  53 ds    $C803-*,$0 ;$C803 interrupt entry point
C803:4C 8E C7   54 jmp  swirq2
C806:DA        56 swcmd3 phx      ;Go to the command routine
C807:20 16 C8   57 jsr  getlc ;Get language card state
C80A:5A        58 phy      ;Save it
C80B:20 00 D0   59 jsr  command

```

25 SWITCHER2

Apple //c diagnostics

31-MAY-85

PAGE 108

```

C80E:FA      60 fixlc    plx
C80F:FE 00 C0  61 inc     $C000,x      ;Restore LC
C812:FA      62 plx     ;Restore real X
C813:4C 84 C7  63 jmp     swrts2

C816:          65 ****
C816:          66 * GETLC - Gets language card state in Y
C816:          67 ****
C816: C816 68 getlc   equ    *
C816:A0 81    69 ldy     #$81
C818:2C 12 C0  70 bit     rdlcram      ;Language card enabled?
C81B:10 0C C829 71 bpl     glcdone
C81D:A0 8B    72 ldy     #$8B
C81F:2C 11 C0  73 bit     rdlcblk2    ;Bank 2?
C822:10 02 C826 74 bpl     glcbnk1
C824:A0 83    75 ldy     #$83      ;Bank 1!
C826:8D 81 C0  76 glcbnk1 sta    romin
C829:60        77 glcdone rts

C82A:          79 * Diagnostic routine tables
C82A: C82A 80 setv    equ    *
C82A:53 43 2B 29  81 ntbl    dfb   83,67,43,41,7
C82F:00 89 03 05  82 swtbl0  dfb   $00,$89,$03,$05,$09,$01,$7F,$5F
C837:00 83 51 53  83 dfb   $00,$83,$51,$53,$55,$57,$0F,$0D,$00,$80
C841:00 81 04 06  84 swtbl1  dfb   $00,$81,$04,$06,$0A,$02,$7F,$60
C849:00 84 52 54  85 dfb   $00,$84,$52,$54,$56,$58,$10,$0E,$00,$7F
C853:00 11 13 14  86 rswtbl  dfb   $00,$11,$13,$14,$16,$18,$FF,$7F
C85B:00 12 1A 1B  87 dfb   $00,$12,$1A,$1B,$1C,$1D,$1E,$1F,$00,$7E,$00
C866:          88 MSB    ON
C866:D2 C1 CD A0  89 rmess   asc   "RAM      ZP"
C866:CD CD D5 C9  90 smess   asc   "MMUIOUGLU"

C875:D3 F9 F3 F4  92 success asc   "System      OK"
C87E: 0002 56 ds    $C880-* ,0 ;Protocol converter
C880: 0780 57 ds    $D000-* ,0
D000:          58 include command ;Serial port command processor

```

```

D000:          2 ****
D000:          3 * The command routine now supports 5 new 2-character commands. These
D000:          4 * commands enable or disable a feature of the serial port and are
D000:          5 * derived from their equivalent in the super serial card for the //.
D000:          6 *
D000:          7 * The new commands are as follows:
D000:          8 *      L - send LF out after CR
D000:          9 *      X - detect XOFF, and wait for XON
D000:         10 *      F - accept keyboard input
D000:         11 *      M - ignore LF in after CR
D000:         12 *      C - auto CR when column count > printer width
D000:         13 *
D000:         14 * Usage of location $779 (port 1) and $77A (port 2) are as follows:
D000:         15 *      bit 7 - echo output to screen if on
D000:         16 *      bit 6 - generate LF after CR if on
D000:         17 *      bit 5 - accept XOFF if on
D000:         18 *      bit 4 - ignore keyboard input if on
D000:         19 *      bit 3 - accept LF in after CR if on
D000:         20 *      bit 2 - a character was received through the ACIA and is in
D000:         21 *              location $5FE (port 1) or $67E (port 2) if on
D000:         22 *      bit 1 - XOFF is accepted, awaiting XON if on
D000:         23 *      bit 0 - signifies comm port if on, printer port if off
D000:         24 ****

D000:    000D  26 charCR  equ   $0D
D000:    0000  27 ucspace equ   $00           ;need an "upper case" space character

D000:48          29 command  pha             ;shove character on stack
D001:3C B8 03  30 bit  sermode,x        ;Already in command?
D004:30 1C D022 31 bmi  incmd            ;If so, go do it
D006:BC 38 06  32 ldy  eschar,x        ;If eschar = 0 ignore commands
D009:F0 14 D01F 33 beq  nocmd            ;Is it the command char?
D00B:5D 38 06  34 eor  eschar,x        ;A
D00E:0A          35 asl  A                ;Ignore high bit
D00F:D0 0E D01F 36 bne  nocmd            ;char not command char
D011:AC FB 07  37 command1 ldy  cursor  ;Save the cursor
D014:8C 79 06  38 sty  oldcur           ;Set command cursor
D017:A0 BF          39 ldy  #cmdcur        ;Set command cursor
D019:8C FB 07  40 sty  cursor           ;cursor
D01C:4C BS D0          41 jmp  cominit1  ;initiate command mode

D01F:38          43 nocmd   sec             ;Mark char not handled
D020:68          44 nocmd2  pla             ;Restore original char
D021:60          45 rts

D022:          D022  47 incmd   equ   *       ;Command mode
D022:BC 42 C1  48 ldy  devno2,x        ;Get index for ACIA
D025:29 5F          49 and  #$5F           ;High bit doesn't matter, upshift lower
case
D027:48          50 pha             ;save character
D028:BD B8 03  51 lda  sermode,x        ;need to see if in 2-chr command
D02B:89 08          52 bit  #$08           ;bit 3 set if so
D02D:D0 03 D032  53 bne  incmd2          ;branch if so
D02F:68          54 pla             ;pull char back, not in 2-chr cmd
D030:80 52 D084  55 bra  incmd1          ;go on with regular command mode

D032:          D032  57 incmd2 equ   *       ;handle 2nd chr of 2-chr commands
D032:68          58 pla             ;pull char off stack
D033:48          59 pha             ; & reshove it to keep stack neat

```

26 COMMAND		Command processor for serial & comm 31-MAY-85			PAGE 110
D034:C9 00	60	cmp	#ucspace	;is it a space? (uppercased)	
D036:D0 04	D03C	bne	incmd3	;no, go on with 2-chr cmd handling	
D038:18	61	clc		;yes, ignore spaces between chrs of	
	62			2-chr cmd	
D039:68	63	pla		;pull uppercased char off stack	
D03A:80 E4	D020	bra	nocmd2	;ie mark them "handled"	
D03C:BD B8 03	66	incmd3	lda	seremode,x	;get seremode back
D03F:48	67	pha			;save seremode for a minit
D040:29 07	68	and	#7		;throw out all but bits 0-2
D042:8D F8 06	69	sta	temp		;save - this is index of which cmd it is
D045:68	70	pla			;get seremode back
D046:29 F0	71	and	#\$F0		;now clear bits 0-3
D048:9D B8 03	72	sta	seremode,x		;since we're done with them now
D04B:68	73	pla			;get character back
D04C:DA	74	phx			;shove x (Cn) on stack
D04D:AE F8 06	75	ldx	temp		;get index to command's 1st chr
D050:C9 45	76	cmp	#\$45		;is it an E?
D052:F0 71	D0C5	77	beq	enable	;yes
D054:C9 44	78	cmp	#\$44		;no, is it a D?
D056:F0 6F	D0C7	79	beq	disable	;yes
D058:FA	80	plx			;retrieve X=Cn
D059:DA	81	phx			;push it back to keep stack neat
D05A:DD 38 06	82	cmp	eschar,x		;compare to the command character
D05D:08	83	php			;save result of comparison for a bit
D05E:AE F8 06	84	ldx	temp		;reload X= index to cmd's first chr
D061:28	85	plp			;retrieve result
D062:F0 13	D077	86	beq	flagit	;yes tis 1-chr cmd followd by nother cmd
D064:C9 0D	87	cmp	#charCR		;is it a (guess what) CR?
D066:F0 17	D07F	88	beq	oneletter	;yes - a 1-chr command
D068:	D068	89	cmd2null	equ *	;unimplemented but legal 2-chr cmd
D068:FA	90	plx			;pull x (Cn) off stack
D069:AD 79 06	91	lda	oldcur		;restore non-cmd-mode cursor
D06C:8D FB 07	92	sta	cursor		
D06F:1E B8 03	93	asl	seremode,x		;clear cmd-mode bit (bit 7 of seremode)
D072:5E B8 03	94	lsr	seremode,x		;by shifting out bit 7 & shifting in a 0
D075:80 A8	D01F	95	bra	nocmd	;return marking character not handled
D077:	D077	97	flagit	equ *	
D077:FA	98	plx			;come here if get eschar after LXFM or T
D078:DA	99	phx			;need X=Cn to set bit 0 of seremode
D079:FE B8 03	100	inc	seremode,x		;but leave Cn on stack too
					;bit 0 was 0, is now 1 - means new cmd mode
D07C:AE F8 06	101	ldx	temp		;reload X=index to cmd's first chr
D07F:	D07F	102	oneletter	equ *	;come here if 2-chr cmd turns out 1 chr
D07F:BD 25 D2	103	lda	cmd2list,x		;get command chr
D082:80 0B	D08F	104	bra	backto1	;treat it as if we just got it
D084:	D084	106	incmd1	equ *	
D084:DA	107	phx			;in command mode, not 2-chrs tho
D085:A2 04	108	ldx	#4		;Save slot
D087:DD 25 D2	109	cmd2loop	cmp cmd2list,x		;check 5 possible 2-chr cmd
D08A:F0 71	D0FD	110	beq cmd2found		;is it there?
D08C:CA	111	dex			;yes, need to flag it for next time
D08D:10 F8	D087	112	bpl cmd2loop		;nope
D08F:	D08F	113	backto1	equ *	;try next if there is one
D08F:A2 0C	114	ldx	#12		;come here to check for 1-chr cmd
D091:DD 18 D2	115	cmdloop	cmp cmdlist,x		;Check 13 commands
D094:F0 74	D10A	116	beq cmfound		
D096:CA	117	dex			;Right char?

```

D097:10 F8 D091 118 bpl cmdloop
D099:FA 119 plx ;We didn't find it
D09A:68 120 pla
D09B:48 121 pha
D09C:29 7F 122 and #$7F ;if char is cntl char
D09E:C9 20 123 cmp #$20 ;it can be the new comd char
D0A0:B0 03 D0A5 124 bcs ckdig ;branch if not cntl character
D0A2:9D 38 06 125 cmdz2 sta eschar,x ;Save comd char, drop thru ckdig to
                                         ;cdone
D0A5:49 30 126 ckdig eor #$30 ;zap it down to 0n if char was a digit
D0A7:C9 0A 127 cmp #$0A ;if not a digit, it is unexpected
                           ;intruder
D0A9:B0 33 D0DE 128 bcs cdone ;If not, branch
D0AB:A0 0A 129 ldy #10 ;A = A + 10 * current number
D0AD:6D 7E 04 130 digloop adc number ;C=0 on first entry
D0B0:88 131 dey
D0B1:D0 FA D0AD 132 bne digloop
D0B3:80 0A D0BF 133 bra cominit ;not starting new cmd mode, just save #
                                         ;start new cmd mode here
D0B5:BD B8 03 D0B5 135 cominit1 equ *
D0B8:29 C0 136 lda sermode,x ;get sermode
                               ;clear bits 0-5 (starting a new cmd seq)
                                         ;they are used for misc during cmd mode)
D0BA:9D B8 03 138 sta sermode,x ;load a 0 to stuff in NUMBER
D0BD:A9 00 139 lda #0
D0BF:8D 7E 04 140 cominit sta number ;Mark in command mode
D0C2:38 141 sec
D0C3:80 25 D0EA 142 bra cmset
                                         ;got a 2-chr command aE
D0C5:38 144 enable equ *
D0C6:90 145 sec ;set carry
D0C7: D0C7 146 dfb $90 ;bcc to skip next byte (the CLC)
                                         ;got a 2-chr command aD
D0C7:18 147 disable equ * ;clear carry
D0C8:08 148 clc ;push P to save carry
D0C9:E0 00 149 php
D0CB:F0 27 D0F4 150 cpx #0 ;if X=0 then command is LE or LD
D0CD:E0 04 151 beq cmd21 ;so just make it act like L or K
D0CF:F0 41 D112 152 cpx #4 ;if X=4 then command is CE or CD
                               ;skip if so
                                         ****
D0D1: 155 ****
D0D1: 156 * for other 2-chr cmds, their FLAGS masks' indexes are 2X+3
D0D1: 157 * for an E or 2X+4 for a D
D0D1: 158 ****
                                         ;copy x to acc for arithmetic
D0D2:18 160 txa
D0D3:0A 161 clc ;clear carry for arithmetic
D0D4:69 03 162 asl A ;multiply index by 2
D0D6:AA 163 adc #3 ;add 3 to get mask index
D0D7:28 164 tax ;put mask index in X
D0D8:B0 01 D0DB 165 pld ;get carry back
                                         ;carry set = Enable so X is ready
D0DA:E8 166 bcs xready ;cmd was Disable so inc X to next mask
D0DB:4C 39 D1 167 inx ;go do mask stuff to FLAGS
                                         ;jmp cmdi
                                         ;so get it
                                         ;shift bit 0 to carry
                                         ;if set, start new cmd mode
                                         ;Restore the cursor
                                         ;& fall through to cmset with carry
                                         ;clear
                                         ;sermode bit 0 tells whether to set or
                                         ;clear cmd mode
D0DE:BD B8 03 171 lda sermode,x
D0E1:4A 172 lsr A
D0E2:B0 D1 D0B5 173 bcs cominit1
D0E4:AD 79 06 174 lda oldcur
D0E7:8D FB 07 175 sta cursor

```

D0EA:08	176	cmset	php	
D0EB:1E B8 03	177	asl sermode,x	;set command mode according to carry	
D0EE:28	178	plp		
D0EF:7E B8 03	179	ror sermode,x	;leaves carry clear	
D0F2:68	180	pla	;character handled	
D0F3:60	181	rts	;because carry clear...	
D0F4: D0F4	183	cmd21	equ *	;come here to handle LE & LD
D0F4:A9 4C	184	lda #\$4C	;make LE look like L	
D0F6:28	185	plp	;get P back with carry indicating E or D	
D0F7:B0 96 D08F	186	bcs backto1	;carry set means it was an E	
D0F9:A9 4B	187	lda #\$4B	;make LD look like K	
D0FB:80 92 D08F	188	bra backto1		
D0FD:8A	190	cmd2found	txa	;copy index of cmd to acc
D0FE:FA	191	plx		;restore X to Cn
D0FF:1D B8 03	192	ora seremode,x	;copy top 2 bits of seremode	
D102:09 08	193	ora #\$08	;& set bit 3 - 2-chr-command-mode flag	
D104:9D B8 03	194	sta seremode,x	;seremode holds index to 2-chr command	
D107:38	195	sec	;set carry so we stay in command mode	
D108:80 E0 D0EA	196	bra cmset	;for next time	
D10A:A9 D1	198	cmfound	lda #<cmdcr	;get hi byte of where to go
D10C:48	199	pha		;save it on stack
D10D:BD F5 D1	200	lda cmdtable,x	;get lo byte of where to go	
D110:48	201	pha		;save it on stack
D111:60	202	rts		;go there by RTSing
D112:28	204	cmd.c	plp	;restore status to check carry bit
D113:FA	205	pix		;restore slot number in x
D114:B0 05 D11B	206	bcs cmd.c1		;skip if enable
D116:9E B8 04	207	stz pwdth,x	;CD is same as PWDTH=0, no CR	
D119:80 C3 D0DE	208	bra cdone		;we're done here
D11B:BC 86 D1	210	cmd.c1	ldy defidx2-\$C1,x	;get y index into aux screenholes
D11E:20 2A D2	211	jsr r.getalt		;go get it from aux
D121:9D B8 04	212	sta pwdth,x		;restore default PWDTH
D124:80 B8 D0DE	213	bra cdone		;we're done here
D126:FA	215	cmdz	plx	
D127:9E B8 04	216	stz pwdth,x		;Zero escape character
D12A:A9 00	217	lda #0		;And the width
D12C:4C A2 D0	218	jmp cmdz2		
D12F: D12F	220	cmdcr	equ *	
D12F: D12F	221	cmdn	equ *	
D12F:7A	222	ply		
D130:AD 7E 04	223	lda number		;Get number inputted
D133:F0 05 D13A	224	beq cmdi2		;skip if 0
D135:99 B8 04	225	sta pwdth,y		;Update printer width
D138:F0	226	dfb \$F0		;BEQ opcode to skip next byte (the PLY)
D139: D139	227	cmdi	equ *	
D139: D139	228	cmdk	equ *	
D139: D139	229	cmdl	equ *	
D139:7A	230	ply		
D13A:B9 B8 06	231	cmdi2	lda flags,y	

```

D13D:3D 02 D2      232     and   mask1,x    ;Mask off bit we'll change
D140:1D 0D D2      233     ora    mask2,x    ;Change it
D143:99 B8 06      234     sta    flags,y    ;Back it goes
D146:98             235     tya    tax      ;Put slot back in x
D147:AA             236     tax    ;(via acc)
D148:4C DE D0      237     cdone2  jmp    cdone   ;Good bye

D14B:88             239     cmdp   dey    ;Make y point to command reg
D14C:A9 1F           240     cmdd   lda    #$1F  ;Mask off high three bits
D14E:38             241     sec    ;C=1 means high 3 bits
D14F:90             242     dfb    $80  ;BCG opcode to skip next byte
D150:A9 F0           243     cmdb   lda    #$F0  ;Mask off lower 4 bits F0 = BNE
D152:18             244     clc    ;F0 will skip this if cmdp or cmdd
D153:39 FB BF       245     and   scntl,y  ;Mask off bits being changed
D156:8D F8 06       246     sta    temp   ;Save it
D159:FA             247     plx    number  ;Get inputed number
D15A:AD 7E 04       248     lda    number  ;Only lower nibble valid
D15D:29 0F           249     and   #$0F  ;If C=1 shift to upper 3 bits
D15F:90 05  D166    250     bcc   noshift
D161:0A             251     asl    A
D162:0A             252     asl    A
D163:0A             253     asl    A
D164:0A             254     asl    A
D165:0A             255     asl    A
D166:0D F8 06       256     noshift ora   temp   ;Get the rest of the bits
D169:C8             257     iny    iiny   ;Put them in the ACIA
D16A:80 17  D183   258     bra    cmdp2  ;increment puts em away where they go.

D16C:B9 FA BF       260     cmds   lda    scomd,y  ;Transmit a break
D16F:48             261     pha    ;Save current ACIA state
D170:09 0C           262     ora    #$0C  ;Do the break
D172:99 FA BF       263     sta    scomd,y
D175:A9 E9           264     lda    #233 ;For 233 ms
D177:A2 53           265     mswait ldx    #83  ;Wait 1 ms
D179:48             266     msloop pha    pla    ;((12*82)+11)+2+3=1000us
D17A:68             267     dex    dex
D17B:CA             268     bne    msloop
D17C:D0 FB  D179   269     dec    a
D17E:3A             270     bne    mswait
D17F:D0 F6  D177   271     pla    pla
D181:68             272     pix    pix
D182:FA             273     equ    *
D183:               D183   274     cmdp2  equ    *
D183:99 FA BF       275     sta    scomd,y
D186:80 C0  D148   276     bra    cdone2

D188:               D188   278     cmdr   equ    *
D188:99 F9 BF       279     sta    sstat,y  ;Reset the ACIA
D18B:AD 7B 06       280     lda    vfactv ;Check if video firmware active
D18E:0A             281     asl    A ;Save it in C
D18F:20 97 C7       282     jsr    swsthk2 ;assume video firmware active
D192:90 03  D197   283     bcc   cmdq   ;branch if good guesser...
D194:20 9D C7       284     jsr    swzzqt2 ;Reset the hooks
D197:18             285     cmdq  clc    ;Quit terminal mode
D198:B0             286     dfb    $B0  ;BCG to skip next byte

```

```

D199:38      287 cmdat      sec          ;Into terminal mode
D19A:FA      288           plx          ;Recover X
D19B:20 A0 D1 289           jsr  setterm
D19E:80 A8   D148        bra  cdone2

D1A0:       D1A0  292 setterm  equ *      ;set/clear terminal mode
D1A0:BD B8 03  293           lda sermode,x ;Get terminal mode status
D1A3:89 40   294           bit #$40    ;Z=1 if not in terminal mode
D1A5:90 12   D1B9  295           bcc stclr   ;Branch if clearing terminal mode
D1A7:D0 20   D1C9  296           bne stwasok ;Was already set
D1A9:E4 39   297           cpx kswh    ;Are we in the input hooks
D1AB:D0 47   D1F4  298           bne strts  ;Leaves C=1 if =
D1AD:09 40   299           ora #$40    ;Set term mode bit
D1AF:AC 79 06  300           ldy oldcur  ;Save what was in oldcur
D1B2:8C 7A 06  301           sty oldcur2 ;Get new cursor value
D1B5:A0 DF   302           ldy #termcur
D1B7:80 07   D1C0  303           bra stset   ;Branch if already clear
D1B9:F0 0E   D1C9  304 stclr   beq stwasok ;Clear the bit
D1BB:29 BF   305           and #$BF    ;Restore the cursor
D1BD:AC 7A 06  306           ldy oldcur2 ;Save cursor to restore later
D1C0:9D B8 03  307 stset   sta sermode,x
D1C3:8C 79 06  308           sty oldcur
D1C6:8C FB 07  309           sty cursor
D1C9:BC 42 C1  310 stwasok ldy devno2,x
D1CC:58      311           cli          ;want to leave with interrupts active
D1CD:08      312           php          ;but off while we twittle bits
D1CE:78      313           sei          ;scmd,y
D1CF:B9 FA BF  314           lda #2      ;disable receiver interrupts if
D1D2:09 02   D1D8  315           ora cmdd2   ; not in terminal mode
D1D6:29 FD   317           and #$FD    ;enable when in terminal mode
D1D8:       D1D8  318 cmdat2  equ *
D1D8:99 FA BF  319           sta scmd,y
D1DB:A9 00   320           lda #0
D1DD:6A      321           ror a      ;set kbd interrupts according to t-mode
D1DE:8D FA 05  322           sta typded
D1E1:10 07   D1EA  323           bpl cmdd3   ;branch if leaving terminal mode
D1E3:9C 7F 05  324           stz twser   ; and ser buf...
D1E6:9C 7F 06  325           stz trser
D1E9:8A      326           txa
D1EA:8D FF 04  327 cmdd3   sta aciabuf ;use x to enable serial buffering
D1ED:28      328           plp
D1EE:8E FF 05  329 flush   stx twkey   ;restore carry, enable interrupts.
D1F1:8E FF 06  330           stx trkey   ;Flush the type ahead buffer
D1F4:60      331 strts   rts

D1F5:       333           MSB OFF      ;command routines' lo bytes
D1F5:       D1F5  334 cmdtable equ *
D1F5:38      335           dfb >cmdi-1
D1F6:38      336           dfb >cmdk-1
D1F7:38      337           dfb >cmdl-1
D1F8:2E      338           dfb >cmdn-1
D1F9:2E      339           dfb >cmdcr-1
D1FA:4F      340           dfb >cmdb-1
D1FB:4B      341           dfb >cmdd-1
D1FC:4A      342           dfb >cmdp-1
D1FD:96      343           dfb >cmdq-1

```

26 COMMAND

Command processor for serial & comm 31-MAY-85

PAGE 115

```

D1FE:87      344      dfb    >cmdr-1
D1FF:6B      345      dfb    >cmds-1
D200:98      346      dfb    >cmdt-1
D201:25      347      dfb    >cmdz-1

D202:          349 * masks for:   I   K   L   N   CR   XE   XD   FE   FD   ME   MD
D202:7F BF BF 7F 350 mask1   dfb   $7F,$BF,$BF,$7F,$FF,$DF,$EF,$EF,$F7,$F7
D202:80 00 40 00 351 mask2   dfb   $80,$00,$40,$00,$00,$20,$00,$00,$10,$00,$00

D218: D218 353 cmdlist equ   *
D218:49 4B 4C 4E 354 asc    "IKLN"
D21C:0D      355      dfb    $0D
D21D:42 44 50 51 356      asc    "BDPQRSTZ" ;cr (part of cmdlist)
D225:          D225 357 cmd2list equ   *
D225:4C 58 46 4D 358      asc    "LXFMC" ;2-chr commands' first chrs

D22A:          360 ****
D22A:          361 * R.GETALT is the same as GETALT in main rom. Only the
D22A:          362 * location is different.
D22A:          363 ****

D22A:AD 13 C0 365 r.getalt  lda   rdramrd ;save state of aux memory
D22D:0A      366      asl
D22E:AD 18 C0 367      lda   rd80col ;and the 80STORE switch
D231:08      368      php
D232:8D 00 C0 369      sta   clr80col ;no 80STORE to get page 1
D235:8D 03 C0 370      sta   rdcardram ;pop in the other half of RAM
D238:B9 78 04 371      lda   $478,y ;read the desired byte
D23B:28      372      plp
D23C:B0 03 D241 373      bcs  r.getalt1 ;and restore memory
D23E:8D 02 C0 374      sta   rdmainram
D241:10 03 D246 375 r.getalt1 bpl  r.getalt2
D243:8D 01 C0 376      sta   set80col
D246:60      377 r.getalt2 rts

D247:03 07 379 defididx2 dfb  3,7 ;same as DEFIDX in main rom.
D249:          59      include mbasic ;Mouse BASIC routines @ 2:C100

27 MBASIC      Mouse BASIC routines           31-MAY-85      PAGE 116
D249: 01B7 2      ds   $D400-* ,0

```

```

D400:
D400:
D400:      4 ****
D400:      5 *
D400:      6 * BASICIN - Input from basic
D400:      7 *
D400:      8 * Creates +XXXXX,+YYYYY,+SS
D400:      9 * XXXXX = X position
D400:     10 * YYYYY = Y position
D400:     11 * SS = Status
D400:     12 *   - = Key pressed
D400:     13 *     1 = Button pressed
D400:     14 *     2 = Button just pressed
D400:     15 *     3 = Button just released
D400:     16 *     4 = Button not pressed
D400:     17 *
D400:     18 ****
D400: D400 19 basicin equ *
D400:91 28 sta (bas1),y ;Fix flashing char
D402:A9 05 lda #>inent ;Fix input entry
D404:85 38 sta ksw1
D406:AD 00 C0 lda kbd ;test the keyboard
D409:0A 24 asl A
D40A:08 25 php ;Save kbd and int stat for later
D40B:78 26 sei ;No interrupts while getting position
D40C:20 41 D4 27 jsr xmread2
D40F:A0 05 28 ldy #5 ;Move X position into the buffer
D411:AE 7C 05 29 ldx mouxh
D414:AD 7C 04 30 lda mouxl
D417:20 5C D4 31 jsr hextodec ;Convert it
D41A:A0 0C 32 ldy #12
D41C:AE FC 05 33 ldx mouyh
D41F:AD FC 04 34 lda mouyl
D422:20 5C D4 35 jsr hextodec
D425:AD 7C 07 36 lda mousstat
D428:2A 37 rol A
D429:2A 38 rol A
D42A:2A 39 rol A
D42B:29 03 40 and #3
D42D:49 03 41 eor #3
D42F:1A 42 inc A
D430:28 43 plp ;Restore int & kbd status
D431:A0 10 44 ldy #16
D433:20 6D D4 45 jsr hexdec2 ;X=0 from last div10
D436:7A 46 ply
D437:A2 11 47 ldx #17 ;X = EOL
D439:A9 8D 48 lda #$8D ;Carriage return
D43B:9D 00 02 49 putinbuf sta inbuf,x
D43E:4C 84 C7 50 swrts2 ;Goback

D441:
D441:      52 ****
D441:      53 *
D441:      54 * XMREAD2 - duplicate of xmread
D441:      55 *
D441:      56 ****
D441: D441 57 xmread2 equ *
D441:A9 20 58 lda #movarm ;Has mouse moved?
D443:2D 7C 06 59 and mouarm

```

```

D446:1C 7C 06      60      trb    mouarm      ;Clear arm bit
D449:2C 63 C0      61      bit    moubut      ;Button pressed?
D44C:30 02 D450    62      bmi    xrbut3
D44E:09 80          63      ora    #$80
D450:2C 7C 07      64      xrbut3      bit    mousstat   ;Pressed last time?
D453:10 02 D457    65      bpl    xrbut4
D455:09 40          66      ora    #$40
D457:8D 7C 07      67      xrbut4      sta    mousstat
D45A:18              68      clc
D45B:60              69      rts
D45C:                70 ***** D45C:                71 *
D45C:                72 * HEXTODEC - Puts +0000, into the input buffer
D45C:                73 * inputs: A = Low byte of number
D45C:                74 *           X = High byte of number
D45C:                75 *           Y = Position of ones digit
D45C:                76 *
D45C:                77 *****
D45C: D45C:                78 hextodec equ  *
D45C:E0 80          79      cpx    #$80      ;Is it a negative number?
D45E:90 0D D46D    80      bcc    hexdec2
D460:49 FF          81      eor    #$FF      ;Form two's complement
D462:69 00          82      adc    #0        ;C = 1 from compare
D464:48              83      pha
D465:8A              84      txa
D466:49 FF          85      eor    #$FF
D468:69 00          86      adc    #0
D46A:AA              87      tax
D46B:68              88      pla
D46C:38              89      sec
D46D:8D 14 02      90      hexdec2 sta   binl      ;Store the number to convert
D470:8E 15 02      91      stx   binh
D473:A9 2B          92      lda   #'+'      ;Store the sign in the buffer
D475:90 02 D479    93      bcc   hdpos2
D477:A9 2D          94      lda   #'-'      ;Save the sign
D479:48              95      hdpos2 pha
D47A:A9 2C          96      lda   #' ,      ;Store a comma after the number
D47C:99 01 02      97      sta   inbuf+1,y
D47F: D47F:                98 hdloop equ  *
D47F:                99 *
D47F:                100 * Divide BINH,L by 10 and leave remainder in A
D47F:                101 *
D47F:A2 11          102      ldx   #16+1      ;16 bits and first time do nothing
D481:A9 00          103      lda   #0
D483:18              104      clc
D484:2A              105 dv10loop rol  A      ;C=0 so first ROL leaves A=0
D485:C9 0A          106      cmp   #10      ;A >= 10?
D487:90 02 D48B    107      bcc   dv10lt      ;Branch if <
D489:E9 0A          108      sbc   #10      ;C = 1 from compare and is left set
D48B:2E 14 02      109 dv10lt rol  binl
D48E:2E 15 02      110      rol  binh
D491:CA              111      dex
D492:D0 F0 D484    112      bne   dv10loop
D494:89 30          113      ora   #'0'      ;Make a ascii char
D496:99 00 02      114      sta   inbuf,y
D499:88              115      dey
D49A:F0 08 D4A4    116      beq   hddone      ;Stop on 0,6,12
D49C:C0 07          117      cpy

```

27 MBASIC

Mouse BASIC routines

31-MAY-85

PAGE 119

```
D49E:F0 04    D4A4  118      beq    hddone
D4A0:C0 0E    119      cpy    #14
D4A2:D0 DB    D47F  120      bne    hdloop
D4A4:68      121  hddone   pla    ;Get the sign
D4A5:99 00 02  122      sta    inbuf,y
D4A8:60      123      rts
D4A9:          60       include banger
```

```

D4A9:      3 * These routines test all 128K ram. All combinations of soft switches
D4A9:      4 * applicable to the //c are tested and verified.
D4A9:      5 *
D4A9:      6 * In the event of any failure, the diagnostic is halted. A message
D4A9:      7 * is written to screen memory indicating the source of the failure.
D4A9:      8 * When RAM fails the message is composed of "RAM ZP" (failure
D4A9:      9 * detected in the first page of RAM) or "RAM" (other 63.75K),
D4A9:     10 * followed by a binary representation of the failing bits set to "1".
D4A9:     11 * For example, "RAM 0 1 1 0 0 0 0" indicates bits 5 and 6 were
D4A9:     12 * detected as failing. To represent auxillary memory, a "*" symbol is
D4A9:     13 * printed preceding the message.
D4A9:     14 *
D4A9:     15 * When the MMU or IOU fail, the message is simply "MMU" or "IOU".
D4A9:     16 * If the IOUDIS or DHIRES switch fails, the message is "GLU".
D4A9:     17 *
D4A9:     18 * The test will run continuously for as long as the Open and Closed
D4A9:     19 * Apple keys remain depressed (or no keyboard is connected) and no
D4A9:     20 * failures are encountered. The message "System OK" will appear in
D4A9:     21 * the middle of the screen when a successful cycle has been run and
D4A9:     22 * either of the Apple keys are no longer depressed. Another cycle
D4A9:     23 * may be initiated by pressing both Apple keys while this message
D4A9:     24 * is on the screen. To exit diagnostics, Control-Reset must be
D4A9:     25 * pressed without the Apple keys depressed.
D4A9:     26 *
D4A9:     27 *
D4A9: 0011 28 GLUIDX EQU $11
D4A9: 0009 29 IOUIDX EQU $09
D4A9: 0001 30 MMUIDX EQU $01
D4A9: 05B8 31 SCREEN EQU $5B8
D4A9: 32 *
D4A9:8D 50 C0 33 DIAGS sta txtclr ;text mode off
D4AC:8D 78 C0 34 sta ioudsbl ;Disable IOU
D4AF:8D 5F C0 35 sta setan3 ;Double hires off
D4B2: 36 * Test Zero-Page, then all of memory. Report errors when encountered.
D4B2: 37 * Accumulator can be anything on entry. All registers used, but no
D4B2: stack.
D4B2: 38 * Addresses between $C000 and $CFFF are mapped to main $D000 bank.

D4B2:A0 04 40 TSTZPG ldy #$4
D4B4:A2 00 41 ldx #0
D4B6:18 42 zp1 clc ;fill zero page with a pattern
D4B7:79 2A C8 43 adc ntbl,y
D4BA:95 00 44 sta $00,x
D4BC:E8 45 inx
D4BD:D0 F7 D4B6 46 bne zp1 ;after all bytes filled,
D4BF:18 47 zp2 clc ; ACC has original value again.
D4C0:79 2A C8 48 adc ntbl,y ;so values can be tested
D4C3:D5 00 49 cmp $00,x
D4C5:D0 10 D4D7 50 bne ZPERROR ;branch if memory failed
D4C7:E8 51 inx
D4C8:D0 F5 D4BF 52 bne zp2 ;loop until all 256 bytes tested
D4CA:6A 53 ror a ;change ACC so location $FF will change
D4CB:20 19 C0 54 bit rdvblbar ; use RDVBL for a little randomness...
D4CE:10 02 D4D2 55 bpl zp3
D4D0:49 A5 56 eor #$A5
D4D2:88 57 zp3 dey ;use a different pattern now
D4D3:10 E1 D4B6 58 bpl zp1 ;branch to retest with other value
D4D5:30 06 D4DD 59 bmi TSTMEM2 ;branch always

```

```
D4D7:55 00      61 ZPERROR    eor    $00,x      ;which bits are bad?
D4D9:18      62 clc
D4DA:4C 73 C4    63 jmp    BADBITS
D4DD:4C C6 C3    64 TSTMEM2   JMP    TSTMEM     ;Off to the rest of it
```

```
D4E0:          D4E0    66 zznm    equ    *
D4E0:20 9D C7    67 jsr    swzzqt2    ;Get out of the hooks
D4E3:68      68 pla
D4E4:7A      69 ply
D4E5:68      70 pla
D4E6:A9 FF    71 lda    #$FF
D4E8:AA      72 tax
D4E9:E8      73 zzloop   inx
D4EA:5D F5 D4    74 eor    qtbl,x
D4ED:9D 00 02    75 sta    inbuf,x
D4F0:10 F7 D4E9    76 bpl    zzloop
D4F2:4C 84 C7    77 jmp    swrtz2
```

D4F5:AD 3B 0A 0B 79 qtbl dfb \$AD,\$3B,\$0A,\$0B,\$48,\$77,\$3E,\$05
D4FD:00 05 08 0C 80 dfb \$00,\$05,\$08,\$0C,\$1E,\$53,\$65,\$37
D505:1C 07 0C 45 81 dfb \$1C,\$07,\$0C,\$45,\$62,\$27,\$00,\$17
D50D:1C 07 07 05 82 dfb \$1C,\$07,\$07,\$05,\$4B,\$6D,\$24,\$02
D515:0E 45 61 32 83 dfb \$0E,\$45,\$61,\$32,\$18,\$02,\$07,\$1D
D51D:53 6A 2B 0C 84 dfb \$53,\$6A,\$2B,\$0C,\$08,\$16,\$53,\$68
D525:3D 06 07 1B 85 dfb \$3D,\$06,\$07,\$1B,\$01,\$E3
D52B: 61 include vectors2

```
D52B:          2 ****
D52B:          3 * VECTORS
D52B:          4 ****
D52B:          5 ds    $FFFA-*,$00
FFFA:88 07      6 dw    swreset2    ;NMI
FFFC:88 C7      7 dw    swreset2    ;RESET
FFFE:8E C7      8 dw    swirq2     ;INT
```

3D A1H	3C A1L	FE78 A1PCLP	FE75 A1PC
FE7F A1PCRTS	3F A2H	3E A2L	41 A3H
40 A3L	43 A4H	42 A4L	45 A5H
44 A5L	45 ACC	C1B3 ACIDONE	04FF ACIABUF
C24E ACIADONE	C1B4 ACIAINT	C1BA ACIAINT2	C1C2 ACIATST
FDD1 ADD	FD84 ADDINP	FBF8 ADV2	?FBF4 ADVANCE
C24C AIAUX	C208 AIEATIT	C24D AIEAT	C200 AINOFLSH
C20A AIPASS	C1DC AIPORT2	C1D6 AITST2	C01E ALTCHARSET
C91D AMOD1	C93A AMOD2	C93C AMOD3	C93B AMOD4
C94A AMOD5	C94F AMOD6	CA29 AMOD7	CA38 AMOD8
?03F5 AMPERV	C5BB APPLE2C	FB60 APPLEII	0438 ASTAT
C580 ATALK	D08F BACKT01	C473 BADBITS	C4A9 BADMAIN
C4B0 BADPRIM	C6A2 BADRD1	C6D3 BADREAD	C4CA BADSWTCH
C7C1 BANGER	2B BAS2H	2A BAS2L	FBC1 BASCALC
FBD0 BASCLC2	FEB3 BASCONT	29 BASH	E000 BASIC
E003 BASIC2	C324 BASCENT	D400 BASICIN	C317 BASICINIT
28 BASL	C47D BBITS1	C4BB BBITS2	FD71 BCKSPC
FA85 BEEPSKIP	FF3A BELL	?FBDD BELL1	FBE4 BELL2
C53F BIGLOOP	0215 BINH	0214 BINL	C329 BINPUT
FE00 BL1	FE04 BLANK	FCD0 BLAST	?C543 BLP2
C547 BLP3	C556 BLP4	4F BOOTDEV	C5F5 BOOTFAIL
3C BOOTTMP	?C326 BPRINT	CAF1 BRANCH	?FA4C BREAK
03F0 BRKV	C4CE BSWTCH1	C4D8 BSWTCH2	C4E4 BSWTCH2A
?FC10 BS	C4E7 BSWTCH3	04 BUTMODE	C061 BUTN0
C062 BUTN1	C38A C03	C307 C3COUT1	?C300 C3ENTRY
C305 C3KEYIN	FD62 CANCEL	D0DE CDONE	D148 CDONE2
?CD7D CG0	F9BA CHAR1	F9B4 CHAR2	05FE CHARBUF
0D CHARCR	C234 CHARPTR	CDCD CHK80	FBD9 CHKBELL
24 CH	C136 CHKMOU	CB4E CHKRT	C130 CHOK
FF7A CHRSRCH	FFCC CHRTBL	D0A5 CKDIG	FC9E CLEOLZ
FC46 CLEOP1	C504 CLICK	CBEE CLR0	CBFC CLR1
CBF1 CLR2	CC02 CLR3	CBC7 CLR40	C00C CLR80VID
CBDA CLR80	C000 CLR80COL	C00E CLRALTCHAR	?C058 CLRAN0
?C05A CLRAN1	?C05C CLRAN2	?C05E CLRAN3	FEE9 CLRCH
C2A5 CLRCOL	FC9C CLREOL	FC5D CLREOP1	FC44 CLREOP2
FC42 CLREOP	CBCF CLRHALF	CD9B CLRIT	CFBD CLRKB02
CC99 CLRKBD	FCA0 CLRIN	CC04 CLRPORT	?CFFF CLRRDM
F838 CLRSC2	?F832 CLRSCR	C481 CLRSTS	C491 CLRS
F83C CLRSC3	F836 CLRTOP	D11B CMD.C1	D112 CMD.C
D0FD CMD2FOUND	D225 CMD2LIST	D087 CMD2LOOP	D0F4 CMD2L
?D068 CMD2NULL	D150 CMDB	D12F CMDCR	BF CMDCUR
D14C CMDD	D139 CMDI	D13A CMDI2	D139 CMDK
D139 CMDL	D218 CMDLIST	D091 CMDLOOP	D12F CMDN
D14B CMDP	D183 CMDP2	D197 CMDQ	D188 CMDR
D16C CMDS	D1D8 CMDT2	D1EA CMDT3	D199 CMDT
D1F5 CMDTABLE	D0A2 CMDZ2	D126 CMDZ	D10A CMFOUND
C168 CMLOK	C14B CMLOOP	C18A CMNOINT	C1A1 CMNOVBL
C18E CMNOY	C170 CMNT0	C175 CMRGHT	C182 CMROK
D0EA CMSET	C155 CMXMOV	C37F CO1	FCCA COLDSTART
0738 COL	30 COLOR	FCE6 COM1	FCF5 COM2
FCFB COM3	D0BF COMINIT	D0B5 COMINIT1	D000 COMMAND
?D011 COMMAND1	C24F COMMPORT	C24C COMOUT	C200 COMSLOT
CF8C COMTBL	C348 COPYROM2	C338 COPYROM	FD6D COUT
FDF0 QOUT1	FDF6 COUTZ	FEF6 CRMON	FC62 CR
?FD8B CROUT1	FD8E CROUT	FC85 CRRTS	37 CSWH
36 CSWL	CD2A CTLADR	CD54 CTLCHAR0	CD58 CTLCHAR
FCA4 CTLDO	CD6F CTLDONE	CD71 CTLGO	CD80 CTLGO1
14 CTLNUM	CD91 CTLOFF	CD95 CTLON	CD15 CTLTAB

07FB CURSOR	C118 CVNOVBL	25 CV	C12B CVBUT
C124 CVMMOVED	FDB6 DATAOUT	FBBC DCX	FEE2 DECCH
C2B6 DEFAULT	C2DF DEFCOM	C2C7 DEFFF	C2EA DEFIDX
D247 DEFIDX2	C2BC DEFLOOP	C6D9 DENIB1	C6D7 DENIBL
C22B DEVNO	C142 DEVNO2	D4A9 DIAGS	D0AD DIGLOOP
FF8A DIG	D0C7 DISABLE	?C983 DISLIN	0356 DNIBL
CBC2 DOCLR	FBB4 DOCOUT1	FB54 DOCTL	C9D8 DOIINST
C9F4 DOLIN	C186 DONE	FD20 DONXTCUR	FECE DOPRØ
C566 DQUIT	?C60B DRV2ENT	D484 DV10LOOP	D4B8 DV10LT
D0C5 ENABLE	C219 ENTR	C111 ENTR1	F8A1 ERR
C9C9 ERR2	?C9CB ERR3	9B ESC	CCD7 ESCØ
?CCE3 ESC1	CCE5 ESC2	CCCØ ESC3	CDØC ESCCHAR
0638 ESCHAR	0013 ESCNUM	CCED ESCRDKEY	CCF8 ESCTAB
C275 EXIT1	C273 EXITX	C63D EXTENT1	?C65C EXTENT
0538 EXTINT	05F9 EXTINT2	F8ØØ F8ORG	FBB3 F8VERSION
C140 FIXCH	C8ØE FIXLC	?FA9B FIXSEV	DØ77 FLAGIT
06B8 FLAGS	?D1EE FLUSH	F962 FMT1	F9A6 FMT2
CD67 FNDCTL	2E FORMAT	?C648 FUGIT	F847 GBASCALC
27 GBASH	26 GBASL	C8C9 GBBRK	F856 CBCALC
C321 GBDONE	C8C1 GBNOC	C3ØD GBNDVR	C8C7 GBNOTROM
C346 GDEAT	C334 GDNOLF	C3ØØ GDNXDN	C348 GDOK
C393 GETALT1	C398 GETALT2	C37C GETALT	C2FD GETBUF2
C2F7 GETBUF	C3A6 GETCOUT	CCA7 GETCUR1	CCAD GETCUR2
CCB7 GETCUR3	CCBF GETCURX	CC9D GETCUR	C322 GETDATA
F8A5 GETFMT	C9E7 GETI1	FC8Ø GETINDX	C986 GETINST1
C816 GETLC	?FD6F GETLM1	FDØØ GETLNZ	?FD6A GETLN
FFA7 GETNUM	C98F GETOP	C2AC GETSTAT	CB57 GETST
C2B2 GETSTAT2	C5B4 GETUP	CEFA GETX	?CFØ6 GETY
CF38 GKEY	C826 GLCBNK1	Ø829 GLCDONE	ØØ11 GLUIDX
C5EE GOBASICIN	C8A7 GDBREAK	CB25 GODDONE	CB22 GODREG
CBØØ GODSP	C9EC GOERR2	C96E GOERR	Ø6 GOODF8
C278 GOREMOTE	FEB6 GO	C19B GOSEN3	C279 GOTERM
?FD25 GOTKEY	F8CC GOTONE	C2C1 GSTNDINT	C2B4 GSTTST
2C H2	C4C8 HANGX	C4ED HANGY	D4A4 HDDONE
D47F HDLLOOP	D479 HDPOØ2	?FCC9 HEADR	D46D HEXDEC2
D45C HEXTODEC	?CØ57 HIRES	?F819 HLINE	F81C HLINE1
FC58 HOME	CDA5 HOMECUR	CE1B HOOKITUP	CE2Ø HOOKUP
F897 IEVEN	Ø2ØØ INBUF	DØ84 INCMD1	CBØ5 INITBL
Ø2ØØ IN	DØ32 INCMD2	DØ22 INCMD	DØ3C INCMD3
FF15 INDX	C4Ø5 INENT	C41A INITMOUSE	FB2F INIT
?FE8B IMPORT	FE8D INPRT	F882 INSDS1	F88E INSDS2
F8DØ INSTDSP	CC12 INVERT	32 INVFLG	CC1C INVX
CØØØ IØADR	FEDE IOPRT1	FEAB IOPRT2	FE9B IOPRT
CØ78 IØUDSBL	CØ79 IØUENBL	ØØØØ IØUIDX	CØ58 IØU
C82A IRQ21	C826 IRQ2	C834 IRQ3	C83E IRQ4
C848 IRQ5	C85B IRQ6	C85E IRQ7	C87Ø IRQ8
C88C IRQDN1	C88E IRQDN2	C896 IRQDN3	C89C IRQDN4
C8A4 IRQDN5	C87F IRQDONE	C8Ø4 IRQENT	?Ø3FE IRQLOC
FFFF IRQVECT	?FA4Ø IRQ	C882 IRQLCOK	CF86 IRQTBLE
C663 ISMRK1	C3C3 JMPDEST	C32C JPINIT	C32F JPREAD
C335 JPSSTAT	C332 JPWRITE	CØ1Ø KBDSTRB	CØØØ KBD
FB88 KBDWAIT	FD1B KEYIN	?FD18 KEYINØ	39 KSWH
38 KSWL	CFDB LACR	CFDB LADIG	CFDE LADONE
CØØØ LCBANK1	CØØØ LCBANK2	2F LENGTH	8A LFEED
FC66 LF	Ø4ØØ LINE1	FE63 LIST2	FE5E LIST
2C LMNEM	ØØ LDCØ	Ø1 LDC1	CFC5 LOOKASC
FD38 LOOKPICK	CØ56 LORES	FE2Ø LT	FE22 LT2
? 4Ø M.4Ø	2Ø M.CTL2	ØØ M.CTL	1Ø M.CURSOR

08 M.GOXY	01 M.MOUSE	80 M.PASCAL	04 M.VMODE
44 MACSTAT	C58E MAKTbl	D202 MASK1	D20D MASK2
2E MASK	05F8 MAXH	04F8 MAXL	077D MAXXH
067D MAXXL	?07FD MAXYH	?06FD MAXYL	C400 MBASIC
C5EA MBBAD	C3D0 MEM1	C3D8 MEM2	C3F3 MEM3
C3F5 MEM4	C3FA MEM5	C405 MEM6	C412 MEM7
C42A MEM8	C42C MEM9	C431 MEMA	C440 MEMB
C44F MEMC	C456 MEMD	C472 MEMERROR	C46C MEMF
0578 MINH	C9C7 MINIERR	FE6C MINI	0478 MINL
057D MINXH	047D MINXL	?05FD MINYH	?04FD MINYL
CFA3 MIRQLP	CFBA MIRQSTD	?C052 MIXCLR	C053 MIXSET
0001 MMUIDX	F9C0 MNML	FA00 MNEMR	F8BE MNNDX1
F8C2 MNNDX2	F8C9 MNNDX3	FDAD MOD8CHK	31 MODE
FF69 MONZ	FF65 MON	067C MOUARM	C063 MOUBUT
C048 MOUCLR	?C058 MOUDSBL	?C059 MOUENBL	07FC MOUMODE
C100 MOUSEINT	CD9F MOUSOFF	CD99 MOUSON	077C MOUSTAT
0478 MOUTEMP	C066 MOUX1	057C MOUXH	C015 MOUXINT
047C MOUXL	C067 MOUY1	05FC MOUYH	C017 MOUYINT
04FC MOUYL	C972 MOV1	20 MOVARM	C34E MOVEAUX
C361 MOVEC2M	CF9A MOVEIRQ	C367 MOVELOOP	FE2C MOVE
C393 MOVERET	C367 MOVESTRT	C970 MOVINST	02 MOVMODE
C900 MPADDLE	D179 MSLOOP	07F8 MSLOT	D177 MSWAIT
CAFF NBRNCH	0300 NBUF1	FBB0 NEWADV1	FBA0 NEWADV
FA47 NEWBRK	FC99 NEWC1	FC90 NEWCLEOLZ	FC8D NEWCLREOL
FC73 NEWCR	CCCC NEWESC	C803 NEWIRQ	?FA81 NEWMON
FC38 NEWOP1	FC35 NEWOPS	CAD1 NEWPCL	FC86 NEWVTAB
FC88 NEWVTABZ	C371 NEXTA1	03FB NMI	CA3B NNBL
D020 NOCMD2	D01F NOCMD	C469 NOERROR	C254 NOESC
?FD45 NOESC1	FD4A NOESC2	FD44 NOESCAPE	FAA3 NOFIX
C5AA NOPATRN	C371 NORREAD	D166 NOSHIFT	C4E6 NOSTAT2
C36A NOT1	C1B2 NOTACIA	FD5F NOTCR1	FD4D NOTCR
CC53 NOTINV	?CC68 NOTINV1	CC6B NOTINV2	FEA7 NOTPRTO
FB94 NOWAIT	C82A NTBL	047E NUMBER	0016 NUMOPS
FCBA NXTA1	FCB4 NXTA4	FF98 NXTBAS	FF90 NXTBIT
FFA2 NXTB52	C9F8 NXTCCH	FD75 NXTCCHAR	FFAD NXTCCHR
?F85F NXTCOL	077B NXTCUR	FF73 NXTTIM	CA06 NXTMN
C9BD NXTOP	FA59 OLDBRK	047F OLDCUR	0679 OLDCUR
067A OLDCUR2	?FF59 OLDRST	D07F ONELETTER	FEC2 OPRT0
FEFE OPTBL	057B DURCH	057B OURCV	C407 OUTENT
?FE95 OUTPORT	FE97 OUTPRT	C1D5 P1ERR	C19E P1INIT
C1A8 P1READ	C1AF P1READ2	C9AD P1SKIP	C1BB P1STATUS
C1CE P1STRD	C1CC P1STWR	C1B4 P1WRITE	C211 P2INIT
C213 P2READ	C217 P2STATUS	C215 P2WRITE	C064 PADDL0
CF71 PASCLC	?CF7F PASCLC2	CC0B PASINVERT	CF35 PASREAD
C850 PASSKIP1	C23D PBFULL	C235 PBOK	F953 PCADJ
F954 PCADJ2	F956 PCADJ3	F95C PCADJ4	3B PCH
CAB4 PCINC2	CAB6 PCINC3	3A PCL	C5F8 PCNVRST
C880 PCNV	CF19 PCTL	C918 PDOK	C90D PDON
CC3D PICK1	CC33 PICK2	CC3F PICK3	CC4A PICK4
CC1D PICKY	95 PICK	CF41 PINIT	CEBC PIORDY
F800 PLOT	F80E PLOT1	CEC0 PNOTRDY	C402 PNULL
FD92 PRA1	F910 PRADR1	F914 PRADR2	F926 PRADR3
F92A PRADR4	F930 PRADRS	F94A PRBL2	?F94C PRBL3
F948 PRBLNK	FDDA PRBYTE	?FB1E PREAD	FB25 PREAD2
?FF2D PRERR	CEF7 PRET	?FDE3 PRHEX	FDE5 PRHEXZ
F8F5 PRMN1	F8F9 PRMN2	C166 PRNOW	?F941 PRNTAX
F8DB PRNTBL	C14A PRNT	F8D4 PRNTOP	?F944 PRNTX
F940 PRNTYX	33 PROMPT	FD96 PRYX2	CF66 PS1

CF54 PSEUP2	CF51 PSEUP	CF30 PSETX	C6B1 PSTATUS
C6BE PSTERR	?C070 PTRIG	C228 PUTBUF	?D43B PUTINBUF
CE3B PVMODE	04B8 PWDTH	CEDD PWR1	FAFD PWRCON
03F4 PWREDUP	CEF4 PWRET	CEC2 PWRITE	CEF1 PWITERET
FB12 PWRUP2	FAA6 PWRUP	D4F5 QTBL	CE45 QUIT
CE44 QX	D241 R.GETALT1	D246 R.GETALT2	D22A R.GETALT
?C060 RD40SW	C018 RD80COL	C01F RD80VID	C63F RDADR
C016 RDALTZP	C648 RDAT0	C6AA RDAT1	C6BA RDAT2
C6BC RDAT3	C6CB RDAT4	C6A6 RDATA	C003 RDCARDRAM
?FD35 RDCHAR	C642 RDDHDR	C656 RDHD0	C65E RDHD1
C667 RDHD2	C671 RDHD3	?C01D RDHIRES	FD0C RDKEY
C011 RDLCBNK2	C012 RDLCRAM	C002 RDMAINRAM	?C01B RDMIX
C01C RDPAGE2	C013 RDRAMRD	C014 RDRAMWRT	C685 RDSEC1
C687 RDSEC2	C68F RDSEC3	C683 RDSECT	FAE4 RDSP1
C014 RDTEXT	C019 RDVBLBAR	?FEFD READ	FAD7 REGDSP
FEBF REGZ	C961 REL1	?F938 RELADR	C955 REL
C96B REL2	FABD RESET.X	C354 RESETLC	FA62 RESET
FF3F RESTORE	?FF44 RESTR1	C641 RETRY1	C657 RETRY
FADA RGDSP1	FB02 RDNSP2	C866 RMESS	2D RMNEM
4F RNDH	4E RNDL	C028 ROMBANK	C081 ROMIN
C37B ROMOK	0478 ROMSTATE	C853 RSWTBL	CF94 RTBL
F80C RTMASK	F87F RTMSKZ	2D RTNH	CAD9 RTNJMP2
?CAD5 RTNJMP	2C RTNL	F831 RTS1	FBF7 RTS2B
FB2E RTS2D	F961 RTS2	FBFC RTS3	FCC8 RTS4B
?FC34 RTS4	?FD05 RTS4C	FE17 RTSS	?FCB3 RTS6
?FF4C SAV1	FF4A SAVE	BFFB SCNTL	BFFA SCOMD
CE58 SCR1	CE5E SCR2	CE66 SCR3	CE79 SCR4
CE82 SCR5	CE8B SCR6	CE96 SCR7	?CE8D SCR8
CEAD SCR9	05B8 SCREEN	CBB9 SCR13	CB9B SCRLEVEN
CBA2 SCRLEFT	CB6D SCRLIN	CBB0 SCRLODD	F879 SCR2
?F871 SCRIN	CE80 SCRIN48	CE53 SCRIN84	CB30 SCROLLDN
?FC70 SCROLL	CB38 SCROLLIT	CB35 SCROLLUP	BFF8 SDATA
C61F SEEKZERO	C27F SERIN	C11C SERISOUT	03B8 SERMODE
C24F SEROUT3	C18A SEROUT	C18F SEROUT2	C255 SEROUT4
C117 SERPORT	C189 SERRTS	C100 SERSLOT	C144 SERVID
CDC0 SET40	C001 SET80COL	C00D SET80VID	CDBE SET80
C00F SETALTCHAR	C009 SETALTZP	?C059 SETAN0	?C05B SETAN1
?C005D SETAN2	C05F SETAN3	C182 SETCH	?F864 SETCOL
FEEC SETCUR	FEEE SETCUR1	CB67 SETDBAS	?FB40 SETGR
CE23 SETHOOKS	FE86 SETIFLG	FE80 SETINV	?C452 SETIOU
CDA1 SETIT	FE89 SETKBD	FE1D SETMDZ	FE18 SETMODE
FE84 SETNORM	?FAA9 SETPG3	FAAB SETPLP	?FB6F SETPWRC
C360 SETROM	CB88 SETSRC	C008 SETSTDZP	D1A0 SETTERM
?FB39 SETTXT	CB83 SETUP2	C21C SETUP	FE93 SETVID
C82A SETV	FB4B SETWND	CE1A SETX	CBC1 SEV1
CC4C SHOWCUR	C5C4 SHOWINST	C28E SIDATA	C45C SILOOP
C463 SINOCH	C280 SINOKBD	C2AC SINOMOD	C205 SIN
CBA8 SKPLFT	CBB4 SKPR	2B SLOTZ	C1 SLTDMY
C86C SMESS	C46A SMINVALID	C2AA SODONE	03F2 SOFTEV
C28D SOOK	C25E SORDY	C2AB SORTS	C286 SOTST
C207 SOUT	C030 SPKR	49 SPNT	BFF9 SSTAT
CF29 STARTXY	48 STATUS	D1B9 STCLR	CA43 STEP
FE71 STEPZ	FB65 STITLE	FBF0 STORADV	C3B8 STORCH
C3DB STORE1	C3EE STORE2	?C3F2 STORE3	C3C1 STORE
C3F9 STORE5	?FE0B STOR	?C3F7 STORE4	C3B3 STORY
D1F4 STRTS	D1C0 STSET	D1C9 STWASOK	FFE3 SUBTBL
C56B SUC2	C875 SUCCESS	C22F SUDODEF	C245 SUDONE
C232 SUNODEF	C240 SUDOUT	?C7C7 SWATALK	C7AF SWAUX

C79D SWBASICIN	C4EF SWCHTST	C7A9 SWCMD	C806 SWCMD3
C537 SWERR	C7DF SWGETB	C7D3 SWGETST	C78E SWIRQ2
C7BB SWMINT	?C797 SWPCNV	C7D9 SWREAD	?C788 SWRESET
C788 SWRESET2	C780 SWRTI	?C780 SWRTI2	C784 SWRTS
C784 SWRTS2	C787 SWRTSOP	C7CD SWSER3	C797 SWSTHK2
C7F1 SWSTHK3	C7A3 SWSTTM	C7F1 SWSTTM3	C82F SWTBL0
C841 SWTBL1	C4F1 SWTST1	C4F3 SWTST2	C4FE SWTST3
C508 SWTST4	C51A SWTSTS	C521 SWTST6	C533 SWTST7
C7B5 SWXFER	?C7EB SWXFG0	C7EB SWXFG02	C7E5 SWZZNM
C79D SWZZQT2	C7F6 SWZZQT3	C15E TAB	?FB5B TABV
C592 TBLLOOP	C5A0 TBLLOOP2	05F8 TEMPA	06F8 TEMP
04F8 TEMP1	05F8 TEMPY	C27C TERM1	DF TERMCUR
C25E TESTKBD	0800 THBUF	?FB09 TITLE	C15C TOOFAR
FFBE TDOSUB	FEGF TRACE	06FF TRKEY	067F TRSER
C3C6 TSTMEM	D4DD TSTMEM2	D4B2 TSTZPG	05FF TWKEY
057F TWSER	C050 TXTCLR	C054 TXTPAGE1	C055 TXTPAGE2
C051 TXTSET	05FA TYPHED	00 UCSPACE	CC93 UD2
CC70 UPDATE	C399 UPSHIFT0	C39B UPSHIFT	FC1A UP
FECA USR	03F8 USRADR	2D V2	C070 VBLCLR
C019 VBLINT	0C VBLMODE	FE36 VERIFY	067B VFACTV
FE58 VFYOK	CE31 VIDMODE	FBFD VIDOUT	FC04 VIDOUT1
FB78 VIDWAIT	F826 VLINEZ	F828 VLINE	04FB VMODE
FC22 VTAB	FB59 VTAB23	FC30 VTAB40	FC24 VTABZ
FCA9 WAIT2	FCAA WAIT3	FCA8 WAIT	FEEB WDTCH
CDD5 WIN0	CDE0 WIN1	CDED WIN2	CDF2 WIN3
CE02 WIN4	CDD2 WIN40	CE18 WINS	CDD4 WIN80
23 WNDBTM	20 WNDLFT	CE0A WNDREST	22 WNDTOP
21 WNDWDTH	C005 WRCARDRAM	?FECD WRITE	C004 WRMAINRAM
CD8D X.CUR.OFF	CD89 X.CUR.ON	CDB7 X.SI	CDB0 X.SO
C3A5 X.UPSHIFT	FDB3 XAM	FDA3 XAM8	FDC6 XAMPM
FE80 XBASIC	C8E6 XBITKBD	C8F9 XBKB1	C8FB XBKB2
CAA6 XBRK	06FB XCORD	C3C0 XFERAZP	C3AA XFERC2M
C3B0 XFERZP	C397 XFER	CAC9 XJMPAT	CAE3 XJMPATX
CAC8 XJMP	CAC0 XJSR	CAEE XJXNOC	C5CF XMBASIC
C5DC XMBOUT	C48E XMCDONE	C4BD XMCLAMP	C482 XMCLEAR
C1AD XMDONE	C471 XMH2	C46F XMHLOOP	C46B XMHOME
C4B6 XMRD2	C493 XMREAD	D441 XMREAD2	C4DC XMTSTINT
CBD4 XNOKEY	C2D5 XNOSBUF	93 XOFF	91 XON
CA98 XQ1	CA9A XQ2	CA64 XQINIT	CA50 XQNDBT0
CA90 XQNTBRA	3C XQT	CA4A XQWAIT	C4AA XRBUT
C4B1 XRBUT2	D450 XRBUT3	D457 XRBUT4	C2F4 XRDDONE
C8D5 XRDKBD	C2E9 XRDNOBUF	C2C3 XRDSER	C2C9 XRDSER2
D0DB XREADY	46 XREG	C8CC XRKBD1	C421 XRLLOOP
CAAC XRTI	CAB0 XRTS	C43B XSETMOU	C450 XSOFF
?C100 XXX	0008 YHI	47 YREG	34 YSAV
35 YSAV1	FFC7 ZMODE	D4B6 ZP1	D4BF ZP2
D4D2 ZP3	D4D7 ZPERROR	D4E9 ZZLOOP	D4E0 ZZNM

** SUCCESSFUL ASSEMBLY := NO ERRORS
 ** ASSEMBLER CREATED ON 30-APR-85 22:46
 ** TOTAL LINES ASSEMBLED 5727
 ** FREE SPACE PAGE COUNT 38

```
SOURCE FILE #01 =>PC
INCLUDE FILE #02 =>PC.EQUATES
INCLUDE FILE #03 =>PC.BOOTSPACE
INCLUDE FILE #04 =>PC.BOOT
INCLUDE FILE #05 =>PC.PACKET
INCLUDE FILE #06 =>PC.CREAD
INCLUDE FILE #07 =>PC.MAIN

0000:    0001      1 IIC      equ   1           ;Which machine?
0000:    0001      2 ROM      equ   1           ;RAM or ROM based
0000:    C000      3 TheOrg   equ   $C000
0000:    1000      4 version  equ   $1000
0000:          5       lst    nou
0000:          6   *
0000: 0001      7       ifeq   IIC
0000:          9       else
```

```
0000:      11      fin
0000:      12      *
0000: 0001  13      X6502
0000:      14      *
0000:      15      *
0000:      16      *
0000:      17      *
0000:      18      *
0000: 19 ; PPPP RRRR 000 TTTT 000 CCC 000 L
0000: 20 ; P P R R O O T O O C C O O L
0000: 21 ; PPPP RRRR O O T O O C C O O L
0000: 22 ; P R R O O T O O C C O O L
0000: 23 ; P R R 000 T 000 CCC 000 LLLL
0000: 24 ;
0000: 25 ; CCC 000 N N V V EEEEE RRRR TTTTT EEEEE RRRR
0000: 26 ; C C O O NN N V V E R R T E R R
0000: 27 ; C O O N N N V V EEEEE RRRR T EEEE RRRR
0000: 28 ; C C O O N NN V V E R R T E R R
0000: 29 ; CCC 000 N N V EEEEE R R T EEEEE R R
0000: 30 ;
```

```
0000: 32 *
0000: 33 *      UniDisk 3.5 Driver Firmware Version 1.0
0000: 34 *
0000: 35 *      Written by Michael Askins x6243 May 15, 1985
0000: 36 *
0000: 37 *      Copyright Apple Computer, Inc. 1985
0000: 38 *      All Rights Reserved
0000: 39 *
0000: 40 *
0000: 41      MSB ON
0000: 42 *
```

```

0000: 44 ****
0000: 45 *
0000: 46 * Modification History:
0000: 47 *
0000: 48 * Rel Date Who Action
0000: 49 * -----
0000: 50 * *** 18 Dec 84 MSA RELEASE VERSION 0.02 (Sony) *
0000: 51 * 10 Jan 85 MSA Added //c support: *
0000: 52 * General conditional assembly overhead *
0000: 53 * 16 Jan 85 MSA Added retries and timeouts *
0000: 54 * MSlot handled correctly *
0000: 55 * Finished Boot code *
0000: 56 * Altered ProDOS errors - add $27 catchall *
0000: 57 * 18 Jan 85 MSA Remove call to WAIT in monitor *
0000: 58 * Add Boot failure messages *
0000: 59 * 22 Jan 85 MSA Add IWM reconfigure for //c version *
0000: 60 * 23 Jan 85 MSA Move Comm routines to $C800 ($C900) *
0000: 61 * Fixed zero page preservation *
0000: 62 * *** 23 Jan 85 MSA RELEASE VERSION 0.03 (Apple) *
0000: 63 * 25 Jan 85 MSA Swap slot dep read and boot code //c) *
0000: 64 * Add other //c differences...
0000: 65 * 30 Jan 85 MSA Add auxtype byte *
0000: 66 * Fix comm error on receive packet *
0000: 67 * Fix checksum to include MSBs of overhead *
0000: 68 * 07 Feb 85 MSA Add COUT support on boot fail *
0000: 69 * *** 08 Feb 85 MSA RELEASE VERSION 1.00A (alpha) *
0000: 70 * 22 Feb 85 MSA Add bytecount in X,Y on PC calls *
0000: 71 * Change hard reset time to 1 ms (was 83) *
0000: 72 * Crunched code by adding ClrPhases *
0000: 73 * Add zeroing of third block byte (ProDOS) *
0000: 74 * 06 Mar 85 MSA Fixed slot 7 goof (stack screw up) *
0000: 75 * No clear phases on retries *
0000: 76 * Hard reset time to 40 ms *
0000: 77 * Pass #parms instead of unit# and no chk *
0000: 78 * Init code (all reset vs. comm reset) *
0000: 79 * Add 2 bytes to pass a full 9 byte cmd *
0000: 80 * 16 Mar 85 MSA Fix bytecount on retries *
0000: 81 * Boot block must be $800=$01, $801<>$00 *
0000: 82 * 17 Mar 85 MSA Remove WRREQ while waiting for motor TO *
0000: 83 * Remove glitch on /ENBL2 in AssignID *
0000: 84 * 20 Mar 85 MSA Add interrupt on/off/poll support *
0000: 85 * Reset pulse to 80 ms *
0000: 86 * //c delay of 100 ms on initial AssignID *
0000: 87 * ID bytes changed *
0000: 88 * Retransmit implemented (RecPack) *
0000: 89 * Add send data packet retries (5) *
0000: 90 * Rearrange PC stack adjust *
0000: 91 * Add //c Appletalk vector *
0000: 92 * 24 Mar 85 MSA Add //c millisecond wait each call *
0000: 93 * *** 25 Mar 85 MSA RELEASE VERSION 1.00B (beta) //e) *
0000: 94 * 18 Apr 85 MSA Clear decimal mode *
0000: 95 * Eight bytes are returned on stat unit#0 *
0000: 96 * Stat Unit#0 scode<>0 is rejected *
0000: 97 * X and Y set to 0008 on status unit#0 *
0000: 98 * Enable interrupts done correctly *
0000: 99 * Add unit#0 parameter count checking *
0000: 100 * *** 22 Apr 85 MSA RELEASE VERSION 1.01B *
0000: 101 * *** 15 May 85 MSA RELEASE VERSION 1.0 *

```

01 PC

Protocol Converter Code for A//c 04-JUN-85 PAGE 4

```
0000: 102 *
0000: 103 ****
0000: 104 *
0000: 105 *
0000: 106     include pc.equates *
```

```

0000:          2 *
0000: 00BF 3 PDIDByte equ $BF ;ProDOS attributes byte
0000: 0000 4 PCID2 equ $0 ;This means a Liron card
0000:          5 *
0000:          6 ****
0000:          7 *
0000:          8 * Zero Page (temps) *
0000:          9 *
0000:          10 ****
0000:          11 *
0000:          12 dsect
0000: 0040 13 zeropage equ $0040
0040: 0040 org zeropage
0040:          15 *
0040:00 16 checksum dfb 0
0041:00 17 topbits dfb 0
0042:00 18 CMDCode dfb 0
0043: 0043 19 CMDCPCount equ *
0043:00 20 CMDCUnit dfb 0 ;ProDOS parameter passing area
0044: 0044 21 CMDBuffer equ *
0044:00 22 CMDBuffer1 dfb 0
0045:00 23 CMDBufferh dfb 0
0046: 0046 24 CMDSCode equ *
0046: 0046 25 CMDBlock equ *
0046:00 26 CMDBlock1 dfb 0
0047:00 27 CMDBlockh dfb 0
0048:00 28 CMDBlocks dfb 0
0049:00 29 CMDSpare1 dfb 0
004A:00 30 CMDSpare2 dfb 0
004B: 004B 31 rcvbuf equ *
004B:00 32 grp7ctr dfb 0
004C:00 33 oddbytes dfb 0
004D: 004D 34 statbyte equ *
004D: 004D 35 bytecount equ *
004D: 004D 36 bytecount1 equ *
004D: 004D 37 next equ *
004D:00 38 next1 dfb 0
004E: 004E 39 AuxType equ *
004E: 004E 40 bytecountn equ *
004E:00 41 next2 dfb 0
004F: 004F 42 RPacketType equ *
004F:00 43 next3 dfb 0
0050: 0050 44 DeviceID equ *
0050:00 45 next4 dfb 0
0051: 0051 46 HostID equ *
0051:00 47 next5 dfb 0
0052: 0052 48 pointer equ *
0052:00 49 next6 dfb 0
0053:00 50 next7 dfb 0
0054:00 00 51 buffer dw 0
0056: 0056 52 auxptr equ *
0056:00 00 53 buffer2 dw 0
0058:00 54 slot dfb 0
0059: 0059 55 temp equ *
0059:00 56 tbodd dfb 0
005A:00 57 Unit dfb 0 ;Current target unit
005B:00 58 WPacketType dfb 0
005C:          59 *

```

```

005C:          60 *
005C: 001C 61 ZPSize    equ   *-zeropage
005C:          62 *
005C:          63 *
0000:          64      dend
0000:          65 *
0000: CFFF 66 ClearIORDOMs equ $CFFF
0000: 0100 67 stack     equ   $100
0000:          68 *
0000:          69 *
0000: 70 ***** *-zeropage
0000:          71 *
0000:          72 * Screenhole Storage *
0000:          73 * *
0000: 74 ***** *
0000:          75 *
0000: 76 * The screenhole layout is as follows:
0000:          77 *
0000:          78 *           //e           //c
0000:          79 *
0000:          80 * ProFlag    $478+n    $478
0000:          81 * Retry      $4F8+n    $4F8
0000:          82 * SHTemp1   $578+n    $578
0000:          83 * SHTempX   $5F8+n    $5F8
0000:          84 * SHTempY   $678+n    $678
0000:          85 * Power1    $6F8+n    ---
0000:          86 * Power2    $778+n    ---
0000:          87 * NumDevices $7F8+n    $6FE
0000:          88 * SvBcL     $6F8      $6F8
0000:          89 * SvBcH     $778      $778
0000:          90 *
0000: 0001 91      do     IIC
0000: 0473 92 scholes  equ   $473      ;Use the slot 0 sholes for temps
0000:          93      else
0000:          95      fin
0000:          96 *
0000: 0473 97 ProFlag  equ   scholes
0000: 04F3 98 Retry    equ   scholes+$80
0000: 0573 99 SHTemp1  equ   scholes+$100
0000: 0573 100 Retry2   equ   SHTemp1
0000: 05F3 101 SHTempX  equ   scholes+$180
0000: 0673 102 SHTempY  equ   scholes+$200
0000: 0001 103      ifeq  IIC
0000:          107      else
0000: 06F9 108 NumDevices equ   $6F9      ;Actually in slot 6
0000:          109      fin
0000:          110 *
0000: 06F8 111 SvBcL   equ   $6F8
0000: 0778 112 SvBcH   equ   $778
0000:          113 *
0000: 0025 114 cv      equ   $25
0000: 0024 115 ch      equ   $24
0000: FC22 116 vtab    equ   $FC22
0000: FDED 117 cout    equ   $FDED
0000: 07DB 118 bootscrn equ   $7DB
0000: 07F8 119 MSlot   equ   $7F8
0000: FE93 120 setvid  equ   $FE93
0000: FE89 121 setkbd  equ   $FE89

```

```

0000: FABA 122 AutoScan equ $FABA
0000: E000 123 Basic equ $E000
0000: 0000 124 loc0 equ $0 ;Boot parms
0000: 0001 125 loc1 equ $1 ;
0000: 126 *
0000: C797 127 SWPROTO equ $C797 ;//c bank switch to $C800
0000: C784 128 SWRTS2 equ $C784 ;RTS to bank 1
0000: 129 *
0000: 130 *
0000: 131 ****
0000: 132 *
0000: 133 * General Equates *
0000: 134 *
0000: 135 ****
0000: 136 *
0000: 00A5 137 PBBValue equ $A5 ;Powerup Byte Base Value
0000: 00FF 138 PBCValue equ $FF ;Powerup Byte Complement Value
0000: 139 *
0000: 0000 140 PowerReset equ $00
0000: 0080 141 CommReset equ $80
0000: 142 *
0000: 0032 143 bsyto1 equ 50 ;(.55 ms) T/0 on /BSY before send
0000: 000A 144 bsyto2 equ 10 ;(.12 ms) T/0 on /BSY after send
0000: 001E 145 statmto equ 30 ;30 bytes stat mark timeout
0000: 0009 146 cmdlength equ 9 ;Command packet length
0000: 00C3 147 packetbeg equ $C3 ;Mark at beginning of packet
0000: 00C8 148 packetend equ $C8 ;End of packet mark
0000: 0080 149 cmdmark equ $80 ;Command packet identifier
0000: 0081 150 statmark equ $81 ;Status Packet identifier
0000: 0082 151 datamark equ $82 ;Data Packet identifier
0000: 152 *
0000: 0007 153 iwmmodem equ $07 ;No timer, asynch, latch
0000: 154 *
0000: 0000 155 SCDeviceStat equ 0 ;Get Device Specific Status
0000: 0001 156 SCGetDCB equ 1 ;Get Dev Ctrl Block (modebits)
0000: 0002 157 SCRetNLStat equ 2 ;Return Newline Status
0000: 0003 158 SCGetDevInfo equ 3 ;Get Device Info Block
0000: 159 *
0000: C080 160 iwm equ $C080
0000: 161 *
0000: C080 162 reqclr equ iwm+0
0000: C081 163 reqset equ iwm+1
0000: C082 164 ca1clr equ iwm+2
0000: C083 165 ca1set equ iwm+3
0000: C084 166 ca2clr equ iwm+4
0000: C085 167 ca2set equ iwm+5
0000: C086 168 lstrbclr equ iwm+6
0000: C087 169 lstrbset equ iwm+7
0000: C088 170 monclr equ iwm+8
0000: C089 171 monset equ iwm+9
0000: C08A 172 enable1 equ iwm+10
0000: C08B 173 enable2 equ iwm+11
0000: C08C 174 16clr equ iwm+12
0000: C08D 175 16set equ iwm+13
0000: C08E 176 17clr equ iwm+14
0000: C08F 177 17set equ iwm+15
0000: 178 *
0000: 179 *

```

```

0000:          180 * Error0 codes
0000:          181 *
0000: 0001 182 noanswer equ 1
0000: 0002 183 nomark equ 2
0000: 0004 184 wasreset equ 4
0000: 0008 185 bytecmp equ 8
0000: 0010 186 csumerr equ $10
0000: 0020 187 nopackend equ $20
0000: 0040 188 bushog equ $40
0000:
0000:          189 *
0000:          190 * Command Codes
0000:          191 *
0000: 0000 192 StatusCmd equ $00
0000: 0001 193 ReadCmd equ $01
0000: 0002 194 WriteCmd equ $02
0000: 0003 195 FormatCmd equ $03
0000: 0004 196 ControlCmd equ $04
0000: 0005 197 InitCmd equ $05
0000:
0000:          198 *
0000:          199 *
0000: 0040 200 Soft     equ %01000000 ;The soft error bit in statbyte
0000:          201 *
0000: 0001 202 BadCmd   equ $01
0000: 0004 203 BadPCnt  equ $04
0000: 0006 204 BusErr   equ $06
0000: 0011 205 BadUnit  equ $11
0000: 001F 206 NoInt    equ $1F
0000: 0021 207 BadCtl   equ $21
0000: 0022 208 BadCtlParm equ $22
0000: 0027 209 IOError   equ $27
0000: 0028 210 NoDrive  equ $28
0000: 002B 211 WriteProt equ $2B
0000: 002D 212 BadBlock  equ $2D
0000: 002F 213 OffLine  equ $2F
0000: 0068 214 LastOne  equ Soft+NoDrive
0000: 0067 215 SoftError equ Soft+IOError
0000:
0000:          216 *
0000: 0010 217 SVMask1 equ $10
0000:          218 *
0000: 0BB8 219 RC1     equ 3000 ;Send a command pack 3000 times (3 sec)
0000: 0005 220 RC2     equ 5   ;Data Packs (sent/rcd) get tried only 5
0000:          times
0000:
0000:          221 *
0000:          222 *
0000:          107 *
0000: 0001 108 do      IIC^ROM ;If //c ROM start is $C500
--- NEXT OBJECT FILE NAME IS CPC.0
C500:  C500 109 org    $C500
C500: 110 else
C500: 116 fin
C500: 117 *
C500: 118 include pc.bootspace

```

```
C500:      2 *1st off
C500:      3 *
C500: 0001    4       ifeq  IIC^ROM      ;If NOT the //c ROM version, do this
C500:      937     fin
C500:      938 *
```

03 PC.BOOTSPACE Slot 5 Boot Code Space 04-JUN-85 PAGE 10

```

C500:      940 *
C500: 0001    941      do    IIC
C500: 0060    942 TheOff   equ    $60      ;On //c IWM in slot 6
C500:      943      else
C500:      945      fin
C500:      946 *
C500:      947 *list on
C500:      948 *
C500:      949 * Here beginneth that code which resideth in the boot space
C500:      950 * at the time the card resteth in slot the fifth.
C500:      951 *
C500: C500 952 C500org  equ   *
C500:      953 *
C500:      954 * Auto Boot signature bytes
C500:      955 * This is also the boot (auto & PR#5) entry point.
C500:      956 *
C500:A2 20  957      ldx    #$20
C502:A2 00  958      ldx    #$00
C504:A2 03  959      ldx    #$03
C506:      960 *
C506:C9 00  961      cmp    #0      ;Flag that this is a boot
C508: 0001    962      do    IIC^ROM
C508:B0 17  C521 963      bcs   BootC
C50A:      964      else
C50A:      966      fin
C50A:      967 *
C50A:      968 * Here is the ProDOS normal entry point
C50A:      969 *
C50A: C50A 970 ProDOSEntry equ *
C50A:      971 *
C50A:      972 * Set up so that ProFLAG will have the top bit set
C50A:      973 *
C50A:38     974      sec
C50B:B0 01  C50E 975      bcs   *+3      ;Skip the clear
C50D:      976 *
C50D:      977 * This is the MLIXface entry point
C50D:      978 *
C50D: C50D 979 MLIXEntry equ   *      ;Only use this label in //c version
C50D:18     980      clc
C50E:A2 05  981      ldx    #$05
C510:7E 73 04 982      ror    ProFLAG,x      ;ProFLAG[7]=1 if ProDOS, =0 if MLI
C513:18     983      clc      ;This is not a boot entry
C514:      984 *
C514:      985 * Now save mslot and clear all $C800 ROMs
C514:      986 *
C514: C514 987 bootcase5 equ   *
C514:A2 C5  988      ldx    #$C5      ;Load value for MSLOT
C516:8E F8 07 989      stx    MSlot
C519:A2 05  990      ldx    #$05
C51B:AD FF CF 991      lda    ClearIORDOMs      ;Clear all $C800 latches but ours
C51E:      992 *
C51E: 0001    993      do    IIC^ROM
C51E:4C 97 C7  994      jmp    SWPROTO
C521:  C521 995 BootC  equ   *
C521:A2 05  996      ldx    #$05      ;Need slot number
C523:      997      else
C523:      1189      fin
C523:      1190 *

```

03 PC.BOOTSPACE Slot 5 Boot Code Space 04-JUN-85 PAGE 11

```
C523:      1191 * 1st off
C523:      1192 *
C523: 0001 1193      ifeq IIC^ROM      ;If not the //c ROM, more boot spaces
C523:      1658      fin
C523:      1659 *1st on
C523:      119 *
C523: 0001 120      do IIC^ROM
C523:      121      include pc.boot
```

```

C523:      2 *
C523: C523  3 Bootcode equ   *
C523:86 58  4       stx   slot
C525:      5 *
C525:0001  6       do    IIC^ROM
C525:A9 C5  7       lda   #$C5
C527:8D F8 07  8       sta   MSlot
C52A:20 76 C5  9       jsr   reset
C52D:      10      else
C52D:      14      fin
C52D:      15 *
C52D:A0 05  16      ldy   #5           ;Copy a command table
C52F:B9 70 C5 17 bc1   lda   boottab,y
C532:99 42 00 18      sta   cmdcode,y
C535:88          19      dey
C536:10 F7  C52F 20      bpl   bc1
C538:      21 *
C538:      22 * Now on //e, patch the Unit number (slot*16)
C538:      23 *
C538: 0001  24      ifeq  IIC^ROM
C538:      31      fin
C538:      32 *
C538:      33 * Now do the read from block zero
C538:      34 *
C538: 0001  35      do    IIC^ROM
C538:20 0A C5 36      jsr   ProDOSEntry
C53B:      37      else
C53B:      39      fin
C53B:B0 15  C552 40      bcs   bootfail ;If fail, check loc
C53D:      41 *
C53D:AE 00 08 42      ldx   $800 ;If ($800)<>1 this is no A// boot disk
C540:CA          43      dex
C541:D0 0F  C552 44      bne   bootfail
C543:      45 *
C543:AE 01 08 46      ldx   $801 ;If $801 is zero, no boot
C546:F0 0A  C552 47      beq   bootfail
C548:      48 *
C548:      49 * It all looks okay. Jump to the code with N0 in X.
C548:      50 *
C548:A5 58  51      lda   Slot
C54A:0A          52      asl   a
C54B:0A          53      asl   a
C54C:0A          54      asl   a
C54D:0A          55      asl   a
C54E:AA          56      tax
C54F:4C 01 08 57      jmp   $801 ;Jump to it
C552:      58 *
C552:      59 * Do this code if the boot can't be done.
C552:      60 * If this was an autoboot (loc=$CN00), continue the slot scan.
C552:      61 * If not, drop into basic after issuing appropriate message
C552:      62 *
C552:      63 *
C552: 0552  64 bootfail equ   *
C552:      65 *
C552: 0001  66      do    IIC
C552:A2 10  67      ldx   #>bmsglen-1
C554: 0554  68 mrochrs equ   *
C554:BD 5F C5 69      lda   bootmsg,x

```

04 PC.BOOT	Service Boot Request	04-JUN-85	PAGE 13
C557:9D DB 07	70	sta bootscrn,x	
C55A:CA	71	dex	
C55B:10 F7 C554	72	bpl mrochrs	
C55D:80 FE C55D	73	coma bra coma	;He's dead Jim.
C55F:	74 *		
C55F:C3 E8 E5 E3	75	bootmsg asc 'Check Disk Drive.'	
C570: 0011	76	bmsglen equ *-bootmsg	
C570:	77	else	
C570:	131	fin	
C570:	132 *		
C570:01 50 00 08	133	boottab dfb ReadCMD,\$50,0,8,0,0 ;Read from 1st; blk0->\$801	
C576:	134 *		
C576:	135 *		
C576:	136 * This routine is called from the //c reset code. It forces a		
C576:	137 * reset of the PC Bus.		
C576:	138 *		
C576: 0001	139	do IIc^ROM	
C576: C576	140	Reset equ *	
C576:A2 08	141	lidx #8	
C578: C578	142	rst1 equ *	
C578:BD 83 C5	143	lda rcode,x	
C57B:95 00	144	sta loc0,x	
C57D:CA	145	dex	
C57E:10 F8 C578	146	bpl rst1	
C580:4C 00 00	147	jmp loc0	
C583:	148 *		
C583: C583	149	rcode equ *	
C583:20 0D C5	150	jsr MLIEntry	
C586:05	151	dfb InitCMD	
C587:07 00	152	dw \$0007	
C589:60	153	rts	
C58A:	154 *		
C58A:01 00	155	cmdlist dfb 1,0 ;One parm - the unit \$00	
C58C:	156	fin	
C58C:	157 *		
C58C:	158 *		
--- NEXT OBJECT FILE NAME IS CPC.1			
C5F5: C5F5	122	org \$C5F5	
C5F5:4C 52 C5	123	jmp bootfail ;Jump to the boot failure message	
C5F8:4C 76 C5	124	jmp reset ;Reset vector	
C5FB:00	125	dfb PCID2	
C5FC:00 00	126	dw 0	
C5FE:BF	127	dfb PDIDByte	
C5FF:0A	128	dfb >ProDOSEntry	
C600:	129 *		
--- NEXT OBJECT FILE NAME IS CPC.2			
C880: C880	130	org \$C880	
C880:4C 4B CD	131	jmp Entry ;The //c bank switch jumps here	
C883:4C E8 CF	132	jmp AppleTalkEntry	
C886:	133	fin	
C886:	134 *		
C886:	135	include pc.packet	
C886:	1	1st cyc	
C886:	2 *		

```

C886:          4 ****
C886:          5 *
C886:          6 *      SendOnePack           Send a CBus Packet   *
C886:          7 *
C886:          8 *      This routine sends a packet of data across the   *
C886:          9 *      bus. The protocol is as follows:                 *
C886:         10 *-----*
C886:         11 *      REQ -----|2                         5|-----* *
C886:         12 *-----*
C886:         13 *      /BSY  ____|1                         3             4|-----* *
C886:         14 *
C886:         15 *      1) Device signals ready for data           *
C886:         16 *      2) Host signals data imminent            *
C886:         17 *      3) Packet is transmitted (sync, command mark,   *
C886:         18 *              ids, contents, checksum [msb=1])    *
C886:         19 *      4) Device signals packet received        *
C886:         20 *      5) Host finishes send data cycle       *
C886:         21 *
C886:         22 *      The bytes are sent in slow mode (32 cycles/byte)  *
C886:         23 *      and the timing is critical. Branches which should  *
C886:         24 *      not cross page boundaries are marked.           *
C886:         25 *
C886:         26 *      Input:  buffer (2 bytes) <- ptr to data to send   *
C886:         27 *              bytecount (2)      <- length (bytes) of data  *
C886:         28 *              packettype (1)     <- command or data packet  *
C886:         29 *              CMDUnit (1)      <- # of device to receive   *
C886:         30 *
C886:         31 *      Output: carry set- handshake error          *
C886:         32 *                  clr- bytes sent                *
C886:         33 *
C886:         34 ****
C886:         35 *
C886:         36 SendOnePack equ *
C886:         37 *
C886:         38 * Prep for the transmission
C886:         39 *
C886:20 64 CB  (6) 40 jsr WritePrep ;Does a bunch of stuff
C889:         41 *
C889:         42 * Enable PC chain.
C889:         43 *
C889:20 80 CA  (6) 44 jsr enablechain ;This sets X reg
C88C:A0 07  (2) 45 ldy #iwmmodem ;This is the mode value
C88E:20 1F CC  (6) 46 jsr SetIWMMode ;Don't mess unless we gotta
C891:         47 *
C891:         48 * Turn on the IWM
C891:         49 *
C891:BD 8B C0  (4) 50 lda enable2,x ;Don't disturb //c internal drive
C894:BD 89 C0  (4) 51 lda monset,x
C897:         52 *
C897:         53 * Loop until the chain becomes unbusy
C897:         54 *
C897:A0 32  (2) 55 ldy #bsyto1 ;Each loop is 11 microseconds
C899:BD 8E C0  (4) 56 ubsy1 lda 17cir,x ;Test if /BSY is hi or lo
C89C:30 07  C8A5(3) 57 bmi chainunbsy ;If hi, bus is not busy
C89E:88  (2) 58 dey
C89F:D0 F8  C899(3) 59 bne ubsy1 ;Keep trying
C8A1:         60 *
C8A1:38  (2) 61 sec

```

```

C8A2:4C CF C9    (3)  62      jmp    sd10
C8A5:          63 *
C8A5:          64 * Tell the bus that data is coming and send the sync bytes
C8A5:          65 * Sync is groups of eight 2's separated by a 6 (micS cell)
C8A5:          66 * (1111111001111111001111111100 ...)
C8A5:          67 *
C8A5:          C8A5  68 chainunbsy equ *
C8A5:BD 81 C0    (4)  69      lda    reqset,x ;Raise REQ
C8A8:          70 *
C8A8:A0 05    (2)  71      ldy    #5           ;Sync plus packet begin
C8AA:          72 *
C8AA:A9 FF    (2)  73      lda    #$FF         ;Send out the 1st byte sync
C8AC:9D 8F C0    (5)  74      sta    17set,x
C8AF:          75 *
C8AF:B9 D6 C9    (4)  76      ssb   lda    preamble,y
C8B2:          77 *
C8B2:          78 *
C8B2:1E 8C C0    (7)  79      ssd   asl    16clr,x ;Wait 'til buffer empty
C8B5:90 FB    C8B2(3) 80      bcc   ssd
C8B7:          81 *
C8B7:9D 8D C0    (5)  82      sta    16set,x
C8BA:88    (2)  83      dey
C8BB:10 F2    C8AF(3) 84      bpl   ssb           ;Back for more bytes
C8BD:          85 *
C8BD:          86 * Send over the destination ID
C8BD:          87 *
C8BD:A5 5A    (3)  88      lda    Unit
C8BF:09 80    (2)  89      ora    #$80         ;Make the device ID
C8C1:20 53 CA  (6)  90      jsr    sendbyte
C8C4:          91 *
C8C4:          92 * Send the source ID (that's us... we're an $80)
C8C4:          93 *
C8C4:20 51 CA  (6)  94      jsr    send80
C8C7:          95 *
C8C7:          96 * Send over the packet type (command or data)
C8C7:          97 *
C8C7:A5 5B    (3)  98      lda    Wpackettype
C8C9:20 53 CA  (6)  99      jsr    sendbyte
C8CC:          100 *
C8CC:          101 * Send the Auxilliary Type byte (an $80 from this rev PC)
C8CC:          102 *
C8CC:20 51 CA  (6)  103     jsr    send80
C8CF:          104 *
C8CF:          105 * Send the status byte (null for us), and length bytes
C8CF:          106 *
C8CF:20 51 CA  (6)  107     jsr    send80
C8D2:A5 4C    (3)  108     lda    oddbytes
C8D4:09 80    (2)  109     ora    #$80
C8D6:20 53 CA  (6)  110     jsr    sendbyte
C8D9:A5 4B    (3)  111     lda    grp7ctr
C8DB:09 80    (2)  112     ora    #$80
C8DD:20 53 CA  (6)  113     jsr    sendbyte
C8E0:          114 *
C8E0:          115 * Now send the "oddbytes" part of the packet contents
C8E0:          116 *
C8E0:A5 4C    (3)  117     lda    oddbytes ;Get # of "odd" bytes
C8E2:F0 15    C8F9(3) 118     beq    sob2 ;Skip if no odd bytes
C8E4:          119 *

```

```

C8E4:A0 FF      (2) 120      ldy    #$FF
C8E6:A5 59      (3) 121      lda    tbodd      ;Get the odd bytes msb's (A[7]=1)
C8E8:          122      *
C8E8:1E 8C C0    (7) 123      sob1   asl    16clr,x  ;Do a write handshake
C8EB:90 FB      C8E8(3) 124      bcc    sob1
C8ED:9D 8D C0    (5) 125      sta    16set,x
C8F0:C8          (2) 126      iny
C8F1:B1 54      (5) 127      lda    (buffer),y ;Get the data byte
C8F3:09 80      (2) 128      ora    #$80      ;Flip on the hi bit
C8F5:C4 40      (3) 129      cpy    oddbytes ;Are we done?
C8F7:90 EF      C8E8(3) 130      blt    sob1
C8F9:          131      *
C8F9:          132      * Now send over the groups of seven contents
C8F9:          133      * Currently assume there must be at least one group of 'em
C8F9:          134      *
C8F9:          C8F9 135      sob2   equ    *
C8F9:A5 4B      (3) 136      lda    grp7ctr ;Check if there are groups to send
C8FB:D0 03      C900(3) 137      bne    sob3      ;=> At least one group
C8FD:4C 99 C9    (3) 138      jmp    datdone ;Skip to send checksum
C900:          139      *
C900:          C900 140      sob3   equ    *
C900:EA          (2) 141      nop    ;Waste 2 cycles
C901:A0 00      (2) 142      ldy    #0
C903:A5 41      (3) 143      start   lda    topbits
C905:9D 8D C0    (5) 144      sta    16set,x
C908:          145      *
C908:          146      * Send first byte
C908:          147      *
C908:A5 4D      (3) 148      lda    next1
C90A:09 80      (2) 149      ora    #$80
C90C:84 59      (3) 150      sty    temp      ;Swap Y for short handshake
C90E:BC 8C C0    (4) 151      ache1   ldy    16clr,x ;Wait 'til buffer ready
C911:10 FB      C90E(3) 152      bpl    ache1
C913:9D 8D C0    (5) 153      sta    16set,x ;Send the byte
C916:A4 59      (3) 154      ldy    temp      ;Get back Y
C918:          155      *
C918:          156      * Prep the next "1st" byte for next time
C918:          157      *
C918:B1 56      (5) 158      lda    (buffer2),y
C91A:85 4D      (3) 159      sta    next1
C91C:0A          (2) 160      asl    a
C91D:26 41      (5) 161      rol    topbits ;Store the top bit
C91F:C8          (2) 162      iny
C920:          163      *
C920:          164      * It's possible that we're at a page boundary now. If so, bump the
C920:          165      * hi order part of the pointer.
C920:          166      *
C920:D0 05      C927(3) 167      bne    skip1
C922:E6 57      (5) 168      inc    buffer2+1
C924:4C 29 C9    (3) 169      jmp    skip2
C927:48          (3) 170      skip1   pha      ;Equalize the cases
C928:68          (4) 171      pla
C929:          172      *
C929:          173      * Push us ahead by an additional 8 cycles for margin reasons
C929:          174      * Plus I gotta get the topbits MSB set somehow...
C929:          175      *
C929:          C929 176      skip2   equ    *
C929:A9 02      (2) 177      lda    #%00000010 ;Flip what will be MSB

```

```

C92B:05 41      (3) 178      ora    topbits
C92D:85 41      (3) 179      sta    topbits
C92F:
          180 *
          181 * Send the second byte
C92F:
          182 *
C92F:A5 4E      (3) 183      lda    next2
C931:09 80      (2) 184      ora    #$80
C933:9D 8D C0    (5) 185      sta    16set,x      ;Send the byte
C936:B1 56      (5) 186      lda    (buffer2),y
C938:85 4E      (3) 187      sta    next2
C93A:0A          (2) 188      asl    a
C93B:26 41      (5) 189      rol    topbits      ;Store the top bit
C93D:C8          (2) 190      iny    ;Next byte
C93E:
          191 *
          192 * Send the third byte
C93E:
          193 *
C93E:A5 4F      (3) 194      lda    next3
C940:09 80      (2) 195      ora    #$80
C942:9D 8D C0    (5) 196      sta    16set,x      ;Send the byte
C945:B1 56      (5) 197      lda    (buffer2),y
C947:85 4F      (3) 198      sta    next3
C949:0A          (2) 199      asl    a
C94A:26 41      (5) 200      rol    topbits      ;Store the top bit
C94C:08          (2) 201      iny    ;Next byte
C94D:
          202 *
C94D:
          203 * Send the fourth byte
C94D:
          204 *
C94D:A5 50      (3) 205      lda    next4
C94F:09 80      (2) 206      ora    #$80
C951:9D 8D C0    (5) 207      sta    16set,x      ;Send the byte
C954:B1 56      (5) 208      lda    (buffer2),y
C956:85 50      (3) 209      sta    next4
C958:0A          (2) 210      asl    a
C959:26 41      (5) 211      rol    topbits      ;Store the top bit
C95B:C8          (2) 212      iny    ;Next byte
C95C:
          213 *
          214 * After the first 256 bytes, we will cross pages here. If we did
          215 * cross, bump the buffer pointer. If not, equalize the cases with
          216 * seven cycles of time wasting.
          217 *
C95C:D0 05      C963(3) 218      bne    skip3
C95E:E6 57      (5) 219      inc    buffer2+1
C960:4C 65 C9    (3) 220      jmp    skip4
C963:48          (3) 221      skip3 pha
C964:68          (4) 222      pla
C965:      C965 223      skip4 equ   *
C965:
          224 *
          225 * Send the fifth byte
C965:
          226 *
C965:A5 51      (3) 227      lda    next5
C967:09 80      (2) 228      ora    #$80
C969:9D 8D C0    (5) 229      sta    16set,x      ;Send the byte
C96C:B1 56      (5) 230      lda    (buffer2),y
C96E:85 51      (3) 231      sta    next5
C970:0A          (2) 232      asl    a
C971:26 41      (5) 233      rol    topbits      ;Store the top bit
C973:C8          (2) 234      iny    ;Next byte
C974:      235 *

```

```

C974:          236 * Send the sixth byte
C974:          237 *
C974:A5 52     (3) 238      lda    next6
C976:09 80     (2) 239      ora    #$80
C978:9D 8D C0   (5) 240      sta    16set,x      ;Send the byte
C97B:B1 56     (5) 241      lda    (buffer2),y
C97D:85 52     (3) 242      sta    next6
C97F:0A        (2) 243      asl    a
C980:26 41     (5) 244      rol    topbits      ;Store the top bit
C982:C8        (2) 245      iny    ;Next byte
C983:          246 *
C983:          247 * Send the last byte of the group
C983:          248 *
C983:A5 53     (3) 249      lda    next7
C985:09 80     (2) 250      ora    #$80
C987:9D 8D C0   (5) 251      sta    16set,x      ;Send the byte
C98A:B1 56     (5) 252      lda    (buffer2),y
C98C:85 53     (3) 253      sta    next7
C98E:0A        (2) 254      asl    a
C98F:26 41     (5) 255      rol    topbits      ;Store the top bit
C991:C8        (2) 256      iny    ;Next byte
C992:          257 *
C992:          258 * Now see if we have sent enough groups of seven
C992:          259 *
C992:C6 4B     (5) 260      dec    grp7ctr
C994:F0 03     C999(3) 261      beq    datdone
C996:          262 *
C996:          263 * Otherwise, back to do more. Note it's too far for a branch.
C996:          264 *
C996:4C 03 C9   (3) 265      jmp    start
C999:          266 *
C999:          267 * Whew! Now send the damn checksum as two FM bytes
C999:          268 *
C999:          C999 269 datdone equ  *
C999:A5 40     (3) 270      lda    checksum      ;c7 c6 c5 c4 c3 c2 c1 c0
C99B:09 AA     (2) 271      ora    #$AA          ; 1 c6 1 c4 1 c2 1 c0
C99D:BC BC C0   (4) 272  scm1  ldy    16clr,x
C9A0:10 FB     C99D(3) 273      bpl    scm1          ;Handshake this byte
C9A2:9D 8D C0   (5) 274      sta    16set,x      ;These are even bits
C9A5:          275 *
C9A5:A5 40     (3) 276      lda    checksum      ;c7 c6 c5 c4 c3 c2 c1 c0
C9A7:4A        (2) 277      lsr    a              ; 0 c7 c6 c5 c4 c3 c2 c1
C9A8:09 AA     (2) 278      ora    #$AA          ; 1 c7 1 c5 1 c3 1 c1
C9AA:20 53 CA   (6) 279      jsr    sendbyte
C9AD:          280 *
C9AD:          281 * Send the end of packet mark
C9AD:          282 *
C9AD:A9 C8     (2) 283      lda    #packetend
C9AF:20 53 CA   (6) 284      jsr    sendbyte
C9B2:          285 *
C9B2:          286 * Wait until write underflow
C9B2:          287 *
C9B2:BD BC C0   (4) 288  sd7   lda    16clr,x
C9B5:29 40     (2) 289      and    #$40
C9B7:D0 F9     C9B2(3) 290      bne    sd7          ;Still writing data
C9B9:          291 *
C9B9:9D 8D C0   (5) 292      sta    16set,x      ;Back to sense mode (dummy write)
C9BC:          293 *

```

```
C9BC:          294 * Now wait until the drive acknowledges receipt of the
C9BC:          295 * string or until timeout
C9BC:          296 *
C9B0:A0 0A      (2) 297     ldy    #bsyto2      ;Load timeout to see bsy low
C9BE:88      (2) 298 patch1 dey      ;A little closer to an error
C9BF:D0 08  C9C9(3) 299     bne    sd9      ;There's still time
C9C1:          300 *
C9C1:          301 * Too much time has elapsed. Drive didn't get string.
C9C1:          302 *
C9C1:A9 01      (2) 303     lda    #noanswer    ;Report error in comm error byte
C9C3:          C9C3 304 dberror equ  *
C9C3:20 9A CA    (6) 305     jsr    SetXN0      ;For dberror entry
C9C6:38      (2) 306     sec      ;Signal a problem
C9C7:B0 06  C9CF(3) 307     bcs    sd10
C9C9:          308 *
C9C9:          309 * See if drive has acknowledged the bytes yet
C9C9:          310 *
C9C9:BD 8E C0    (4) 311 sd9     lda    17clr,x      ;Wait 'til /BSY lo
C9CC:30 F0  C9BE(3) 312     bmi    patch1
C9CE:          313 *
C9CE:          314 * Finish the sequence
C9CE:          315 *
C9CE:18      (2) 316     cic      ;This is a normal exit
C9CF:BD 80 C0    (4) 317 sd10    lda    reqclr,x      ;Set REQ lo
C9D2:BD 8C C0    (4) 318     lda    16clr,x      ;Back into read mode
C9D5:          319 *
C9D5:          320 * Pull back the bytecount in all cases
C9D5:          321 *
C9D5:60      (6) 322     rts
C9D6:          323 *
C9D6:          324 *
C9D6:          325 * This table, when sent in reverse order, provides a
C9D6:          326 * sync pattern used to synchronize the drive IWM with
C9D6:          327 * the data stream. The first byte (last sent) is the
C9D6:          328 * packet begin mark.
C9D6:          329 *
C9D6:C3      330 preamble dfb packetbeg
C9D7:FF FC F3 CF 331 synctab dfb $FF,$FC,$F3,$CF,$3F
C9DC:          332 *
C9DC:          333 *
```

```
C9DC:          335 *
C9DC:          336 * These routines are for wasting specific amounts of time
C9DC:          337 * This code segment should not cross page boundaries.
C9DC:          338 *
C9DC:20 E1 C9  (6) 339 waste32 jsr  waste14
C9DF:EA      (2) 340 waste18 nop
C9E0:EA      (2) 341 waste16 nop
C9E1:EA      (2) 342 waste14 nop
C9E2:60      (6) 343 waste12 rts
C9E3:          344 *
C9E3:          345 *
C9E3:          C9E3 346 markerr equ  *
C9E3:4C C3 C9  (3) 347     jmp    dberror
```

```

C9E6:      349 ****
C9E6:      350 *
C9E6:      351 *   ReceivePack      Get a packet from bus resident *
C9E6:      352 *
C9E6:      353 *
C9E6:      354 *   REQ ____|2          5|_____*_
C9E6:      355 *
C9E6:      356 *   /BSY ___|1          3          4|_____*_
C9E6:      357 *
C9E6:      358 *     1) Drive signals ready to send packet *
C9E6:      359 *     2) Host signals ready to receive data *
C9E6:      360 *     3) Packet is transmitted (sync, mark, IDs, data, *
C9E6:           checksum [msb=1])
C9E6:      361 *
C9E6:      362 *     4) Drive signals packet dispatched *
C9E6:      363 *     5) Host acknowledges receipt of packet *
C9E6:      364 *
C9E6:      365 *     The bytes are sent in slow mode (32 cycles/byte) *
C9E6:      366 *     and the timing is critical. Branches which should *
C9E6:           not cross page boundaries are marked. *
C9E6:      367 *
C9E6:      368 *
C9E6:      369 *     Input: buffer <- address where packet guts left *
C9E6:      370 *
C9E6:      371 *     Output: carry set- handshake error *
C9E6:           cir- bytes received *
C9E6:           A <- error# if carry set *
C9E6:      374 *
C9E6:      375 ****
C9E6:      376 *
C9E6:      377 grabstatus equ *
C9E6:      378 ReceivePack equ *
C9E6:      379 *
C9E6:      380 * Init the checksum *
C9E6:      381 *
C9E6:A9 00  (2) 382     lda    #$00
C9E8:85 40  (3) 383     sta    checksum
C9EA:      384 *
C9EA:      385 * Copy over buffer -> buffer2
C9EA:      386 *
C9EA:A5 54  (3) 387     lda    buffer
C9EC:85 56  (3) 388     sta    buffer2
C9EE:A5 55  (3) 389     lda    buffer+1
C9F0:85 57  (3) 390     sta    buffer2+1
C9F2:      391 *
C9F2:      392 * Set up the indirect pointer for jump to 2nd part of code
C9F2:      393 *
C9F2:      0001 394     ifeq  IIc^ROM      ;Don't do in //c version
C9F2:           fin
C9F2:      402 *
C9F2:20 80 CA  (6) 403     jsr    enablechain ;Set X register to $N0
C9F5:      404 *
C9F5:BD 8D C0  (4) 405     lda    16set,x      ;Prep for sense mode
C9F8:      406 *
C9F8:      407 * Now wait for BSY to go hi, signalling 'ready w/ status'
C9F8:      408 *
C9F8:BD 8E C0  (4) 409 rdh1  lda    17clr,x      ;Read sense
C9FB:10 FB  C9FB(3) 410     bpl    rdh1        ;Wait till a high
C9FD:      411 *
C9FD:      412 * Signal Liron we're ready to receive

```

```

C9FD:          413 *
C9FD:BD 81 C0  (4) 414      lda    reqset,x      ;Raise /REQ
CA00:          415 *
CA00:          416 * Wait for a byte from Liron or timeout
CA00:          417 *
CA00:A0 1E     (2) 418      ldy    #statmto      ;Max bytes 'til stat mark
CA02:BD 8C C0  (4) 419      rdh2   lda    16clr,x
CA05:10 FB    CA02(3) 420      bpl    rdh2       ;*** No Page Cross ***
CA07:88      (2) 421      dey
CA08:30 D9    C9E3(3) 422      bmi    markerr      ;Didn't find a packet in time
CA0A:          423 *
CA0A:          424 * Is it the beginning of the packet?
CA0A:          425 *
CA0A:C9 C3     (2) 426      cmp    #packetbeg    ;Find the packet begin mark
CA0C:D0 F4    CA02(3) 427      bne    rdh2       ;Back again - no timeout for now
CA0E:          428 *
CA0E:          429 * Okay load up the table with this stuff
CA0E:          430 *
CA0E:          CA0E   431      rdh5   equ    *
CA0E:          432 *
CA0E:A0 06     (2) 433      ldy    #6           ;Seven bytes of overhead
CA10:BD 8C C0  (4) 434      rdh3   lda    16clr,x
CA13:10 FB    CA10(3) 435      bpl    rdh3       ;*** No Page Cross ***
CA15:29 7F     (2) 436      and    #%01111111
CA17:99 4B 00  (5) 437      sta    rcvbuf,y
CA1A:49 80     (2) 438      eor    #$80       ;Pop MSB back on for checksum
CA1C:45 40     (3) 439      eor    checksum
CA1E:85 40     (3) 440      sta    checksum
CA20:88      (2) 441      dey
CA21:10 ED    CA10(3) 442      bpl    rdh3
CA23:          443 *
CA23:          444 * Set groups of seven buffer pointer buffer2
CA23:          445 *
CA23:A5 4C     (3) 446      lda    oddbytes
CA25:F0 27    CA4E(3) 447      beq    start2      ;Skip alteration if no oddbytes
CA27:18      (2) 448      clc
CA28:65 54     (3) 449      adc    buffer
CA2A:85 56     (3) 450      sta    buffer2
CA2C:A5 55     (3) 451      lda    buffer+1
CA2E:69 00     (2) 452      adc    #0
CA30:85 57     (3) 453      sta    buffer2+1
CA32:          454 *
CA32:A0 00     (2) 455      ldy    #0
CA34:          456 *
CA34:          457 * Now receive the odd bytes
CA34:          458 *
CA34:BD 8C C0  (4) 459      start0 lda    16clr,x      ;Read in the odd bytes topbits
CA37:10 FB    CA34(3) 460      bpl    start0
CA39:0A      (2) 461      asl    a           ;Pop off the start bit
CA3A:85 41     (3) 462      sta    topbits
CA3C:          CA3C   463      start1 equ    *
CA3C:BD 8C C0  (4) 464      lda    16clr,x      ;Get an odd byte
CA3F:10 FB    CA3C(3) 465      bpl    start1
CA41:06 41     (5) 466      asl    topbits
CA43:B0 02    CA47(3) 467      bcs    gob1       ;If MSB set, leave start bit
CA45:49 80     (2) 468      eor    #$80       ;MSB clear- flip start bit
CA47:91 54     (6) 469      gob1  sta    (buffer),y
CA49:C8      (2) 470      iny
                                         ;Squirrel it away
                                         ;Next spot

```

```

CA4A:C4 4C      (3) 471      cpy    oddbytes   ;Are we done?
CA4C:90 EE  CA3C(3) 472      bit    start1     ;If more, branch
CA4E:          473 *
CA4E:          CA4E  474 start2 equ   *
CA4E:          0001  475      do     IIC^ROM
CA4E:4C 72 CC  (3) 476      jmp    SlotDepRd
CA51:          477      else
CA51:          479      fin
CA51:          480 *
CA51:          CA51  481 Send80 equ   *
CA51:A9 80  (2) 482      lda    #$80
CA53:          CA53  483 SendByte equ   *
CA53:BC 8C C0  (4) 484      ldy    16clr,x
CA56:10 FB  CA53(3) 485      bpl    SendByte
CA58:9D 8D C0  (5) 486      sta    16set,x
CA5B:45 40  (3) 487      eor    checksum
CA5D:85 40  (3) 488      sta    checksum
CA5F:60  (6) 489      rts
CA60:          490 *
CA60:          491 *
CA60:          492 *
CA60:          493 *
CA60:          CA60  494 resetchain equ   *
CA60:20 8A CA  (6) 495      jsr    ClrPhases
CA63:BD 81 C0  (4) 496      lda    reqset,x
CA66:BD 85 C0  (4) 497      lda    ca2set,x
CA69:A0 50  (2) 498      ldy    #80           ;Hard reset for 80 ms
CA6B:20 73 CA  (6) 499      jsr    YMSWait
CA6E:          500 *
CA6E:20 8A CA  (6) 501      jsr    ClrPhases
CA71:          502 *
CA71:A0 0A  (2) 503      ldy    #10           ;About 10 mS reset time!
CA73:          504 *
CA73:          CA73  505 YMSWait equ   *
CA73:20 7A CA  (6) 506      jsr    OneMS
CA76:88  (2) 507      dey
CA77:D0 FA  CA73(3) 508      bne    YMSWait
CA79:60  (6) 509      rts
CA7A:          510 *
CA7A:          CA7A  511 OneMS equ   *
CA7A:A2 C8  (2) 512      ldx    #200
CA7C:CA  (2) 513 onems1 dex
CA7D:D0 FD  CA7C(3) 514      bne    onems1
CA7F:60  (6) 515      rts
CA80:          516 *
CA80:          517 *
CA80:          CA80  518 enablechain equ   *
CA80:20 9A CA  (6) 519      jsr    SetXN0
CA83:BD 83 C0  (4) 520      lda    ca1set,x
CA86:BD 87 C0  (4) 521      lda    lstrbset,x
CA89:60  (6) 522      rts
CA8A:          523 *
CA8A:          524 *
CA8A:          CA8A  525 ClrPhases equ   *
CA8A:20 9A CA  (6) 526      jsr    SetXN0
CA8D:BD 80 C0  (4) 527      lda    reqclr,x
CA90:BD 82 C0  (4) 528      lda    ca1clr,x
CA93:BD 84 C0  (4) 529      lda    ca2clr,x

```

```
C96:BD 86 C0    (4) 530      lda    lstrbclr,x
C99:60    (6) 531      rts
C9A:
C9A:      532 *
C9A:      533 *
C9A:      C9A   534 SetXN0 equ    *
C9A:      0001  535      do     IIC
C9A:A2 60    (2) 536      idx    #$60
C9C:
C9C:      537      else
C9C:      544      fin
C9C:      545 *
C9C:60    (6) 546      rts
C9D:
C9D:      547 *
C9D:      548 * Shift tables for use when reading. Each table should not
C9D:      549 * straddle pages.
C9D:      550 *
C9D:80 80 80 80  551 shift1 dfb   $80,$80,$80,$80,$80,$80,$80,$80
CAA5:00 00 00 00  552      dfb   0,0,0,0,0,0,0,0
CAAD:80 80 80 80  553 shift2 dfb   $80,$80,$80,$80,0,0,0,0
CAB5:80 80 80 80  554      dfb   $80,$80,$80,$80,0,0,0,0
CABD:80 80 00 00  555 shift3 dfb   $80,$80,0,0,$80,$80,0,0
CAC5:80 80 00 00  556      dfb   $80,$80,0,0,$80,$80,0,0
CACD:80 00 80 00  557 shift4 dfb   $80,0,$80,0,$80,0,$80,0
CAD5:80 00 80 00  558      dfb   $80,0,$80,0,$80,0,$80,0
CADD:
CADD:      559 *
CADD:      560 *
```

```

CADD:          562 *
CADD:      CADD  563 SendData equ *
CADD:A9 05    (2) 564 lda   #>RC2
CADD:A0 00    (2) 565 ldy   #<RC2
CAE1:20 00 CB (6) 566 jsr   SendPile
CAE4:90 05 CAEB(3) 567 bcc   sdoubt
CAE6:A9 80    (2) 568 lda   #CommReset
CAE8:20 90 CF (6) 569 jsr   AssignID
CAEB:      CAEB  570 sdoubt equ *
CAEB:60    (6) 571 rts
CAEC:          572 *
CAEC:          573 *
CAEC:      CAEC  574 SendPack equ *
CAEC:20 00 CB (6) 575 jsr   SendPile ;Try to send a pack
CAEF:90 FA CAEB(3) 576 bcc   sdoubt
CAF1:A9 80    (2) 577 lda   #CommReset ;This is a communications failure
CAF3:20 90 CF (6) 578 jsr   AssignID ;Reset to try again
CAF6:          579 *
CAF6:AD F8 06 (4) 580 lda   SvBcL ;Get back the packetlength
CAF9:85 4D    (3) 581 sta   bytecountl
CAF8:AD 78 07 (4) 582 lda   SvBcH
CAFE:85 4E    (3) 583 sta   bytecounth
CB00:          584 *
CB00:      CB00  585 SendPile equ *
CB00:A9 B8    (2) 586 lda   #>RC1 ;Retry count (big!)
CB02:A0 0B    (2) 587 ldy   #<RC1
CB04:          588 *
CB04:      CB04  589 AltSendPile equ *
CB04:A6 58    (3) 590 ldx   slot
CB06:9D F3 04 (5) 591 sta   Retry,x
CB09:98    (2) 592 tya
CB0A:9D 73 05 (5) 593 sta   Retry2,x
CB0D:          594 *
CB0D:          595 * SendPack destroys the bytecount
CB0D:          596 *
CB0D:      CB0D  597 spile1 equ *
CB0D:A5 4D    (3) 598 lda   bytecountl
CB0F:8D F8 06 (4) 599 sta   SvBcL
CB12:A5 4E    (3) 600 lda   bytecounth
CB14:8D 78 07 (4) 601 sta   SvBcH
CB17:          602 *
CB17:20 86 CB (6) 603 jsr   SendOnePack ;Send the packet
CB1A:          604 *
CB1A:AD F8 06 (4) 605 lda   SvBcL
CB1D:85 4D    (3) 606 sta   bytecountl
CB1F:AD 78 07 (4) 607 lda   SvBcH
CB22:85 4E    (3) 608 sta   bytecounth
CB24:          609 *
CB24:90 0C CB32(3) 610 bcc   spilout
CB26:A6 58    (3) 611 ldx   slot
CB28:DE F3 04 (7) 612 dec   Retry,x
CB2B:D0 E0 CB0D(3) 613 bne   spile1
CB2D:DE 73 05 (7) 614 dec   Retry2,x
CB30:10 DB CB0D(3) 615 bpl   spile1 ;If all fails, carry is set
CB32:60    (6) 616 spilout rts
CB33:          617 *
CB33:      CB33  618 RecPack equ *
CB33:A4 58    (3) 619 ldy   Slot

```

```
CB35:A9 05      (2) 620      lda    #>RC2
CB37:99 F3 04      (5) 621      sta    Retry,y
CB3A:           CB3A      622 rpk1  equ    *
CB3A:20 E6 C9      (6) 623      jsr    ReceivePack
CB3D:90 0F      CB4E(3) 624      bcc    rpout
CB3F:A0 01      (2) 625      ldy    #1
CB41:20 73 CA      (6) 626      jsr    YMSWait
CB44:20 C3 C9      (6) 627      jsr    dberror ;Recycle handshake and set carry
CB47:A6 58      (3) 628      idx    Slot
CB49:DE F3 04      (7) 629      dec    Retry,x
CB4C:D0 EC      CB3A(3) 630      bne    rpk1   ;Carry set still
CB4E:           CB4E      631 rpout equ    *
CB4E:60      (6) 632      rts    *
CB4F:           633 *      *
CB4F:           634 *
```

```

CB4F:          636 ****
CB4F:          637 *
CB4F:          638 * Divide7           Do DIV and MOD 7 and set auxptr *
CB4F:          639 *
CB4F:          640 * This routine divides the bytecount by seven. The *
CB4F:          641 * quotient gives the number of groups of seven bytes to *
CB4F:          642 * be sent, and the remainder gives the number of "odd" *
CB4F:          643 * bytes.
CB4F:          644 *
CB4F:          645 * Input:   bytecount,h <- # of bytes to write
CB4F:          646 *           buffer      <- pointer to data
CB4F:          647 * Output:  auxptr      <- pointer to speed up csumming
CB4F:          648 *           oddbytes    <- bytecount MOD 7
CB4F:          649 *           grp7ctr     <- bytecount DIV 7
CB4F:          650 *
CB4F:          651 ****
CB4F:          652 *
CB4F: 00 24 49 653 pdiv7tab dfb 0,36,73
CB52:00 04 01 654 pmod7tab dfb 0,4,1
CB55:00 01 02 04 655 div7tab dfb 0,1,2,4,9,18
CB5B:00 01 02 04 656 mod7tab dfb 0,1,2,4,1,2
CB61:
CB61:00 7F FF 658 auxptrinc dfb 0,$7F,$FF
CB64:
CB64:          CB64 659 *
CB64:          CB64 660 WritePrep equ *
CB64:          CB64 661 Divide7 equ *
CB64:
CB64:          662 *
CB64:          663 * Set up auxptr <- buffer+$80  if $0FF < bytecount < $200
CB64:          664 *         or auxptr <- buffer+$100 if $1FF < bytecount
CB64:          665 *
CB64:A6 4E    (3) 666   ldx   bytecounth ;0, 1 or 2
CB66:F0 13    CB7B(3) 667   beq   noauxptr ;Auxptr used only for full pages
CB68:
CB68:A5 55    (3) 668 *
CB6A:85 57    (3) 669   lda   buffer+1
CB6A:85 57    (3) 670   sta   auxptr+1 ;Copy over hi order part
CB6C:
CB6C:A9 80    (2) 671   *
CB6C:A9 80    (2) 672   lda   #$80 ;Anticipate smaller bytecount
CB6E:E0 01    (2) 673   cpx   #1 ;Check bytecount
CB70:F0 04    CB76(3) 674   beq   sap1 ;=> $0FF < bytecount < $200
CB72:
CB72:E6 57    (5) 675   *
CB72:A9 00    (2) 676   inc   auxptr+1 ;Add $100 to bytecount instead
CB74:A9 00    (2) 677   lda   #0 ;Make sure lo order unaltered
CB76:18:
CB77:65 54    (3) 678   sap1  clc
CB77:65 54    (3) 679   adc   buffer
CB79:85 56    (3) 680   sta   auxptr
CB7B:
CB7B:          681 *
CB7B:          682 * Now look up the first order guess for DIV and MOD. X still has
CB7B:          683 * bytecount DIV 256.
CB7B:
CB7B:          CB7B 684 *
CB7B:          685 noauxptr equ *
CB7B:BD 4F CB  (4) 686   lda   pdiv7tab,x
CB7E:85 4B    (3) 687   sta   grp7ctr
CB80:BD 52 CB  (4) 688   lda   pmod7tab,x
CB83:85 4C    (3) 689   sta   oddbytes
CB85:
CB85:          690 *
CB85:          691 * Now add in the mods and divs for each of the five hi order
CB85:          692 * bits in the lo order bytecount, correcting each time MOD becomes
CB85:          693 * bigger than 6.

```

```

CB85:          694 *
CB85:A2 05    (2) 695      ldx   #5           ;Do for five bits
CB87:A5 4D    (3) 696      lda   bytecountl
CB89:85 59    (3) 697      sta   temp         ;Store lo order for shifting
CB8B:29 07    (2) 698      and   #%00000111  ;Save lo three for later
CB8D:A8      (2) 699      tay
CB8E:          700 *
CB8E:          CB8E 701 divide3 equ  *
CB8E:06 59    (5) 702      asl   temp         ;C <- next from bytecountl
CB90:90 15    CBA7(3) 703      bcc   divide2
CB92:BD 5B CB  (4) 704      lda   mod7tab,x  ;If clear, no effect on DIV,MOD
CB95:          CB95 705 divide4 equ  *
CB95:18    (2) 706      clc
CB96:65 4C    (3) 707      adc   oddbytes   ;Got new MOD value
CB98:09 07    (2) 708      cmp   #7           ;Is it too big?
CB9A:90 02    CB9E(3) 709      blt   divide1   ;=> NO leave MOD - 0->C
CB9C:E9 07    (2) 710      sbc   #7           ;Bring MOD under 7 - C still set
CB9E:          CB9E 711 divide1 equ  *
CB9E:85 4C    (3) 712      sta   oddbytes
CBA0:BD 55 CB  (4) 713      lda   div7tab,x  ;Get DIV for this 2^n
CBA3:65 4B    (3) 714      adc   grp7ctr   ;Add to DIV along with correction (C)
CBA5:85 4B    (3) 715      sta   grp7ctr   ;Update the DIV
CBA7:          CBA7 716 divide2 equ  *
CBA7:CA    (2) 717      dex
CBA8:30 06    CBB0(3) 718      bmi   divide5
CBA8:D0 E2    CB8E(3) 719      bne   divide3   ;One less bit to deal with
CBAC:          720 *
CBAC:98    (2) 721      tya
CBAD:4C 95 CB  (3) 722      jmp   divide4   ;Escape after 6 times through loop
CBB0:          723 *
CBB0:          CBB0 724 divide5 equ  *
CBB0:          725 *
CBB0:          726 *

```

```

CBB0:          728 ****
CBB0:          729 *
CBB0:          730 * PreCheck           Does the checksumming prepass *
CBB0:          731 *
CBB0:          732 *   Input: bytecount <- bytes in buffer
CBB0:          733 *           buffer    <- pointer to data to send
CBB0:          734 *           auxptr   <- extra pointer to speed process
CBB0:          735 *   Output: checksum <- 8 bit XOR of data to be sent
CBB0:          736 *
CBB0:          737 ****
CBB0:          738 *
CBB0: CBB0 739 PreCheck equ *
CBB0:          740 *
CBB0:          741 * Checksum any full pages
CBB0:          742 *
CBB0:A5 55     (3) 743      lda   buffer+1
CBB2:48        (3) 744      pha   ;Preserve buffer pointer
CBB3:A9 00      (2) 745      lda   #0
CBB5:A6 4E      (3) 746      ldx   bytecount
CBB7:F0 16      CBCF(3) 747      beq   lastpass ;If no complete pages, skip this
CBB9:          CBB9 748 xor2   equ   *
CBB9:BC 61 CB   (4) 749      ldy   auxptrinc,x ;Get number of bytes each ptr
CBBB:          CBBC 750 xor1   equ   *
CBBC:51 54      (5) 751      eor   (buffer),y
CBBC:51 56      (5) 752      eor   (auxptr),y
CBC0:88        (2) 753      dey   ;One less
CBC1:D0 F9      CBBC(3) 754      bne   xor1
CBC3:51 54      (5) 755      eor   (buffer),y
CBC5:51 56      (5) 756      eor   (auxptr),y ;Have to deal with 0 case
CBC7:          757 *
CBC7:          758 * Now move the buffer up for next section
CBC7:          759 *
CBC7:E0 01      (2) 760      cpx   #1
CBC9:F0 02      CBCD(3) 761      beq   xor5 ;If 256 and up bytes, bump x1
CBCB:E6 55      (5) 762      inc   buffer+1 ; otherwise x2
CBCD:E6 55      (5) 763 xor5   inc   buffer+1
CBCF:          *
CBCF:          CBCF 765 lastpass equ *
CBCF:          766 *
CBCF:          767 * Do the remaining less than a page with a single pointer
CBCF:          768 *
CBCF:A4 4D      (3) 769      ldy   bytecount
CBD1:F0 09      CBDC(3) 770      beq   xor4
CBD3:51 54      (5) 771      eor   (buffer),y ;Compensate for nth byte
CBD5:51 54      (5) 772 xor3   eor   (buffer),y
CBD7:88        (2) 773      dey   ;
CBD8:D0 FB      CBD5(3) 774      bne   xor3
CBD9:51 54      (5) 775      eor   (buffer),y ;Last damn (0th) byte
CBDC:          776 *
CBDC:          777 * Store result away. Retrieve old buffer value.
CBDC:          778 *
CBDC:          CBDC 779 xor4   equ   *
CBDC:85 40      (3) 780      sta   checksum
CBDE:68        (4) 781      pla   ;
CBDF:85 55      (3) 782      sta   buffer+1
CBE1:          783 *
CBE1:          784 *

```

```
CBE1:          786 ****
CBE1:          787 *
CBE1:          788 * DetTopBits           Get topbits for odd bytes *
CBE1:          789 *
CBE1:          790 *   Also sets buffer2 pointer to pointer at groups of *
CBE1:          791 *   seven bytes.
CBE1:          792 *
CBE1:          793 *   Input:    oddbytes <- # of "odd" bytes      *
CBE1:          794 *               buffer   <- pointer to data      *
CBE1:          795 *   Output:   tbodd    <- topbits for odd bytes      *
CBE1:          796 *               buffer2  <- buffer+oddbytes      *
CBE1:          797 *
CBE1:          798 ****
CBE1:          799 *
CBE1:          CBE1  800 DetTopBits equ *
CBE1:          801 *
CBE1:A4 4C     (3) 802      ldy    oddbytes
CBE3:88        (2) 803      dey
CBE4:A9 00        (2) 804      lda    #0
CBE6:85 59        (3) 805      sta    tbodd
CBE8:
CBE8:B1 54     (5) 807  gtbob  lda    (buffer),y
CBEA:0A        (2) 808      asl    a
CBEB:66 59     (5) 809      ror    tbodd
CBED:88        (2) 810      dey
CBEF:10 F8    CBE8(3) 811      bpl    gtbob
CBF0:38        (2) 812      sec
CBF1:66 59     (5) 813      ror    tbodd
CBF3:
CBF3:A5 4C     (3) 815      lda    oddbytes
CBF5:18        (2) 816      clc
CBF6:65 54     (3) 817      adc    buffer
CBF8:85 56     (3) 818      sta    buffer2
CBFA:A5 55     (3) 819      lda    buffer+1
CBFC:69 00     (2) 820      adc    #0
CBFE:85 57     (3) 821      sta    buffer2+1
CC00:
CC00:          822 *
CC00:          823 *
```

```

CC00:          825 ****
CC00:          826 *
CC00:          827 * Sun           Set up next buffer and topbits *
CC00:          828 *
CC00:          829 *   Primes the pipe for the group of seven bytes routine *
CC00:          830 *   setting the topbits byte and the "next" buffer. *
CC00:          831 *   The routine also advances the buffer pointer by 7 to *
CC00:          832 *   prepare for the groups of seven transfer. *
CC00:          833 *
CC00:          834 *   Input:   buffer2  <- points to groups of 7 data   *
CC00:          835 *   Output:  next1,7  <- first 7 bytes in buffer   *
CC00:          836 *           topbits  <- MSBs of first 7 bytes   *
CC00:          837 *
CC00:          838 ****
CC00:          839 *
CC00: CC00 840 Sun    equ   *
CC00:          841 *
CC00:          842 * Copy first seven bytes into the pipeline
CC00:          843 *
CC00:A0 06    (2) 844 ldy   #6
CC02:38    (2) 845 sun2 sec
CC03:B1 56    (5) 846 lda   (buffer2),y
CC05:99 4D 00    (5) 847 sta   next,y
CC08:30 01    CC0B(3) 848 bmi   sun1
CC0A:18    (2) 849 clc
CC0B:66 41    (5) 850 sun1 ror   topbits
CC0D:88    (2) 851 dey
CC0E:10 F2    CC02(3) 852 bpl   sun2
CC10:38    (2) 853 sec
CC11:66 41    (5) 854 ror   topbits
CC13:
CC13:          855 *
CC13:          856 * Advance the pointer
CC13:          857 *
CC13:A5 56    (3) 858 lda   buffer2
CC15:18    (2) 859 clc
CC16:69 07    (2) 860 adc   #7
CC18:85 56    (3) 861 sta   buffer2
CC1A:90 02    CC1E(3) 862 bcc   sun3
CC1C:E6 57    (5) 863 inc   buffer2+1
CC1E:          CC1E 864 sun3 equ   *
CC1E:60    (6) 865 rts
CC1F:          866 *
CC1F:          867 *

```

```

CC1F:          869 *
CC1F:          870 * X is slot*16, Y is the desired mode
CC1F:          871 *
CC1F:          872 * Set up the IWM mode register. Extreme care should be taken
CC1F:          873 * here. Setting the mode byte with indexed stores causes a false
CC1F:          874 * byte to be written a cycle before the real value is written.
CC1F:          875 * This false value, if it enables the timer, causes the IWM Rev A
CC1F:          to
CC1F:          876 * pop the motor on, inhibiting the setting of the mode until the
CC1F:          877 * motor times out! We avoid this by setting the mode byte only
CC1F:          when
CC1F:          878 * it is not what we want, and if it's not we stay here until we
CC1F:          879 * see that it is what we want.
CC1F:          880 *
CC1F:          CC1F 881 SetIWMMode equ *
CC1F:          BD 00    (4) 882 lda monclr,x      ;Motor must be off
CC22:BD 8D C0    (4) 883 lda 16set,x       ;Set up to access mode register
CC25:4C 2C CC    (3) 884 jmp careful        ;Don't mess unless we gotta
CC28:98          (2) 885 bsz tya             ;Get back the target value
CC29:9D 8F C0    (5) 886 sta 17set,x       ;Try storing the mode value
CC2C:          CC2C 887 careful equ *
CC2C:98          (2) 888 tya             ;Compare with observed value
CC2D:5D 8E C0    (4) 889 eor 17clr,x       ;Can only read low 5 bits
CC30:29 1F          (2) 890 and #$1F           ;If not right, back to try again
CC32:D0 F4          CC28(3) 891 bne bsz
CC34:60          (6) 892 rts
CC35:          893 *
CC35:          894 *
CC35:          0001 895 Do IIC
CC35:          CC35 896 WaitIWMOff equ *
CC35:          897 *
CC35:          898 * Make sure you're in read mode and wait 'til Disk // motor is off
CC35:          899 *
CC35:20 9A CA    (6) 900 jsr SetXN0      ;Set X
CC38:BD 8E C0    (4) 901 lda 17clr,x
CC3B:BD 8D C0    (4) 902 lda 16set,x
CC3E:          CC3E 903 wiwm1 equ *
CC3E:BD 8E C0    (4) 904 lda 17clr,x
CC41:29 20          (2) 905 and #%00100000
CC43:D0 F9          CC3E(3) 906 bne wiwm1
CC45:BD 8C C0    (4) 907 lda 16clr,x
CC48:          908 *
CC48:          909 * Wait an additional 700 microseconds to allow 12V on Disk // to
CC48:          decay
CC48:          910 *
CC48:5A          (3) 911 phy
CC49:A0 8C          (2) 912 ldy #140
CC4B:88          (2) 913 wiwm2 dey
CC4C:D0 FD          CC4B(3) 914 bne wiwm2
CC4E:7A          (4) 915 ply
CC4F:          916 *
CC4F:60          (6) 917 rts
CC50:          918 fin
CC50:          919 *
CC50:          920 *
CC50:          921 * This takes grp7ctr and oddbytes and calculates
CC50:          7*grp7ctr+oddbytes.
CC50:          922 * The results are in Y(hi) and A(lo). This is the number of bytes
CC50:          923 * that were received in the last ReceivePack.
CC50:          924 *
CC50:          CC50 925 Rcvcount equ *
CC50:A5 4B          (3) 926 lda grp7ctr

```

```

CC52:A8      (2) 927      tay
CC53:A2 00    (2) 928      ldx   #0
CC55:86 4B    (3) 929      stx   grp7ctr
CC57:A2 03    (2) 930      idx   #3
CC59:0A      (2) 931 times7 asl   a
CC5A:26 4B    (5) 932      rol   grp7ctr
CC5C:CA      (2) 933      dex
CC5D:D0 FA    CC59(3) 934      bne   times7
CC5F:18      (2) 935      clc
CC60:65 4C    (3) 936      adc   oddbytes
CC62:90 02    CC66(3) 937      bcc   t71
CC64:E6 4B    (5) 938      inc   grp7ctr
CC66:84 4C    (3) 939 t71    sty   oddbytes
CC68:38      (2) 940      sec
CC69:E5 4C    (3) 941      sbc   oddbytes
CC6B:B0 02    CC6F(3) 942      bcs   t72
CC6D:C6 4B    (5) 943      dec   grp7ctr
CC6F:A4 4B    (3) 944 T72    ldy   grp7ctr
CC71:60      (6) 945      rts
CC72:         946 *
CC72:         947 *
CC72:         136 *
CC72: 0001     137      do   IIC^ROM
CC72:           138      include pc.cread
CC72:           CC72      1 SlotDepRd equ *
CC72:           CC72      2 start25 equ *
CC72:A0 00    (2) 3       ldy   #0
CC74:A5 4B    (3) 4       lda   grp7ctr
CC76:48      (3) 5       pha
CC77:D0 03    CC7C(3) 6       bne   start35      ;Save groups of seven counter
CC79:4C 09 CD  (3) 7       jmp   done5      ;Go get the checksum
CC7C:         8 *      *
CC7C:         9 * Okay, get the groups of seven
CC7C:         10 * Start by getting the topbits for this group of seven
CC7C:           11 *
CC7C:           CC7C      12 start35 equ *
CC7C:AD EC C0  (4) 13      lda   16clr+TheOff ;Get topbits
CC7F:10 FB    CC7C(3) 14      bpl   start35
CC81:85 59    (3) 15      sta   temp      ;Just a second
CC83:         16 *
CC83:         17 * Split up the seven bits into two indices for topbit tables
CC83:         18 *      *
CC83:4A      (2) 19      lsr   a      ;0 1 d1 d2 d3 d4 d5 d6
CC84:4A      (2) 20      lsr   a      ;0 0 1 d1 d2 d3 d4 d5
CC85:4A      (2) 21      lsr   a      ;0 0 0 1 d1 d2 d3 d4
CC86:29 0F    (2) 22      and   #%00001111 ;First index into the tables
CC88:AA      (2) 23      tax
CC89:A5 59    (3) 24      lda   temp      ;1 d1 d2 d3 d4 d5 d6 d7
CC8B:29 07    (2) 25      and   #%00000111 ;0 0 0 0 d5 d6 d7
CC8D:85 59    (3) 26      sta   temp      ;Keep for last three bytes
CC8F:         27 *
CC8F:         28 * Now read the first byte, reunite its msb, store it, and checksum
CC8F:           it.
CC8F:         29 *
CC8F:AD EC C0  (4) 30      lda   16clr+TheOff
CC92:10 FB    CC8F(3) 31      bpl   *-3      ;Back 1 instruction
CC94:5D 9D CA  (4) 32      eor   shift1,x ;Recombine the MSB with data
CC97:91 56    (6) 33      sta   (buffer2),y ;Store it away
CC99:45 40    (3) 34      eor   checksum ;Add it to the checksum

```

```

CC9B:85 40      (3)  35      sta    checksum
CC9D:C8      (2)  36      iny
CC9E:
CC9E:          37 *
CC9E:          38 * Now, the second Y turn over occurs at this point in the loop.
CC9E:          Update
CC9E:          39 * the buffer pointer if it occurred.
CC9E:          40 *
CC9E:D0 02 CCA2(3) 41      bne   *+4
CCA0:E6 57      (5)  42      inc    buffer2+1
CCA2:
CCA2:          43 *
CCA2:          44 * Now the second byte
CCA2:          45 *
CCA2:AD EC C0  (4)  46      lda    16clr+TheOff
CCA5:10 FB  CCA2(3) 47      bpl   *-3           ;Back 1 instruction
CCA7:5D AD CA  (4)  48      eor    shift2,x   ;Recombine the MSB with data
CCAA:91 56  (6)  49      sta    (buffer2),y  ;Store it away
CCAC:45 40  (3)  50      eor    checksum     ;Add it to the checksum
CCAE:85 40  (3)  51      sta    checksum
CCB0:C8  (2)  52      iny
CCB1:
CCB1:          53 *
CCB1:          54 * Now the third byte
CCB1:          55 *
CCB1:AD EC C0  (4)  56      lda    16clr+TheOff
CCB4:10 FB  CCB1(3) 57      bpl   *-3           ;Back 1 instruction
CCB6:5D BD CA  (4)  58      eor    shift3,x   ;Recombine the MSB with data
CCB9:91 56  (6)  59      sta    (buffer2),y  ;Store it away
CCBB:45 40  (3)  60      eor    checksum     ;Add it to the checksum
CCBD:85 40  (3)  61      sta    checksum
CCBF:C8  (2)  62      iny
CCC0:
CCC0:          63 *
CCC0:          64 * Now the fourth byte
CCC0:          65 *
CCC0:AD EC C0  (4)  66      lda    16clr+TheOff
CCC3:10 FB  CCC0(3) 67      bpl   *-3           ;Back 1 instruction
CCC5:5D CD CA  (4)  68      eor    shift4,x   ;Recombine the MSB with data
CCC8:91 56  (6)  69      sta    (buffer2),y  ;Store it away
CCCA:45 40  (3)  70      eor    checksum     ;Add it to the checksum
CCCC:85 40  (3)  71      sta    checksum
CCCE:C8  (2)  72      iny
CCCF:
CCCF:          73 *
CCCF:          74 * The first Y turn over occurs at this point in the loop. Update
CCCF:          75 * the buffer pointer if it occurred.
CCCF:
CCCF:D0 02 CCD3(3) 77      bne   *+4
CCD1:E6 57      (5)  78      inc    buffer2+1
CCD3:
CCD3:A6 59  (3)  79 *
CCD3:          80      ldx    temp        ;Now we need the other index
CCD5:
CCD5:          81 *
CCD5:          82 * Now the fifth byte
CCD5:          83 *
CCD5:AD EC C0  (4)  84      lda    16clr+TheOff
CCD8:10 FB  CCD5(3) 85      bpl   *-3           ;Back 1 instruction
CCDA:5D AD CA  (4)  86      eor    shift2,x   ;Recombine the MSB with data
CCDD:91 56  (6)  87      sta    (buffer2),y  ;Store it away
CCDF:45 40  (3)  88      eor    checksum     ;Add it to the checksum
CCE1:85 40  (3)  89      sta    checksum
CCE3:C8  (2)  90      iny
CCE4:
CCE4:          91 *
CCE4:          92 * Now the sixth byte

```

```

CCE4:          93 *
CCE4:AD EC C0  (4) 94      lda   16clr+TheOff
CCE7:10 FB  CCE4(3) 95      bpl  *-3           ;Back 1 instruction
CCE9:5D BD CA  (4) 96      eor   shift3,x    ;Recombine the MSB with data
CCEC:91 56    (6) 97      sta   (buffer2),y  ;Store it away
CCEE:45 40    (3) 98      eor   checksum     ;Add it to the checksum
CCF0:85 40    (3) 99      sta   checksum
CCF2:C8      (2) 100     iny
CCF3:          101 *
CCF3:          102 * And, finally, the seventh byte
CCF3:          103 *
CCF3:AD EC C0  (4) 104     lda   16clr+TheOff
CCF6:10 FB  CCF3(3) 105     bpl  *-3           ;Back 1 instruction
CCF8:5D CD CA  (4) 106     eor   shift4,x    ;Recombine the MSB with data
CCFB:91 56    (6) 107     sta   (buffer2),y  ;Store it away
CCFD:45 40    (3) 108     eor   checksum     ;Add it to the checksum
CCFF:85 40    (3) 109     sta   checksum
CD01:C8      (2) 110     iny
CD02:          111 *
CD02:          112 * Now see if this is the last group of seven to receive
CD02:          113 *
CD02:C6 4B    (5) 114      dec   grp7ctr
CD04:F0 03  CD09(3) 115      beq   done5       ;Go to get the checksum etc
CD06:4C 7C CC  (3) 116      jmp   start35    ;Another topbits ...
CD09:          117 *
CD09:          118 * Get and reconstruct the checksum
CD09:          119 *
CD09:          120 done5 equ  *
CD09:AD EC C0  (4) 121      lda   16clr+TheOff
CD0C:10 FB  CD09(3) 122      bpl  *-3
CD0E:85 59    (3) 123      sta   temp        ;1 c6 1 c4 1 c2 1 c0
CD10:          124 *
CD10:68      (4) 125      pla   grp7ctr      ;Restore groups of 7 counter
CD11:85 4B    (3) 126      sta   grp7ctr
CD13:AD EC C0  (4) 127      lda   16clr+TheOff ;1 c7 1 c5 1 c3 1 c1
CD16:10 FB  CD13(3) 128      bpl  *-3
CD18:38      (2) 129      sec
CD19:2A      (2) 130      rol   a             ;c7 1 c5 1 c3 1 c1 1
CD1A:25 59    (3) 131      and   temp        ;c7 c6 c5 c4 c3 c2 c1 c0
CD1C:45 40    (3) 132      eor   checksum    ;When we're done, should be zero
CD1E:          133 *
CD1E:          134 * Get the packet end mark. Is it correct?
CD1E:          135 *
CD1E:AC EC C0  (4) 136 rdha5 ldy   16clr+TheOff ;Preserve A
CD21:10 FB  CD1E(3) 137      bpl   rdha5
CD23:          138 *
CD23:C0 C8    (2) 139      cpyp #packetend
CD25:D0 1C  CD43(3) 140      bne   npenderr5
CD27:          141 *
CD27:          142 * Didn't have time before to checksum oddbytes. Do it now
CD27:          143 * A still has the partial checksum
CD27:          144 *
CD27:A6 4C    (3) 145      idx   oddbytes
CD29:F0 08  CD33(3) 146      beq   icbt15
CD2B:A0 00    (2) 147      ldy   #0
CD2D:51 54    (5) 148 icbt5 eor   (buffer),y
CD2F:C8      (2) 149      iny
CD30:CA      (2) 150      dex

```

```
CD31:D0 FA  CD2D(3) 151      bne    icbt5
CD33:          152 *
CD33:          153 * Okay, checksum oughta be zero.  If not, checksum error.
CD33:          154 *
CD33:          CD33 155 icbt15 equ   *
CD33:AA (2) 156 tax
CD34:D0 11  CD47(3) 157      bne    cserror5
CD36:          158 *
CD36:          159 * Wait for /BSY to go low
CD36:          160 *
CD36:          CD36 161 lsbssywait5 equ   *
CD36:AD C0 (4) 162      lda    16set+TheOff
CD39:AD EE C0 (4) 163 rdh45 lda    17clr+TheOff
CD3C:30 FB  CD39(3) 164      bmi    rdh45
CD3E:          165 *
CD3E:          166 * Got the bytes, now acknowledge their receipt
CD3E:          167 *
CD3E:AD E0 C0 (4) 168      lda    reqclr+TheOff ;Lower REQ
CD41:          169 *
CD41:18 (2) 170      clc
CD42:60 (6) 171      rts
CD43:          172 *
CD43:A9 20 (2) 173 npenderr5 lda #nopackend
CD45:D0 02  CD49(3) 174      bne    gserror5
CD47:A9 10 (2) 175 cserror5 lda #csumerr
CD49:38 (2) 176 gserror5 sec
CD4A:60 (6) 177      rts
CD4B:          178 *
CD4B:          139      fin
CD4B:          140 *
CD4B:          141      include pc.main
```

```

CD4B:          2 *
CD4B:          3 *
CD4B:    CD4B   4 Entry equ  *
CD4B:90 03 CD50(3) 5 bcc bentry      ;If non-boot, skip jump to boot
CD4D:4C 23 C5  (3) 6 jmp bootcode
CD50:
CD50:          7 *
CD50:          8 * X is still set to slot number.
CD50:          9 *
CD50:    CD50  10 bentry equ  *
CD50:          11 *
CD50:    0001 12 do  IIC^ROM
CD50:A9 40  (2) 13 lda #%01000000
CD52:1C 78 04  (6) 14 trb ProFlag+5 ;ProFlag is fixed in //c
CD55:          15 *
CD55:    CD55 16 atentry equ  *
CD55:          17 fin
CD55:          18 *
CD55:D8  (2) 19 cld           ;Don't want decimal mode!!
CD56:8A  (2) 20 txa
CD57:A8  (2) 21 tay           ;Really want it in Y... no ROR ABS,Y!
CD58:
CD58:          22 *
CD58:          23 * If this is a PC call, then get the address of the parm table
CD58:B9 73 04  (4) 24 *
CD5B:30 11 CD6E(3) 25 lda  ProFlag,y
CD5D:
CD5D:68  (4) 26 bmi  noplay
CD5D:          27 *
CD5E:99 F3 05  (5) 28 pla           ;Get lo order
CD61:18  (2) 29 sta  SHTempX,y ;Keep lo parm address-1
CD62:69 03  (2) 30 clc
CD64:AA  (2) 31 adc #3
CD65:68  (4) 32 tax           ;Lo order new return address
CD66:99 73 06  (5) 33 pla           ;Get hi order address
CD69:69 00  (2) 34 sta  SHTempY,y ;Keep hi parm addr-1
CD6B:48  (3) 35 adc #0
CD6C:8A  (2) 36 pha           ;Push back new return address hi
CD6D:48  (3) 37 txa
CD6E:          38 pha           ;Push new return address lo
CD6E:          39 *
CD6E:    CD6E 40 noplay equ  *
CD6E:
CD6E:          41 *
CD6E:          42 * On the //c, it is important to have the Disk // enable lines
CD6E:          43 * off for as long as possible before using the IWM (phases, /WRREQ
CD6E:          44 * lines). Wait here 'til the Disk // motors are off.
CD6E:          45 *
CD6E:    0001 46 do  IIC
CD6E:20 35 CC  (6) 47 jsr  WaitIWMOff ;Must preserve Y!!
CD71:
CD71:          48 fin
CD71:          49 *
CD71:          50 * We can't really tolerate interrupts in most of the code, so
CD71:          disable
CD71:          51 *
CD71:08  (3) 52 php           ;Save interrupt status
CD72:78  (2) 53 sei           ;No interrupts please
CD73:
CD73:          54 *
CD73:          55 * Preserve the zero page work area
CD73:          56 *
CD73:A2 1B  (2) 57 ldx  #ZPSize-1
CD75:B5 40  (4) 58 pzp  lda  ZeroPage,x
CD77:48  (3) 59 pha

```

```

CD78:CA      (2)   60      dex
CD79:10 FA    CD75(3)  61      bpl    pzp
CD7B:          62 *
CD7B:          63 * Okay, we're safe... now it's all right to store in zero page
CD7B:          64 *
CD7B:84 58     (3)   65      sty    Slot
CD7D:          66 *
CD7D:0001     67      ifeq   IIc^ROM
CD7D:          80      fin
CD7D:          81 *
CD7D:          82 * Now map any ProDOS unit references to our sequential ones.
CD7D:          83 * The method is bizarre and magicians never reveal their secrets.
CD7D:          84 *
CD7D:CD7D     85 allset equ  *
CD7D:A5 43    (3)   86      lda    CMDUnit      ;76543210 7&6 specify unit
CD7F:2A      (2)   87      rol    a           ;6543210X C<-7
CD80:08      (3)   88      php
CD81:2A      (2)   89      rol    a           ;543210X7 C<-6
CD82:2A      (2)   90      rol    a           ;43210X76 (6 is grp of 2)
CD83:28      (4)   91      plp
CD84:2A      (2)   92      rol    a           ;C<-7
CD85:29 03    (2)   93      and   #%00000011  ;ProDOS only installs up to 4
CD87:49 02    (2)   94      eor   #%00000010  ;000000/67; 6 was /grpsoftwo
CD89:C0 04    (2)   95      cpy   #4           ;If in slot 1,2,or3 reverse grps of two
CD8B:B0 02    CD8F(3)  96      bge   allset1
CD8D:49 02    (2)   97      eor   #%00000010
CD8F:AA      (2)   98      allset1 tax
CD90:E8      (2)   99      inx
CD91:86 43    (3)  100      stx   CMDUnit      ;You got it
CD93:          101 *
CD93:          102 * Now if this is through the MLI xface, gotta copy stuff into the
CD93:          103 * send buffer from the parameter list.
CD93:          104 *
CD93:B9 73 04  (4)  105      lda   ProFlag,y
CD96:10 03    CD9B(3)  106      bpl   darnit
CD98:4C 3F CE  (3)  107      jmp   skipcopy
CD9B:          108 *
CD9B:          109 * Get the address of the in-line parameter table
CD9B:          110 *
CD9B:CD9B     111 darnit equ  *
CD9B:B9 F3 05  (4)  112      lda   SHTempX,y  ;Get back the low part buff addr
CD9E:85 54    (3)  113      sta   buffer
CDA0:B9 73 06  (4)  114      lda   SHTempY,y  ; and the hi part
CDA3:85 55    (3)  115      sta   buffer+1
CDA5:          116 *
CDA5:          117 * Now pull out the command code, and the address of the parameters.
CDA5:          118 *
CDA5:A0 01    (2)  119      ldy   #1           ;Stacked address is EA-1
CDA7:B1 54    (5)  120      lda   (buffer),y
CDA9:85 42    (3)  121      sta   cmdcode      ;Nice
CDAB:C8      (2)  122      iny
CDAC:B1 54    (5)  123      lda   (buffer),y  ;Get lo part of parmlist address
CDAE:AA      (2)  124      tax
CDAF:C8      (2)  125      iny
CDB0:B1 54    (5)  126      lda   (buffer),y  ;Get hi part
CDB2:85 55    (3)  127      sta   buffer+1
CDB4:86 54    (3)  128      stx   buffer
CDB6:          129 *

```

```

CDB6:          130 * Now buffer points to parmlist
CDB6:          131 * Check command type, and pigeonhole the parmlist length
CDB6:          132 *
CDB6:A9 01    (2) 133      lda    #BadCmd
CDB8:A6 42    (3) 134      ldx    cmdcode
CDBA:E0 0A    (2) 135      cpx    #$A           ;Only valid codes are 0-9
CDCB:90 03    CDC1(3) 136      blt    noeh        ;=> at least he got that right
CDBE:4C 0F CF (3) 137      Errorhitch jmp Error   ;Gee, maybe we should promote this guy...
CDC1:          CDC1    138      noeh   equ   *
CDC1:A0 00    (2) 139      ldy    #0           ;Set for indct compare
CDC3:B1 54    (5) 140      lda    (buffer),y  ;Get # of parms?
CDC5:85 5A    (3) 141      sta    Unit
CDC7:          142 *
CDC7:          143 * Now copy the bytes
CDC7:          144 *
CDC7:          CDC7    145      okaycnt equ  *
CDC7:A0 08    (2) 146      ldy    #>cmdlength-1 ;Always copy the maximum
CDC9:          CDC9    147      copyloop equ  *
CDC9:B1 54    (5) 148      lda    (buffer),y  ;Pull it out of their hat
CDCB:99 42 00 (5) 149      sta    cmdcode,y   ;Stuff it into mine
CDCE:88      (2) 150      dey
CDCF:D0 F8    CDC9(3) 151      bne    copyloop   ;Copy 'em all
CDD1:          152 *
CDD1:          153 * Okay. The caller of the PC could be making one of three calls
CDD1:          154 * with a unit number of $00, Control, Init or Status. Check for
CDD1:          155 * these and do what is appropriate.
CDD1:          156 *
CDD1:A5 43    (3) 157      lda    CMDUnit
CDD3:D0 6A    CE3F(3) 158      bne    skipcopy   ;Never mind
CDD5:          159 *
CDD5:          160 * Check the parameter count for this call to unit#0
CDD5:          161 *
CDD5:A6 42    (3) 162      ldx    CMDCode
CDD7:BD 86 CF (4) 163      lda    parmtab,x  ;Get the length this command
CDDA:29 7F    (2) 164      and    #$7F         ;Force 0 -> MSB
CDDC:A8      (2) 165      tay
CDDD:A9 04    (2) 166      lda    #BadPCnt   ;Antic bad count
CDDF:C4 5A    (3) 167      cpy    Unit        ;User's pcount is currently here
CDE1:D0 DB    CDBE(3) 168      bne    ErrorHitch ;What a baby!
CDE3:          169 *
CDE3:          170 * Now service one of the three commands
CDE3:          171 *
CDE3:E0 05    (2) 172      cpx    #InitCMD
CDE5:D0 0A    CDF1(3) 173      bne    notinit   ;Not an Init call
CDE7:A9 00    (2) 174      lda    #PowerReset ;Just like powerup or reset key//c
CDE9:20 90 CF (6) 175      jsr    AssignID   ;Do a reset cycle
CDEC:A9 00    (2) 176      Aokay   lda   #0       ;No error allowed
CDEF:4C 31 CF (3) 177      jmp    sa2
CDE1:          178 *
CDF1:8A      (2) 179      notinit txax      ;Equiv to 'cmp #StatusCMD'
CDF2:D0 24    CE18(3) 180      bne    maybectrl
CDF4:          181 *
CDF4:A9 21    (2) 182      lda    #BadCtl   ;Antic a non zero stat code
CDF6:A6 46    (3) 183      ldx    CMDSCode  ;Stat unit#0 can only be code=0
CDF8:D0 C4    CDBE(3) 184      bne    ErrorHitch
CDF8:          185 *
CDF8:8A      (2) 186      txax      Slot      ;Equiv to 'lda #0'
CDFB:A6 58    (3) 187      ldx

```

```

CDFD:A0 07      (2) 188    ldy   #7
CDFF:91 44      (6) 189    nin1   sta   (CmdBuffer1),y ;Clear some space
CE01:88          (2) 190    dey
CE02:D0 FB      CDFF(3) 191    bne   nin1
CE04:
CE04:BD F9 06      (4) 192    *
CE04:BD F9 06      (4) 193    lda   NumDevices,x
CE07:91 44      (6) 194    sta   (CMDBuffer1),y ;Stick it where they want it
CE09:08          (2) 195    iny
CE0A:
CE0A: 0001      196    *
CE0A:AD F9 04      (4) 197    do    IIC
CE0D:             198    lda   $4F9      ;//c Port 1 interrupt status
CE0D:             199    else
CE0D:             201    fin
CE0D:             202    *
CE0D:91 44      (6) 203    sta   (CMDBuffer1),y ;Store PC interrupt status
CE0F:
CE0F:A9 08      (2) 204    *
CE0F:A9 08      (2) 205    lda   #8
CE11:88          (2) 206    dey
CE12:20 F2 CF      (6) 207    jsr   squirrel
CE15:
CE15:4C EC CD      (3) 208    *
CE18:             CE18  maybectrl equ *
CE18:C9 04      (2) 210    jmp   Aokay      ;Skip down (up) with no error
CE18:C9 04      (2) 211    cmp   #ControlCMD
CE1A:D0 0B      CE27(3) 212    bne   BUnit      ;Unit #0 was a bad one
CE1C:
CE1C:A6 46      (3) 213    *
CE1E:F0 0B      CE2B(3) 214    ldx   CMDSCode      ;We allow two control calls for Unit#0
CE1E:F0 0B      CE2B(3) 215    beq   enabint      ;0 means enable interrupts
CE20:CA          (2) 216    dex
CE21:F0 14      CE37(3) 217    beq   disableint      ;1 means disable interrupts
CE23:A9 21      (2) 218    lda   #badctl
CE25:             CE25  ErrorHitch2 equ *
CE25:D0 97      CDBE(3) 219    bne   ErrorHitch      ;No other codes allowed
CE27:
CE27:             CE27  BUnit equ *
CE27:A9 11      (2) 220    lda   #badUnit      ;Only certain calls can have Unit#0
CE29:D0 93      CDBE(3) 221    bne   ErrorHitch      ;Branch always
CE2B:
CE2B: 0001      222    BUnit equ *
CE2B:             CE2B  enabint equ *
CE2B:A9 C0      (2) 223    do    IIC
CE2D:8D F9 05      (4) 224    lda   #$C0
CE30:A9 0F      (2) 225    sta   $5F9
CE32:0C 9A C0      (6) 226    lda   #$0F
CE35:D0 05      CE3C(3) 227    tsb   $C09A
CE37:             CE37  BUnit equ *
CE37:A9 01      (2) 228    lda   #$01
CE39:1C 9A C0      (6) 229    trb   $C09A
CE3C:4C EC CD      (3) 230    aokayhitch jmp  A0key
CE3F:
CE3F:             231    *
CE3F:             232    bne   aokayhitch
CE3F:             233    *
CE37:             234    disableint equ *
CE37:A9 01      (2) 235    lda   #$01
CE39:1C 9A C0      (6) 236    trb   $C09A
CE3C:4C EC CD      (3) 237    aokayhitch jmp  A0key
CE3F:
CE3F:             238    *
CE3F:             239    else
CE3F:             240    fin
CE3F:             241    *
CE3F:             242    * Okay, everything's all groovy. ProDOS re-enters here.
CE3F:             243    * Check Unit number to be sure there is a corresponding device
CE3F:             244    *
CE3F:             245    skipcopy equ *
CE3F:             246    lda   #NoDrive      ;Anticipate bad unit number
CE3F:A9 28      (2) 247    *
CE3F:             248    *
CE3F:             249    skipcopy equ *
CE3F:             250    lda   #NoDrive      ;Anticipate bad unit number

```

```

CE41:A4 58      (3) 251      ldy    slot
CE43:BE F9 06    (4) 252      idx    NumDevices,y
CE46:E4 43      (3) 253      cpx    CMDUnit
CE48:90 DB      CE25(3)   254      blt    ErrorHitch2 ;Safe- If C clr then Z is clr
CE4A:
255 *
CE4A:           256 * Set buffer and bytecount in anticipation of the inevitable
CE4A:           257 * SendPack.
CE4A:A9 09      (2) 258      lda    #>cmdlength
CE4C:85 4D      (3) 259      sta    bytecount1
CE4E:A9 00      (2) 260      lda    #<cmdlength
CE50:85 4E      (3) 261      sta    bytecounth
CE52:85 55      (3) 262      sta    buffer+1
CE54:A9 42      (2) 263      lda    #>cmdcode
CE56:85 54      (3) 264      sta    buffer
CE58:
265 *
CE58:           266 * If it's a PC call, omit the next two steps
CE58:           267 *
CE58:A6 58      (3) 268      ldx    Slot
CE5A:BD 73 04    (4) 269      lda    ProFlag,x ;Is it a call from ProDOS?
CE5D:10 13      CE72(3)   270      bpl    notstat ;=> Statcode already set...
CE5F:
CE5F:           272 * Need to generate a parameter count for a ProDOS call
CE5F:           273 *
CE5F:A6 42      (3) 274      ldx    CMDCode
CE61:BD 86 CF    (4) 275      lda    ParmCTab,x
CE64:29 7F      (2) 276      and    #$7F
CE66:85 5A      (3) 277      sta    Unit
CE68:
278 *
CE68:           279 * ProDOS always needs the highest blockno byte zeroed
CE68:           280 *
CE68:A9 00      (2) 281      lda    #0
CE6A:85 48      (3) 282      sta    CMDBlocks
CE6C:
CE6C:           284 * If this is a ProDOS status call, set stat code to zero
CE6C:           285 *
CE6C:A5 42      (3) 286      lda    CMDCode
CE6E:D0 02      CE72(3)   287      bne    notstat ;=> Not status so forget it
CE70:
CE70:           288 lda    #SCDeviceStat ;A is already zero
CE70:85 46      (3) 289      sta    CMDSCode ;Store in command table
CE72:
CE72:           290 *
CE72:           291 * Okay, finally send over the damn command
CE72:           292 *
CE72:           CE72 293 notstat equ  *
CE72:A5 5A      (3) 294      lda    Unit
CE74:A6 43      (3) 295      ldx    CmdPCount ;Swap the Parmcount & unit#
CE76:86 5A      (3) 296      stx    Unit
CE78:85 43      (3) 297      sta    CMDPCount ;Now they're correct
CE7A:
CE7A:A9 80      (2) 299      lda    #cmdmark
CE7C:85 5B      (3) 300      sta    WPacketType
CE7E:
CE7E:20 8A CA    (6) 302      jsr    ClrPhases ;Bring all phases off
CE81:
CE81:20 EC CA    (6) 304      jsr    SendPack
CE84:B0 46      CECC(3)   305      bcs    behitch ;If not okay, skip to bus error
CE86:
CE86:           306 *
CE86:           307 * Now copy over the buffer address for any data xfer.
CE86:           308 *

```

```

CE86:A5 44      (3) 309      lda    CMDBuffer
CE88:85 54      (3) 310      sta    buffer
CE8A:A5 45      (3) 311      lda    CMDBuffer+1
CE8C:85 55      (3) 312      sta    buffer+1
CE8E:
CE8E:           313 *
CE8E:           314 * Now for some commands, we have to send over a packet of data, too.
CE8E:           315 * See if this command is one of THOSE.
CE8E:
CE8E:A6 42      (3) 317      ldx    cmdcode
CE90:BD 86 CF    (4) 318      lda    parmctab,x
CE93:10 3B      CED0(3) 319      bpl    noxtrasend ;Encoded in top bit
CE95:
CE95:           320 *
CE95:           321 * The buffer address and bytecount depend on the call type.
CE95:
CE95:E0 04      (2) 323      cpx    #ControlCmd
CE97:D0 18      CEB1(3) 324      bne    NOControl
CE99:
CE99:           325 *
CE99:           326 * In the case of control, bytecount:=(buffer) then buffer:=buffer+2
CE99:           327 *
CE99:A0 01      (2) 328      ldy    #1
CE99:B1 54      (5) 329      lda    (buffer),y ;Get Hi order bytecount
CE9D:AA          (2) 330      tax
CE9E:88          (2) 331      dey
CE9F:B1 54      (5) 332      lda    (buffer),y
CEA1:48          (3) 333      pha
CEA2:18          (2) 334      clc
CEA3:A9 02      (2) 335      lda    #2
CEA5:65 54      (3) 336      adc    buffer
CEA7:85 54      (3) 337      sta    buffer
CEA9:68          (4) 338      pla
CEAA:90 13      CEBF(3) 339      bcc    secondsend ;Get back Lo order bytecount
CEAC:E6 55      (5) 340      inc    buffer+1
CEAE:4C BF CE    (3) 341      jmp    secondsend ;Skip hi ord increment
CEB1:
CEB1:           342 *
CEB1:           343 NOControl equ *
CEB1:E0 02      (2) 344      cpx    #WriteCMD ;Check for a writeblock
CEB3:D0 06      CEBB(3) 345      bne    NOWBlock ;Must be control or write
CEB5:
CEB5:           346 *
CEB5:           347 * In the case of WriteBlock, the length is 512 and the buffer
CEB5:           348 * address is at buffer in the command table
CEB5:
CEB5:A9 00      (2) 350      lda    #0
CEB7:A2 02      (2) 351      ldx    #2
CEB9:D0 04      CEBF(3) 352      bne    secondsend
CEBB:
CEBB:           353 *
CEBB:           354 * For FileWrite, the buffer address is at CMDbuffer
CEBB:           355 * and the length is at CMDblock.
CEBB:
CEBB:           356 *
CEBB:           357 NOWBlock equ *
CEBB:A6 47      (3) 358      ldx    CMDBlockh
CEBD:A5 46      (3) 359      lda    CMDBlockl
CEBF:
CEBF:           360 *
CEBF:           361 secondsend equ *
CEBF:86 4E      (3) 362      stx    bytecounth
CEC1:85 4D      (3) 363      sta    bytecountl
CEC3:
CEC3:A9 82      (2) 365      lda    #datamark
CEC5:85 5B      (3) 366      sta    WPacketType ;Identify this as a data packet

```

```

CEC7:          367 *
CEC7:20 DD CA  (6) 368      jsr   SendData
CECA:90 04     CED0(3) 369      bcc   noxtrasend
CECC:          CECC  370 behitch equ  *
CECC:A9 06     (2) 371      lda   #BusErr      ;This is the bus error hitch
CECE:D0 3F     CF0F(3) 372      bne   Error
CED0:          373 *
CED0:          374 * On ProDOS status call, we've got to point the buffer pointer
CED0:          375 * correctly to zero page... it's the only case special case
CED0:          376 * (on Write, Format and Control no data comes back).
CED0:          377 *
CED0:          CED0  378 noxtrasend equ *
CED0:A4 58     (3) 379      ldy   Slot
CED2:B9 73 04  (4) 380      lda   ProFlag,y
CED5:10 0C     CEE3(3) 381      bpl   getresults
CED7:A5 42     (3) 382      lda   cmdcode
CED9:D0 08     CEE3(3) 383      bne   getresults
CEDB:          384 *
CEDB:A9 45     (2) 385      lda   #>CMDBufferh ;Want status in these four
CEDD:A2 00     (2) 386      ldx   #<CMDBufferh
CEDF:85 54     (3) 387      sta   buffer
CEE1:86 55     (3) 388      stx   buffer+1
CEE3:          389 *
CEE3:          390 * Please to be calling ReceivePack
CEE3:          391 *
CEE3:          CEE3  392 getresults equ *
CEE3:20 33 CB  (6) 393      jsr   RecPack      ;Get status byte (maybe read data too)
CEE6:B0 E4     CEC0(3) 394      bcs   behitch
CEE8:          395 *
CEE8:          396 * Figure how many bytes were sent and put that in X,Y temps
CEE8:          397 *
CEE8:20 50 CC  (6) 398      jsr   Rcvcount      ;Do the times 7...
CEE8:20 F2 CF  (6) 399      jsr   squirrel      ;Store away count in SHTEMPS
CEE8:          400 *
CEE8:          401 * For the ProDOS status call, we've got to look at the status byte
CEE8:          402 * returned and return a DIP error if appropriate.
CEE8:          403 * Also overwrite the X,Y temps with # blocks if this is a ProDOS
CEE8:          404 * Stat call.
CEE8:A5 42     (3) 405      lda   CMDCode      ;Is it a ProDOS status call
CEF0:D0 1B     CF0D(3) 406      bne   noerror
CEF2:A6 58     (3) 407      ldx   Slot
CEF4:BD 73 04  (4) 408      lda   ProFlag,x
CEF7:10 14     CF0D(3) 409      bpl   noerror
CEF9:          410 *
CEF9:A5 46     (3) 411      lda   CMDBlock1    ;This'll get loaded into the XY regs
                                         later
CEF9:9D F3 05  (5) 412      sta   SHTempX,x
CEF9:A5 47     (3) 413      lda   CMDBlockh
CF00:9D 73 06  (5) 414      sta   SHTempY,x
CF03:          415 *
CF03:A5 45     (3) 416      lda   CMDBufferh  ;Check status byte
CF05:29 10     (2) 417      and   #SVMask1
CF07:D0 04     CF0D(3) 418      bne   noerror      ;No DIP
CF09:A9 2F     (2) 419      lda   #OffLine
CF0B:D0 02     CF0F(3) 420      bne   Error
CF0D:          421 *
CF0D:          422 * Now it's time to think about returning to the caller
CF0D:          423 * Remember that ProDOS doesn't want to know about soft errors,
CF0D:          424 * only fatal ones. If this is a ProDOS call, and the soft error

```

```

CF0D:          425 * bit in the statbyte is set, there IS NO error (statbyte is
                cleared).
CF0D:          426 * Also, ProDOS wants only I/O, Write Protect, No Device, Offline.
CF0D:          427 * If any other hard error comes from the device on a ProDOS call,
CF0D:          428 * map it to an I/O Error. (Gross me out.)
CF0D:
CF0D:          CF0D 430 noerror equ *
CF0D:A5 4D    (3) 431 lda statbyte
CF0F:          CF0F 432 Error equ *
CF0F:A4 58    (3) 433 ldy Slot      ;Need access to screenholes
CF11:99 F3 04  (5) 434 sta Retry,Y ;Keep unadulterated error in slot
CF14:AA      (2) 435 tax         ;Set the Z flag
CF15:F0 1A    CF31(3) 436 beq sa2   ;Special case the zero
CF17:          437 *
CF17:BE 73 04  (4) 438 ldx ProFlag,y ;Set N to ProDOS call or not
CF1A:10 15    CF31(3) 439 bpl sa2   ;If PC call, no mapping occurs
CF1C:          440 *
CF1C:A2 00    (2) 441 ldx #0       ;Assume a soft error
CF1E:C9 40    (2) 442 cmp #$01000000 ;Soft error check
CF20:B0 0E    CF30(3) 443 bge storeaway ;If $40 or bigger, map to zero
CF22:
CF22:A2 27    (2) 445 ldx #IOError ;Now anticipate ProDOS I/O error
CF24:C9 2B    (2) 446 cmp #WriteProt
CF26:F0 09    CF31(3) 447 beq sa2   ;OK to return Write Protect
CF28:C9 28    (2) 448 cmp #NoDrive
CF2A:F0 05    CF31(3) 449 beq sa2   ;OK to return Drive disconnected
CF2C:C9 2F    (2) 450 cmp #OffLine
CF2E:F0 01    CF31(3) 451 beq SA2
CF30:
CF30:          CF30 452 *
CF30:          CF30 453 storeaway equ *
CF30:8A      (2) 454 txa           ;Use the default value
CF31:          CF31 455 sa2 equ *
CF31:A4 58    (3) 456 ldy Slot
CF33:99 73 05  (5) 457 sta SHTemp1,y ;Keep in screenhole
CF36:
CF36:          458 *
CF36:          459 * If this is the //c version, we need to reset the IWM to its
CF36:          460 * former disk // state. This is done by setting the mode register
CF36:          461 * to a little known (and less documented) mode which speeds up the
CF36:          462 * internal motor timeout. When the motor enable has timed out,
CF36:          463 * mode can be set back to zero. This method is necessary because
CF36:          464 * if the timer is enabled within the timeout period, the motor on
CF36:          465 * a Rev A IWM pops on for the full timeout period (since mode
CF36:          466 * changes
CF36:          467 do IIC
CF36:AD E8 C0  (4) 468 lda monclr+$60 ;Motor off
CF39:2C ED C0  (4) 469 bit 16set+$60 ;Into mode reg access mode
CF3C:A9 2B    (2) 470 lda #$2B      ;This is the magic "speed up" value
CF3E:8D EF C0  (4) 471 sta 17set+$60 ;Throw into mode register
CF41:EA      (2) 472 nop           ;You're supposed to wait a while
CF42:EA      (2) 473 nop
CF43:EA      (2) 474 nop
CF44:EA      (2) 475 nop
CF45:          CF45 476 waitoff equ *
CF45:AD EE C0  (4) 477 lda 17clr+$60 ;Wait 'til motor off
CF48:29 20    (2) 478 and #$20
CF4A:D0 F9    CF45(3) 479 bne waitoff
CF4C:A0 00    (2) 480 ldy #0       ;Now set the reg back to $00
CF4E:A2 60    (2) 481 ldx #$60     ;IWM's in slot 6
CF50:20 1F CC  (6) 482 jsr SetIWMode

```

```

CF53:AD EC C0    (4) 483      lda    16clr+$60
CF56:AD E2 C0    (4) 484      lda    ca1clr+$60
CF59:AD E6 C0    (4) 485      lda    lstrbclr+$60
CF5C:A4 58        (3) 486      ldy    Slot           ;Need Slot in Y
CF5E:
CF5E:            487      fin
CF5E:            488 *
CF5E:            489 * Now, restore our zero page area.
CF5E:            490 *
CF5E:A2 00        (2) 491      ldx    #0
CF60:68          (4) 492      rzp    pla
CF61:95 40        (4) 493      sta    zeropage,x
CF63:E8          (2) 494      inx
CF64:E0 1C        (2) 495      cpx    #ZPSize
CF66:90 F8        CF60(3)   496      blt    rzp
CF68:
CF68:            497 *
CF68:            498 * We're into the stretch! Restore interrupt mask, load X, Y, and A
CF68:            499 * and set the carry if the error byte is non-zero.
CF68:            500 *
CF68:28          (4) 501      plp    ;Restore interrupt flag
CF69:B9 F3 05    (4) 502      lda    SHTempx,y ;Get X value
CF6C:AA          (2) 503      tax
CF6D:B9 73 05    (4) 504      lda    SHTemp1,y ;Grab the error result code
CF70:48          (3) 505      pha
CF71:B9 73 06    (4) 506      lda    SHTempy,y ;Pull out the Y value
CF74:A8          (2) 507      tay    ;No more access to screenholes
CF75:18          (2) 508      clc    ;Anticipate zero result code
CF76:68          (4) 509      pla    ;Pull back result code
CF77:F0 01        CF7A(3)   510      beq    finals skip
CF79:38          (2) 511      sec    ;Return with carry clear
CF7A:             CF7A      512      finals skip equ *
CF7A:            513 *
CF7A:0001         514      do     IIC^ROM
CF7B:2C 78 04    (4) 515      php    ;Save carry and Z flag
CF7E:70 04        CF84(3)   516      bit    ProFlag+5 ;Ick - ProFlag is fixed in //c
CF80:28          (4) 517      bvs    ick1   ;If bit 6=1, then return to alt ROM
CF81:4C 84 07    (3) 518      plp    ;Volr so return across ROM bank bdy
CF84:             CF84      519      jmp    SWRTS2
CF84:28          (4) 520      ick1   equ    *
CF85:60          (6) 521      plp
CF86:             522      rts    ;Flags set correctly again
CF86:             523      else
CF86:             525      fin
CF86:             526 *
CF86:             527 *
CF86:             CF86      528      parmctab equ *
CF86:03          529      dfb    %00000011 ;Status: 3 parms/no data send
CF87:03          530      dfb    %00000011 ;Read: 3 parms/no data send
CF88:83          531      dfb    %10000011 ;Write: 3 parms/data send
CF89:01          532      dfb    %00000001 ;Format: 1 parm /no data send
CF8A:83          533      dfb    %10000011 ;Control: 3 parms/data send
CF8B:01          534      dfb    %00000001 ;Init: 1 parm /no data send
CF8C:01          535      dfb    %00000001 ;Open: 1 parm /no data send
CF8D:01          536      dfb    %00000001 ;Close: 1 parm /no data send
CF8E:03          537      dfb    %00000011 ;CharRead: 3 parms/data send
CF8F:83          538      dfb    %10000011 ;CharWrite: 3 parms/data send
CF90:             539 *
CF90:             540 *

```

```

CF90:      542 *
CF90:      CF90  543 AssignID equ *
CF90:48    (3) 544 pha           ;Save the init code
CF91:20 60 CA (6) 545 jsr  resetchain ;Reset all of those things
CF94:68    (4) 546 pla
CF95:AA    (2) 547 tax           ;Save InitCode
CF96:      548 *
CF96:      549 * Save the command code, unit, and init code 'cause we'll trample
CF96:      550 * 'em.
CF96:45 42  (3) 551 lda  CMDCode
CF98:48    (3) 552 pha
CF99:A5 43  (3) 553 lda  CMDPCount
CF9B:48    (3) 554 pha
CF9C:A5 46  (3) 555 lda  CMDSSCode
CF9E:48    (3) 556 pha
CF9F:86 46  (3) 557 stx  CMDSSCode ;Store away the type of INIT
CFA1:
CFA1:      558 *
CFA1:      559 * Set up to send DefID command packets
CFA1:      560 *
CFA1:A9 05  (2) 561 lda  #InitCmd
CFA3:85 42  (3) 562 sta  CMDCode
CFA5:A9 00  (2) 563 lda  #0
CFA7:85 5A  (3) 564 sta  Unit
CFA9:A9 02  (2) 565 lda  #2      ;# parms in Init call
CFA8:85 43  (3) 566 sta  CMDPCount
CFAD:
CFAD:      567 *
CFAD:      568 * Point the buffer pointer
CFAD:      569 *
CFAD:A9 42  (2) 570 lda  #>CMDCode
CFAF:85 54  (3) 571 sta  buffer
CFB1:A9 00  (2) 572 lda  #<CMDCode
CFB3:85 55  (3) 573 sta  buffer+1
CFB5:A9 00  (2) 574 lda  #cmdmark
CFB7:85 5B  (3) 575 sta  WPacketType
CFB9:
CFB9:20 8A CA (6) 577 jsr  ClrPhases ;Make sure phases are off
CFBC:
CFBC:      578 *
CFBC:      579 * Send an ID for the next device in the chain
CFBC:      580 *
CFBC:      CFBC  581 mordevices equ *
CFBC:E6 5A  (5) 582 inc  Unit
CFBE:A9 09  (2) 583 lda  #>cmdlength
CFC0:85 4D  (3) 584 sta  bytecount ;ReceivePack scrambles count
CFC2:A9 00  (2) 585 lda  #<cmdlength
CFC4:85 4E  (3) 586 sta  bytecounth
CFC6:
CFC6:20 86 C8  (6) 588 jsr  SendOnePack ;Send the command
CFC9:00 05  CFD0(3) 589 bcc  mdev2 ;If okay, skip to get response
CFCB:
CFCB:06 5A  (5) 591 dec  Unit
CFCD:4C D7 CF  (3) 592 jmp  mdev1
CFD0:
CFD0:20 E6 C9  (6) 594 mdev2 jsr  ReceivePack ;Get the response
CFD3:A5 4D  (3) 595 lda  statbyte
CFD5:F0 E5  CFBC(3) 596 beq  mordevices
CFD7:
CFD7:      597 *
CFD7:      598 * Okay, we done last device. Squirrel away the number of devices.
CFD7:      599 *

```

07 PC.MAIN	ID Assignment	Cycle	04-JUN-85	PAGE 47
CFD7:A5 5A	(3)	600 mdev1 lda Unit		
CFD9:A4 58	(3)	601 ldy slot		
CFDB:99 F9 06	(5)	602 sta NumDevices,y ;Devices out there		
CFDE:		603 *		
CFDE:		604 * Recover the scrambled ProDOS parms		
CFDE:		605 *		
CFDE:68	(4)	606 pla		
CFDF:85 46	(3)	607 sta CMDSCode		
CFE1:68	(4)	608 pla		
CFE2:85 43	(3)	609 sta CMDPCount		
CFE4:68	(4)	610 pla		
CFE5:85 42	(3)	611 sta CMDCode		
CFE7:		612 *		
CFE7: 0001		613 ifeq IIC^ROM		
CFE7:		622 fin		
CFE7:60	(6)	623 rts		
CFE8:		624 *		
CFE8:		625 *		
CFE8: 0001		626 do IIC		
CFE8: CFE8		627 AppleTalkEntry equ *		
CFE8:		628 *		
CFE8:		629 * This is an entry for the //c AppleTalk stump.		
CFE8:		630 *		
CFE8:A2 05	(2)	631 ldx #5		
CFEA:A9 40	(2)	632 lda #X01000000 ;PC call & return to alt ROM		
CFEC:9D 73 04	(5)	633 sta ProFlag,x		
CFEF:4C 55 CD	(3)	634 jmp atentry ;Just like normal		
CFF2:		635 fin		
CFF2:		636 *		
CFF2:		637 *		
CFF2: CFF2		638 squirrel equ *		
CFF2:A6 58	(3)	639 ldx Slot		
CFF4:9D F3 05	(5)	640 sta SHTempX,x		
CFF7:98	(2)	641 tya		
CFF8:9D 73 06	(5)	642 sta SHTempY,x		
CFFB:60	(6)	643 rts		
CFFC:		644 *		
CFFC:		645 *		
CFFC:		142 *		
CFFC: 0001		143 ifeq IIC^ROM		
CFFC:		145 fin		
CFFC:		146 *		
CFFC: CFFC		147 zzzzz equ *		
CFFC: 0001		148 ifeq IIC^ROM ;If not //c ROM, pad bytes		
CFFC:		153 fin		
CFFC:		154 *		

C90E ACHE1	C08F ALLSET1	?CD7D ALLSET	?CB04 ALTSENDPILE
CE3C AOKAYHITCH	C0EC AOKAY	CFE8 APPLETALKENTRY	CF90 ASSIGNID
CD55 ATENTRY	?FABA AUTOSCAN	CB61 AUXPTRINC	56 AUXPTR
? 4E AUXTYPE	? 2D BADBLOCK	01 BADCMD	? 22 BADCTLPARM
21 BADCTL	04 BADPCNT	11 BADUNIT	?E000 BASIC
C52F BC1	CECC BEHITCH	CD50 BENTRY	CC28 BIZ
0011 BMSGLEN	C521 BOOTC	?C514 BOOTCASES	C523 BOOTCODE
C552 BOOTFAIL	C55F BOOTMSG	07DB BOOTSCRN	C570 BOOTTAB
32 BSYT01	0A BSYT02	54 BUFFER	56 BUFFER2
CE27 BUNIT	06 BUSERR	? 40 BUSHOG	? 08 BYTECMP
4D BYTECOUNT	4E BYTECOUNTH	4D BYTECOUNTL	?C500 C500ORG
C082 CA1CLR	C083 CA1SET	C084 CA2CLR	C085 CA2SET
CC2C CAREFUL	C8A5 CHAINUNBSY	40 CHECKSUM	? 24 CH
CF9F CLEARIORDMS	CA8A CLRPHASES	47 CMDBLOCKH	46 CMDBLOCKL
48 CMDBLOCKS	? 46 CMDBLOCK	45 CMDBUFFERH	44 CMDBUFFERL
44 CMDBUFFER	42 CMDCODE	09 CMDLENGTH	?C58A CMDLIST
80 CMDMARK	43 CMDPCOUNT	46 CMDSCODE	? 49 CMDSPARE1
? 4A CMDSPARE2	43 CMDUNIT	C55D COMA	80 COMMRESET
04 CONTROLCMD	CDC9 COPYLOOP	?FDED COUNT	CD47 CSERRORS
10 CSUMERR	? 25 CV	CD9B DARNIT	82 DATAMARK
C999 DATDONE	C9C3 DBERROR	?CBE1 DETTOPBITS	? 50 DEVICEID
CE37 DISABINT	CB55 DIV7TAB	CB9E DIVIDE1	CBA7 DIVIDE2
CB8E DIVIDE3	CB95 DIVIDE4	CBB0 DIVIDES	?CB64 DIVIDE7
CD09 DONE5	CE2B ENABINT	?C08A ENABLE1	C08B ENABLE2
CA80 ENABLECHAIN	CD4B ENTRY	CF0F ERROR	CDBE ERRORHITCH
CE25 ERRORHITCH2	CF7A FINALSKIP	? 03 FORMATCMD	CEE3 GETRESULTS
CA47 GOB1	?C9E6 GRABSTATUS	04 GRP7CTR	CD49 GSERRORS
CBE8 GTBOB	? 51 HOSTID	CD33 ICBT15	CD2D ICBTS
CF84 ICK1	01 IIC	05 INITCMD	27 IOERROR
C080 IWM	07 IWMMODE	C08C L6CLR	C08D L6SET
C08E L7CLR	C08F L7SET	? 68 LASTONE	CBCF LASTPASS
00 LOC08	? 01 LOC1	?CD36 LSTBSYWAITS	C086 LSTRBCLR
C087 LSTRBSET	C9E3 MARKERR	CE18 MAYBECTRL	CFD7 MDEV1
CFD0 MDEV2	C50D MLIENTRY	CB5B MOD7TAB	C088 MONCLR
C089 MONSET	C554 MORCHRS	CFBC MORDEVICES	07F8 MSLOT
4D NEXT1	4E NEXT2	50 NEXT4	4D NEXT
4F NEXT3	51 NEXT5	52 NEXT6	53 NEXT7
CDFF NIN1	01 NOANSWER	CB7B NOAUXPTR	CEB1 NOCONTROL
28 NODRIVE	CDC1 NOEH	CF0D NOERROR	? 1F NOINT
? 02 NOMARK	20 NOPACKEND	CD6E NOPLAY	CDF1 NOTINIT
CE72 NOTSTAT	CEBB NOWBLOCK	CED0 NOXTRASEND	CD43 NPENDERRS
06F9 NUMDEVICES	4C ODDBYTES	2F OFFLINE	?CDC7 OKAYCNT
CA7C ONEMS1	CA7A ONEMS	C3 PACKETBEG	C8 PACKETEND
CF86 PARMCTAB	C9BE PATCH1	? A5 PBBVALUE	? FF PBCVALUE
00 PCID2	BF PDIDBYTE	CB4F PDIV7TAB	CB52 PMOD7TAB
? 52 POINTER	00 POWERRESET	C9D6 PREAMBLE	?CBB0 PRECHECK
C50A PRODOSENTRY	0473 PROFLAG	CD75 PZP	0BB8 RC1
05 RC2	C583 RCODE	4B RCVBUF	CC50 RCVCOUNT
C9F8 RDH1	CA02 RDH2	CA10 RDH3	CD39 RDH45
?CA0E RDHS	CD1E RDH45	01 READCMD	C9E6 RECEIVEPACK
CB33 RECPACK	C080 REQCLR	C081 REQSET	C460 RESETCHAIN
C576 RESET	0573 RETRY2	04F3 RETRY	? 01 ROM
? 4F RPACKETTYPE	CB3A RPK1	CB4E RPOUT	C578 RST1
CF60 RZP	CF31 SA2	CB76 SAP1	? 00 SCDEVICESTAT
? 01 SCGETDCB	? 03 SCGETDEVINFO	0473 SCHOLES	C99D SCM1
? 02 SCRETNLSTAT	C9CF SD10	C9B2 SD7	C9C9 SD9
CAEB SDOUT	CEBF SECONDSEND	CA51 SEND80	CA53 SENDBYTE
CADD SENDDATA	C886 SENDONEPACK	CAEC SENDPACK	CB00 SENDPILE

CC1F SETIWMODE	?FE89 SETKBD	?FE93 SETVID	CA9A SETXN0
CA9D SHIFT1	CAAD SHIFT2	CABD SHIFT3	CACD SHIFT4
0573 SHTEMP1	05F3 SHTEMPX	0673 SHTEMPY	C927 SKIP1
C929 SKIP2	C963 SKIP3	C965 SKIP4	CE3F SKIPCOPY
58 SLOT	CC72 SLOTDEPRD	C8E8 SOB1	C8F9 SOB2
C900 SOB3	? 67 SOFTERROR	40 SOFT	CB0D SPILE1
CB32 SPILOUT	CFF2 SQUIRREL	CBAF SSB	C8B2 SSD
?0100 STACK	CA34 START0	CA3C START1	?CC72 START25
C903 START	CA4E START2	CC7C START35	4D STATBYTE
? 81 STATMARK	1E STATMTO	? 00 STATUSCMD	CF30 STOREAWAY
CC0B SUN1	CC02 SUN2	?CC00 SUN	CC1E SUN3
0778 SVBCH	06F8 SVBCL	10 SVMASK1	C797 SWPROTO
C784 SWRTS2	?C9D7 SYNCTAB	CC66 T71	CC6F T72
59 TBODD	59 TEMP	60 THEOFF	?C000 THEORG
CC59 TIMES7	41 TOPBITS	C899 UBSY1	5A UNIT
?1000 VERSION	?FC22 VTAB	CC35 WAITIWMOFF	CF45 WAITOFF
? 04 WASRESET	?C9E2 WASTE12	C9E1 WASTE14	?C9E0 WASTE16
?C9DF WASTE18	?C9DC WASTE32	CC3E WIWM1	CC4B WIWM2
5B WPACKETTYPE	02 WRITECMD	CB64 WRITEPREP	2B WRITEPROT
CBBC XOR1	?CBB9 XOR2	CBD5 XOR3	CBDC XOR4
CBCD XOR5	CA73 YMSWAIT	40 ZEROPAGE	1C ZPSIZE
?CFFC ZZZZZ			
** SUCCESSFUL ASSEMBLY := NO ERRORS			
** ASSEMBLER CREATED ON 30-APR-85 22:46			
** TOTAL LINES ASSEMBLED 3969			
** FREE SPACE PAGE COUNT 70			

```
SOURCE FILE #01 =>INCLUDES.2CROM
INCLUDE FILE #02 =>APTALK.2CVARS
INCLUDE FILE #03 =>APTALK.C700
INCLUDE FILE #04 =>APTALK.ROMSTUFF

0000:          2 ****
0000:          3 *
0000:          4 *           AppleTalk //c
0000:          5 *
0000:          6 *           INCLUDES File
0000:          7 *
0000:          8 *           by
0000:          9 *           Fern Bachman
0000:         10 *
0000:         11 *           Copyright Apple Computer, Inc. 1985
0000:         12 *           All Rights Reserved.
0000:         13 *
0000:         14 ****

0000:          16 * This file contains the includes necessary to
0000:          17 * generate the AppleTalk //c code which goes in the
0000:          18 * //c ROM.

0000: 0002 20           X6502          ;Allow 65C02 opcodes!!
0000:          21           MSB   ON
0000:          23           INCLUDE APTALK.2CVARS
```

```

0000:      3 ****
0000:      4 *
0000:      5 *          AppleTalk //c Protocol Converter
0000:      6 *
0000:      7 *          Variables
0000:      8 *
0000:      9 *          by
0000:     10 *          Fern Bachman
0000:     11 *
0000:     12 *          Copyright Apple Computer, Inc. 1985
0000:     13 *          All Rights Reserved.
0000:     14 *
0000:     15 ****

0000:      17 * Apple //c zero page used at boot and not restored.

0000: 0008 19 ZP8 EQU $8 ;Used and not restored

0000:      21 * AppleTalk //c Converter Box stuff

0000: 0081 23 DIAGCMD EQU $81 ;Diag call command #

0000:      25 * The following table contains the only
0000:      26 * valid CODESCMD's recognized by the
0000:      27 * AppleTalk//c box when using the protocol
0000:      28 * converter's STATUS command.

0000:      30 * $0=Short status request
0000:      31 * $1=Return DCB info
0000:      32 * $2=NEWLINE info
0000:      33 * $3=Return DIB
0000: 0004 34 CMDCINIT EQU $4 ;$4=AppleTalk Init command
0000: 0005 35 CMDCSTATUS EQU $5 ;$5=AppleTalk Status command
0000: 0006 36 CMDCREADREST EQU $6 ;$6=AppleTalk Readrest cmd
0000: 0007 37 CMDREADPROT EQU $7 ;$7=AppleTalk Readprot cmd
0000: 0008 38 CMDCDIAG EQU $8 ;$8=AppleTalk Diag command
0000: 0009 39 CMDCREBOOT EQU $9 ;$9=AppleTalk Reboot command
0000: 000A 40 CMDCID1 EQU $A ;$A=AppleTalk ID call 1
0000:      41 * $B=AppleTalk ID call 2

0000:      43 * Protocol converter commands used by the
0000:      44 * AppleTalk //c firmware.

0000: 0000 46 PCSTATUSCMD EQU $0 ;Prot Conv status command
0000: 0009 47 PCWRITECMD EQU $9 ;Prot Conv write command

0000:      49 * RELVERNUM is the version number
0000:      50 * for 6502 RElease VERSION NUMber.
0000:      51 * It must be kept updated as this product
0000:      52 * is updated.

0000: 0000 54 RELVERNUM EQU 0 ;Release version #=0

0000:      56 * STATBYTE codes

```

```

0000: 00A8 58 NODEVCON EQU $28+$80 ;Dev to access not connected
0000: 60 * AppleTalk specific error codes for STATBYTE
0000: 61 * used by the AppleTalk //c firmware.

0000: 00B4 63 NOUNIQUEID EQU $80+$30+$04 ;No unique node addr found
0000: 64 BYTECTR603 EQU $80+$30+$05 ;# bytes to send >603
0000: 65 LASTPACKET EQU $80+$30+$0F ;Last packet in series
0000: 66 ID1 EQU 'F ;ID byte1 for finding ApTalk
0000: 67 ID2 EQU 'B ;ID byte2 for finding ApTalk

0000: 0004 69 PCOUNTW EQU $4 ;Write call PCOUNT
0000: 0006 70 PCOUNTS4.B EQU $6 ;Status call PCOUNT for 4-B

0000: 72 * Apple //c zero page usage

0000: 0039 74 KSWH EQU $39 ;Input hook hi byte

0000: 76 DSECT
00C0: 00C0 77 ORG $C0 ;
00C0: 00C0 78 ZP2CUSE EQU *
00C0: 0001 79 PARAMNUM DS 1,0 ;Number of parameters
00C1: 0001 80 NUMUNIT DS 1,0 ;Unit number
00C2: 0002 81 PTRBUFF DS 2,0 ;Buffer pointer
00C4: 00C4 82 CODECMDS EQU * ;Command code
00C4: 0001 83 NUMLOWRITE DS 1,0 ;# of bytes to write lo byte
00C5: 00C5 84 BYTELONUM EQU * ;# of bytes to read from box
00C5: 00C5 85 NUMHIWRITE EQU * ;# of bytes to write hi byte
00C5: 0001 86 BYTEUSER DS 1,0 ;User info byte
00C6: 00C6 87 BYTEHINUM EQU * ;# of bytes to read from box
00C6: 0001 88 TYPEWRITER DS 1,0 ;Write type code
00C7: 0002 89 TESTTMP DS 2,0 ;Diag read from address

00C9: 0001 91 ADDR0 DS 1,0 ;Used as temp and restored
00CA: 0001 92 ADDR1 DS 1,0 ;Used as temp and restored

00CB: 000B 94 ZP2CUSELEN EQU *-ZP2CUSE ;# of bytes used in //c zpage
00CB: 0002 96 BOOTIT DS 2,0 ;Boot prog strt adr

0000: 98 DEND

0000: 100 * AppleTalk //c non zero page usage

0000: 03F2 102 SOFTEV EQU $3F2 ;Reset vector
0000: 07FE 103 APTALKUNIT EQU $7FE ;Unit # screen hole
0000: 047F 104 SCRНHOLE0 EQU $47F ;DRIVERFLAG placed here
0000: 077F 105 SCRНHOLE1 EQU $77F ;Print drvr #>start-1
0000: 07FF 106 SCRНHOLE2 EQU $7FF ;Print drvr #<start-1
0000: 0478 107 SCRNTMP0 EQU $478 ;Temp use only
0000: 07F8 108 MSLOT EQU $7F8 ;Card slot # ($Cn) for ints
0000: C7D3 109 ALTROMSW EQU $C7D3 ;Switch to alt ROM vector
0000: C784 110 MAINROMSW EQU $C784 ;Switch to main ROM vector
0000: C883 111 ALTPRCNVENTRY EQU $C883 ;Alt ROM prot conv entry point
0000: FB2F 112 INIT EQU $FB2F ;Get in Text mode

```

02 APTALK.2CVARS AppleTalk //c Variables. 22-APR-85 16:01 PAGE 4

0000: FC58 113 HOME EQU \$FC58 ;Clear screen
0000: FE84 114 SETNORM EQU \$FE84 ;Normal char display
0000: FE89 115 SETKBD EQU \$FE89 ;Keyboard is input device
0000: FE93 116 SETVID EQU \$FE93 ;Video is output device

--- NEXT OBJECT FILE NAME IS APTALK.2CROM.0
C700: C700 24 ORG \$C700 ;Cn00 page for //c goes here
C700: 25 INCLUDE APTALK.C700

```

C700:      4 ****
C700:      5 *
C700:      6 *          AppleTalk //c
C700:      7 *
C700:      8 *          $C700 Routines
C700:      9 *
C700:     10 *         by
C700:     11 *         Fern Bachman
C700:     12 *
C700:     13 *         Copyright Apple Computer, Inc. 1985
C700:     14 *         All Rights Reserved.
C700:     15 *
C700:     16 *****

C700: 18 * Entry at $C700 means that the user wants
C700: 19 * to initialize the printer driver interface
C700: 20 * if one is loaded into main memory.
C700: 21 * To determine whether a driver is available
C700: 22 * or not we must perform the following steps;
C700: 23 *
C700: 24 *   1. Determine which slot we are in to get $Cn.
C700: 25 *   2. Test the 1st screen hole $3B8+$Cn to verify
C700: 26 *      that it is $Cn ($Cn is the flag indicating
C700: 27 *      a driver has been installed.)
C700: 28 *
C700: 29 * If a driver is not available the monitor ROM
C700: 30 * is mapped in and a JMP to the monitor RESET
C700: 31 * routine is executed.
C700: 32 *
C700: 33 * If a driver is available we pass data to is
C700: 34 * in the following form;
C700: 35 *
C700: 36 *      Y = user Y
C700: 37 *      X = user X
C700: 38 *      A = user A
C700: 39 *      P = Print character status
C700: 40 *          V=1 if init printer driver requested
C700: 41 *          C=1 if input to printer
C700: 42 *          C=0 if output to printer
C700: 43 * The driver can test the input/output hooks hi
C700: 44 * bytes to determine if the call is from BASIC or
C700: 45 * from machine language. If $37 is $Cn then the
C700: 46 * user did a PR#n. If $39 is $Cn then the user
C700: 47 * did a IN#n. If the hooks do not have $Cn as
C700: 48 * the high byte then the user entered from
C700: 49 * machine language. It is up to the driver to
C700: 50 * correctly observe this protocol.

C700:2C 03 C7      52     BIT    TDSETV      ;
C703:      C703 53 TOSETV  EQU    *        ;Bit here to set 'V'
C703:70 1B C720 54 BVS    BASICENT    ;
C705:      55 *BASICINPUT EQU    *        ;BASIC wants char if here
C705:38      56 SEC      ;Identifier byte #1 ($38)
C706:90      57 DFB    $90        ;BCC opcode
C707:      58 *BASICOUTPUT EQU   *        ;BASIC sends char if here
C707:18      59 CLC      ;Identifier byte #2 ($18)

```

```

#3 APTALK.C700      AppleTalk//c C700 Rtns          22-APR-85  16:01 PAGE 6

C708:B8      60      CLV      ;Clear V if entered near here
C709:00 15   C720      61      BVC      BASICENT ;Skip PASCAL protocol stuff

C70B:        63 *GENERIC EQU *      ;PASCAL generic sig byte
C70B:01      64      DFB      $01      ;
C70C:        65 *DEVSIG EQU *      ;9=bus card//B=Apple tech ID
C70C:9B      66      DFB      $9B      ;
C70D:1C      67      DFB      >PASERR ;Offset to PASCAL err rtn
C70E:1C      68      DFB      >PASERR ;Offset to PASCAL err rtn
C70F:1C      69      DFB      >PASERR ;Offset to PASCAL err rtn
C710:1C      70      DFB      >PASERR ;Offset to PASCAL err rtn
C711:88      71      DFB      $88      ;<>0 if no offsets follow

C712:        73 * The entry point APPLETALK must appear at
C712:        74 * $Cn12 in this and all future AppleTalk cards
C712:        75 * for the Apple // product line.

C712:        77 *AppleTalk Call

C712:        79 * LDY #<PARAMLST
C712:        80 * ;Y must contain hi byte of parameter list
C712:        81 * LDX $>PARAMLST :
C712:        82 * ;X must contain lo byte of parameter list
C712:        83 * LDA #$Cn
C712:        84 * ;A must contain the slt # of the AppleTalk card+$C0
C712:        85 * JSR APPLETALK
C712:        86 * ;Call the interface (in ROM in //c and in RAM
C712:        87 * section of peripheral card in //e)
C712:        88 * BNE ERRROUTINE
C712:        89 * ;<>0 then an err occurred

C712:        91 *APPLETALK EQU *      ;FIXED entry point!!!!!!!
C712:18      92      CLC      ;Vector to actual routine
C713:80 2A   C73F      93      BRA      APPLETALK1 ;Go to AppleTalk entry ptr

C715:        95 * REBOOT is accessed by a JMP/JSR to $Cn15.
C715:        96 * This causes boot code to be transferred from the
C715:        97 * AppleTalk//c converter box ROM to the //c RAM and
C715:        98 * causes the execution of that code.

C715:        C715 100 REBOOTAPTALK EQU *      ;Jmp here to reboot AppleTalk
C715:38      101      SEC      ;Set carry means reboot
C716:78      102      SEI      ;No interrupts during boot
C717:A2 FF    103      LDX      #$FF      ;Reset stack ptr for boot
C719:9A      104      TXS      ;
C71A:80 26   C742      105      BRA      APPLETALK2 ;

C71C:        C71C 107 PASERR EQU *      ;PASCAL error entry point
C71C:38      108      SEC      ;Set carry for error
C71D:A2 03    109      LDX      #$03      ;Error code for PASCAL
C71F:60      110      RTS      ;Back to PASCAL

C720:        0000 112 CN20FILL EQU $C720-* ;CN20FILL,$00
C720:        0000 113 DS      CN20FILL,$00 ;Fill to $Cn20 for BASICENT

```

03 APTALK.C700	AppleTalk//c C700 Rtns		22-APR-85 16:01 PAGE 7
C720: C720	115 BASICENT EQU *		;MUST start at \$Cn20
C720:8D 78 04	116 STA SCRNTMP0		;Save user's output byte
C723:A9 C7	117 LDA #\$C7		;Say we're in slot 7
C725:8D F8 07	118 STA MSLOT		>>>> REQUIRED <<<<
C728:08	119 PHP		;Save V/C status
C729:C5 39	120 CMP KSWH		;If=KSWH then IN#n was done
C72B:F0 E8 C715	121 BEQ REBOOTAPTALK		;If so then must reboot
C72D:28	122 PLP		;Restore V/C status
C72E:4D 7F 04	123 EOR SCRNHOLE0		;Test for driver installed
C731:D0 1A C74D	124 BNE APTEALKOFFLN		>>= to flag then error
C733:AD FF 07	125 LDA SCRNHOLE2		;Hi byte of prntr drv prg
C736:48	126 PHA		;To stack for RTS type jump
C737:AD 7F 07	127 LDA SCRNHOLE1		;Lo byte-1 of prntr drv prg
C73A:48	128 PHA		;
C73B:AD 78 04	129 LDA SCRNTMP0		;Restore user's output byte
C73E:60	130 RTS		;Exit to printer driver
 C73F: C73F	132 APPLETALK1 EQU *		
C73F:8D F8 07	133 STA MSLOT		;Save \$Cn in case of interrupt
C742: C742	134 APPLETALK2 EQU *		
C742:20 D3 C7	135 JSR ALTROMSW		;Continue in alt ROM
C745:70 01 C748	136 BVS F0S		;V=1 if from boot code
C747:60	137 RTS		;V=0 then return to user
 C748: C748	139 F0S EQU *		;From Other Side (alt ROM)
C748:B0 03 C74D	140 BCS APTEALKOFFLN		;Error so display message
C74A:6C CB 00	141 JMP (BOOTIT)		;Start of boot code
 C74D: C74D	143 APTEALKOFFLN EQU *		
C74D:AD 81 C0	144 LDA \$C081		;Switch in LC ROM
C750:AD 81 C0	145 LDA \$C081		;
C753:20 84 FE	146 JSR SETNORM		;No inverse stuff
C756:20 2F FB	147 JSR INIT		;Fix up some stuff
C759:20 58 FC	148 JSR HOME		;Clear screen for message
C75C:20 93 FE	149 JSR SETVID		;Screen is output device
C75F:20 89 FE	150 JSR SETKBD		;Keyboard is input device
 C762:A0 10	152 LDY #APOFFMSGLEN-1		;Length of error message
C764: C764	153 APOFFLOOP EQU *		*
C764:B9 6F C7	154 LDA APOFFMSG,Y		;Get character to show
C767:99 DB 07	155 STA \$7DB,Y		;Display on screen
C76A:88	156 DEY		;
C76B:10 F7 C764	157 BPL APOFFLOOP		;Loop til done
C76D: C76D	158 BRAHANGLOOP EQU *		;Hang til user presses reset
C76D:80 FE C76D	159 BRA BRAHANGLOOP		;Loop forever
 C76F:	161 MSB ON		
 C76F: C76F	163 APOFFMSG EQU *		
C76F:C1 F0 F0 EC	164 ASC "AppleTalk Offline"		
 C780: 0011	166 APOFFMSGLEN EQU *-APOFFMSG		;Length of error message
 C780: 0000	168 C7FILL80 EQU \$C780-*		;
C780: 0000	169 DS C7FILL80,\$FF		;Fill to version number

03 APTALK.C700 AppleTalk//c C700 Rtns 22-APR-85 16:01 PAGE 8

```
0000:          171      DSECT
C7FF:    C7FF  172      ORG $C7FF ;Version # goes at $C7FF
C7FF:          174 *RELVERSION EQU *
C7FF:00          175      DFB RELVERNUM ;Release version number
;
C780:          177      DEND
--- NEXT OBJECT FILE NAME IS APTALK.2CROM.1
C580:    C580  26      ORG $C580 ;$C580-$C77F in aux ROM
C580:          27      INCLUDE APTALK.ROMSTUFF
```

```

C580:          4 *****
C580:          5 *
C580:          6 *      AppleTalk //c Protocol Converter
C580:          7 *
C580:          8 *      Alternate ROM Stuff Routines
C580:          9 *
C580:         10 *      by
C580:         11 *      Fern Bachman
C580:         12 *
C580:         13 *      Copyright Apple Computer, Inc. 1985
C580:         14 *      All Rights Reserved.
C580:         15 *
C580:         16 *****

C580:          18 *ARAPPLETALK EQU *
C580:90 59 C5DB 19     BCC ARAPPLETALK2 ;Alternate ROM entry point
                           ;C=0 then regular ApTalk call

C582:          21 *DOBOOTCODE EQU *      ;Alt ROM ApTalk Reboot entry
C582:A9 C7 22     LDA #\$C7           ;Put $Cn at \$8 for boot program
C584:85 08 23     STA ZP8            ;
C586:85 C7 24     STA TESTTMP        ;<>0 then indicates from here
C588:20 06 C6 25     JSR ARINIT1       ;Verify AppleTalk online
C58B:B0 38 C5D5 26     BCS GETCODE4      ;C=1 then offline

C58D:64 C3 28     STZ PTRBUFF+1      ;Response buffer is same
C58F:A9 C2 29     LDA #>PTRBUFF      ; as send buffer.
C591:85 C2 30     STA PTRBUFF        ;
C593:A9 09 31     LDA #CMDCREBOOT    ;Reboot command
C595:20 6A C7 32     JSR CALLSETUP     ;Setup some stuff before JSR
C598:20 83 C8 33     JSR ALTPRCNVENTRY ;Call the prot conv
C59B:00 34     DFB PCSTATUSCMD    ;Prot Conv status command
C59C:C0 00 35     DW ZP2CUSE        ;Parameter buffer
C59E:D0 25 C5D5 36     BNE GETCODE4      ;<> = then errors

C5A0:45 C2 38     LDA PTRBUFF        ;Save start for later
C5A2:85 CB 39     STA BOOTIT        ;
C5A4:45 C3 40     LDA PTRBUFF+1      ;
C5A6:85 CC 41     STA BOOTIT+1      ;

C5A8:          43 GETCODE2 EQU *
C5A8:20 83 C8 44     JSR ALTPRCNVENTRY ;Call the prot conv
C5A8:00 45     DFB PCSTATUSCMD    ;Prot Conv status command
C5AC:C0 00 46     DW ZP2CUSE        ;Parameter buffer
C5AE:F0 25 C5D5 47     BEQ GETCODE5      ;= then no errors
C5B0:C9 3F 48     CMP #LASTPACKET-\$80 ;Last packet read yet?
C5B2:D0 11 C5C5 49     BNE GETCODE4      ;<> last pkt then error
C5B4:18 50     CLC               ;C=0 if last pkt received

C5B5:          52 * ROM boot program received. Now enable ACIA
C5B5:          53 * interrupt capability for AppleTalk boot
C5B5:          54 * program.

C5B5:A9 C0 56     LDA #\$C0           ;
C5B7:8D F9 05 57     STA \$5F9          ;Enable firmware to pass int

```

```

04 APTALK.ROMSTUFF AppleTalk//c Alt-ROM stuff           22-APR-85  16:01 PAGE 10

C5BA:A9 0F      58       LDA    #$F          ;Set up ACIA
C5BC:0C 9A C0    59       TSB    $C09A        ;

C5BF:      C5BF  61 GETCODE3 EQU   *          ;V=1 to indicate from here
C5BF:2C 74 C6    62       BIT    FF          ;Return to main ROM
C5C2:4C 84 C7    63       JMP    MAINROMSW   ;

C5C5:      C5C5  65 GETCODE4 EQU   *          ;Error exit for reboot routine
C5C5:38      66       SEC    ;C=1 on error
C5C6:9C F2 03    67       STZ    SOFTEV      ;RESET vctrs to basic
C5C9:A9 E0      68       LDA    #<$E000      ;BASIC coldstart location
C5CB:8D F3 03    69       STA    SOFTEV+1    ;
C5CE:49 A5      70       EOR    #$A5        ;
C5D0:8D F4 03    71       STA    SOFTEV+2    ;Power up byte
C5D3:80 EA      C5BF  72       BRA    GETCODE3  ;Exit this half of ROM

C5D5:      C5D5  74 GETCODE5 EQU   *          ;Inc for next block
C5D5:E6 C3      75       INC    PTRBUFF+1    ;
C5D7:E6 C3      76       INC    PTRBUFF+1    ;
C5D9:80 CD      C5A8  77       BRA    GETCODE2  ;

```

```

C5DB:      C5DB    81 ARAPPLETALK2 EQU *
C5DB:08    82 PHP      ;Reg AppleTalk call conts here
C5DC:D8    83 CLD      ;Make sure no ints in here
C5DD:78    84 SEI      ;MUST enter with Dec mode clear
C5DE:8C 78 04  85 STY SCRNTMP0 ;Force off int ability
                           ;Save Y temporarily

C5E1:A0 0B  87 LDY #ZP2CUSELEN ;# of bytes to save on stk
C5E3:      C5E3    88 ARSTKSVE
C5E3:B9 BF 00  89 LDA ZP2CUSE-1,Y ;Get value to save
C5E6:48    90 PHA      ;Save it
C5E7:88    91 DEY      ;Test for more
C5E8:D0 F9  C5E3  92 BNE ARSTKSVE ;<>= go for more

C5EA:86 C9  94 STX ADDR0      ;User data buffer ptr
C5EC:AE 78 04  95 LDX SCRNTMP0 ;Recall 'Y'
C5EF:86 CA  96 STX ADDR1      ;Hi byte of data buff ptr
C5F1:B1 C9  97 LDA (ADDR0),Y ;Get command #
C5F3:F0 7A  C66F  98 BEQ ARAPTALK2 ;0 is invalid command
C5F5:30 78  C66F  99 BMI ARAPTALK2 ;- then test for DIAG call
C5F7:C9 06  100 CMP #6       ; else test for valid #
C5F9:B0 78  C673  101 BCS CMDEXITE ;>=6 is illegal
C5FB:0A    102 ASL      ;Make command # into index
C5FC:AA    103 TAX      ;
C5FD:08    104 INY      ;Inc to 2nd byte in user buff
C5FE:B1 C9  105 LDA (ADDR0),Y ;Pick up the data there
C600:C8    106 INY      ;Inc index for later
C601:7C 74 C7  107 JMP (APTALKCMDS-2,X) ;Jump to routine

```

04 APTALK.ROMSTUFF AppleTalk init entry point 22-APR-85 16:01 PAGE 12

```

C604:      C604  110 ARINIT   EQU   * ;AppleTalk init call entry
C604:64 C7    111           STZ   TESTTMP ;#=0 indicates from here

C606:      C606  113 ARINIT1  EQU   * ;AppleTalk init call entry
C606:9C FE 07  114           STZ   APTALKUNIT ;
C609:      C609  115 ARINIT2  EQU   *
C609:EE FE 07  116           INC   APTALKUNIT ;Save in screen hole
C60C:A9 0A    117           LDA   #CMDCID1 ;Commands code #
C60E:20 6A C7  118           JSR   CALLSETUP ;Set up some stuff
C611:A9 C7    119           LDA   #$C7 ;Point to ROM in case
C613:85 C3    120           STA   PTRBUFF+1 ; some device sends us
C615:64 C2    121           STZ   PTRBUFF ;Lo byte is zero

C617:20 83 C8  123           JSR   ALTPRCNVENTRY ;Call the protocol converter
C61A:00       124           DFB   PCSTATUSCMD ;Prot Conv status command
C61B:C0 00    125           DW    ZP2CUSE ;Pointer to call buffer
C61D:C9 46    126           CMP   #ID1-$80 ;ApTalk ID status code 1??
C61F:D0 0F    C630  127           BNE   NOTHISUNIT ;Not ID1 then maybe last unit #

C621:E6 C4    129           INC   CODECMDS ;Commands code now CMDCID2
C623:20 83 C8  130           JSR   ALTPRCNVENTRY ;Call the protocol converter
C626:00       131           DFB   PCSTATUSCMD ;Prot Conv status command
C627:C0 00    132           DW    ZP2CUSE ;Pointer to call buffer
C629:C9 42    133           CMP   #ID2-$80 ;ApTalk ID status code 2??
C62B:D0 03    C630  134           BNE   NOTHISUNIT ;Not ID2 then maybe last unit #
C62D:18       135           CLC   ;If here then we've got it
C62E:80 04    C634  136           BRA   MAYBCONTINIT ;See it we should cont INIT call

C630:      C630  138 NOTHISUNIT EQU   * ;Test for dev not connected
C630:C9 28    139           CMP   #NODEVCON-$80 ;C=1 if bad unit # tried
C632:D0 D5    C609  140           BNE   ARINIT2 ;
C634:      C634  141 MAYBCONTINIT EQU   * ;
C634:A5 C7    142           LDA   TESTTMP ;0-init call->0=reboot call
C636:F0 01    C639  143           BEQ   ARINIT4 ;=0 then cont init call
C638:60       144           RTS   ;V=1 return to reboot call

C639:      C639  146 ARINIT4  EQU   * ;Continue init call here
C639:B0 28    C663  147           BCS   DOEXIT1 ;C=1 then AppleTalk unit not avail
C63B:A0 04    148           LDY   #CMDCINIT ;Commands code for init
C63D:80 02    C641  149           BRA   ARINIT6 ;Skip ARSTATUS entry point

C63F:      C63F  151 ARSTATUS  EQU   * ;Alt ROM status entry point
C63F:A0 05    152           LDY   #CMDCSTATUS ;Command code for status

C641:      C641  154 ARINIT6  EQU   * ;
C641:E6 C9    155           INC   ADDR0 ;Calculate user buffer
C643:D0 02    C647  156           BNE   STUPPTRS ;C=0 then leave hi byte alone
C645:E6 CA    157           INC   ADDR1 ;
C647:      C647  158 STUPPTRS EQU   * ;
C647:B2 C9    159           LDA   (ADDR0) ;Get user byte
C649:85 C5    160           STA   BYTEUSER ;Put in buffer
C64B:A5 C9    161           LDA   ADDR0 ;
C64D:85 C2    162           STA   PTRBUFF ;Put in buffer
C64F:A5 CA    163           LDA   ADDR1 ;
C651:85 C3    164           STA   PTRBUFF+1 ;
C653:98       165           TYA   ;Move commands code to 'A'

```

```
C654:      C654  167 CALLBOX  EQU   *
C654:20 6A C7    168  JSR   CALLSETUP   ;Setup some stuff for JSR
C657:20 83 C8    169  JSR   ALTPRCNVENTRY ;Go to prot conv
C65A:00          170  DFB   PCSTATUSCMD  ;Prot Conv status command
C65B:C0 00        171  DW    ZP2CUSE    ;Pointer to buffer
```

```

C65D: C65D 174 DOEXIT EQU *
C65D:F0 0B C66A 175 BEQ NECMDEXIT ;=0 then no errors to report
C65F:C9 30 176 CMP #$30 ;Less than $30 then make err4
C661:B0 02 C665 177 BCS DOEXIT2 ;
C663: C663 178 DOEXIT1 EQU *
C663:A9 04 179 LDA #NOUNIQUEID-$80-$30 ;Make no unique id error
C665: C665 180 DOEXIT2 EQU *
C665:29 0F 181 AND #$F ;Lo nibble has correct error code
C667:AA 182 TAX ;Error code must be in X
C668:D0 0B C675 183 BNE ECMDEXIT ;<>= if errors
C66A: C66A 184 NECMDEXIT EQU *
C66A:A2 00 185 LDX #0 ;0= no error
C66C:18 186 CLC ;C=0 = no error
C66D:80 07 C676 187 BRA CMDEXIT ;Exit now

C66F: C66F 189 ARAPTALK2 EQU *
C66F:C9 81 190 CMP #DIAGCMD ;Is it a DIAG call?
C671:F0 17 C68A 191 BEQ ARDIAG ;If so go do it

C673: C673 193 CMDEXITE EQU *
C673: C674 194 FF EQU *+1
C673:A2 FF 195 LDX #$FF ;Illegal command error
C675: C675 196 ECMDEXIT EQU *
C675:38 197 SEC ;Error command exit
C676: C676 198 CMDEXIT EQU *
C676:A0 F5 199 LDY #$100-ZP2CUSELEN ;# of bytes to restore
C678: C678 200 ARSTKRST EQU *
C678:68 201 PLA ;Recall value from stack
C679:99 CB FF 202 STA ZP2CUSE-$100+ZP2CUSELEN,Y ;Store value back in zpage
C67C:C8 203 INY ;Next
C67D:D0 F9 C678 204 BNE ARSTKRST ;Loop til done

C67F:B8 206 CLV ;V=0 if from here
C680:68 207 PLA ;Modify entry status to reflect
C681:29 04 208 AND #$04 ; correct exit status
C683:D0 01 C686 209 BNE NOTACTIVE ;<>0 =ints were off at entry

C685:58 211 CLI ;If here, ints were on at entry
C686: C686 212 NOTACTIVE EQU *
C686:8A 213 TXA ;Put error command in A
C687:4C 84 07 214 JMP MAINROMSW ;Exit back to main ROM

```

04 APTALK.ROMSTUFF AppleTalk diag entry point 22-APR-85 16:01 PAGE 15

```

C68A:      C68A 216 ARDIAG    EQU   *
C68A:C8     217 INY          ;Move data to param buffer
C68B:B1 C9   218 LDA (ADDR0),Y ;User buffer ptr lo byte
C68D:85 C2   219 STA PTRBUFF  ;
C68F:C8     220 INY          ;
C690:B1 C9   221 LDA (ADDR0),Y ;User buffer ptr hi byte
C692:85 C3   222 STA PTRBUFF+1;
C694:      C694 223 ARDIAG1  EQU   *
C694:C8     224 INY          ;
C695:B1 C9   225 LDA (ADDR0),Y ;User data
C697:99 C2 00  226 STA BYTELONUM-3,Y ;Put in param buffer
C69A:C0 06   227 CPY #6        ;Y=6 then done
C69C:D0 F6   C694 228 BNE ARDIAG1 ;Loop til 4 moved

C69E:A9 08   230 LDA #CMDCDIAG ;Diag command code
C6A0:20 6A C7  231 JSR CALLSETUP ;Set some stuff for JSR

C6A3:      C6A3 233 ARDIAG2  EQU   *
C6A3:20 83 C8  234 JSR ALTPRCNVENTRY ;Alt ROM prot conv entry point
C6A6:00     235 DFB PCSTATUSCMD ;Prot Conv status command
C6A7:C0 00   236 DW  ZP2CUSE    ;Ptr to commands buffer
C6A9:F0 06   C6B1 237 BEQ ARDIAG4 ;=0 then not last packet sent
C6AB:C9 3F   238 CMP #LASTPACKET-$80 ;Hi bit not fed to us
C6AD:F0 BB   C66A 239 BEQ NECMDEXIT ;=0 then last packet received
C6AF:80 B2   C663 240 BRA DOEXIT1  ;Error command exit

C6B1:      C6B1 242 ARDIAG4  EQU   *
C6B1:18     243 CLC          ;If here then more to come
C6B2:8A     244 TXA          ;Add # bytes read to buff ptr
C6B3:65 C2   245 ADC PTRBUFF  ;Lo byte to 'A'
C6B5:85 C2   246 STA PTRBUFF  ;Save for next call
C6B7:98     247 TYA          ;Hi byte to add
C6B8:65 C3   248 ADC PTRBUFF+1;Save for next call
C6BA:85 C3   249 STA PTRBUFF+1;Back for more
C6BC:80 E5   C6A3 250 BRA ARDIAG2

```

```

#4 APTALK.ROMSTUFF AppleTalk Rdprot/Rdrest entry      22-APR-85 16:01 PAGE 16
C6BE:      C6BE  253 ARREADPROT EQU  *          ;Read protocol entry point
C6BE:B8    254      CLV          ;Clear V if from here
C6BF:80 07  C6C8  255      BRA  ARREADREST2   ;Start into readrest routine

C6C1:      C6C1  257 ARREADPROT2 EQU  *          ;
C6C1:A9 07  258      LDA  #CMDCREADPROT ;Readprot command code
C6C3:80 8F  C654  259      BRA  CALLBOX     ;Call box for execution

C6C5:      C6C5  261 ARREADREST EQU  *          ;AppleTalk readrest call entry
C6C5:20 74 C6  262      BIT  FF          ;Sets V flag
C6C8:      C6C8  263 ARREADREST2 EQU  *          ;AppleTalk readrest call entry
C6C8:85 C2  264      STA  PTRBUFF    ;'A' has lo byte of RAM ptr
C6CA:B1 C9  265      LDA  (ADDR0),Y ;'A' has hi byte of RAM ptr
C6CC:85 C3  266      STA  PTRBUFF+1 ;
C6CE:C8  267      INY          ;Get/move 2 more bytes
C6CF:B1 C9  268      LDA  (ADDR0),Y ;
C6D1:85 C5  269      STA  BYTEUSER    ;
C6D3:C8  270      INY          ;
C6D4:B1 C9  271      LDA  (ADDR0),Y ;
C6D6:85 C6  272      STA  BYTEHINUM ;
C6D8:50 E7  C6C1  273      BVC  ARREADPROT2 ;V=0 then exit here
C6DA:A9 06  274      LDA  #CMDCREADREST ;Readrest command code
C6DC:20 6A C7  275      JSR  CALLSETUP   ;Set up some stuff for JSR
C6DF:20 83 C8  276      JSR  ALTPRCNVENTRY ;Call the prot conv
C6E2:00  277      DFB  PCSTATUSCMD ;Prot Conv status command
C6E3:C0 00  278      DW   ZP2CUSE     ;Buffer pointer
C6E5:48  279      PHA          ;Save for awhile
C6E6:5A  280      PHY          ;Save for awhile
C6E7:A0 04  281      LDY  #4          ;Put # of bytes read in user buff
C6E9:8A  282      TXA          ;Move to A to save
C6EA:91 C9  283      STA  (ADDR0),Y ;
C6EC:68  284      PLA          ;Move hi byte too
C6ED:C8  285      INY          ;Next loc in user buff
C6EE:91 C9  286      STA  (ADDR0),Y ;
C6F0:68  287      PLA          ;Restore error byte

C6F1:      C6F1  289 ARREXIT  EQU  *          ;
C6F1:40 5D C6  290      JMP  DOEXIT     ;

```

```

C6F4:          293 * Now move data to write into card. The
C6F4:          294 * data is obtained from the table pointed
C6F4:          295 * to in the WRITE parameter list.
C6F4:          296 * The WRITE parameter list is set up as
C6F4:          297 * follows:

C6F4:          299 * WRITETBL EQU *
C6F4:          300 * DW 1           ;Length in bytes
C6F4:          301 * DW addr of dest addr ;Ptr to dest address
C6F4:          302 * DW 1           ;Length in bytes
C6F4:          303 * DW addr of src addr ;Ptr to Src address
C6F4:          304 * DW 1           ;Length in bytes
C6F4:          305 * DW addr of LAP type ;Ptr to LAP type
C6F4:          306 * DW $bbbb        ;Length in bytes
C6F4:          307 * DW addr of DDP data ;Ptr to DDP data
C6F4:          308 * DW $bbbb        ;Length in bytes
C6F4:          309 * DW addr of ATP data ;Ptr to ATP data
C6F4:          310 * DW $bbbb        ;Length in bytes
C6F4:          311 * DW addr of misc data ;Ptr to misc data
C6F4:          312 * DW $FFxx       ;Terminator <- REQUIRED

C6F4:          C6F4 314 ARWRITE EQU *      ;AppleTalk write call entry
C6F4:AA          315 TAX             ;Save in X
C6F5:B1 C9          316 LDA  (ADDR0),Y ;Hi byte of user WRITETBL
C6F7:85 CA          317 STA  ADDR1        ;
C6F9:86 C9          318 STX  ADDR0        ;
C6FB:AA          319 TAX             ;Must save for later
C6FC:64 C7          320 STZ  TESTTMP      ;Sum of # bytes to send
C6FE:64 C8          321 STZ  TESTTMP+1   ;Hi byte of above
C700:A0 00          322 LDY  #0           ;Add together # bytes to
C702:            C702 323 SEND2MANYLP EQU * ;send to see if too many
C702:B1 C9          324 LDA  (ADDR0),Y ;Lo byte of # of bytes in buff
C704:65 C7          325 ADC  TESTTMP      ;Add to total
C706:85 C7          326 STA  TESTTMP      ;Update total
C708:C8          327 INY             ;
C709:B1 C9          328 LDA  (ADDR0),Y ;Hi byte of # of bytes in buff
C70B:1A          329 INC             ;Sets Z if A was $FF (end)
C70C:F0 0E          C710 330 BEQ  FOUNDEND    ;Off to brighter things
C70E:3A          331 DEC             ;Restore original number
C70F:65 C8          332 ADC  TESTTMP+1   ;Add to total
C711:85 C8          333 STA  TESTTMP+1   ;Update total
C713:C8          334 INY             ;Inc past buffer pointers
C714:C8          335 INY             ;
C715:C8          336 INY             ;Inc to lo byte of # bytes in buff
C716:D0 EA          C702 337 BNE  SEND2MANYLP ;Loop if here
C718:E6 CA          338 INC  ADDR1        ;> then 255 buffers if here
C71A:80 EG          C702 339 BRA  SEND2MANYLP ;;

C71C:            C71C 341 FOUNDEND EQU *      ;Restore to it's orig value
C71C:86 CA          342 STX  ADDR1        ;Do a quick chk for too many
C71E:A5 C8          343 LDA  TESTTMP+1   ;If hi byte is >=3 then too many
C720:C9 03          344 CMP  #3           ;<3 then it's short enough
C722:90 05          C729 345 BCC  ITSHORTENUF ;Error code
C724:A2 05          346 LDX  "#BYTEGTR603-$80-$30
C726:4C 75 C6          347 JMP  ECMDEIXT    ;Error command exit

C729:            C729 349 ITSHORTENUF EQU * ;If pkt len is OK come here
C729:A0 00          350 LDY  #0           ;Start back at 1st buffer

```

04 APTALK.ROMSTUFF	AppleTalk write entry point	22-APR-85 16:01 PAGE 18	
C72B:A9 04	351	LDA #PCOUNTW	;# of parameters for write call
C72D:20 6E C7	352	JSR CALLSETUP2	;Set up some stuff for JSR
C730:64 C6	353	STZ TYPEWRITE	;Data packet type is 0
C732:	C732	355 ARWRITE2 EQU *	
C732:B1 C9	356	LDA (ADDR0),Y	;Get lo byte of # bytes to send
C734:85 C4	357	STA NUMLOWRITE	;Put in buffer
C736:08	358	INY	;
C737:B1 C9	359	LDA (ADDR0),Y	;
C739:C9 FF	360	CMP #\$FF	;Terminator reached yet?
C73B:F0 1F	C75C	361 BEQ SAYSENDIT	;Yes then send 'send it' req
C73D:85 C5	362	STA NUMHIWRITE	;
C73F:C8	363	INY	;Put buffer ptrs in buff now
C740:B1 C9	364	LDA (ADDR0),Y	;
C742:85 C2	365	STA PTRBUFF	;
C744:C8	366	INY	;
C745:B1 C9	367	LDA (ADDR0),Y	;
C747:85 C3	368	STA PTRBUFF+1	;
C749:C8	369	INY	;Ready for next loop
C74A:D0 02	C74E	370 BNE ARWRITE4	;Skip inc
C74C:E6 CA	371	INC ADDR1	;For page cross
C74E:	C74E	372 ARWRITE4 EQU *	
C74E:84 C7	373	STY TESTTMP	;MUST preserve 'Y'
C750:20 83 C8	374	JSR ALTPRCNVENTRY	;Call prot conv
C753:09	375	DFB PCWRITERCMD	;Prot Conv write command
C754:C0 00	376	DW ZP2CUSE	;Buffer
C756:D0 99	C6F1	377 BNE ARREXIT	;Error then exit
C758:A4 C7	378	LDY TESTTMP	;Restore Y
C75A:80 D6	C732	379 BRA ARWRITE2	;Loop til done
C75C:	C75C	381 SAYSENDIT EQU *	;If here last packet was sent
C75C:64 C4	382	STZ NUMLOWRITE	;0 out # of bytes this packet
C75E:64 C5	383	STZ NUMHIWRITE	;
C760:85 C6	384	STA TYPEWRITE	<>0 means send Aptalk pkt
C762:20 83 C8	385	JSR ALTPRCNVENTRY	;Call prot conv
C765:09	386	DFB PCWRITERCMD	;Prot Conv write command
C766:C0 00	387	DW ZP2CUSE	;Buffer
C768:80 87	C6F1	388 BRA ARREXIT	;Return to user

04 APTALK.ROMSTUFF AppleTalk ROMSTUFF subrtns/tables 22-APR-85 16:01 PAGE 19

```
C76A:      C76A  392 CALLSETUP EQU  *          ;Setup some stuff for Prot Conv
C76A:85 C4  393     STA  CODECMDS           ;Save cmd code for Prot Conv
C76C:A9 06  394     LDA  #PCOUNTS4.B       ;# of parameters for call

C76E:      C76E  396 CALLSETUP2 EQU  *          ;Alternate entry point
C76E:85 C0  397     STA  PARAMNUM           ;
C770:AD FE 07  398     LDA  APTALKUNIT        ;Move unit number to buff
C773:85 C1  399     STA  NUMUNIT            ;Put in buffer
C775:60      400     RTS   .                  ;Back to caller

C776:      C776  402 APTALKCMDS EQU  *          ;AppleTalk init call
C776:04 C6  403     DW   ARINIT             ;AppleTalk readrest call
C778:C5 C6  404     DW   ARREADREST         ;AppleTalk write call
C77A:F4 C6  405     DW   ARWRITE            ;AppleTalk status call
C77C:3F C6  406     DW   ARSTATUS            ;AppleTalk readprot call
C77E:BE C6  407     DW   ARREADPROT         ;AppleTalk readprot call

C780:      0000  409 ROMSTUFFFILL EQU $C780-*    ;Fill character
C780:      0000  410     DS   ROMSTUFFFILL,$FF ;Fill character

C780:      28          LST   ASYM,VSYM        ;List by symbol and address
```

C9 ADDR0	CA ADDR1	C883 ALTPRCNVENTRY	C7D3 ALTROMSW
C764 APOFFLOOP	C76F APOFFMSG	0011 APOFFMSGLN	C73F APPLETALK1
C742 APPLETALK2	C776 APTALKCMD	C74D APTALKOFFLN	07FE APTALKUNIT
C5DB ARAPPLETALK2	C66F ARAPOTALK2	C68A ARDIAG	C694 ARDIAG1
C6A3 ARDIAG2	C6B1 ARDIAG4	C609 ARINIT2	C639 ARINIT4
C604 ARINIT	C606 ARINIT1	C641 ARINIT6	C6BE ARREADPROT
C6C1 ARREADPROT2	C6C8 ARREADREST2	C6C5 ARREADREST	C6F1 ARREXIT
C63F ARSTATUS	C678 ARSTKRST	C5E3 ARSTKSVE	C732 ARWRITE2
C74E ARWRITE4	C6F4 ARWRITE	C720 BASICENT	CB BOOTIT
C76D BRAHANGLOOP	B5 BYTEGTR603	C6 BYTEHINUM	C5 BYTELONUM
C5 BYTEUSER	00 C7FILL80	C654 CALLBOX	C76E CALLSETUP2
C76A CALLSETUP	08 CMDCDIAG	0A CMDCID1	04 CMDCINIT
07 CMDCREADPROT	06 CMDCREADREST	09 CMDCREBOOT	05 CMDCSTATUS
C676 CMDEXIT	C673 CMDEXITE	00 CN20FILL	C4 CODECMDS
81 DIAGCMD	065D DOEXIT	C663 DOEXIT1	C665 DOEXIT2
C675 ECMDEXIT	C674 FF	C748 FDS	C71C FOUNDEND
C5A8 GETCODE2	C5BF GETCODE3	C5C5 GETCODE4	C5D5 GETCODES
FC58 HOME	C6 ID1	C2 ID2	FB2F INIT
C729 ITSHORTENUF	39 KSWH	BF LASTPACKET	C784 MAINROMSW
C634 MAYBCONTINIT	07F8 MSLOT	C66A NECMDEXIT	A8 NODEVCON
C686 NOTACTIVE	C630 NOTTHISUNIT	B4 NOUNIQUEID	C5 NUMHIWRITE
C4 NUMLOWRITE	C1 NUMUNIT	C0 PARAMNUM	C71C PASERR
06 PCOUNTS4.B	04 PCOUNTW	00 PCSTATUSCMD	09 PCWRITEMCMD
C2 PTRBUFF	C715 REBOOTAPITALK	00 RELVERNUM	00 ROMSTUFFFILL
C75C SAYSENDIT	047F SCRNHOLE0	077F SCRNHOLE1	07FF SCRNHOLE2
0478 SCRNTMP0	C702 SEND2MANYLP	FE89 SETKBD	FE84 SETNORM
FE93 SETVID	03F2 SOFTEV	C647 STUPPTRS	C7 TESTTMP
C703 TOSETV	C6 TYPEWRITE	0B ZP2CUSELEN	C0 ZP2CUSE
08 ZP8			

00 ROMSTUFFFILL	00 RELVERNUM	00 CN20FILL	00 PCSTATUSCMD
00 C7FILL80	04 PCOUNTW	04 CMDCINIT	05 CMDCSTATUS
06 CMDCREADREST	06 PCOUNTS4.B	07 CMDCREADPROT	08 ZP8
08 CMDCDIAG	09 PCWRITEMCMD	09 CMDCREBOOT	0A CMDCID1
0B ZP2CUSELEN	0011 APOFFMSGLN	39 KSWH	81 DIAGCMD
A8 NODEVCON	B4 NOUNIQUEID	B5 BYTEGTR603	BF LASTPACKET
C0 PARAMNUM	C0 ZP2CUSE	C1 NUMUNIT	C2 PTRBUFF
C2 ID2	C4 CODECMDS	C4 NUMLOWRITE	C5 BYTEUSER
C5 BYTELONUM	C5 NUMHIWRITE	C6 TYPEWRITE	C6 ID1
C6 BYTEHINUM	C7 TESTTMP	C9 ADDR0	CA ADDR1
CB BOOTIT	03F2 SOFTEV	0478 SCRNTMP0	047F SCRNHOLE0
077F SCRNHOLE1	07F8 MSLOT	07FE APTALKUNIT	07FF SCRNHOLE2
C5A8 GETCODE2	C5BF GETCODE3	C5C5 GETCODE4	C5D5 GETCODE5
C5DB ARAPPLETALK2	C5E3 ARSTKSVE	C604 ARINIT	C606 ARINIT1
C609 ARINIT2	C630 NOTHISUNIT	C634 MAYBCONTINIT	C639 ARINIT4
C63F ARSTATUS	C641 ARINIT6	C647 STUPPTRS	C654 CALLBOX
C65D DOEXIT	C663 DOEXIT1	C665 DOEXIT2	C66A NECMDEXIT
C66F ARAPLTALK2	C673 CMDEXITE	C674 FF	C675 ECMDEXIT
C676 CMDEXIT	C678 ARSTKRST	C686 NOTACTIVE	C68A ARDIAG
C694 ARDIAG1	C6A3 ARDIAG2	C6B1 ARDIAG4	C6BE ARREADPROT
C6C1 ARREADPROT2	C6C5 ARREADREST	C6C8 ARREADREST2	C6F1 ARREXIT
C6F4 ARWRITE	C702 SEND2MANYLP	C703 TOSETV	C715 REBOOTAPLTALK
C71C FOUNDEND	C71C PASERR	C720 BASICENT	C729 ITSHORTENUF
C732 ARWRITE2	C73F APPLETALK1	C742 APPLETALK2	C748 FOS
C74D APTALKOFFLN	C74E ARWRITE4	C75C SAYSENDIT	C764 APOFFLOOP
C76A CALLSETUP	C76D BRAHANGLOOP	C76E CALLSETUP2	C76F APOFFMSG
C776 APTALKCMDS	C784 MAINROMSW	C7D3 ALTROMSW	C883 ALTPRCNVENTRY
FB2F INIT	FC58 HOME	FE84 SETNORM	FE89 SETKBD
FE93 SETVID			
** SUCCESSFUL ASSEMBLY := NO ERRORS			
** ASSEMBLER CREATED ON 15-JAN-84 21:28			
** TOTAL LINES ASSEMBLED 738			
** FREE SPACE PAGE COUNT 79			

Index

Cast of Characters

^ (caret) 12
\$ (dollar sign) 12
 (Open-Apple key) 15
65C02 21
 (Solid-Apple key) 15
32K ROM 2
3.5 ROM v

A

A register 21, 51
absolute addressing mode 14
accumulator
 See A register
accumulator addressing mode 15
ACIA 27, 37
addressing modes 14-15
 absolute 14
 accumulator 15
 implied 15
 relative 15
 zero page 14
alternate bank
 See ROM
Apple II identification 3
Apple IIe 46
ASCII input mode 17
assembly-language program(s) 10
 debugging 15
 example of 13
Asynchronous Communications
 Interface Adapter
 See ACIA

B

banks, ROM 2
booting 4
 external disk drive 3, 4
 UniDisk 3.5 4

C

C flag
 See Processor Status register
^ (caret) 12
carriage return 5
cassette output signal 3
CBus
 See Protocol Converter Bus
CLOSE 41
column overflow 5
Command Name 24
Command Number 24
commands, serial port 4-5
communications error 51
CONTROL 35-38

D

device
 control block 27, 37
 information block 27
 service interrupt 37
 status 26
disk, eject 37
disk controller unit (IWM) 7
Disk II drive, external 3
Disk IIc 7
\$ (dollar sign) 12
DOS 4

E

eject disk 37
entry point, Protocol Converter 20
error codes, summary of 51-52
external disk drive, booting 3

F

find keyboard 5
FORMAT 34

G, H, I

identification bytes 2-3
implied addressing mode 15
INIT 39
initialization 39
installing ROM 2
interrupt handler 3-4
 switching ROM banks with 3
interrupts 27, 37
 mouse movement 4
 vertical blanking 4
I/O error 51
IWM
 See disk controller unit

J, K

keyboard, disabling 5

L

leaving the Mini-Assembler 12
line feed 5

M

- machine language programs 10-11
- Macintosh with UniDisk 42, 43, 44, 45
- main bank
 - See ROM*
- mask line feeds 5
- microprocessor 21
 - See also* 65C02 registers
- Mini-Assembler 6, 10-15
 - address formats 14
 - leaving 12
 - starting 10
 - using 11
- modes, addressing
 - absolute 14
 - accumulator 15
 - implied 15
 - relative 15
 - zero page 14
- Monitor 3, 6, 10
- mouse-interrupt handler, creating 4

N

- newline status 27, 37

O

- OPEN 40
 - 15

P

- Parameter List 24
- Pascal 4
- Processor Status register 21, 51
- ProDOS 4, 20
- program counter 11
- Protocol Converter 6, 20-52
 - entry point 20
 - example of a call to 46-49
 - issuing calls to 20-22
 - locating 20
- Protocol Converter Bus 7
- Protocol Converter call(s)
 - CLOSE 41
 - CONTROL 35-38
 - FORMAT 34
 - INIT 39

Q, R

- READ 42-43
- READ BLOCK 30-31
- register(s)
 - A 21, 51
 - Processor Status 21, 51
 - 65C02 21, 25, 28, 51
 - X 25
 - Y 25
- relative addressing mode 15
- resets 36, 39
- restarting
 - See* booting
- ROM
 - alternate bank 2, 3
 - identification 3
 - installing 2
 - main bank 2
 - switching banks 2, 3
 - 32K 2
 - 3.5 v

S

- serial port commands 4-5
 - column overflow 5
 - find keyboard 5
 - line feed 5
 - mask line feeds 5
 - XON/XOFF protocol 5
- 65C02 registers 21, 25, 28, 51
 - 15
- stack space 22
- starting
 - See* booting
- starting the Mini-Assembler 10
- STATUS 25-29
- STEP command 15-17

T

- 32K ROM
 - See ROM*
- 3.5 ROM
 - See ROM*
- TRACE command 17

U

- UniDisk 3.5
 - booting 4
 - device control block with 27, 37
 - ejecting disk with 37
 - Macintosh with 42, 43, 44, 45
 - status 28
 - using CLOSE with 41
 - using OPEN with 40
 - using READ with 42, 43
 - using WRITE with 44, 45
 - using the Mini-Assembler 11

V

- vertical-blanking interrupts 4

W

- WRITE 44-45
- WRITE BLOCK 32-33

X

- X register 25
- XON/XOFF protocol 5

Y

- Y register 25

Z

- zero page
 - addressing 14
 - locations 22