

Videoterm 80 Column Display

Installation and Operation Manual

>Edit: A(djst C(py D(lete F(ind I(nsrt J(mp R(place Q(uit X(chng Z(ap [1.1]

The VIDEOTERM 80 Column Display for the Apple][computer gives full 80 by 24 upper/lower case display and compatibility with DOS, CP/M and Pascal environments. Below is a sample of Videoterm text.

of transmitting characters to a display device at ultra high speed regardless of the mapping scheme of that device or whether the device allows memory mapped display at all. The primary application of this method would be for use with word processors and communication packages.

The primary drawback of word processors that take advantage of memory mapped video is that they require the display memory to be contiguous and do not utilize advanced features such as hardware scrolling in the display device. A secondary drawback is that the word processor must be written to accomodate non-memory mapped devices as well and must handle these in a different way.

The approach to solving these problems is to define general purpose drivers that can be used with non-memory mapped devices and can also be made to drive memory mapped devices at very high speed.

(1) (2) (3) (4) (5) (6) (7) (8) (9) (0) (1) (-) (RST) (E;0) (Q) (W) (E) (R) (T) (Y) (U) (U) (O) (P) (RPT) (RETURN) (CTR) (A) (S) (D) (F) (G) (H) (W) (K) (L) (S) (G) (F) (SHIFT) (X) (C) (V) (B) (N) (M) (F) (F) (F) (SHIFT)

VIDEX VIDEOTERM Installation and Operation Manual

Curtis White

Darrell Aldrich

Fourth Edition November 1982 First Printing: March, 1980 Second Printing: August, 1980 Third Printing: January, 1982

Published by: VIDEX 897 N.W. Grant Ave. Corvallis, Oregon 97330 Phone: (503) 758-0521

All rights reserved. No part of this publication may be reproduced without prior written permission of VIDEX. Please call for more information.

Copyright © 1980 by VIDEX.

Apple][® Apple Compter, Inc.
Micromodem][® D.C. Hayes Associate, Inc.
ROMWriter® Mountain Hardware, Inc.
EasyWriter® Information Unlimited Software, Inc.
Softcard® Microsoft

Apple PIE® Programma International, Inc. Video 100 is a product of Leedex Corporation

Videx is a trademark of Videx, Inc.

TABLE OF CONTENTS

| Disclaimer Warranty | |
|--|--|
| OVERVIEW Introduction Physical Description VIDEOTERM Features Apple][Hardware Peprequisites and Options | . 1-3 . 1-6 |
| INSTALLATION AND CHECKOUT How to Install the VIDEOTERM Board Installation Checklist Checkout How to Verify Correct Performance Video Monitor Adjustment Fault Diagnosis | . 2-8 . 2-9 . 2-9 . 2-13 |
| OPERATION Using the VIDEOTERM Board VIDEOTERM Initialization Upper and Lower Case Special Key Operation | . 3-3 . 3-5 |
| SOFTWARE Apple Language Interactions Assembly Language Integer Basic Applesoft Pascal Language Considerations in General Software Examples Assembly Language Integer Basic | . 4-1 . 4-2 . 4-3 . 4-4 . 4-7 . 4-9 . 4-13 |
| Applesoft Pascal Using VIDEOTERM with Other Software EasyWriter Apple PIE Others Interfacing with Other Peripherals | . 4-22 . 4-28 . 4-30 . 4-30 . 4-30 |
| Softcard D.C. Hayes Micromodem][Creating New Character Sets Text Graphics | . 4-31 . 4-31 . 4-35 . 4-35 |

| FIRMWARE | |
|---|-------|
| Firmware Control of the VIDEOTERM Board | . 5-1 |
| CRTC Internal Register Use | .5-2 |
| How to Modify CRTC Registers | |
| Device Select Operation | .5-9 |
| Video Set-Up Flags | .5-10 |
| VIDEOTERM Memory Mapping | .5-12 |
| VIDEX VIDEOTERM Firmware Listing | .5-15 |
| HARDWARE OPERATION | |
| Theory of Operation | . 6-1 |
| Shift Wire Mod | . 6-4 |
| The Soft Video Switch | |
| APPENDIX | |
| ASCII Character Code Chart | . A-1 |
| Owners Notes | |
| Technical Summary | |

PROGRAM LISTINGS

| Program | Listing 1 | | | | | | |
|-------------------|---|--|--|--|--|--|--|
| Program | Listing 2 | | | | | | |
| Program Listing 3 | | | | | | | |
| Program | Listing 4 | | | | | | |
| Program Listing 5 | | | | | | | |
| Program Listing 6 | | | | | | | |
| Program Listing 7 | | | | | | | |
| 3 | · | | | | | | |
| | FIGURES AND ILLUSTRATIONS | | | | | | |
| Fig. 1: | Board Installed in System: Interior View 2-2 | | | | | | |
| Fig. 2: | VIDEX Switchplate Assembly Mating | | | | | | |
| g | with VIDEOTERM Board | | | | | | |
| Fig. 3: | Board Installed in System: Exterior View 2-6 | | | | | | |
| Fig. 4: | Insertion of Character Set EPROM into | | | | | | |
| g | the VIDEOTERM Board4-35 | | | | | | |
| Fig. 5: | Line Drawing Character Set Keyboard | | | | | | |
| g. O. | Correspondence | | | | | | |
| Fig. 6: | Alternate Character Sets | | | | | | |
| Fig. 7: | Standard Character Set | | | | | | |
| Fig. 8: | Blank Forms for Future Character Sets 4-52 | | | | | | |
| Fig. 9: | VIDEOTERM Soldering Points6-7 | | | | | | |
| Fig. 10: | VIDEOTERM Board Photograph | | | | | | |
| Fig. 11: | Schematic Diagram of VIDEOTERM Board Endsheet | | | | | | |
| | | | | | | | |
| TABLES | | | | | | | |
| Table 1: | VIDEOTERM Use of Apple][RAM | | | | | | |
| Table 2: | VIDEOTERM Control parameters | | | | | | |
| Table 3: | Address Definitions by Language | | | | | | |
| | | | | | | | |
| Table 4: | CRTC Register Assignments | | | | | | |

Notice:

Videx, Inc. reserves the right to make improvements or changes in the product described in this manual at any time without notice.

Disclaimer of All Warranties and Liability:

Videx. Inc. makes no warranties, neither express nor implied except as explicitly set forth in the Limited Warranty below, with respect to this manual nor with respect to the product described in this manual, its quality, performance, merchantability or fitness for any purpose. Videx, Inc. software is sold or licensed "as is". The entire risk as to its quality and performance is with the buyer. Should the programs prove defective following their purchase, the buyer (and not Videx, Inc., its distributors, or its retailers] assumes the entire cost of all necessary servicing, repair, or correction and any incidental or consequential damages. In no event will Videx, Inc. be liable for direct, indirect, incidental, or consequential damages resulting from any defect in the hardware/software, even if Videx, Inc. has been advised of the possibility of such damages. Some states do not allow the exclusion or limitation of implied warranties or liability for incidental or consequential damages, so the above limitation or exclusion may not apply to you.

VIDEX VIDEOTERM

Limited Warranty:

Videx, Inc. warrants this product to be free from defects in material and workmanship for a period of ninety [90] days from the date of original purchase, Videx, Inc. agrees to repair or, at our option, replace any defective unit without charge. Videx, Inc. assumes no responsibility for any special or consequential damages. No other warranty, neither express nor implied, is authorized by Videx, Inc. Some states do not allow the exclusion or limitation of implied warranties or liability for incidental or consequential damages, so the above limitation or exclusion may not apply to you.

Please return the registration card in order that VIDEX can notify you of new products, VIDEOTERM updates and new software.

Mail to: VIDEX

897 N.W. Grant Ave. Corvallis, OR 97330 * IMPORTANT NOTICE: THE VIDEOTERM MUST NOW BE PLACED only IN SLOT 3. *

Since this manual was published, some changes have been made in the Videoterm and other products. The Soft Video Switch, an automatic version of the Switchplate, was introduced. We generally recommend use of the Soft Video Switch over the Switchplate, however the two may be used together. A new release of firmware, Firmware 2.4, has been included on your Videoterm. Here are some of the features which have been added to your Videoterm by the new firmware:

- * The popular Escape I, J, K & M cursor movement commands
- * Pascal Card Type 6 protocol (eliminating the need for the
- program Vidpatch, found on page 4-27)

 * The Monitor /// is supported (a CRT from Apple Computer)
- * The Soft Video Switch is supported (page 6-5)
- * The Shift Wire Mod is supported (page 6-4)
- * CP/M's inverse/normal protocol (CNTL-O/CNTL-N)
- * Interrupts are handled properly
- * 20% faster output

There are two features documented in this manual which have been removed:

- * The 80 characters by 18 line format (used by the 7 x 12 character
- * Slot independence (the Videoterm MUST be placed in Slot 3)

More new products for your Videoterm include an 80 column VisiCalc Pre-Boot Disc, an AppleWriter] [Pre-Boot Disc and a Videoterm Utilities Disc.

OVERVIEW

Introduction

The new Apple II peripheral that you have just purchased combines the features of an asynchronous serial interface card with the "guts" of a high speed terminal to transform your current black and white video monitor into a full feature intelligent video display terminal. When properly adjusted, the interface card clearly displays upper and lower case characters using a 7 by 9 character dot matrix size (the full matrix is actuall 9 by 9). An optional 7 by 12 matrix size (full size is 9 by 12) is also available. You may select for 18 or 24 lines each containing 80 characters. Special characters may be defined by the user and preprogrammed EPROM chips are available that offer various character fonts. These capabilities are available under both the Pascal operating system and both Basic languages that Apple Computer. Inc., supplies.

All of these features are included on one printed circuit (PC) board, the size of the Applesoft or Language board, utilizing only 24 integrated circuits. The use of CMOS and low power electronic components reduces the power draw needed for the board to properly function and virtually eliminates power conflicts with other expansion cards. An on-board clock circuit regulates video signal timing, providing the user with a clear, flicker-free video image.

The firmware used with the VIDEOTERM board is fairly transparent to standard Apple II and Apple II-compatible software. The call addresses for various board functions are fully documented, allowing you to interface your software directly with the display software if you desire. Specific software interface information for the D. C. Hayes

Micromodem II (requires an EPROM replacement firmware chip available from VIDEX), the ROMWriter by Mountain Hardware, EasyWriter by Information Unlimited Software and the Microsoft Softcard is included. A variety of other software application examples are included, along with specifics on Apple Basic interaction with the VIDEOTERM.

The remainder of this Overview chapter is devoted to a description of the physical appearance of the VIDEOTERM board, a full description of all features of the board and the necessary Apple II system prerequisites for its proper functioning.

It is best to close with a word of advice concerning your new purchase. Treat it well and with respect as the quality instrument that it is and it will reward you with years of service, probably lasting through the life of your Apple II system. If any difficulty with the unit arises, you should contact the store where you purchased the VIDEOTERM. They should be able to determine if the fault lies with the VIDEOTERM or if your video monitor is incorrectly adjusted. If they cannot help you, please feel free to contact VIDEX directly so that the problem may be quickly corrected.

Physical Description

As you can see when you hold the VIDEOTERM board in your hand, the board is small, compact and relatively uncluttered with electronic components. The implementation of the interface design is quite economic, both in terms of initial purchase price and by minimizing the number of parts which may fail. The board measures only 7.25 by 2.75 inches, about the same size as the Applesoft Basic firmware card or the Language card.

As you look at the component side of the board, you will notice a small crystal can on the right-hand side of the board, possibly with the label 'Crystek'. This is the on-board crystal clock which, with the rest of the clock logic circuit, ensures flicker-free display characters on your monitor. The clock should be labelled 17.430.

At the upper left of the board, you will see the four small prongs of the video signal takeoff jack and a fifth small prong next to it which is the light pen takeoff jack. It is designed to be used with a possible optional light pen.

A separate connector is included which connects these five prongs to a standard video output female This connector will not be included if you have purchased the optional, and more versatile, Switchplate assembly with your VIDEOTERM. Switchplate assembly has an identical connector end to attach to the VIDEOTERM board. The assembly allows you to switch between the VIDEOTERM's video output signal and the Apple II's video output signal without having to change any of the cable separate jumper connections. Α cable. double-ended male RCA audio cable, connects a second female video jack on the Switchplate to the Apple II's video monitor output female jack located on the

rear of the computer next to the cassette I/O ports. By a simple flick of the switch, you may then display either PR#0 output on your video monitor, this being in the standard default Apple II video output format of 24 lines by 40 characters, or PR#n output (where n is the number of the slot in which the VIDEOTERM board has been placed), which is in the VIDEOTERM output format. Thus, you need only use one monitor with the VIDEOTERM, although it is more convenient and provides more user options if you have two monitors, one a color TV connected to the standard Apple II video output (through a standard RF Modulator), the other a black and white video monitor connected to the VIDEOTERM board. This allows simultaneous displays of 24 lines of text, each line containing 80 characters, and full high resolution, color graphics or another 24 lines of text, each line containing the Apple II standard of 40 characters.

The large chip in the middle of the board is the CRT Controller (CRTC) chip. Above it is the EPROM (erasable programmable read-only memory chip) which contains the current optional character set which the board may display. By switching this EPROM with another, the optional character set may be changed. The board comes equipped with the standard ASCII character set in a second EPROM located below and to the right of the long CRTC chip. The Character Generator chip, located above the CRTC and to the right of the optional character set EPROM, does the actual work of creating the display character. The VIDEOTERM board is described fully in the Hardware Operation chapter starting at page 6-1. A labelled photograph and a complete board schematic drawing are included as Figures 10 and 11, respectively.

At the bottom right of the board, a part of the board protrudes and has many parallel electrical contacts printed on it. This is the expansion slot interface connector. It is this part of the board

which will be pushed into the Apple II's expansion bus slot to install the VIDEOTERM. You should avoid touching the connectors with your fingers as this may impair the quality of electrical contact. In general, hold the card by its edges when examining it and grasp it firmly by its upper corners when installing or removing it from the Apple II.

VIDEOTERM Features

The VIDEOTERM Board offers you a great many features, some of which are only found on more expensive video display terminals. A complete list of all features is given below. At the end of each description, a manual page reference is given so that you may immediately read more concerning that feature. This allows you to use this section as a cross-index to the more detailed instructions and information which follow.

- <1> 80 Character columns by 24 character lines are displayed at once. The number of lines is changeable to 18. You will definitely want to use the 18 line mode if you have purchased the optional 7 by 12 character matrix EPROM (pages 3-3 to 3-4).
- Text is printed in upper and/or lower case at your discretion (page 3-5). All 96 ASCII display characters are available, as are some of the control characters and a set of graphics characters (Table 2, page 3-4).
- <3> All text character entry is done directly using the Apple II's keyboard. "CTRL-A" keystroke sequence is used to shift from upper to lower case, and from upper case (page 3-5). Lower lower to stored internally as case letters are lower case and do not have "CTRL-A" embedded with them. Alternate entry keystroke sequences are needed to the VIDEOTERM features. access some of These are all fully defined herein (pages 3-6 to 3-10).

- You have direct screen cursor control in Apple's Basic languages using the familiar ESCape key sequences (pages 3-8 to 3-9). In Pascal, cursor control is the same as the Pascal defaults and may be controlled using GOTOXY (pages 3-9 to 3-10 and 4-28).
- <5> is completely The VIDEOTERM board compatible with Pascal. You will not need any software 'patches' to make the right the first time, every board work (page 4-4). time Applesoft Basic and Integer Basic usage requires some slight modification to existing user programs precautions in writing some programs that access the VIDEOTERM, but these are well-defined and have been kept to a minimum. Such constraints are fully described (pages 4-2 to 4-4).
- 6> Both Basics are listed on the VIDEOTERM using all 80 columns. Keywords are not split and you may start or stop listings by using the "CTRL-S" entry just like the Apple Autostart ROM (page 3-8).
- <7> The VIDEOTERM board generates an almost immediate response to all inputs. The effective transfer rate between the the display is extremely computer and approximately 12,000 BAUD. Speed high. enhanced because there is no need to encode the signal into a standard parallel or serial interface format. very quick screen response is evident in all text printing and scrolling.
- <8> The VIDEOTERM board follows all OEM specifications as issued by Apple Computer, Inc. This guarantees that your board will be fully compatible with all

current and future Apple II peripherals (pages 3-1 and 4-30 to 4-33). The economy minded design of the board ensures that the VIDEOTERM board power draw will be low, further reducing peripheral conflicts.

<9> The board is compatible with the Apple Serial Interface board. the Asynchronous Serial Interface board, the D. C. Hayes Micromodem II (using optional customized firmware available the Microsoft Softcard, and many other peripherals that allow interaction with a video display terminal 4-33ff). VIDEOTERM is compatible with EasyWriter Professional the Processing System, the Apple PIE editor and other word processors available for Apple II (page 4-30). With only the slight modifications, you will find that most software will work excellently with the VIDEOTERM. And the board compatible with VIDEX KEYBOARD the ENHANCER, allowing direct lower case text entry from the Apple II keyboard (pages 1-11).

<10> The VIDEOTERM board allows you the option of displaying, either through keyboard or software control, a set of user defined predefined graphic character sets, in addition to the standard 96 ASCII display characters. Although more limited than the Apple high resolution graphics, many interesting graphical displays can be generated in this fashion. Using the Mountain Hardware ROMWriter (or EPROM programmer) the user can create any desired graphical or character set (page 4-35ff).

- VIDEOTERM in no way interferes with the memory-mapped graphics display of the Apple II itself (page 5-12 to 5-14). You may thus generate graphical output on either of the two high-resolution graphics pages, or display text data on the direct Apple II video monitor and also have a full page of text and/or VIDEOTERM graphics symbols displayed on your black and white monitor.
- <12> Optional hardware modifications may be made to the VIDEOTERM. These allow use a 2708, 2716 or 2758 EPROM for the set, setting the optional property of the contract of the contr character entire screen to inverse video (black white field), or using characters on а the characters eighth bit to invert that one character (the cursor is lost in this option). These hardware modifications are simple and fully described herein (pages 6-4 to 6-8).
- <13> The VIDEOTERM cursor is fully programmable in size and may be set to flash at one of two different rates (page 5-8).
- You may simultaneously display on the VIDEOTERM text that is being sent to a printer (pages 4-9 to 4-13). This software may be modified to allow you to examine what your printer will print before actually doing so.

Apple II Hardware Prerequisites and Options

To fully use all the features and capabilities of the VIDEOTERM board, you should have the following pieces of equipment. However, any Apple II or Apple II Plus with at least 16K of RAM will work, even if the VIDEOTERM is your only Apple II peripheral.

- (1) An Apple II or Apple II Plus, with at least 16K of Random Access Memory.
- (2) A black and white video monitor. We have found the Leedex video-100 monitor and the Sanyo monitor to be excellent monitors for use with the VIDEOTERM. Any monitor that can handle at least a 12 mH bandwidth is acceptable. We have even heard of use of the VIDEOTERM with a TI Color monitor, but the use of Color monitors is not recommended.
- (3) Optionally, an RF Modulator linked to a Color TV to use for graphics displays, additional text displays and as the monitor when the system is first turned on.
- (4) Optionally, at least one, and as many as six, disk drives for full system utilization.
- (5) Optionally, an Apple Language card. The 80 character per line VIDEOTERM screen display format is especially useful with Apple Pascal (or the Softcard).
- (6) Optionally, a VIDEX Switchplate assembly may be added to allow easy use of a single monitor for both Apple II standard video output and VIDEOTERM output.

- (7) Optionally, a VIDEX KEYBOARD ENHANCER for full text entry, both upper and lower case, direct from your Apple II keyboard. This allows access of nine new characters and operates in three different modes.
- (9) Optionally, a ROMWriter or other EPROM programmer for creation of user defined character and graphic sets.

How to Install the VIDEOTERM Board

VIDEX VIDEOTERM consists of two parts: the VIDEOTERM board itself and a connector from the the video monitor. An optional product, board to the VIDEX Switchplate assembly is also called The VIDEX Switchplate assembly has its available. attached jumper cable that replaces the simple connector. If you have installed various standard peripherals before, then you should scan Apple II these instructions, examine the photographs, follow the checklist at the end of this section as you install the board, and then proceed directly to the Checkout section, page 2-9. If you have never peripheral card in the Apple installed a expansion slots, then carefully read the following explanation through completely at least twice before attempting the installation. After the detailed explanation, there is a short checklist, page 2-8, to follow when installing the board.

To orient you as to how the board appears when installed, a photograph of the completed installation is included as Figure 1. The view shows the inside of the Apple II with the completed installation, including the Switchplate. Examine these photographs carefully before installing the board and again after installation but before turning on your computer's power switch.

VIDEX CAN ASSUME NO LIABILITY OR RESPONSIBILITY FOR DAMAGES CAUSED BY INCORRECT VIDEOTERM INSTALLATION!

So please double check all connections before you power up the system.

In the following instructions, it is assumed that you are seated at your Apple II, with the

keyboard directly in front of you as if you were about to type. You should clear the top of the Apple II so that you can easily open the computer case and install the board.

- (1) Turn the power switch OFF. The power switch is located at the rear of the Apple II near the power cord connector. It is imperative that this be done, as permanent damage may be done the VIDEOTERM board, the Apple II Motherboard and/or any of the other peripheral boards that may be plugged into the expansion bus at the time. It is much more safe and sure to also completely detach the power cord from the Apple II. That way, it is impossible to accidently have power supplied to the computer before you are ready.
- (2) Remove the cover from the Apple II. Grasp the cover under its rear lip at each corner using, one hand at each corner, and pop the cover loose from its fasteners. Then pull the cover




Figure 1: Board Installed in System: Interior View

- directly out toward the rear to avoid possible prying on the keyboard. When the cover is free, lift and remove it from the Apple II.
- (3) Inside. covering almost the entire bottom of the computer case, is the green PC Motherboard of the Apple II. Across the rear of the Motherboard is a row of 8 connectors or expansion slots. It is into one of these slots that you will install the VIDEOTERM The leftmost slot is slot #0 and the rightmost slot is #7, with the other slots numbered sequentially between the two. #0 should contain your Basic firmware card, containing either Applesoft or Intger Basic, or the Apple Language card. Slot #6 should be reserved for use with the Apple Disk controller card. The VIDEOTERM board may go into any of the other slots, but strongly recommended that it be placed in slot #3, as this is the slot that Pascal expects a terminal to be located in. Standard Apple II software will undoubtedly be written with this consideration in mind, so it is probably best just to use slot #3 right from the start. However, there is no penalty for not using slot and complete information regarding this use of the other slots is given herein. All examples will assume that the VIDEOTERM board has been placed in slot #3.
- (4) Attach the optional VIDEX Switchplate assembly, if you have one, to the outside of the Apple II case in one of the notches cut into the case for that purpose. Any notch may be used, since the connector, which will the VIDEOTERM attach to board, is sufficient length to reach the regardless of the location of the installation slot. To attach the VIDEX Switchplate assembly, loosen the two screws (you should

not completely remove them as this will make installation a little harder), separate the the assembly and slip the PC boards of assemb1v into a notch. The plate of the assembly which has the switch and two video I/O ports should go on the outside while the board with the VIDEOTERM connector should go inside. the Orient the Switchplate assembly so that the ports are on the bottom switch is on top. the Center Switchplate in the notch and clamp it into place by tightening the two screws on the Switchplate assembly.

the VIDEOTERM board's protruding (5) Position expansion slot interface connector directly over the chosen expansion slot. The card be aligned vertically and not twisted any manner. Holding firmly onto the board, push the expansion corners of the interface connector into its slot. Check that




Figure 2: VIDEX Switchplate Assembly Mating with the VIDEOTERM Board

the board is firmly pushed all the way into the slot by rocking it a bit. Make sure that the board has not been tilted down toward the center of the Apple II, as this could result in incomplete connections with the expansion bus (probably with disastrous effects when the power is turned on).

- (6) Attach the enclosed connector to the five video output takeoff prongs on the board as shown in Figure 2 (this connector also slides onto the light pen prong). If you have the VIDEX Switchplate assembly, attach its connector to the VIDEOTERM board in exactly the same manner. The standard connector will not be included if you have also purchased the VIDEX Switchplate assembly. Note that the positioning of the 5 prongs and the design of the connector makes it virtually impossible to connect the two incorrectly.
- (7) Attach your video monitor to the VIDEOTERM by plugging the male end of the video monitor input plug into the female plug on the enclosed connector. If you have the Switchplate assembly, plug your video monitor male plug into the female plug on the outside of the Switchplate assembly. It should go into the upper of the two I/O video ports, the one labelled M for Monitor.
- (8) If you are using the optional VIDEX assembly, then you should use a Switchplate separate standard double-ended male RCA audio cable to connect the lower video monitor input port on the Switchplate assembly (labelled A for Apple) to the Apple II's video monitor The Apple II's port is located output port. next to the cassette I/O ports on the rear of Apple II. Figure 3 shows the completed assembly of the VIDEX Switchplate assembly and

its connections from a back exterior viewpoint. Flip the switch on the Switchplate the right position (assuming that you are still seated facing the keyboard) so that you sending PR#0 output to your video will be This will assist in checking out the monitor. VIDEOTERM board as you can tell if your video monitor is working when you turn on your Apple II. If you have Apple Language card, you need make this connection and you should place the switch on the VIDEX Switchplate assembly left position. Actually, if you run in the just Pascal, you will not need the VIDEX Switchplate assembly but can make do simply with the enclosed, less versatile, standard However, you will find this less connector. convenient when using either Basic language.




Figure 3: Board Installed in System: Exterior View

- (9) Carefully replace the Apple II cover. At the same time, press down firmly on both rear corners of the lid to resecure it.
- (10) Reattach the power cable and turn on the power switch located on the back of the Apple II.

Installation Checklist

You are now ready to proceed to the Checkout section, page 2-9. To assist you in the actual installation, you may wish to use the following outline as a checklist.

- (1) Turn OFF the power switch and unplug the power cord.
- (2) Remove the cover.
- (3) Insert the VIDEX Switchplate assembly, if you have it, into a notch and tighten its clamp.
- (4) Insert the board into the chosen expansion slot.
- (5) Attach the enclosed connector to the 5 takeoff prongs on the board. If you have it, attach the VIDEX Switchplate assembly's connector to the VIDEOTERM board instead of the connector. (Note that the standard connector is not included if you have purchased the VIDEX Switchplate assembly.)
- (6) Connect your video monitor input plug to the appropriate output plug depending on your use of the enclosed connector or the VIDEX Switchplate assembly.
 - (7) Connect the Switchplate assembly to the Apple II's video monitor output port using a separate double-male audio plug. Place the switch in the right position (left if you have Pascal).
 - (8) Recheck <u>all</u> connections. Replace and resecure the cover.
 - (9) Plug in the power cord and turn on your Apple II!

Checkout

Naturally, the first thing that you will want to do is verify that the VIDEOTERM board is working correctly and that all of its features operate as described. This section will tell you how to make sure that the board is operating normally, make minor adjustments and fix minor errors, or diagnose serious hardware problems which would justify contacting us. All boards are tested before sale, but problems can arise with anything, electronic or otherwise.

A. How to Verify Correct Performance

Verification of board performance will be discussed by type of Apple II system configuration. We need to discuss each language and how the Autostart ROM presence or absence affects the checkout. We will start with a standard Basic Apple II system utilizing one of the two Basic languages. Before we try the board using one of the Basics, however, we will use the Apple II Monitor to do some initial adjustment.

When you turn your system on, it should beep and fill the screen with question marks and/or other symbols and an asterisk with a flashing square cursor next to it will appear near the lower left corner, indicating that you are in the Apple II Monitor. The Monitor's capabilities are described at length in the Apple II Reference Manual. Suffice it to say here that the Monitor is very powerful and you may adequately verify the VIDEOTERM board's correct response from here with a few simple tests.

If you have the Autostart-ROM installed in your Apple II, the probable conditon with the Apple II-Plus, you will see

APPLE II

at the top center of your screen. If you have the Disk II system, it will automatically be turned on and a copy of the DOS will be written into your Apple's RAM. Your "HELLO" program that you "INIT"ed the diskette with will be loaded and run. Without the Disk II peripheral, your computer will simply go into either the Applesoft or Integer Basic language, depending on which language is set as the default. (The default language is the one in the Apple II in its Motherboard sockets \$D8 to \$F8, or on your Applesoft or Integer Basic card depending on its switch position.) Once you are in either language, type

CALL -154 (CR)

and you will be placed in the monitor mode.

If you have the standard Monitor ROM, initialize your disk operating system (if you have one), as this will make some of our later tests a little faster. You do this, of course, by typing "6 CTRL-P", where the hyphen indicates that you hold down the Control key while depressing the P key. Naturally, you will terminate all your responses to the Apple II by striking the Return key. After your disk drive finishes whirring, return to the Monitor by pushing the Reset button.

Now, no matter your system configuration using the Basic languages, you are ready to activate the VIDEOTERM board. Type "3 CTRL-P", if you have the board in slot 3. If not, type "n CTRL-P", where n is the number of the slot that you have placed the board in. Flip the switch on the VIDEX Switchplate assembly to the left position. Asterisk should be visible on the Left side of the monitor display with a flashing cursor next to it. Reenter either Basic by typing

*3DOG (CR)

and ask for a "CATALOG". If you don't have a Disk II system, then reenter either Basic by typing "CTRL-B" and fill the screen with caracters by depressing any alphanumeric key and. depressing it, hold down the Repeat key for a few You might want to pause at this time and fine adjust your video monitor since your screen should now be almost full of characters. (With Disk II, try to CATALOG a full diskette so that you can down the entire left side of your characters screen.) If everything is proceeding smoothly, load and list a Basic program. If you have both versions of Basic installed, try typing "FP" or "INT" as appropriate, and loading and listing a program in the other language. If you don't have the Disk II system, then you can change Basic languages by typing

>POKE -16256,0 (CR) (Integer)

?OVERFLOW ERROR IN 60908 (or similar error message will appear on screen)

*"CTRL-B" (CR) (Enter Applesoft)

or

POKE 49280,0 (CR) (Applesoft)
*"CTRL-B" (CR) (Enter Integer Basic)

which will work with or without the Autostart-ROM. Note that "CTRL-B" should not be typed literally, but means that you should strike the B key while holding down the Control key.

If you have a problem at any time, refer first to the Video Monitor Adjustment section, page 2-13, and then proceed to the Fault Diagnosis section, page 2-16 if your question still has not been answered. If everything has been verified, then you may proceed to the Operation section, page 3-1 below.

If you are lucky enough to have either the Apple Language card or the Microsoft Softcard, you will especially enjoy the convenience of the full 80 character wide display and soon be making full use the lower case capabilities. It is very of important that you place the board in slot 3, as this is the normal terminal display interface slot. explained above, you will not need the VIDEX Switchplate assembly for exclusive Pascal use of the VIDEOTERM board, although it is convenient to have so that you can use more than one monitor at a If you do have the VIDEX Switchplate time. assembly, make sure the switch is in the left position. Go ahead and activate your system by turning on your Apple II. If by chance you have replaced the Autostart ROM with its non-Autostart brother, then you will have to type "6 CTRL-P". You should see the Pascal announcement in the center of vour screen. Proceed to the Video Monitor Adjustment section, page 2-13, until you do have the display.

As soon as you have the Pascal menu prompt line showing, go ahead and try asking for a directory. Feel free to try editing any of your programs. You'll be amazed at the different look your programs and text will have. If you have any difficulties, reread the Video Monitor Adjustment section, page 2-13. If all else fails, consult the Fault Diagnosis section, page 2-16.

B. Video Monitor Adjustment

Let us start with the worst possible case and work toward less dramatic problems.

<1> No picture at all: Always begin by checking what is simplest to fix and usually makes you feel the dumbest. Is the TV monitor turned on? Is it plugged into the power outlet? you know that the video display works? Could it have burned out tubes? Carefully recheck the connections associated with the board. being sure to turn off the Apple II before you do any radical wiggling of the board. Are the connections as described in the section on How to Install the VIDEOTERM board, page 2-1? the switch in the correct postion on the VIDEX Switchplate assembly? Are all the connections tight? If everything is OK, you should be seeing something on the video display. If the screen is obviously on but you cannot see anything, proceed to the next possibility.

- <2> No visible characters: This is probably due to the screen contrast and brightness controls being slightly out of adjustment. Turn both the contrast and the brightness controls up see if you notice anything. The next possibility is that the display is shifted slightly off the screen. Look for the horizontal and vertical hold adjustments. which should be located on the front of your monitor. Try twisting each of these slightly in either direction. You should be able to see some type of signal being displayed. Use these two controls to steady and center the display. Once the screen is filled with characters, you might notice that the ones at the top are slightly larger or smaller than the ones at the bottom of the screen. Quite often black and white monitors will have a vertical-size, vertical-line (or linearity) and horizontal width adjustment controls. Usually, these controls will be on the back of the set. Infrequently, they are located inside the cabinet. You should not try to open the cabinet to adjust them, unless you are qualified in servicing TVs. By adjusting these controls, you should be able to obtain a uniform character image over the entire display.
- <3> Persistent rolling: Use the vertical hold adjustment. If you can not correct this, consult the Fault Diagnosis section, page 2-16.
- <4> Bent characters: Try adjusting the horizontal hold adjustment control very slightly in both directions. This problem usually occurs on the top line of the screen.
- <5> <u>Uneven sized characters</u>: Usually caused by incorrect adjustment of the vertical linearity

- control. Try varying the setting of it slightly in each direction.
- <6> Indistinct or fuzzy characters: This can usually be corrected by adjusting the focus, fine focus, brightness and/or contrast controls. Characters may be distinctly smeared if your monitor is not terminated with 75 ohms of impedance or if the input gain is too high.
- <7> Overall pointers: One thing to check if you are having problems is the resistance setting on some monitors. The 75 ohm setting should monitors have a focus used. Some be adjustment and this can be used to sharpen or clarify the image. Don't be discouraged. Patiently try various combinations of settings without radically changing anything. You should soon have a clear picture. If you are still having problems, perhaps a friend or the dealer that you bought the board from could help you. If all else fails, please feel free to contact VIDEX directly and we'll be happy to try to help you solve the problem.

Fault Diagnosis

If you are using a standard black and white TV set, we suggest that you modify the TV for use strictly as a video monitor. Don Lancaster's The Cheap Video Cookbook (Howard W. Sams & Co., Indianapolis, IN, 1978) contains the information needed for this transformation on pages 148 to 150.

Our extensive testing of the VIDEOTERM and our experience based on direct feedback after thousands of user hours has convinced us that the VIDEOTERM is generally quite error free. If you suspect a hardware problem, go to your local Apple dealer and ask him to briefly test the various Integrated Circuits on the VIDEOTERM. This can be done by simply swapping in new ICs, an easy task since all ICs are fully socketed and not soldered in place. A bad IC will be at the root of most problems.

Also, have your dealer check the various solder blob connections described in Optional Hardware Modifictions, starting on page 6-4. The solder points X1 and X2 should match the IC U5 (see Figure 10) specification, X3 and X4 must match the choice of 2708 or 2716 EPROM, and X5 must match with X6. X7 will be set as normal video when you receive the board. These connections are illustrated in Figure 9 of that section.

In the rare event that your dealer cannot diagnose and correct the fault, return the board postpaid directly to VIDEX in Corvallis, Oregon, for prompt servicing.

OPERATION

Using the VIDEOTERM Board

For those of you who have owned other Apple II peripherals, or Apple compatible peripherals, you will find that the board acts exactly as you would expect when you use the PR#n command (where n is the slot number) to direct printed output to the video display screen instead of the normal PR#O screen. The board uses the reserved locations for peripheral boards in the Apple's Random Access Memory. These slot dependent location addresses are given in both hexadecimal and decimal notation, along with their usage, in Table 1.

If this is your first Apple II peripheral, you it amazingly easy to operate. When you will find system, you merely type "PR#3", on your turn assuming you have installed the board in slot 3 (PR#n for slot n), and you will see the asterisk, Integer Basic prompt, or the Pascal Applesoft or menu prompt line on the video monitor display You then proceed to use your computer available. normally. but now you have fingertips some powerful as it were. new capabilities.

It should be noted that the VIDEOTERM board only uses a few locations in the Apple II's memory. The screen display is memory-mapped out of RAM which is located on the VIDEOTERM board itself. As the Apple II memory addresses used are set aside for that purpose by Apple itself, you are able to use the VIDEOTERM board and have no memory use conflicts with any of your programs, any software that you may have purchased, or with any other peripheral that you may have which has also followed Apple's OEM guidelines.

Table 1

VIDEOTERM Use of Apple II RAM

Addresses used are relative to the slot used for the VIDEOTERM board. Slot n is the slot the board has been placed in. See page 134 in the Apple II Reference Manual for the sets of addresses available as scratchpad Random Access Memory locations.

| Description | Hex Addr | Dec Addr |
|---|---|--|
| Screen base addr. (low) Screen base addr. (high) Cursor horiz. position Cursor vert. position Pascal char. write loc. First line on screen Power off/leadin counter | \$478 + n \$4F8 + n \$578 + n \$5F8 + n \$678 + n \$6F8 + n \$778 + n | 1144 + n 1272 + n 1400 + n 1528 + n 1656 + n 1784 + n 1912 + n 2040 + n |
| Video set-up flags | 9/ro T H | 2040 T II |

The first two storage locations are used to store an address of a location in VIDEOTERM's on-board RAM. This address is where the first character in the line currently being edited/listed is stored. This address will be \$000 to \$7FF, inclusive.

The cursor horizontal position is the current of column location the cursor (0-79. inclusive, from left to right). The cursor vertical position is the current line location of the cursor (0-23, inclusive, from top to bottom). The Pascal write character location is where the Apple Pascal system looks to find the next character to send to a terminal or other peripheral. The first line on screen pointer is used in text scrolling. The various video set-up flags are discussed in the software section, page 5-9.

VIDEOTERM Initialization

When you first activate the VIDEOTERM board with the "PR#3", or when you reset the board to its standard default, you will see 80 characters per line and 24 lines per page or screen, with each character defined as a 7 by 9 matrix within a total 8 by 10 matrix cell, allowing for a slight border around the character.

To change this, simply type "CTRL-Z <params>" where you substitute one of the parameters listed in Table 2 for the angle brackets and their contents. (Pascal users will need to write a short program to send this character sequence to the VIDEOTERM.) For example, if you wanted to use the alternae character set, you would type "CTRL-Z 3". Presto-chango, as they say, and there it is. You should try each of the options and then type a little to observe the different display responses you achieve.


Before we continue, let us mention a unique feature of the VIDEOTERM board. Try using the entry of "CTRL-Z" followed by any control character H through O. You will notice that when you type the control character, you will see displayed the correct ASCII abbreviation for that action. For example, when you type "CTRL-H" (or the back arrow), you will see "BS" displayed as two tiny diagonally-space capital letters in the position of one normal display character.

Return to the Apple Display

When you enter the VIDEOTERM WITH THE "PR#3" statement, the Apple automatically issues a "IN#3" command. However, when you enter "PR#0", THE VIDEOTERM will not reset the "IN" switch by itself. You should thus always follow this command with "IN#0".

Table 2 VIDEOTERM Control Parameters

| CTRL-Z Followed by: | Description |
|-----------------------------|---|
| 0 | Clears the 80 column screen and Home's the cursor. |
| 1 | Turns off the VIDEOTERM and activates the 40 column screen. |
| 2 | Selects the standard 7x9 Character set (the character set in location U20 see page A-4) |
| 3 | Selects the alternate 7x9 Character set (the character set in location U17 see page A-4) |
| CTRL-@ to | Displays one of the set of Mid-resolution graphics characters. |
| CTRL-Q to CTRL-Underline | Displays one of the set of line drawing graphics characters. |
| CTRL-H to CTRL-P | Displays small abbreviation of ASCII function (i.e., CTRL-H shows a BS for Backspace) |



Low-resolution graphics characters: each occupies one character position on the screen display

Upper and Lower Case

You will, of course, want to use lower case right away and no wonder. Lower case is significantly easier to read and recognize than is all capital type, reducing eye strain and reading time, When you first activate the VIDEOTERM board, it will still be in all upper case. To place it in lower case, simply type "CTRL-A". This acts just like a toggle switch or flip-flop in that you are now in lower case mode for as many characters as you wish to type. That is, the next character and all following characters will be uncapitalized.

To do a shift lock, so that you are returned to upper case, type another "CTRL-A". You have flipped the switch, so to speak, and each time that you enter the "CTRL-A" you will go into the mode that you are not currently in. This method of operating the upper and lower case modes is fairly convenient except in the case where you wish to capitalize only the next character. At present, the only way to do this from the keyboard is by typing a sequence such as "CTRL-A Q CTRL-A UITE" to obtain the display 'Quite'. Installation of the VIDEX KEYBOARD ENHANCER will solve this problem, as it allows the use of the shift keys in a manner exactly like that of a standard typewriter keyboard. Note that the lower case characters are stored internally as true lower case. The "CTRL-A" is NOT stored.

Special Key Operation

Most keys will display just as they are typed. However, certain keystroke sequences utilized in conjunction with the Control key, have specific and standard results. These various sequences will be discussed here in detail. In general, they will work the same in all Apple languages, so that by printing that keystroke character sequence to the VIDEOTERM board you will obtain the desired result. Notice that you will not be able to enter all of these directly from your keyboard without the VIDEX KEYBOARD ENHANCER.

As a special note, both the "CTRL-A" and the ESCape key sequences are "swallowed" by the VIDEOTERM board and are not transferred to the Apple II input buffer. All other special key sequences are transferred into the buffer.

CTRL-A: Shift Toggle. The typing of the "A" key CHR\$(1) while holding the Control key down toggles the VIDEOTERM into the other case mode. Thus, if you are in upper case, you will be shifted to lower case, while if you are in upper case you will be shifted to lower case. The case mode remains unchanged until another "CTRL-A" is issued. The "CTRL-A" is not entered into a line of text when typed in from the keyboard. It serves only as a shift toggle.

CTRL-G: Sound the Bell. The typing of the "G" key CHR\$(7) while holding the Control key depressed causes the bell to be sounded. Doing this from the Apple II keyboard directly will cause the computer to sound a small beep from its internal speaker. Try this with the VIDEOTERM board active and with it inactive (i.e., try it before and after you type "PR#3"). The bell will have a

different sound when you have the VIDEOTERM board activated to let you know that it is currently on.

- CTRL-H: Non-destructive Back Space function. This CHR\$(8) operation forces the cursor back one character on the display without destroying the character displayed at the previous location. The "CTRL-H" acts exactly like the single key on the Apple II keyboard labelled with the arrow pointing to the left (found just under the Return key on the right side of the keyboard).
- CTRL-J: Line Feed function. This operation causes
 CHR\$(10) a line feed to be issued which forces the
 cursor down to the next line without
 changing the column position of the cursor.
 At the bottom of the screen, this will
 cause the text to be scrolled up one line
 so that the page display will be altered.
 A Carriage Return will also have a line
 feed associated with it.
- CTRL-K: Clear to End of Screen function. This CHR\$(11) operation will clear the text from the present cursor location to the end of the screen. The character at the cursor location will also be <u>deleted</u> but the cursor itself will not move.
- CTRL-L: Form Feed function. The issuance of a form CHR\$(12) feed command will clear the screen entirely of all information displayed, just as if you had ejected a page and started a new one with a printer. This does not destroy any information stored internally in your Apple's RAM, but rather simply starts a new screen. It is important to note here that the "HOME" command in Applesoft and the "CALL -936" statement in either language MUST be replaced with a "PRINT CHR\$(12)" in

Applesoft or "PRINT <CTRL-L>" in either language. See the Apple Language Interactions section in the Software chapter, pages 4-1 to 4-6.

CTRL-M: Carriage Return function. In Pascal, this CHR\$(13) operation will move the cursor to the leftmost column on the screen without changing its line position. In either Basic language, an automatic Line Feed function (CTRL-J) is also performed at the same time.

CTRL-S: Stop/start text scrolling. This ASCII
CHR\$(19) control character will cause the current
text scrolling operation to stop, freezing
the display. Text scrolling can be resumed
by typing another "CTRL-S" (or any other
character).

CTRL-U: Copy character function. This operation, CHR\$(21) in either Basic, causes the cursor to be advanced one position, copying the character that it was positioned at into the input buffer of the Apple as if it had just been typed from the keyboard. The right arrow, located on the right of the keyboard just under the Return key, performs the same function. This will only work with direct keyboard or program input utilizing the GETLN routine, pages 33-34 of the Apple II Reference Manual. This will not work with the "GET" statement.

CTRL-Y: Home the cursor. This operation causes
CHR\$(25) the cursor to be positioned in the first
row, first column without changing the
display. It is not the same as the Form
Feed function described above.

CTRL-Z: Initialization Lead-in function. Use CHR\$(26) as the lead-in character for reinitiali-

zation of the VIDEOTERM. The user may choose 18 or 24 lines of text, standard or alternate character sets, display of a control character or normal or inverse video utilizing this function. See Table 2, page 3-4, for a fuller description.

ESCAPE: Edit Control Lead-in function. The ESCape CHR\$(27) key works exactly as it does for the Apple II standard video display. It is used as the lead-in character for an editing command. Follow the ESCape key entry with any of the standard editing keystrokes. These include:

- A -- Advance cursor
- B -- Backspace cursor
- C -- Move cursor down a line
- D -- Move cursor up a line
- E -- Clear to end of line
- F -- Clear to end of screen
- @ -- Clear screen

Note that many of this ESCape key sequences are the same as other Control key sequences mentioned above. Also note that the ESCape key sequences utilizing 'I', 'J', 'K', and 'M' that are available with the Autostart ROM are not usable with the VIDEOTERM.

CTRL-SHIFT-L: Non-Destructive Forward Space func-CHR\$(28) tion. This operation moves the cursor forward one character on the display without actually copying the character at previous location to the input buffer. its will not be able to enter this key sequence directly from your keyboard unless you have the VIDEX KEYBOARD ENHANCER installed. Both the Control and the Shift keys must be depressed before striking 'L'. You will still be able to use this function from Applesoft.

CTRL-SHIFT-M: Clear to End of Line function. This CHR\$(29) operation erases all characters from the current cursor location to the end of the present line. Both the Control and the Shift keys be depressed before you strike the 'M' key. Otherwise you will cause a Carriage Return (CTRL-M) to occur.

CTRL-SHIFT-N <x> <y>: Cursor Positioning function. CHR\$(30) This operation is equivalent to the ASCII It allows you to directly code GOTOXY. move the cursor to any specified position on the screen. It is completely compatible with the Apple Pascal GOTOXY function. You follow the "CTRL-SHIFT-N" entry with two specify the x and y (or numbers which horizontal and vertical) screen location that the cursor is to be relocated at. The and y coordinates are entered as ASCII code sequences above decimal value 32. Try sending various codes to the VIDEOTERM using this function and observe the movement of the cursor in each of the different character cell matrix Start with "CTRL-SHIFT-N & *" as a start. The upper left corner of the screen is ' spaces). The lower right and ' '(two corner of the screen is '7' and 'o'.

CTRL-SHIFT-0: Reverse Linefeed function. This CHR\$(31) operation forces the cursor up one line without changing its column location. Once the cursor reaches the top of the screen, it will not move anymore. Again, you will need the VIDEX KEYBOARD ENHANCER in order to enter this key sequence directly from your keyboard. It is still available from Applesoft.

Now that you have your VIDEOTERM installed and you are satisfied that the monitor is properly adjusted, you are probably very anxious to use it. In the previous chapter you have seen how various key sequences are used to control the VIDEOTERM directly from the keyboard. This chapter contains a sample programs, in each of the Apple II number of languages, to acquaint you with software control of the board. But first we will detail a few necessary changes that you will need to make to some of your existing programs in order to use them with the And we will give the language specific VIDEOTERM. addresses necessary for modifying the VIDEOTERM's internal registers, which are described in the next chapter, starting on page 5-2. We will then the VIDEOTERM in conjunction describe the use of with some other available Apple II peripherals, in particular the use of the ROMWriter to create a new character set.

Apple Language Interactions

The VIDEOTERM has been designed to minimize the interaction it has with user software. Unfortunately, there <u>is</u> some interaction and you will need to make some slight modifications to your current programs, and avoid the use of certain programming statements in the software that you write. This section fully documents those changes.

A. Assembly Language

The only real restriction in Apple Assembly language is to not use those RAM locations, described in Table 1, page 3-2, which the VIDEOTERM uses. This is true regardless of which peripheral you purchase, as Apple Computer, Inc. has set aside these locations specifically for firmware located on

an expansion board. Naturally, you can use these locations either directly in Assembly language, or from other languages, to modify the cursor location, to modify the video set—up flags, to access the start address, in the VIDEOTERM RAM, of the screen start address, and many other things.

B. Integer Basic

You cannot use the "CALL -936" command. You must substitute in its place "PRINT CTRL-L". Naturally, when this is listed, you will see "PRINT", SINCE THE CTRL-L is not printed. You should adopt the trick taught Disk II owners which is to define a character string variable equal to the non-printing character(s) and print that variable. Thus

- 10 L\$="<CTRL-L>":REM THIS IS CTRL-L
 20 PRINT L\$:REM USE THIS IN PLACE OF
 ALL 'HOME' AND 'CALL -936'
 STATEMENTS
- If you use any "CALL -958" statements, which serve to clear the screen of text from your current cursor positon on, you will need to replace these with "PRINT CTRL-K" statements. Use a procedure such as that described above to enter these changes into your programs.

If you use any "CALL -868" statements, which serves to clear the present line from your current cursor positon on, you will need to replace these with "PRINT CTRL-SHIFT-M" statements. Again, use a procedure such as that described above to enter these changes into your programs.

In general, you should be slightly suspicious of any "CALL n" type statements that you use in any of your programs.

You should also be wary of the interaction of

"PEEK" and "POKE" instructions, as these may not work quite as you had planned. However, these should work properly, as should your "VTAB" and "TAB" commands. Expect some minor surprises the first time you run some of your programs using the VIDEOTERM.

Note that graphics statements will not work as expected. Such statements include

GR
PLOT x,y
HLIN x,y AT n
VLIN x,y AT n

These will be sent to a separate display, such as a color TV, if you have one attached to your Apple video output plug separately from your VIDEOTERM. In fact, even with one monitor, the Apple video display is changed and can be viewed by typing "PR#O". Otherwise, use "REM"s to disable such statements. There is some limited use of graphics on the VIDEOTERM as demonstrated in the example programs, starting on page 4-8.

C. Applesoft

Those restrictions stated above concerning "CALL n" statements for Integer Basic also hold true for Applesoft, and similar corrections should be made to your programs. Of special concern is that the Home command will not work with the VIDEOTERM, so substitute "CHR\$(12)" in its place. Note that the availability of the "CHR\$(n)" function in Applesoft makes it much easier to print the various character sequences that control the operation of the VIDEOTERM.

You should not expect any of the graphics commands to affect the VIDEOTERM, as these will again affect only the normal Apple II display. The commands affected are:

GR
PLOT X,Y
HLIN X1,X2 AT Y
VLIN Y1,Y2 AT X
SCRN(X,Y)
HGR
HGR2
HCOLOR=X
HPLOT X,Y
HPLOT X1,Y1 TO X2,Y2
DRAW n AT X,Y

A limited usage of graphics in Applesoft programs is demonstrated in the sample program starting on page 4-21.

The following Applesoft statements will also have no affect on the VIDEOTERM display:

FLASH INVERSE NORMAL

These commands will simply be ignored when executed.

D. Pascal

Your VIDEOTERM will work immediately with the Apple Language card, but there are a few helpful changes you should make. After you install the VIDEOTERM, execute "APPLE3: SETUP" and then change

HAS LOWERCASE to TRUE Set screen width to 80

You will now get Pascal prompt lines and all Directory and Edit lines in their full expanded 80 column format. Of course, you had a 79 column display from the moment you initiated your Pascal system with the VIDEOTERM. However, by setting the

screen width to 80, from 79, you will obtain longer Pascal prompt lines.

```
Program Listing Number One program peekpoke;
```

```
type
   trixarray = packed array [0..1] of 0..255;
   trixtype = record
            case boolean of
              false: (address: integer);
                       (pointer: ^trixarray);
               true:
            end;
var
   i, val: integer;
   ch: char;
function peek (addr: integer): integer;
   var trix: trixtype;
   begin
      with trix do
         begin
            address:= addr;
            peek: = pointer [0];
         end;
      end; {poke}
procedure poke (addr, value: integer);
   var trix: trixtype;
   begin
      with trix do
         begin
            address:= addr;
            pointer [0]: value;
         end;
    end; {poke}
begin (main program)
   page (output);
   writeln ('Peek and Poke program', chr(13));
   ch:= ' ';
   repeat
      if not (ch in ['q', 'r', 'w', 'Q', 'R', 'W']) then
        begin
           writeln ('Options:');
           writeln ('
                               R) ead memory address');
           writeln ('
                               W)rite to memory address');
           writeln ('
                               Q)uit');
        end;
     writeln (chr(13), 'Select.....', chr(13));
      read (keyboard, ch);
      case ch of
         'R', 'r': begin
                 write ('Address to be examined: ');
                 read (1);
                 writeln (peek(i):10, chr (peek (i)):10);
                 writeln;
              end;
         'W', w': begin
                 write ('Address:
                 read (i);
                 write ('Value to be poked: ');
                 read (val);
                 poke (i, val);
                 writeln;
              end;
         'Q', 'q': writeln (chr(13), 'That', chr (39), 's all folks.....');
     end; {case}
  until (ch = 'Q') or (ch = 'q');
end.
                                    4-6
```

Language Considerations in General

For the most part, you will want to know the memory usage of the VIDEOTERM and how to perform the various operations mentioned in the Firmware chapter, on pages 5-1 to 5-8, in each of the various languages. Sample statements are given in Table 3.

Memory usage in the \$C080+ region of the Apple II addressing space is also of interest. VIDEOTERM usage of this area is also detailed in Table 3. The assignment of the different 16-byte address blocks to the 8 possible expansion slots is given in Table 25, page 82, of the Apple II Reference Manual, available from your Apple dealer. For a discussion of the utilization of the 2K byte firmware memory space, \$C800 to \$CFFF, mentioned in the Apple II Reference Manual on pages 84-85, see the section on VIDEOTERM Memory Mapping, starting in the next chapter on page 5-11. It might be good idea to briefly skim through that section before reading the detailed comments on each of the example programs.

Remember, as noted on page 3-5, that you must execute a "IN#0" following a "PR#0" in order to reactivate the input device correctly. Otherwise, all Apple II display characters will be placed on top of each other.

Table 3: Address Definitions by Language

table summarizes the addresses to be accessed for device select as described in Apple Language Modifictions, pages 4-1 to 4-7, and How to Modify CRTC Registers, page These are the language specific address equivalents of each Hexadecimal Apple II memory address. For example, suppose the board is in slot 3. We will enter the whose value we wish to change first, followed by the value that is to be placed in that register. A total of two bytes of information must be specified. The following sets of statements are equivalent: the register number of

Applesoft 49296 49312 49328 49344 49360 49376 POKE(49328),01:POKE(49329),112 (CR) Integer Basic -16176 -16240-16224-16208-16192 -16160Monitor \$0000 \$C0A0 \$COBO \$0000 SCODO \$COE0

Slot

4

>POKE(-16208),01:POKE(-16207),112 (CR)

*C0B0: 01 70 (CR)

Software Examples

The following program listings are offered as examples of how the VIDEOTERM can be controlled by one of your programs. They are not meant to be taken as the best way to use the board, but as indicative of what you can do. Each example will be explained in detail so that you can see just how the program works. Throughout the rest of this chapter, the symbol "(CR)" is used to indicate that you should strike the Return key.

A. Assembly Language

Program Listing 2 gives an example of how the VIDEOTERM can be controlled using Assembly Language. The object of the program is to allow you to view on your monitor the same text that is currently being listed on your printer. To enter this program, go into the Apple Monitor by typing

Then type the following (note that you do not have to type the "*"; the Apple II displays this symbol to let you know that it is ready for more input)

*300:48 8A 48 98 48 20 42 03 (CR)
*308:20 00 C8 A9 80 20 ED FD (CR)
*310:A5 36 8D 40 03 A5 37 8D (CR)
*318:41 03 A9 2B 85 36 A9 03 (CR)
*320:85 37 20 EA 03 68 A8 68 (CR)
*328:AA 68 60 8D 7B 06 8A 48 (CR)
*330:98 48 20 42 03 20 C1 C8 (CR)
*338:68 A8 68 AA AD 7B 06 4C (CR)
*340:00 C0 8D FF CF 8D 00 C3 (CR)
*348:AO 30 8C F8 06 A2 C3 8E (CR)
*350:F8 07 60 80 08 08 AO 10 (CR)

PROGRAM LISTING # 2

```
LST ON
                 2
0000:
                3 *
0000:
                4 BYTE
                           EOU $678
0000:
                5 NO
                            EQU $6F8
                           EOU $7F8
0000:
                6 MSLOT
                7 COUT
0000:
                           EQU SFDED
               8 *
0000:
                           ORG $300
0000:
                9
              10
                           OBJ $300
              11 *
0300:
0300: 48
                           PHA
                                         SAVE REGISTERS
              12 START
0301: 8A
               13
                            TXA
0302: 48
               14
                            PHA
0303: 98
                15
                            TYA
0304: 48
                16
                            PHA
                           JSR SETREGS SET-UP FOR ENTRY INTO C800 ROM
0305: 20 42 03
               17
                           JSR $C800
0308: 20 00 C8 18
                                         INITIALIZE VIDEOTERM
                          LDA #$80
030B: A9 80
               19
                                         TRANSMIT FAKE CHARACTER TO PRINTER
030D: 20 ED FD 20
                           JSR COUT
0310: A5 36
               21
                          LDA $36
                                         STORE OLD OUTPUT VECTOR
0312: 8D 40 03 22
                          STA JMPADR+1 INTO A JMP OPERAND
               23
0315: A5 37
                           LDA $37
0317: 8D 41 03
               24
                           STA JMPADR+2
031A: A9 2B
                25
                           LDA #<OUT1 SET UP NEW OUTPUT VECTOR
031C: 85 36
                26
                           STA $36
031C: 85 36 26
031E: A9 03 27
0320: 85 37 28
                          LDA #>OUT1
                          STA $37
0322: 20 EA 03 29
                                        SWAP IN DOS OUTPUT VECTOR
                           JSR S3EA
0325: 68
               30 DONE
                          PLA
                                         RECOVER REGISTERS
0326: A8
               31
                           TAY
0327: 68
               32
                           PLA
               33
0328: AA
                            TAX
0329: 68
                34
                            PLA
032A: 60
                35
                           RTS
                36 *
0328:
032B: 8D 7B 06
                                        SAVE BYTE TO OUTPUT
                37 OUT1
                           STA BYTE+3
032E: 8A
               38
                           TXA
                                         SAVE REGISTERS
032F: 48
               39
                           PHA
0330: 98
               40
                           TYA
0331: 48
               41
                          PHA
0332: 20 42 03 42
                          JSR SETREGS SET-UP FOR ENTRY INTO C800 ROM
                           JSR $C8B3
0335: 20 B3 C8 43
                                         OUTPUT BYTE TO VIDEOTERM
0338: 68
               44
                           PLA
                                         RECOVER REGISTERS
0339: A8
                45
                           TAY
033A: 68
               46
                           PLA
               47
033B: AA
                           TAX
033C: AD 7B 06 48
                          LDA BYTE+3
                                        OUTPUT BYTE TO PRINTER
033F: 4C 00 CO 49 JMPADR JMP $C000
                                         THIS ADDRESS WILL BE CHANGED
0342:
               50 *
0342: 8D FF CF
              51 SETREGS STA $CFFF
                                        TURN OFF CO-RESIDENT ROMS
0345: 8D 00 C3 52
                           STA $C300
                                        SELECT CO-RESIDENT ROM IN SLOT 3
0348: A0 30
               53
                           LDY #$30
                                         SET UP THE NO INDEX
034A: 8C F8 06
                54
                           STY NO
034D: A2 C3
                55
                           LDX #$C3
                                         SET UP THE CN INDEX
034F: 8E F8 07
                           STX MSLOT
                56
0352: 60
               57
                           RTS
0353:
```

When you have finished entering these values, type

*300.357 (CR)

This will cause a copy of what you have entered above to be displayed on your video screen. Carefully double-check your entry to make sure that it is the same. You can also type

*300L (CR)

This will cause the Apple to display a listing like that in Program Listing 2, except that no comments will be written by the Apple II disassembler. To continue the listing, type

*L (CR)

Repeat this last entry once more to finish your listing. The important entries are the actual hexadecimal operation codes that are displayed to the left of the Assembly language operation codes, since some of the symbols, such as COUT will not be displayed.

There are several alterations you will have to make if you have installed the VIDEOTERM in some slot other than 3. Substitute

*347:Cn (CR)

*34E:Cn (CR)

WHERE N IS THE SLOT NUMBER IN WHICH THE VIDEOTERM has been placed. Also

*349:<8+n>0 (CR)

is necessary. Note that BO would be entered if in slot 3, CO if in slot 4 and so forth.

Notice the two instructions using "BYTE+3" in

the listing at locations \$32B and \$33C, respectively. These must be changed to the equivalent of "BYTE+n". Do this by using Table 1 to calculate the new value to be placed at locations \$32C and \$33D. Note that the same values will be placed in each location. Assuming that the VIDEOTERM has been placed in slot 5, then we would calculate

\$678 + n = \$678 + \$5 = \$67D

and we would type

*32C:7D (CR)
*33C:7D (CR)

This completes the necessary changes in the program for use with the VIDEOTERM's changed location. You should save this routine onto your diskette or cassette. The routine starts at \$300 and has a length of \$58.

In order to use the routine from either Basic language, enter the following into your program

PR#p:CALL 768

where p is the slot number that your printer is in (also true below).

In order to test the program, simply enter the one-line program (again, using either Basic, but using Integer Basic here as an example)

>10 PR#p:CALL 768:END >RUN

Note that even with the Apple Disk you should enter the program as above. Do not enter (where D\$ is a "CTRL-D")

>10 PRINT D\$;"PR#p":CALL 768:END

as this will not work with the VIDEOTERM.

If you do not have the Apple Disk Operating System (DOS), then you should modify the above Assembly Language program by typing

*322:EA EA EA

These are NOP (No Operation) codes, and they effectively keep the program from accessing DOS to obtain its output address (also called a vector, since it points to a location which itself contains an address). The 6502 microprocessor will simply ignore this instruction and execute the following one This program modification should be done before saving your copy of the program.

An important reminder is that the printer is the controlling device, not the VIDEOTERM, so that some of the VIDEOTERMs control key sequences will \underline{not} be activated, but printer control characters \underline{will} be.

B. Integer Basic

Program Listing 3 is an example of how to place a character on the screen in a desired location using an Integer Basic program. This program will fill the video display with the entire character set, with each line repeating the set but shifted over one column so as to make a diagonal pattern. The screen is filled in a random order, so that it takes several minutes to completely fill the screen, but the display is about 80% complete after one minute. This program is an excellent one to use to help fine tune the adjustment on your monitor.

Before we begin, it might be helpful if you briefly review the discussion of how the VIDEOTERM's on-board RAM maps into the display and how it is accessed by internal Apple II addresses.

Essentially, the on-screen location of a character corresponds to its address in the RAM which is located on the board. A unique set of addresses in the Apple II allows you to access the VIDEOTERM RAM directly, but this same set of Apple II addresses can specify any one of 4 different address locations on the VIDEOTERM. A technique called "paging" is used, and by determining which page we are using (each page being 512 bytes long), we have determined where the character we are writing is really going in the VIDEOTERMS RAM, and therefor, on the display screen.

Let's take a look in detail at how the program operates. Line 10 defines several Basic variables. START is the address, in decimal, of the memory location in the Apple II where a VIDEOTERM address is stored. This VIDEOTERM address, in turn, is defined as the location where the first character of the first line on the screen is stored (see \$6F8 + n, Table 1). This is needed since the actual memory location in the on-board RAM of the first display line on the screen varies. By adding the SLOT value to START we will obtain the correct Apple II address. This is done in line 15, with the result being assigned to the variable LINE1.

DEVICE is the name of the variable assigned the value of the base address of the 16-byte group of slot dedicated addresses reserved for the various peripherals. (Again, see the Apple II Reference Manual, page 82.) The value -16256 is equal to \$C080 or 49280. By adding SLOT times 16, we get the value assigned to LINE2 in line 15. Note that if SLOT = 3, then LINE2 = -16208 or 49328 or \$C080, exactly the values we see in Table 3 for slot 3 usage! Because we have the VIDEOTERM in slot 3, SLOT = 3 in line 10.

The value for SCREEN is equivalent to 53224 or \$CC00, the Apple II address of the first character of the current active page of VIDEOTERM Random

PROGRAM LISTING # 3

```
>LIST
10 START=1784:DEVICE=-16256:SLOT=3:SCREEN=-13312:PLOT=100
15 LINE1=START+SLOT:LINE2=DEVICE+SLOT*16
20 X= RND (80)
30 Y= RND (24)
40 BYTE=(X+Y) MOD 96+32
50 GOSUB PLOT
60 GOTO 20: REM

100 ADDRESS=(X+Y*80+ PEEK (LINE1)*16) MOD 2048
110 PAGE=ADDRESS512
120 SELECT= PEEK (LINE2+PAGE*4)
130 POKE SCREEN+(ADDRESS MOD 512),BYTE
140 RETURN
```

>

Access Memory. See the next chapter, page 5-11, for an explanation of how the addresses \$CC00 to \$CDFF are used in writing characters to the VIDEOTERM memory. For now, just note that this is the base address for VIDEOTERM RAM access.

Lines 20 and 30 assign a random integer number between 0 and 79 to X and a random integer number 23 to Y. These correspond to the between 0 and column (X) and the row (Y) that we will put the character in on the display screen. In line 40, we then use the screen position to determine which character will be printed there. The sum of X and Y is taken modulo 96, which just means that a value between 0 and 95 will be chosen depending on the actual value of the sum. Then the value 32 is This value is then assigned to the variable added. If you look at the ASCII symbols defined in BYTE. the Appendix Table, you will see that this limits us to choosing an ASCII character whose decimal value is between 32 and 127, inclusive. This includes all the standard display characters, but excludes the control characters.

Line 50 directs program control to the PLOT subroutine, starting at program line 100. Finally, line 60 returns us to line 20 to repeat the process. Note that the REM statement contains a "CTRL-J" to space the PLOT subroutine down one line for easier reading.

Line 100 starts the PLOT subroutine. A value is calculated and assigned to the variable ADDRESS. This value is calculated as follows. First, the on-screen character location is calculated as a number between 0 and 1919 (X + Y * 80). The on-screen character locations are numbered from 0 to 79 on the first line, 80 to 159 on the second, and so forth, to 1840 to 1919 on the twenty-fourth line. This is added to the VIDEOTERM start screen address multiplied by the value of 16. We do this because the start screen address was divided by 16 in the

firmware to save one byte of room.

The resulting number of this process is then taken modulo 2048, since there is only 2K RAM on-board and thus there are only 2048 locations to store information at. This is called "wrap-around" since the character stored at VIDEOTERM RAM address 2047 is followed on the screen by the character stored at address 0.

Line 110 assigns to PAGE the current active page of on-board memory that will be accessed by Apple II addresses in the range \$CC00 to \$CDFF. Then line 120 assigns to SELECT the value stored at the location \$C0BO, \$C0B4, \$C0B8 and \$C0BC, depending on the current active "PAGE". The value stored there is of no consequence. The access by the "PEEK" activates the appropriate page. It is important that a "PEEK" access be utilized at this time for that purpose! (It can also be done at an earlier time, but only after the correct address has been calculated.)

130 then writes the actual chosen Line character, BYTE to the VIDEOTERM memory using a Simultaneously, the character appears poke. the monitor screen. The address for on displayed the POKE is the base address of the VIDEOTERM SCREEN (\$CC00) plus the page-relative address of the character ("ADDRESS MOD 512"). Line the "RETURN" statement that ends the 140 is subroutine.

You might want to play around with the program a little. A faster display of the character set can be obtained if you substitute "FOR" statements in place of the two Random number calls on lines 20 and 30 and "NEXT" statements in place of the "GOTO" statement on line 60. You can also change line 40 to print any set of characters that you would like to see. Try modifying it to display the graphics character set located at "CTRL-P" to "CTRL-SHIFT-O".

PROGRAM LISTING # 4

PR#0 >LIST

>

```
5 DIM A(3):A(0)=1:A(1)=2:A(2)=4:A(3)=8
10 START=1784:DEVICE=-16256:SLOT=3:SCREEN=-13312:PLOT=100
15 LINE1=START+SLOT:LINE2=DEVICE+SLOT*16
20 FOR X=0 TO 79
30 FOR Y=0 TO 71
50 GOSUB PLOT
60 NEXT Y,X: REM

100 ADDRESS=(X+Y/3*80+ PEEK (LINE1)*16) MOD 2048
120 SELECT= PEEK (LINE2+ADDRESS/512*4)
130 ADD=SCREEN+(ADDRESS MOD 512)
147 R=Y MOD 3
155 BYTE= PEEK (ADD) MOD 8
157 STRIP=A(R+1)
160 POKE ADD,BYTE/STRIP*STRIP+BYTE MOD A(R)+A(R)*COL
180 RETURN
```

4-18

Program Listing 4 follows the same pattern as the previous example. The object of this program is to demonstrate the writing of one of the graphics characters in the range "CTRL-Z CTRL-@" to "CTRL-Z CTRL-G" as explained in Table 2. Let us examine this example in detail.

Line 5 assigns to the elements of the array A the corresponding powers of 2. Thus, A(0) = 1, A(1) = 2, (2) = 4, and A(3) = 8. These will be used later in the program rather than an equivalent calculation of the power of 2, because access of an array element is much faster than the exponentiation operation.

Lines 10 and 15 are similar to those lines in Program Listing 2. Lines 20 and 30 set up a pair of "FOR-NEXT" loops. Notice that in the current order, the screen will be filled a column at a time. To change this, simply reverse the order of the two lines and change the "NEXT" statement in line 60.

Line 40 determines the color of the graphics character to be printed which in this case is color 1 (magenta). This will appear as a white dot on your Black and White monitor. In the listing it is assigned a constant value, but we will change this later. Line 50 calls the PLOT subroutine and line 60 continues the loops. Notice that the order of Y and X need to be exchanged if you change the order of the "FOR" statements. The "REM" statement of line 60 contains a "CTRL-J" to skip a line in the listing.

Line 100 begins the PLOT subroutine. We choose the ADDRESS in the VIDEOTERMS RAM at which the graphics symbol will be placed as in the preceding example. Note that Y must be divided by 3 to obtain a value between 0 and 23, inclusive. Line 120 activates the proper memory page, in a slightly different fashion than was done in line 120 of the

previous example. Line 130 calculates the page-specific address. The following lines require considerable explanation. Before we describe these in detail, let's consider what is happening overall.

We wish to change the entire screen from black to white by changing only one low-resolution pixel at a time. As can be seen in Table 2, page 3-4, each "CTRL-<char>" in the low-resolution graphics character set contains 3 pixels. We will start with the equivalent of "CTRL-@" in character position 0 (first column, first row). We wish to replace it with the symbol corresponding to "CTRL-A" as this changes the color of the first pixel. Then, we will replace that with "CTRL-C", and then with "CTRL-G". This adds, in smooth increments, one pixel at a time in that character position.

Now let's look at the program in detail. Line 147 takes the modulo base 3 of the row variable, Y. Note that the Y indexed "FOR-NEXT" loop runs from 0 to 71. This is because each graphics symbol only occupies one-third of a row! So we must take the row number modulo base 3 to determine which of the 3 pixels at our current location is to be changed to white.

Line 155 gets the contents of the current screen location. This will be a value between 0 and 7, and will correspond to the assigned low-resolution graphics character already there. You will note that if you turn Table 2 on edge, with the page number to your left, that the pixel assignments fall in a normal bit pattern from the values 0 ("CTRL-@"), 1 ("CTRL-A"), and so forth, to 7 ("CTRL-G"). (See bits 0, 1 and 2 for this character group in the ASCII Character Code Chart, page A-1.) Note that no matter which character is actually at that location, a number between 0 and 7 will still be selected.

For example, if your screen was filled with

characters as a result of running the previous example, and you ran this example without first clearing the screen, then the program would detect some character, perhaps a ".". The rightmost three bits add up to 6. Thus, BYTE could be assigned a 6, which it would interpret as a "CTRL-F". We will follow this example as we continue to examine the program.

Line 157 assigns a power of 2 to STRIP based on the value of R. Since R must be 0, 1 or 2, STRIP will be 1, 2 or 4, respectively. In our example, we would obtain 2 for Y = 0, 4 for Y = 1, and 8 for Y = 0. Note that this calculation depends on which of the three pixel we are adding to the display and not the value of any character that might already exist at that location.

line 60 the actual "POKE" of the character address ADD is done. The value "POKE"d is arrived at as follows. First, the higher order bits of the first three bits of BYTE are obtained by dividing and multiplying by STRIP. In our example, 6 would be divided by 2 (A(1) = 2 for R = 0, which the first value used in any character alwavs location due to line 147), and then multiplied by 2, yielding 6. Thus, we have not changed bit 1 or 2 at all by this operation, which is the object -- to leave them undisturbed. This operation, with R = 0, clears bit 0. When R = 1, we would clear bits 0 and 1, and when R = 2, we would clear bits 0, 1 and 2. Then the "BYTE MOD A(R)" instruction gets any previously set bits in this group (i.e., none for R 0. bit 0 for R = 1, and bits 0 and 1 for R = 2). Following our example, with R = 0, we would obtain a since the modulo base I is always 0. Finally, the "A(R) * COL" does the actual setting of bit 0. our example, it will be equal to $1 \times 1 = 1$. Thus, our final "POKE" will be with a value of 7 and we will fill the entire character location with a white square in one jump. This is why the line being drawn on the screen appears to jump faster

down the column when there are other characters on the screen when you start to run the program. If you clear the screen before running, the drawing will be done in a smooth fashion.

On the next pass on this row, the value 7 will be obtained by BYTE (all pixels colored), so that with R = 1, we will calculate the value of 4 = BYTE / STRIP * STRIP, 1 = BYTE MOD A(1), and 2 = A(1) * COL, so that again a 7 will be obtained. You can verify that the same result will occur for R = 2.

Now if the display was blank to begin with, for R=0 we would obtain the value of 1 to be "POKE"d, for R=1 we would obtain 3, and for R=2 we would obtain 7. You should verify this by calculating the values for line 160 using BYTE = 0 to start.

Try modifying this program by substituting "COL = RND(2)" at line 40. This will randomly determine if the current pixel should be colored or not.

C. Applesoft

The VIDEOTERM is relatively easy to work from Applesoft due to its intrinsic "ASC" and "CHR\$" functions. As an example of how to implement a shift/shift-lock feature under program control using the "ESC" key as the shift key, examine Program Listing 5.

Line 5 starts by defining the "ESC" key (CHR\$(27)) to be the shift key toggle. We also set the upper/lower case mode flag, UL = 1, indicating that all characters are to be interpreted in the lower case. A value of 2 will indicate that we wish to capitalize only the next character and a value of 3 will indicate that we wish to have all upper case characters until we again type the "ESC" key.

Line 8 makes sure that UL will always be

PROGRAM LISTING # 5

PR#0

```
3 VTAB 23: PRINT "VIDEOTERM IS ACTIVE SCREEN": PRINT CHR$ (4); "PR#3"
5 UL = 1:AS = CHR$ (27)
8 IF UL = 4 THEN UL = 1
10 GET X5:X = ASC (X$)
15 IF XS = AS THEN UL = UL + 1: GOTO 8
20 ON UL GOTO 30,40,50
30 XS = CHR$ (X + (32 * (X > 63)))
40 UL = 1
50 PRINT XS;: GOTO 10
100000 END
```

limited to the values 1, 2 or 3. Line 10 is used to obtain a keyboard character, and then the ASCII decimal value of the character is assigned to the variable X.

In line 15, we test to see if we have received the "ESC" key entry. If we have, then we increment UL and go to line 8 to make sure that UL does not get too large. Thus, if UL = 1 and we get the "ESC" key, then we change to upper case for the next character (UL = 2). If another "ESC" entry follows immediately, then we will go into shift lock (UL = 3). Another "ESC" in a row will leave us in lower case again (UL = 4 --> UL = 1). This functions very much like a normal typewriter.

As soon as we receive any other key entry, we will proceed to line 20. We jump to a location dependent on the current UL value. If in lower case mode, we will go to line 30. Here we take the value X and add 32 to it if the character is a letter, i.e., if its ASCII decimal value exceeds 63. (See the ASCII Character Code Chart, page A-1. We are effectively mapping columns 4 and 5 into columns 6 and 7, respectively.) We emphasize that this is only done when UL = 1.

If UL = 2, then we go to line 40, skipping the lower case conversion. Line 40 sets UL = 1 again, since the first "ESC" key was not followed immediately by another "ESC". If UL = 3, we would proceed immediately to line 50 to print the character just obtained. Note that for any of the "GOTO"s we will "fall through", executing the following instructions, until line 50 sends us back to line 10.

Now let's see how the program works using an example. Enter the program and save it. Now run it. Let's enter the proper combination of characters so that we will see

HELLO out There

displayed on the VIDEOTERM. Start by typing the "ESC" twice. Then type "HELLO", one letter at a time. UL will now equal 3. Enter another "ESC" and type "OUT". The value of UL was changed to 4 and then to 1 before "OUT" was typed, so we will see the word displayed in lower case. Finally, type the "ESC" key once and type "THERE". The program will type the "T" in upper case and the rest in lower case. UL was set equal to 2 for "T", and then back to 1 at line 40.

You might want to incorporate this technique into some of your own programs. The character string could be appended to another one until a full line was obtained and then it could be saved as part of a text file. The technique can also be used with Assembly language to interface your word processor with the VIDEOTERM.

Program Listing 6 gives an example of cursor positioning in Applesoft. Th program is simple and straightforward. Line 5 prints a "CTRL-D". Line 10 creates a string of 8 backspaces. Then the program will request that you enter an X and Y coordinate of a character location in the range of 1 to 80 for X and 1 to 24 for Y. Note that this is different than how the columns and rows are actually numbered, but it is easier to count that way. Enter the values on one line, separated by a comma and terminated by striking the Return key.

Line 35 positions the cursor to the appropriate location and line 50 displays the Rub-out character (CHR\$(127)) there. Then line 50 returns us to line 20 for input of another pair of coordinates.

While very simple, note that this is generally useful. You should try translating the Integer Basic examples into Applesoft, especially the low-resolution graphics example. That example and

PROGRAM LISTING # 6

```
5 PRINT CHR$ (12);

10 FOR I = 1 TO 8:H$ = H$ + CHR$ (8): NEXT I

20 VTAB 1: PRINT "ENTER X & Y COORDINATES ";H$;

30 INPUT X,Y

35 PRINT CHR$ (30); CHR$ (31 + X); CHR$ (31 + Y);

50 PRINT CHR$ (127)

70 GOTO 20
```

this one can be integrated to yield a simple plotting program. The low-resolution grapics set gives 80 by 72 pixels, almost three times the density of the Apple II's format of 40 by 48 in low-resolution graphics mode.

These listings are patch programs for KEYPRESS, the appropriate one should be run for your version of Pascal with the disk that has SYSTEM.APPLE on it in the drive that is volume #4. In addition to enabling the KEYPRESS function, the type-ahead buffer and system break have also been enabled.

```
PROGRAM VIDPATCH;
(* This program patches the SYSTEM.APPLE console check routine for version *)
(* 1.0 to allow KEYPRESS, SYSTEM BREAK and type ahead buffers to operate *)
(* with the VIDEOTERM.
                                               Darrell Aldrich 10/80
                                                                             *)
VAR BUF: PACKED ARRAY [0..31,0..511] OF 0..255;
F:FILE;
I: INTEGER;
BEGIN
  RESET(F, '#4: SYSTEM . APPLE');
  I:=BLOCKREAD (F, BUF, 32);
  CLOSE(F);
  BUF[3,147]:=4;
  BUF[3,366]:=234;
                    BUF[3,367]:=234;
                                       BUF [3,368] := 234;
  BUF[3,202]:=160; BUF[3,203]:=48;
                                       BUF[3,204]:=173;
                                                         BUF[3,205]:=0;
                                       BUF[3,208]:=18;
  BUF[3,206]:=192;
                    BUF[3,207]:=16;
                                                         BUF[3,209]:=32;
  BUF[3,210]:=111: BUF[3,211]:=216; BUF[3,212]:=234;
  RESET(F, '#4: SYSTEM. APPLE');
  I:=BLOCKWRITE(F,BUF,32);
  CLOSE(F):
END.
PROGRAM VIDPATCH;
(* This program patches the SYSTEM.APPLE console check routine for version *)
(* 1.1 to allow KEYPRESS, SYSTEM BREAK and type ahead buffers to operate *)
                                                   Darrell Aldrich 1/81
(* with the VIDEOTERM.
VAR BUF: PACKED ARRAY [0..31,0..511] OF 0..255;
F:FILE;
I:INTEGER;
BEGIN
  RESET(F, '#4: SYSTEM. APPLE');
  I:=BLOCKREAD (F,BUF,32);
 CLOSE(F);
  BUF[3,389]:=160;
                        BUF[3,390]:=48;
  BUF[3,394]:=60;
  BUF[3,455]:=173;
                    BUF[3,456]:=0;
                                       BUF[3,457]:=192;
                                                           BUF [3,458] :=16;
  BUF[3,459]:=29;
                    BUF[3,460]:=32;
                                       BUF[3,461]:=24;
                                                           BUF[3,462]:=218;
  BUF[3,463]:=234;
  BUF[4,207]:=3;
  RESET(F,'#4:SYSTEM.APPLE');
  I:=BLOCKWRITE(F,BUF,32);
  CLOSE(F);
                                    4-27
END.
```

D. Pascal

The use of the VIDEOTERM with Pascal is especially easy due to the great flexibility of the language and the Apple Language card operating system. As a quick example, Program Listing 7 shows how, to utilize the "GOTOXY" function.

Program XYADDRESS defines three integer variables and a single string variable. I is used a loop index, and X and Y are, naturally, the X and Y screen coordinates of the desired character When the program begins, the string location. variable S is set equal to "VIDEX" and the screen is cleared. Then each of the letters of S are accessed one at a time by execution of the "FOR" loop. The "CASE" statement is used to assign the actual screen at which the chosen character will be coordinates printed. Then the "GOTOXY" function moves the cursor there. and the Pascal internal "COPY" function is used to acquire the correct character from S and display it on the screen at the cursor location. The next character is then done until the "FOR" loop has been completed.

Enter the program using the Editor, then quit and update your work file. Compile and run it. The program will print "VIDEX" in a V pattern on the screen, starting in column 0, row 1 and ending in column 79, row 1.

You should also review the Program PEEKPOKE, Program Listing 1, for a method of accessing and changing internal memory location values.

PROGRAM LISTING #7

```
(*$L PRINTER: *)
PROGRAM XYADDRESS;
VAR I, X, Y: INTEGER;
      S:STRING;
BEGIN
 S:='VIDEX'; (* INITIALIZES STRING *)
 PAGE(OUTPUT);
                    (* BLANKS SCREEN *)
 FOR I:=1 TO 5 DO BEGIN
 CASE I OF
   1: BEGIN X:=0;Y:=1;END;
   2: BEGIN X:=19;Y:=11;END;
   3: BEGIN X:=39;Y:=23;END;
   4: BEGIN X:=59;Y:=11;END;
   5: BEGIN X:=79;Y:=1;END;
   END; (* OF CASE STATEMENT *)
GOTOXY(X,Y); WRITE(COPY(S,1,1)); (* USES COPY INTRINSIC STRING FUNCTION *)
END: (* OF FOR LOOP *)
END. (* OF PROGRAM *)
```

Using VIDEOTERM with Other Software

A. EasyWriter Professional Word Processing System

The EasyWriter, by Information Unlimited Software, is now totally compatible with the VIDEOTERM. Be sure to specify that you own a VIDEOTERM when you purchase EasyWriter, or contact IUS or your Apple dealer for details on how to acquire software updates incorporating full VIDEOTERM utilization. You can now view your text as it will be printed before printing it. The resulting display is much easier to read and on-screen text editing is improved.

B. Apple PIE

The Apple PIE editor, avaiable from Programma International, makes full use of all VIDEOTERM features. Be sure to inform them that you own a VIDEOTERM if you purchase the editor from Programma directly, or from your local Apple dealer, to ensure that you get the new version. Contact Programma directly for information on updating your version of Apple PIE, if you currently own a copy.

C. Others

At present, several other software houses are modifying or creating software for full VIDEOTERM compatibility. If you return the enclosed registration page, VIDEX will keep you informed of new and modified software products as they become available.

Interfacing with Other Peripherals

A. Softcard

The new Softcard by Microsoft utilizes software which, as far as the VIDEOTERM is concerned, looks much the same as the Apple Language card. The installation of the VIDEOTERM card in slot 3 will cause the Softcard to treat your video screen as if it was an ordinary display terminal. You should not have to make any adjustments or changes to the Input/Output routines of the CP/M Operating System. See the Checkout section, page 2-12, and follow the same procedures that you did with Apple Pascal in adjusting your monitor for the VIDEOTERM.

B. D. C. Hayes Micromodem II

The VIDEOTERM and the Micromodem II are compatible.

There are two basic ways to use the VIDEOTERM and the Micromodem together. As a 'dumb' terminal, without any program in memory, or under the control of a communication program. If you are going to use the Micromodem in the dumb terminal mode, it may be advantageous to use the VIDEX Micromodem firmware, which replaces the firmware on the Micromodem board. With our version of the firmware installed the prompts that the Micromodem issues will be sent to the VIDEOTERM's screen. Without our firmware the prompts will be sent to the 40 column display, even if the VIDEOTERM is turned on! It is important to note that there are some changes in the operation of the Micromodem with our firmware installed.

The most important modification is the removal of the self-test feature of the original Micromodem II firmware. Attendant to this change is the removal of the OUTA entry point in the firmware, which was used with the self-test procedure. It is therefore very important to keep your original firmware EPROM in a safe place, as you will need it for testing the unit when you desire. The other changes to the firmware are:

The flashing cursor is no longer removed when a character is received.

In the original firmware, bit 5 of the FLAGS register (\$77B) was unused. It is now used for the VIDEOTERM bit. If bit 5 is set it indicates that the VIDEOTERM board is present and output will be routed to it directly. If it is not set, output will be sent to the normal Apple II display.

Two new Zero Page locations are defined. VIDEXL (\$08) and VIDEXH (\$09) hold the address of the VIDEOTERM output call address. Remember that this first address is called a vector because it points to another location whose contents are of interest. When the VIDEOTERM board is present, output is routed via an indirect jump (hexadecimal operation code 6C, see page 123 of the Apple II Reference Manual) which uses the address stored at VIDEXL and VIDEXH.

To use the VIDEOTERM with the Micromodem the sign on process to a dial on computer network varies slightly. The following illustration shows the correct way to use the Micromodem and the VIDEOTERM together. (This example assumes the VIDEOTERM is in slot 3, the Micromodem is in slot 2, and the VIDEX micromodem firmware installed in the Micromodem II)

| | PROCEDURE | RESULTS |
|-----|-------------------|------------------------|
| 1) | Connect VIDEOTERM | (If the soft switch is |
| | | not being used) |
| 2) | PR#3 | Prompt returns |
| 3) | IN#2 | Prompt returns |
| 4) | POKE 1786,0 | (To enable lower case |
| | | display) |
| 5) | CRTL-A | MICROMODEM:? |
| 6) | CTRL-F | MICROMODEM: BEGIN TERM |
| 7) | CTRL-A | MICROMODEM:? |
| 8) | CTRL-Q | MICROMODEM:DIAL: |
| 9) | type number | MICROMODEM: AWAIT CARR |
| 10) | wait | MICROMODEM: CONN |

DECITE TO

DDOCEDIME

At this point you should be able to sign on to a computer network (such as the Source or Micro-Net) normally, with the display in 80 columns! If you did not have the VIDEX Micromodem firmware the procedure would be the same but you would not have any display on the VIDEOTERM until after step 10. (information on step 4 can be found in the Micromodem manual)

Another popular way to use the Micromodem and the VIDEOTERM together is through the use of a Communications Program.

A good communications program can be invaluable in making the most of your time when connected to another computer. An important thing to look for when buying a communications program is: Compatability with the VIDEOTERM. Although most programs work well with the VIDEOTERM some do not. It is always a good idea to try out a program before buying it to insure that you will have no problems setting up the program before trying to use it.

If you are going to use the Micromodem with a communications program it is important to note that you have NO need for the VIDEX micromodem firmware. In fact some programs, such as Apple Computer's News and Quotes and Dow Jones program will NOT work with the modified ROM. However, most programs will work properly with the VIDEX Micromodem firmware installed in the Micromodem.

The following is a list of communications programs that are known to work with a VIDEOTERM and Micromodem.

ASCII Express 'The Professional'
Transend
Data Capture 4.0 (VIDEOTERM version)
B. I. T. S.
Z Term (for CP/M)

This is in no way a comprehensive list of all the communications programs that work with the VIDEOTERM rather, it is a sampling of programs that are currently available. New programs are constantly being released for the Apple][and should not be overlooked when buying a communications program.

Creating New Character Sets

You may use any 2708, 2758 or 2716 EPROM programmer, although the most common and popular programmer is the ROMWriter available from Mountain Hardware. The ROMWriter utilizes 2716 EPROMs. You should check the Optional Hardware Modification section, page 6-4 to 6-6, to ensure that your VIDEOTERM is correctly set up for the size of EPROM that you are planning to use. Note that the 2758 should be set up like a 2716.

A. Text

Naturally, you may print all 128 ASCII characters on your video monitor using the VIDEOTERM. However, the expanded character set available on the 2708 EPROM on the VIDEOTERM contains another 64 characters which may be printed




Figure 4: Insertion of Character set EPROM into the VIDEOTERM board

using the keyboard or by printing characters from your running programs. To activate the expanded character set, enter or "PRINT" the "CTRL-Z 3". Return to the standard character set with "CTRL-Z 2". Depending on the EPROM that you have installed, you may have virtually any character font available to you. If you don't have an EPROM installed in your VIDEOTERM, the selection of the expanded character set will simply generate blank white squares.

VIDEX offers a variety of character fonts on 2708 and 2716 EPROMs. Write to us for a current list of available character sets. These EPROMS are easily installed in place of part U-17 in the photograph on page A-4. Figure 4 shows a photograph of the insertion of an EPROM into this location. Be careful when inserting or withdrawing any chip from the board as you can easily bend the pins which may result in their breaking.

Figure 5 shows the keyboard correspondence for Line Drawing set EPROM. Figure 6 shows an example report form created using this character The actual use of character cells within the matrix for this character set is shown in Figure 7a, pages 4-40 to 4-43. The character set provided in your 2716 EPROM Character Generator is shown in Figure 7b, pages 4-44 to 4-51. Several blank forms have been included as Figure 8, pages 4-52 to 4-55, for you to use in creating your own character set. Feel free to photocopy as many of these blank forms as you like. You can program these yourself if you have a 2708 EPROM Programmer for the Apple II. You can even use a 2716 EPROM to obtain a total of 128 new characters by simply resoldering two jumpers on the VIDEOTERM board (see page 6-4 and Figure 9b).

Follow the instructions included with your EPROM programmer to program your chip. We advise that you try programming the standard character set

on your first attempt and use it to replace the VIDEX supplied EPROM in U-20. That way you can verify that you are following the correct procedures in "burning" your EPROMs.

B. Graphics

You can generate your own set of graphics display characters using your EPROM programmer. Follow exactly the same method you used in generating text character sets.

ASCII:



FRENCH:



KATAKANA:



ASCII UC:




GERMAN:



SPANISH:




SYMBOL:



SUPER & SUBSCRIPT:





APL:





EPSON:


















































FIRMWARE

For the casual user, not much need be said firmware that the board comes equipped with. For the most part, you will be satisfied with the boards performance and much of what it does, why how to modify it will does it and If, however, you transparent you. to register contents and tinkering with this section will provide you with some esoterica. very interesting information.

We will begin this section with a discussion of the CRT Controller chip that is the heart of the VIDEOTERM board, the chip's function and how to access its various registers and options. This will be followed by a discussion of how to modify some of the internal registers that your firmware uses.

Firmware Control of the VIDEOTERM Board

Included in a 2708 EPROM on the VIDEOTERM board is the software which controls the CRT Controller and other aspects of character processing. A listing of this 6502 assembly language program begins on page 5-x. A careful study of this listing and its included comments will do much to instruct you on how to access and control the VIDEOTERM from your own assembly language programs.

At the heart of the VIDEOTERM board is the Hitachi HD46505SP CRT Controller IC chip (CRTC). It is the largest chip on the board and occupies a postion just to the upper-left of center. While all keyboard operations, cursor movements, read and write operations, and editing are under the 6502 microprocessor unit's (MPU's) control, the CRTC provides all video timing for interfacing to raster scan CRT displays.

The use of static Ram on the VIDEOTERM board relieves the CRTC of the task of memory refresh. Its other features are fully employed. These functions include an internal cursor register which may be altered so that the cursor may be programmed to a unique shape, which allows ready recognition of which program or part of a program is executing. A light pen strobe input signal allows capture of the status of an internal light pen register.

A. CRTC Internal Register Use

The CRTC contains a set of internal registers which are user software programmable. The contents of these registers are regularly scanned by the CRTC to determine such matters as horizontal and vertical raster timing, position of the cursor, cursor size and shape, interlace mode and several other items. Let us see what each of the 18 available registers does.

Horizontal timing of the raster scan controlled by Registers RO, R1, R2 and R3. These registers control the frequency, position and width pulse and the frequency, of the horizontal sync and duration of the horizontal display position The screen display point of reference for horizontal registers is the left most displayed position. These registers contain data character which in 'character time' units, determined by is the MCM6571A Character Generator. The timing units given in Table 4 for the various character cell matrix sizes which are available through the "CTRL-Q <params>" character sequence.

RO: An 8-bit write-only register that determines the horizontal frequency which is the total, minus one, of displayed and non-displayed character time units. This is called the Horizontal Total Register.

- R1: An 8-bit write-only register that determines the number of displayed charactes per line. This is termed the Horizontal Display Register.
- R2: An 8-bit write-only register that determines the horizontal sync position on the horizontal line. This is termed the Horizontal Sync Position Register.
- R3: A 4-bit write-only register that determines the width of the horizontal sync pulse. This is termed the Horizontal Sync Width Register.

A variety of vertical registers control the vertical sync pulse frequency and position and the vertical display frequency and position. It also generates row selects for interlace or non-interlace modes. The point of reference for the vertical registers is the top character position displayed. These registers are programmed in 'character time' units.

- R4: Α 7-bit write-only register that the vertical refresh rate in determines with R5. The calculated conjunction number of character line times is usually integer plus a fraction to obtain exactly a 50 or 60 Hz vertical refresh The integer number of character line times minus one is entered into this register which is called the Vertical Total Register.
- R5: A 5-bit write-only register contains the fraction needed to obtain, in conjunction with R4, the needed exact 50 or 60 Hz vertical refresh rate. This is called the Vertical Total Adjust Register.
- R6: A 7-bit write-only register determines the

number of displayed character row on the screen (in 'character row' time units. This is called the Vertical Displayed Register.

- R7: A 7-bit write-only register determines the vertical sync position with respect to the top reference line. This is called the Vertical Sync Position Register.
- 2-bit write-only register controls the R8: raster scan mode. As long as bit 0 is (0), the display is in Normal Sync clear Mode (non-Interlaced). When bit 0 is set (1). bit 1 determines the mode. If it is clear (0), then Interlace Sync Mode is If bit 1 is set (1), then Interlace set. Sync with Video Mode is set. The Normal Sync Mode is what is normally selected by the VIDEOTERM. Interlace Sync doubles the number of dots, duplicating each dot below its position, thus increasing the quality of the displayed character. Interlace Sync with Video keeps the character dot matrix the same, but doubles the number of lines on the screen so that twice as many characters, each one-half their normal size, are displayed on the screen. This mode should only be chosen if you are using a long-phosphor video monitor. This is called the Interlace Mode Register.
- R9: A 5-bit write-only register that determines the number of scan lines per character row including spacing around the character row. This is one less than the number of scan lines. This register is called the Maximum Scan Line Address Register.

There are eight more registers available which affect four other display characteristics. Since

these registers are utilized in pairs, we will describe them in that way.

and R11: The Cursor Start and End Registers, respectively. R10 is a 7-bit and R11 is a 5-bit write-only register. In both, bits 0 to 4 are the start and end row of the cursor. R10, the start row, may be set at any value from 0 to 11 (decimal). R11, the end row, may be set at any value greater than or equal to the start row value. Thus if the start row was 0 and the end row was 11, a full cursor would be displayed, while if the start and end rows were both 11 an underline cursor would be formed. In addition, bits 5 and 6 of R10 are used to set the Cursor Display Mode. If bit 6 is clear (0), the cursor will not blink, while if it is set (1), it will blink at a rate determined by bit 5. If bit 6 is clear then the status of bit 5 determines if there is a cursor displayed (cleared or 0) or not (set or 1). When bit 6 is set and bit 5 is clear (0), you set a 1/16th field rate blink. When bit 5 is set, you obtain a 1/32nd field rate blink. You can set these registers so that you can obtain a wide variety of customized and individually recognizable cursors which can greatly aid you in identifying which software program is currently running.

R12 and R13: These are the high and low, respectively, addresses for determining where to start writing on the screen. You should not change or utilize these registers in any way as you will interfere with the scrolling operation of the VIDEOTERM. R12 is a 6-bit and R13 is an 8-bit pair of write-only registers called the Start Address Register.

R14 and R15: These are high and low, respectively, address components of a 14-bit address determining the current cursor location. You do not need to access these locations directly, but may reposition the cursor through the use of the

"SHIFT-CTRL-N <x> <y>" sequence where the x and y screen coordinates, in ASCII character codes are given in place of the angle brackets. Rl4 is a 6-bit and Rl5 is an 8-bit pair of read/write registers called the Cursor Register.

R16 and R17: These are high and low, respectively, address components of a 14-bit address which is stored when the Light Pen strobe goes high. The address which is stored is the CRTC Address Counter. R16 is a 6-bit and R17 is an 8-bit pair of read-only registers.

Table 4 on the following page summarizes this information and gives the standard VIDEOTERM default values used with its various character cell matrix sizes.

Table 4: CRTC Register Assignments

B. How to Modify CRTC Registers

Now that you know what the various registers are, you undoubtedly want to know how to modify their contents. To do this you must place two values into specific Apple II memory locations. The first value is the register number, in hexadecimal, that you wish to write into and the second value is the new value to be entered. Thus, if you wanted to change the cursor to a non-blinking upper half of a cursor five rows thick, you would want to enter "OA O1" and "OB O5" to place line numbers 1 and 5 into R10 and R11, respectively. If you wanted to make this cursor blink, you would enter "OA 61" where the \$61 (decimal 97) indicates that both bits 5 and 6 of the word are set.

But how do you determine the address at which to enter these numbers? This is done using a device select operation, which algorithm is as follows. Your first hex address character must be a 'C' as this is the address space used by Apple II in dealing with its peripherals. The next number must These are the high address of the device zero. select 16-byte group. The third number will be eight plus the slot number so that if your board is 3 the number will be 'B' in hex. in slot first three numbers of the correct address are chosen according to Table 3, page 4-7. Also look at Table 25, page 82, in the Apple II Reference Manual. The last number of the four is either a '0' or '1'. Enter the CRTC Register to be changed using '0' and the value to be placed in that register using '1'. Let us continue with our cursor modification example above and enter the correct information, assuming that you have the VIDEOTERM in slot 3. Enter the Monitor by typing

CALL -154 (CR)

Then enter

*COBO:OA (CR)
*COB1:O1 (CR)
*COBO:OB (CR)
*COB1:O5 (CR)

You can also enter the information with

*COBO:OA O1 (CR)
*COBO:OB O5 (CR)

You have now set the cursor to a non-blinking, upper-half cursor, five martix cell rows thick. You have done this by reinitializing registers R10 and R11.

C. Device Select Operation

Device selection is mentioned several times throughout this manual. The calculation of the correct 16-byte device specific group has been demonstrated to be slot dependent. The preceding section should how to use the device select to modify a CRTC register. However, whenever a "PEEK" or "POKE" command is executed in this group, several things happen. To understand this, we need to describe how the lowest 4 bits of this two-byte address affects the VIDEOTERM. This is the 'x' in the \$COBx address. (For other slots, substitute \$8+n, where n is the slot number of the VIDEOTERM.)

The very lowest bit, bit 0, controls whether a register is being accessed (0) or the contents of the register is being accessed (1). The next lowest bit, bit 1, controls whether an eight or nine cell matrix width is being used. VIDEOTERM automatically interprets this as 0 (9 cells), so there is no reason to change this.

The next two bits, bits 2 and 3, determine which page will be selected (see VIDEOTERM memory mapping, page 5-12. If the value of both is zero,

page zero is selected, if their value together is one, page one is selected, and so forth. Thus, access of \$COBO selects for slot 3, a register access and page zero all at once. Similarly, \$COC5 selects for slot 4, register contents access and page one use (bit 2 and bit 0 set).

D. Video Set-Up Flags

Table 1 defined the VIDEOTERM's use of available Apple II RAM scratchpad locations. Location \$7F8 (decimal 2040) was defined as being used as video set-up flags. These flags will be explained here.

Each word of storage in the Apple II contains 8 bits. The bit locations in the word are identified by a number between 0 and 7, with bit 0 the bit furthest to the right in the word (representing the 1's place) and bit 7 is the furthest to the right (representing the 128's place, i.e. 2'). Only 4 of the 8 bits are used as flags.

- Bit 0: Alternate character set flag. When set to 0, it selects the standard character set. When set to 1, it selects the alternate character set. If you have the modified the VIDEOTERM to use its inverse video option, then the setting of 0 selects for standard video and 1 selects for an inverse character (black on white field).
- Bit 4: Number of rows flag. When set to 0, it selects for display of 18 lines of text. When set to 1, it selects for display of 24 lines of text.
- Bit 6: Upper/lower case flag. When set to 0, it selects for non-conversion of entered text so that an upper case character (all that you can type directly from the keyboard) will remain upper case. When set to 1, it

selects for conversion of the entered character to lower case. This flag is toggled by the "CTRL-A" entry.

Bit 7: GETLN flag. When set to 0 it indicates that the VIDEOTERM input came from a "GET" statement. When set to 1, it indicates that your input has resulted from use of the Apple's GETLN routine, which means input came from a program's "INPUT" statement or directly from the keyboard. The behaviour of this routine is fully documented in the Apple II Reference Manual, pages 33-34.

VIDEOTERM Memory Mapping

As explained in the Apple II Reference Manual on pages 84 and 85, the Apple II address range from \$C800 to \$CFFF is reserved for mapping into 2K of EPROM memory located on a peripheral card. Which card, determined by its slot location, is referenced by these addresses is determined by the "PR#n" statement.

For the VIDEOTERM, the 1K range from \$C800 to \$CBFF is used to access the controlling firmware on the board. The address range from \$CC00 to \$CDFF is used to address the VIDEOTERM's on-board RAM. The range from \$CE00 to \$CFFF is not presently used.

The address range from \$CC00 to \$CDFF only covers 512 bytes of storage. Since the VIDEOTERM HAS 2K of on-board RAM, four times the address range, it would seem impossible to access all of the on-board memory! To overcome this apparent limitation, a technique called "paging" is used.

Basically, paging works as follows. The 2048 byte RAM area is subdivided into four 512-byte segments, each called a "page". Once the VIDEOTERM is activated by the correct memory reference, it will automatically set the correct active page. You then write the character that you want displayed to the relative address within the 512-byte group. This is called a "page-relative address" and may be calculated by taking the 2048-byte address modulo 512. Then write the character you want displayed to that address.

Let us review the process as you would implement it in one of your programs. Determine the address within the 2048 byte on-board RAM that you wish to access. This technique is illustrated in the Applesoft and Integer Basic language software examples in the preceding chapter on pages 4-12 to

4-23, and reviewed again below. Then execute a "PEEK" on a page-specific address in the reserved peripheral 16-byte group. For slot 3. these addresses would be \$COBO, \$COB4, \$COB8 and \$COBC (49328 TO 49340). This sets the VIDEOTERM's current active page to the correct page. Finally, "POKE" the desired character, represented by its ASCII character code in decimal, into the page-relative acquired by taking the actual address 'MOD address You have just placed that character in the 512". VIDEOTERM's on-board memory and you will see the character properly displayed in its chosen position on your monitor screen.

Note that when you determine the actual 2048 byte address, you must use the current screen start line address stored at \$6F8 + n = 1784 + n, where n is the number of the slot in which the VIDEOTERM is located. (See Table 1, page 3-2.) Multiply the contents of this location by 16. Next determine where on the screen you want to place the character. The column number, X, may vary between 0 and 79, and the row number, Y, may vary between 0 and 23. The on-screen location will be X + 80 * Y. This will generate a number between 0 and 1919. Add this to the start location times 16. Take this result modulo 2048 to keep it in the correct numerical range. The final algorithm is

ADDRESS = X + Y * 80 + PEEK(1784 + n) * 16

To activate the correct page, take the start address of the 16-byte group dedicated to the slot in which the VIDEOTERM is located. This address is \$C080 + n * 16 = 45184 + n * 16, where n is the slot location. Add to this result the desired page to be activated. This is calculated by taking the above ADDRESS/512. A page number between 0 and 3 is thus calculated. We then multiply by 4 to put this number in bits 2 and 3 (see page 5-9). Lastly, "PEEK" at the address which is the sum of the start address and four times the page number. Thus

PAGE = ADDRESS/512 SELECT = PEEK(45184 + n * 16 + PAGE * 4)

The correct VIDEOTERM RAM page is now activated, and any character written into the address space \$CC00 (52224) to \$CDFF (53247) will go to the active page.

For Integer Basic, subtract the value 65536 from the above decimal address equivalents to generate the correct negative decimal address equivalent. The peripheral-specific 16-byte address group base addresses are listed in Table 3, page 4-7, for all Apple languages.

```
1
2
3
            VIDEOTERM INTERFACE
4
             FIRMWARE V. 2.4
5
        WRITTEN BY DARRELL ALDRICH
             (C) 1981 VIDEX
     *************************
10
     * ZERO PAGE EQUATES
11
12
13
     CH
              EQU $24
14
     CV
              EQU
                   $25
15
     BASL
              EQU
                   $28
16
     XSAVE
              EQU
                   $35
17
     CSWL
              EQU
                    $36
18
     CSWH
              EQU
                    $37
19
     KSWL
              EQU
                    $38
     KSWH
50
              EQU
                    $39
21
     RNDL
              EQU
                    $4F
22
     RNDH
              EQU $4F
23
24
     * TEMPORARIES
25
26
     CRFLAG
              EQU
                   $478
27
     ASAV1
              EQU
                   $4F8
     XSAV1
                    $578
28
              EQU
     TEMPX
29
              EQU
                    $5F8
30
     OLDCHAR
              EQU
                    $678
31
     N0
              EQU
                    $6F8
                   $778
32
     MSLOT
              EQU
33
34
     * MISC EQUATES
35
36
     IN
              EQU $200
     IORTS
              EQU $FFCB
37
38
39
     * SLOT N PERMANENTS
40
41
     BASEL
              EQU $478
                               ; SCREEN BASE ADDRESS LOW
42
     BASEH
              EQU $4FB
                               ; SCREEN BASE ADDRESS HIGH
43
     CHORZ
              EQU
                   $578
                               : CURSOR HORIZONTAL POSITION
44
     CVERT
              EQU
                   $5FB
                               : CURSOR VERTICAL POSITION
                               ; I/O BYTE FOR PASCAL ENTRIES
45
     BYTE
              EQU
                    $67B
46
     START
              EQU
                   $6FB
                               ; SCREEN START ADDRESS
                               ; POWER OFF AND LEAD IN COUNTER
47
     POFF
              EQU
                   $77B
48
49
     * BO, B1 IS GO TO XY LEAD IN COUNTER
50
     * B2 IS CONTROL Z LEADIN COUNTER
     * B3-B7 IS POWER OFF FLAG
51
52
53
     FLAGS
              EQU $7FB
                               ; VIDEO SET UP FLAGS
54
55
     * BO ALTERNATE CHARACTER SET 1=ON 0=OFF
56
     * B1
57
     * B2
58
     * B3
```

```
50
                    * B4 ROWS OF CHARACTERS 1=24 0=18
               60
                    * 85
                    * B6 LOWER / UPPER CASE CONVERSION FLAG 1=ON 0=OFF
               62
                    * B7 GETLN FLAG 1=INPUT CAME FROM GETLN ROUTINE
               63
               64
               45
                    * 10 DEVICES
               66
                    KBD
                             EQU $C000
               67
               68
                    KBDSTRB EQU
                                  $C010
               69
                    SPKR
                             EQU
                                   $C030
               70
                    DEV0
                             EQU
                                   $COB0
               71
                    DEV1
                             FOII
                                  $C0B1
               72
                    DISPO
                             EQU
                                  $CC00
               73
                    DISP1
                             EQU $CD00
               74
               75
                             ORG
                                  $C800
               76
                             OBJ $6800
               77
               78
                    * SET UP CRTC AND CLEAR SCREEN
               79
               80
               81
C800: AD 7B 07 82
                    SETUP
                             LDA POFF
                                             ; GET POWER OFF FLAG
C803: 29 F8
                                  #$F8
                                              ; STRIP OFF LEAD IN COUNTERS
               83
                             AND
C805: C9 30
               84
                             CMP
                                   #$30
                                             : HAS POWER BEEN TURNED OFF?
                                             : RETURN IF NOT
C807: F0 21
               85
                             BEQ
                                  SETEXIT
C809: A9 30
               86
                    RESTART LDA
                                  #$30
C80B: 8D 7B 07 87
                             STA
                                  POFF
                                             : SET DEFAULTS FOR FLAGS
CBOE: 8D FB 07 88
                             STA
                                  FLAGS
C811: A9 00
               89
                             LDA
                                  #$00
C813: 8D FB 06 90
                             STA
                                  START
C816: 20 61 C9 91
                             JSR
                                  CLSCRN
C819: A2 00
               92
                             LDX
                                  #$00
C818: 8A
               93
                    LOOP
                             TXA
                                             ; FOR THE CRTC ADDRESS
C81C: 8D B0 C0 94
                             STA
                                  DEV0
                                             ; GET PRAMETER
                             LDA
                                  TABLE, X
C81F: 80 A1 C8 95
C822: 8D B1 C0 96
                             STA DEVI
                                             : STORE INTO CRTC
C825: E8
               97
                             INX
                             CPX
C826: E0 10
               98
                                  #$10
                                  LOOP
                                              ; CONTINUE LOOP UNTIL DONE
C828: D0 F1
               99
                             BNE
CB2A: 8D 59 CO 100 SETEXIT STA
                                  $C059
C82D: 60
                             RTS
               101
               102
               103
CB2E: AD FB 07 104 EXIT
                             LDA FLAGS
C831: 29 08
               105
                             AND
                                  #$08
                                  NORMOUT
C833: F0 09
               106
                             BEQ
C835: 20 93 FE 107
                             JSR
                                  $FE93
C838: 20 22 FC 108
                             JSR $FC22
C83B: 20 89 FE 109
                             JSR
                                 $FE89
                                             ; RECOVER REGISTERS
C83E: 68
               110 NORMOUT PLA
C83F: A8
               111
                             TAY
C840: 68
               112
                             PLA
C841: AA
               113
                             TAX
C842: 68
                             PLA
               114
C843: 60
               115
                             RTS
               116
               117
               118
                   * GET CHARACTER FROM KEYBOARD
```

```
119
C844: 20 D1 C8 120
                    RDKEY
                              JSR
                                  CSRMOV
                                               ; POSITION CURSOR
                              INC
                                               : UPDATE BASIC RANDOM NUMBER
C847: E6 4E
                     KEYIN
                                   RNOL
                121
                                   KEYIN2
C849: D0 02
                122
                              BNE
C848: E6 4F
                123
                              INC
                                   RNOH
C84D: AD 00 C0 124
                     KEYIN2
                                   KBD
                                               ; POLL KEYBOARD
                              LDA
                                               ; LOOP UNTIL KEY IS STRUCK
C850: 10 F5
               125
                              BPL
                                   KEYLI
C852: 20 5C C8 126
                              JSR
                                   KEYSTAT
C855: 90 F0
               127
                              BCC
                                   KEYIN
C857: 2C 10 CO 128
                    NOKEY
                                   KBDSTRB
                                               : CLEAR KEYBOARD STROBE
                              BIT
C85A: 18
                129
                              CLC
                130
                              RTS
C85B: 60
                131
                                               ; CHECK FOR CONTROL K
                    KEYSTAT
                              CMP
C85C: C9 8B
                132
                                   #$8B
                                               ; SKIP IF NOT
C85E: D0 02
                              BNE
                                   NOTK
                133
                                               ; SUBSTITUTE A RIGHT BRACKET
                              LDA
                                    #$DB
C860: A9 DB
                134
                    NOTK
                              CMP
                                    #$81
                                               ; CHECK FOR CONTROL A
C862: C9 81
                135
C864: D0 0A
                136
                              BNE
                                   NTSHFT
                                               ; SKIP IF NOT
C866: AD FB 07 137
                              LDA
                                   FLAGS
                              EOR
                                   #$40
C869: 49 40
                138
                                               ; TOGGLE UPR/LWR CASE FLAG
C86B: 8D FB 07 139
                              STA
                                   FLAGS
                                               ; GET NEXT KEY
                                   NOKEY
C86E: B0 E7
                140
                              BGE
C870: 48
                141
                    NTSHFT
                              PHA
                                               ; SAVE CHARACTER
C871: AD FB 07 142
                              LDA
                                   FLAGS
                              ASL
C874: 0A
                143
C875: 0A
                144
                              ASL
                                               : CHECK UPR/LWR CASE CONVERSION FLAG
                              PLA
                                               ; RESTORE CHARACTER
C876: 68
                145
C877: 90 1F
                146
                              BCC
                                    INDONE
                                               ; DON'T CONVERT IF FLAG CLEAR
C879: C9 B0
                147
                              CMP
                                    #$B0
                                               ; DON'T CONVERT SPECIAL CHARACTERS
                                    INDONE
C878: 90 1B
                              BLT
                148
                                    $C063
C870: 2C 63 C0 149
                              BIT
                                   NOSHIFT
C880: 30 14
                150
                              BMI
C882: C9 B0
                              CMP
                                    #"0"
                151
C884: F0 0E
                152
                              BEQ
                                    ZERO
C886: C9 C0
                153
                              CMP
                                    #"8"
                              BNE
                                   NOTE
C888: D0 02
                154
C88A: A9 D0
                155
                              LDA
                                    #"P"
                                    #"["
C88C: C9 DB
                156 NOTE
                              CMP
                                    INDONE
C88E: 90 08
                157
                              BLT
CB90: 29 CF
                158
                              AND
                                    #$CF
C892: D0 04
                159
                              BNE
                                    INDONE
                                    #"]"
                     ZERO
                              LDA
C894: A9 DO
                160
                     NOSHIFT
                              ORA
                                    #$20
C896: 09 20
                161
                     INDONE
                              PHA
                                               ; DUPLICATE CHARACTER
C898: 48
                162
                                               ; STRIP OFF HIGH BIT
C899: 29 7F
                163
                               AND
                                    #$7F
                              STA
                                    BYTE
                                               : SAVE FOR PASCAL
C89B: 8D 7B 06 164
                                               ; RECOVER FOR BASIC
C89E: 68
                165
                              PLA
                              SEC
C89F: 38
                166
                              RTS
C8A0: 60
                167
                168 *
C8A1: 78 50 5E
C8A4: 29 18 08
                              HEX 7B505E291B081819
C8A7: 18 19
                169 TABLE
C8A9: 00 08 E0
CBAC: 08 00 00
C8AF: 00 00
                170
                              HEX 0008E00800000000
                171
                172
```

* SECONDARY BASIC OUTPUT ROUTINE

173

```
174
                175
C881: 8D 7B 06 176
                     BASOUT 1
                              STA BYTE
                                               ; SAVE CHARACTER
C884: A5 25
                177
                                                ; PERFORM VTAB
                               LDA
                                    CV
C8B6: CD FB 05 178
                                    CVERT
                               CMP
C8B9: F0 06
                179
                               8EQ
                                    CVOK
C8BB: 8D FB 05 180
                               STA
                                    CVERT
C88E: 20 04 CA 181
                               JSR
                                    VTAB
C8C1: A5 24
               182
                     CVOK
                               LDA
                                    CH
                                               : PERFORM HTAB
C8C3: CD 78 05 183
                               CMP
                                    CHORZ
CBC6: 90 03
                               BCC
                                    PSCLOUT
                184
C8C8: 8D 78 05 185
                               STA
                                    CHORZ
CBCB: AD 7B 06 186
                     PSCLOUT
                               LDA
                                               ; GET CHARACTER
                                    BYTE
C8CE: 20 89 CA 187
                               JSR
                                    OUTPT1
                                               ; OUTPUT CHARACTER
C8D1: A9 OF
               188
                     CSRMOV
                               LDA
                                    #$0F
                                               ; SET UP CRTC ADDRESS
C8D3: 8D 80 C0 189
                               STA
                                    DEV0
                                               ; FOR CURSOR LOW ADDRESS
C8D6: AD 7B 05 190
                               LDA
                                    CHORZ
                                                ; CALCULATE ADDRESS
C8D9: C9 50
                191
                               CMP
                                    #80
C8DB: B0 13
                192
                               BCS
                                    RTS6
C8DD: 6D 78 04 193
                               ADC
                                    BASEL
C8E0: 8D B1 C0 194
                               STA
                                    DEV1
                                               ; SAVE ADDRESS
C8E3: A9 0E
               195
                              LDA
                                    #$0E
                                               ; SET UP CRTC ADDRESS
C8E5: 8D B0 C0 196
                                    DEV0
                               STA
                                               ; FOR CURSOR HIGH ADDRESS
C8E8: A9 00
                197
                              LDA
                                    #$00
                                               ; CALCULATE ADDRESS
C8EA: 6D FB 04 198
                               ADC
                                    BASEH
C8ED: 8D 81 C0 199
                                               ; SAVE ADDRESS
                               STA
                                    DEV1
CBF0: 60
                200 RTS6
                              RTS
                201
                202
                203
                     * PERFORM ESCAPE FUNCTIONS
                204
C8F1: 49 C0
                205
                     ESC1
                              EOR
                                   #$C0
C8F3: C9 08
                                    #$0B
                204
                               CMP
C8F5: 80 1D
                207
                               BGE
                                    RTS3
C8F7: A8
                208
                               TAY
C8F8: A9 C9
                209
                               LDA
                                    #>BELL
C8FA: 48
                210
                              PHA
C8F8: 89 F2 C8 211
                                   ESCTBL, Y
                              LDA
CBFE: 48
               212
                              PHA
C8FF: 60
                213
                              RTS
                214
C900: EA
                              NOP
                215
                216
                                    CHORZ
C901: AC 7B 05 217
                    CLREDL
                                               ; PUT CURSOR HORIZONTAL INTO Y
                              LDY
                                               : USE A SPACE
C904: A9 A0
               218
                    CLEOLZ
                              LDA
                                    #$A0
C906: 20 71 CA 219
                     CLEOL 2
                               JSR
                                    CHRPUT
                                               ; PUT CHARACTER ON SCREEN
C909: C8
               220
                               INY
C90A: C0 50
                221
                               CPY
                                    #80
                                               ; CONTINUE UNTIL
C90C: 90 FB
                555
                               BLT
                                    CLEOL 5
                                               ; Y >= 80
C90E: 60
                553
                              RTS
                224
C90F: A9 34
               225
                    LEADIN
                              LDA
                                    #$34
                                               : SET LEAD IN BIT
C911: 8D 7B 07 226
                     PSAVE
                              STA
                                    POFF
C914: 60
               227
                     RTS3
                              RTS
C915: A9 32
                     GOXY1
                              LDA
                                    #$32
                                               ; SET LEADIN COUNT TO 2
                558
C917: D0 F8
                              BNF
                                    PSAVE
                229
                230
C919: A0 C0
               231
                     BELL
                              LDY
                                    #$C0
                                               ; BEEP THE SPEAKER
C918: A2 80
               232
                     BELL1
                              LDX
                                    #$R0
C91D: CA
               233
                     BELL2
                              DEX
```

```
C91E: D0 FD
                234
                              BNE BELL2
C920: AD 30 C0 235
                                   SPKR
                              LDA
C923: 88
                236
                              DEY
                                   BELL1
C924: D0 F5
                237
                              BNF
C926: 60
                238
                              RTS
                239
                240
                241
                    * STORE CHARACTER ON SCREEN AND ADVANCE CURSOR
                242
C927: AC 7B 05 243
                     STOADV
                              LDY
                                   CHORZ
C92A: C0 50
                244
                              CPY
                                   #80
C92C: 90 05
                245
                              BCC
                                   NOT81
C92E: 48
                246
                              PHA
C92F: 20 B0 C9 247
                              JSR
                                   CRLF
C932: 68
                248
                              PLA
                    NOT81
C933: AC 7B 05 249
                              LDY
                                   CHORZ
                                               ; PLACE CHARACTER ON SCREEN
C936: 20 71 CA 250
                              JSR
                                   CHRPUT
                                               : INCREMENT CURSOR HORIZONTAL INDEX
C939: EE 7B 05 251
                     ADVANCE
                              INC
                                   CHORZ
C93C: 2C 78 04 252
                              BIT
                                   CRFLAG
C93F: 10 07
                253
                              BPL
                                   RTS8
C941: AD 78 05 254
                              LDA
                                   CHORZ
                              CMP
C944: C9 50
                255
                                   #80
                              BCS
C946: B0 68
                256
                                   CRLF
C948: 60
                257
                    RTS8
                              RTS
                258
                     * CLEAR TO END OF hAGE
                259
                240
C949: AC 7B 05 261
                    CLREOP
                              LDY
                                   CHORZ
                                               ; GET CURSOR HORIZONTAL INTO Y
C94C: AD FB 05 262
                              LDA
                                   CVFRT
                                                 GET CURSOR VERTICAL INTO A
C94F: 48
                    CLEOP1
                                               ; SAVE CURRENT LINE ON STACK
                263
                              PHA
                                               ; CALCULATE BASE ADDRESS
C950: 20 07 CA 264
                              JSR
                                   VTABZ
                                               ; CLEAR TO END OF LINE, SET CARRY
C953: 20 04 C9 265
                              JSR
                                   CLEOLZ
                              LDY
                                    #$00
                                               ; CLEAR FROM HORIZONTAL INDEX 0
C956: A0 00
                599
C958: 68
                267
                              PLA
C959: 69 00
                              ADC
                                   #$00
                                               ; INCREMENT CURRENT LINE (C=1)
                268
                                               ; DONE TO BOTTOM OF WINDOW?
C95B: C9 18
                269
                              CMP
                                   #24
                                   CLEOP 1
                                               ; IF NOT KEEP CLEARING LINES
C95D: 90 F0
                270
                              BCC
C95F: B0 23
                              BCS
                                   JVTAB
                                               : VERTICAL TAB TO CURSOR POSITION
                271
                272
                273
                     * CLEAR SCREEN
                274
                275
C961: 20 67 C9 276
                     CLSCRN
                              JSR HOME
                                               : HOME CURSOR
C964: 98
                277
                              TYA
C965: F0 E8
                                               ; CLEAR TO END OF PAGE
                278
                              BEQ CLEOP1
                279
                280
                     * HOME CURSOR
                281
C967: A9 00
                     HOME
                              LDA
                                   #$00
                                               ; SET CURSOR POSITION TO 0,0
                585
C969: 8D 7B 05 283
                              STA
                                   CHORZ
C96C: 8D FB 05 284
                              STA
                                   CVERT
C96F: A8
                285
                              TAY
C970: FO 12
                286
                              BEQ
                                   JVTAB
                                               ; VERTICAL TAB TO CURSOR POSITION
                287
C972: CE 78 05 288
                              DEC
                                   CHORZ
                                               ; DECREMENT CURSOR HORIZONTAL INDEX
                     BS
                                               ; IF POS, OK. ELSE MOVE UP
C975: 10 9D
                289
                              BPL
                                   RTS3
                                               ; SET CURSOR HORIZONTAL TO
C977: A9 4F
                290
                              LDA
                                    #79
C979: 8D 7B 05 291
                                   CHORZ
                                               : RIGHTMOST SCREEN POSITION
                              STA
                292
                293
                     * MOVE CURSOR UP
```

```
294
C97C: AD FB 05 295 UP
                                             ; GET CURSOR VERTICAL INDEX
                             LDA CVERT
C97F: F0 93
               296
                                             ; IF TOP LINE THEN RETURN
                             BEQ
                                  RTS3
C981: CE FB 05 297
                                             ; DECREMENT CURSOR VERTICAL INDEX
                             DEC
                                  CVERT
C984: 4C 04 CA 298 JVTAB
                             JMP
                                  VTAB
                                             ; VERTICAL TAB TO CURSOR POSITION
               299
               300
C987: A9 30
               301 NOTGOXY LDA #$30
                                             : CLEAR LEAD IN BITS
C989: 8D 7B 07 302
                             STA
                                  POFF
C98C: 68
               303
                             PLA
                                             : RECOVER CHARACTER
C98D: 09 80
               304
                             ORA
                                  #$80
                                  #"1"
C98F: C9 B1
               305
                             CMP
C991: D0 67
               306
                             BNE
                                 NOTO
C993: A9 08
                                  #$OR
               307
                             LDA
C995: 8D 58 CO 308
                             STA
                                  $C058
C998: D0 58
               309
                             BNE FLOSET
               310
C99A: C9 B2
                                  #"2"
               311 NOT1
                             CMP
C99C: D0 51
               312
                             BNE NOT2
C99E: A9 FE
               313 LOLITE
                             LDA
                                  #$FE
C9A0: 2D FB 07 314 FLGCLR
                             AND FLAGS
C9A3: 8D FB 07 315
                  FLGSAV
                             STA
                                 FLAGS
C9A6: 60
               316
                             RTS
               317
               318
               319
                   * PASCAL OUTPUT ENTRY POINT
               320
               321
C9A7: 8D 7B 06 323 PSOUT
                             STA BYTE
C9AA: 4E 78 04 324
                             LSR CRFLAG
C9AD: 4C CB C8 325
                             JMP PSCLOUT
                                             : JUMP FOR PASCAL ENTRY
               326
               327
               358
                    * CR LF ROUTINE
               329
C9B0: 20 27 CA 330
                  CRLF
                             JSR
                                 CR
C9B3: EE FB 05 331 LF
                                 CVERT
                                             : INCREMENT CURSOR VERTICAL
                             INC
C986: AD FB 05 332
                             LDA CVERT
C9B9: C9 18
                             CMP
                                             ; OFF SCREEN?
               333
                                  #24
                                             : IF NOT MOVE CURSOR
C988: 90 4A
               334
                             BCC
                                  VTABZ
C9BD: CE FB 05 335
                             DEC
                                 CVERT
                                             : IF SO DECREMENT CURSOR VERTICAL
               336
C9C0: AD FB 06 337
                             LDA START
                                             : INCREMENT THE START ADDRESS
C9C3: 69 04
               338
                             ADC
                                  #$04
                                             ; BY ONE LINE
C9C5: 29 7F
               339
                             AND #$7F
C9C7: 8D FB 06 340
                             STA START
C9CA: 20 12 CA 341
                             JSR
                                  BASCLC1
                                             ; CALCULATE THE START ADDRESS
C9CD: A9 0D
               342
                             LDA
                                  #$0D
                                             ; SET UP CRTC ADDRESS
C9CF: 8D B0 C0 343
                             STA DEVO
                                             ; FOR START LOW ADDRESS
                                             ; GET START LOW
C9D2: AD 78 04 344
                             LDA BASEL
C9D5: 8D B1 C0 345
                             STA DEV1
                                             ; SAVE START LOW
C9D8: A9 0C
               346
                             LDA
                                 #$0C
                                             ; SET UP CRTC ADDRESS
                                             ; FOR START HIGH ADDRESS
C9DA: 8D B0 C0 347
                             STA DEVO
                                             ; GET START HIGH
C9DD: AD FB 04 348
                             LDA BASEH
C9E0: 8D B1 C0 349
                             STA DEVI
                                             ; SAVE START HIGH
                                             ; PUT WINDOW BOTTOM-1 INTO A
C9E3: A9 17
               350
                             LDA #23
C9E5: 20 07 CA 351
                            JSR VTABZ
                                             ; CALCULATE BASE ADDRESS
C9E8: A0 00
               352
                             LDY
                                 #$00
C9EA: 20 04 C9 353
                             JSR CLEOLZ
                                            : CLEAR BOTTOM LINE
```

```
C9ED: 80 95
               354
                             BCS JVTAB
                                            ; MOVE CURSOR BACK
               355
                             CMP #"3"
                   NOT 2
C9EF: C9 B3
               356
                                  JSTOADV
C9F1: D0 0E
               357
                             BNF
C9F3: A9 01
               358 HILITE
                             LDA
                                  #$01
C9F5: 0D F8 07 359 FLOSET
                             DRA FLAGS
C9F8: D0 6
               360
                             BNE FLGSAV
               361
               362
               363 * BASIC INITIAL I/O ENTRY POINT
               344
               365
               366
C9FA: C9 B0
               367
                    NOT 0
                             CMP #"0"
C9FC: D0 9C
               368
                             BNE NOT1
C9FE: 4C 09 C8 369
                             JMP RESTART
               370
                   JSTOADV JMP STOADV
CA01: 4C 27 C9 371
               372
CA04: AD FB 05 373
                    VTAB
                             LDA CVERT
STA ASAV1
                                             : GET CURSOR VERTICAL
CA07: 8D F8 04 374
                   VTABZ
                                              ; MULTIPLY A BY 5
CAOA: OA
               375
                             ASL
CAOB: OA
               376
                             ASL
CAOC: 6D F8 04 377
                             ADC
                                 ASAV1
CAOF: 6D FB 06 378
                             ADC START
                                             ; ADD START
CA12: 48
               379 BASCLC1 PHA
                                             ; SAVE A
CA13: 4A
               380
                             LSR
                                             ; CALCULATE BASEH
CA14: 4A
               381
                             LSR
CA15: 4A
               382
                             LSR
CA16: 4A
               383
                             LSR
CA17: 8D FB 04 384
                             STA BASEH
CA1A: 68
                                             ; RECOVER A
               385
                             PLA
                                             ; CALCULATE BASEL
CA18: 0A
               386
                             ASL
CA1C: 0A
               387
                             ASL
CA1D: 0A
                             ASL
               388
                             ASL
CA1E: 0A
               389
CA1F: 8D 7B 04 390
                             STA BASEL
CA22: 60
               391
                   RTS2
                             RTS
               392
                   *
               393
CA23: C9 0D
               394
                    VIDOUT
                             CMP #$0D
CA25: DO 06
               395
                             BNE VDOUT1
CA27: A9 00
               396
                             LDA
                                 #$00
CA29: 8D 7B 05 397
                             STA
                                 CHORZ
               398
CA2C: 60
                             RTS
CA2D: 09 80
               399
                   VDOUT1
                             ORA
                                 #$80
                                             ; SET HIGH BIT
CA2F: C9 A0
               400
                             CMP
                                  #$A0
CA31: B0 CE
                                  JSTOADV
                                             : IF NOT CONTROL PRINT IT
               401
                             BGE
CA33: C9 87
               402
                             CMP
                                  #$87
CA35: 90 08
               403
                             BLT
                                  RTS4
                                             : CTRL @ - F
CA37: A8
               404
                             TAY
CA38: A9 C9
               405
                             LDA #>BELL
CA3A: 48
               406
                             PHA
CA3B: B9 B9 C9 407
                             LDA CTLTBL-$87.Y
CA3E: 48
               408
                             PHA
CA3F: 60
               409 RTS4
                             RTS
               410
CA40: 18
                             DFB BELL-1
               411
                    CTLTBL
CA41: 71
               412
                             DFB BS-1
CA42: 13
               413
                             DFB RTS3-1
```

```
CA43: B2
              414
                           DFB LF-1
CA44: 48
              415
                           DFB CLREOP-1
CA45: 60
              416
                           DFB CLSCRN-1
CA46: AF
              417
                           DFB CRLF-1
CA47: 9D
                           DFB LOLITE-1
              418
CA48: F2
              419
                           DFB HILITE-1
CA49: 13
              420
                           DFB RTS3-1
CA4A: 13
                           DFB RTS3-1
              421
CA48: 13
              422
                           DFB RTS3-1
CA4C: 13
             423
                           DFB RTS3-1
CA4D: 13
              424
                           DFB RTS3-1
CA4E: 13
              425
                           DFB RTS3-1
                           DFB
CA4F: 13
              426
                                RTS3-1
CA50: 13
              427
                           DFB RTS3-1
CA51: 13
                           DFB RTS3-1
             428
CA52: 66
             429
                           DFB HOME-1
CA53: 0E
              430
                           DFB LEADIN-1
              431
                           DFB RTS3-1
CA54: 13
CA55: 38
              432
                            DFB
                                ADVANCE-1
CA56: 00
              433
                            DFB CLREOL-1
CA57: 14
              434
                            DFB GOXY1-1
              435
CA58: 7B
                            DFB UP-1
              436
                  * CALCULATE SCREEN ADDRESS AND SWITCH IN CORRECT PAGE
              437
              438
              439
              440 PSNCALC CLC
CA59: 18
CA5A: 98
              441
                            TYA
CA58: 6D 7B 04 442
                           ADC
                                BASEL
CA5E: 48
              443
                            PHA
CA5F: A9 00
              444
                           LDA
                                #$00
                                           ; CALCULATE SCREEN ADDRESS HIGH
CA61: 6D FB 04 445
                           ADC
                                 BASEH
CA64: 48
              446
                           PHA
              447
                           ASL
CA65: 0A
                           AND #$0C
                                           ; USE BIT 0 AND 1 FOR PAGING
CA66: 29 0C
              448
              449
                            TAX
CA68: AA
CA69: BD B0 C0 450
                           LDA
                                DEVO, X
                                          ; SET CORRECT SCREEN PAGE
                           PLA
CA6C: 68
              451
CA6D: 4A
              452
                            LSR
CA6E: 68
              453
                            PLA
CA6F: AA
              454
                            TAX
CA70: 60
              455
                            RTS
              456
              457
              458 * PUT A CHARACTER AT CVERT, CHORZ
              459
              460
              461 CHRPUT ASL
CA71: 0A
                                           ; SAVE SHIFTED CHARACTER
CA72: 48
              462
                           PHA
CA73: AD FB 07 463
                            LDA FLAGS
                                           ; GET CHARACTER SET FLAG
CA76: 4A
              464
                           LSR
                                           ; SHIFT IT INTO CARRY
                                           ; RECOVER SHIFTED CHARACTER
CA77: 68
              465
                            PLA
                                           ; ROTATE CARRY INTO CHARACTER
CA78: 6A
              466
                            ROR
CA79: 48
                           PHA
                                           ; SAVE CHARACTER
              467
                           JSR PSNCALC
                                           ; SET UP SCREEN ADDRESS
CA7A: 20 59 CA 468
CA7D: 68
                            PLA
                                           : RECOVER CHARACTER
             469
CA7E: B0 05
              470
                            BCS WRITE1
                                           : SELECT MEMORY RANGE
                                          ; STORE CHARACTER ON SCREEN
CA80: 9D 00 CC 471
                            STA DISPO, X
CA83: 90 03
              472
                            BCC
                                WSKIP
                                           : SKIP
                          STA DISP1, X
                                           ; STORE CHARACTER ON SCREEN
CA85: 9D 00 CD 473 WRITE1
```

```
CA88: 60
               474 WSKIP
                          RTS
                                      ; RECOVER X REGISTER
               475
               476
               477
                   * GENERAL DUTPUT ROUTINE
               478
               479
               480 OUTPT1
CA89: 48
                             PHA
                                             : SAVE CHARACTER
CA8A: A9 F7
               481
                             LDA
                                 #$F7
CA8C: 20 A0 C9 482
                             JSR FLGCLR
CA8F: 8D 59 CO 483
                             STA
                                  $C059
CA92: AD 7B 07 484
                             LDA
                                  POFF
CA95: 29 07
               485
                             AND
                                             ; CHECK FOR LEAD IN
                                  #$07
CA97: DO 04
               486
                             BNE
                                  LEAD
                                             ; BRANCH IF LEAD IN
CA99: 68
               487
                             PLA
                                             ; RECOVER CHARACTER
                                  TUOGIV
CA9A: 4C 23 CA 488
                             JMP
                                             : OUTPUT CHARACTER
               489
CA9D: 29 04
                             AND
                                             ; CHECK FOR GO TO XY
               490 LEAD
                                 #$04
CA9F: F0 03
               491
                                             ; IF NOT SKIP
                             BEQ
                                  GOXY3
CAA1: 4C 87 C9 492
                             JMP
                                  NOTGOXY
CAA4: 68
               493 GOXY3
                             PLA
                                             : RECOVER CHARACTER
CAA5: 38
               494
                             SEC
CAA6: E9 20
               495
                             SBC
                                  #$20
                                             ; SUBTRACT 32
                             AND #$7F
CAA8: 29 7F
               496 GOTOXY
                                             : STRIP OFF UNEEDED BITS
                                             ; SAVE A
CAAA: 48
               497
                             PHA
                                             ; DECREMENT LEAD IN COUNTER
CAAB: CE 7B 07 498
                             DEC
                                 POFF
CAAE: AD 7B 07 499
                             LDA
                                  POFF
CAB1: 29 03
               500
                             AND
                                  #$03
                                             ; GET COUNT
CA83: D0 15
                                             ; SKIP IF COUNT NOT ZERO
               501
                             BNE GOXY2
CAB5: 68
               502
                             PLA
                                             : RECOVER A
                                            ; IF A > WINDOW BOTTOM
                                 #24
CAB6: C9 18
               503
                             CMP
CAB8: B0 03
               504
                             BGE BADY
                                             ; THEN DON'T MOVE CURSOR VERTICAL
CABA: 8D FB 05 505
                             STA
                                 CVERT
CABD: AD F8 05 506 BADY
                             LDA
                                  TEMPX
                                             ; GET CURSOR HORIZONTAL PRAMETER
CACO: C9 50
               507
                             CMP
                                 #80
                                             ; IF A > 80 THEN
CAC2: B0 03
                                             ; DON'T MOVE CURSOR HORIZONTAL
               508
                             BGE BADX
CAC4: 8D 7B 05 509
                             STA
                                 CHORZ
                                 VTAB
CAC7: 4C 04 CA 510 BADX
                             JMP
                                            ; VERTICAL TAB TO CURSOR POSITON
                             PLA
                                            ; RECOVER A
CACA: 68
               511
                    GOXY2
                             STA TEMPX
CACB: 8D F8 05 512
                                             ; SAVE CURSOR HORIZONTAL PARMETER
CACE: 60
               513
                             RTS
               514
               515
                   * STOP LIST ROUTINE
               516
               517
               518
CACF: AD 00 CO 519 STPLST
                             LDA KBD
CAD2: C9 93
               520
                             CMP
                                 #$93
CAD4: DO OF
                             BNE STPDONE
               521
CAD6: 2C 10 C0 522
                             BIT
                                 KRDSTRR
CAD9: AD 00 CO 523 STPLOOP
                             LDA
                                 KBD
CADC: 10 FB
               524
                             BPL
                                 STPL OOP
CADE: C9 83
               525
                             CMP
                                  #$83
CAE0: F0 03
               526
                             BEQ
                                 STPDONE
CAE2: 2C 10 C0 527
                             BIT
                                 KBOSTRB
CAE5: 60
               528 STPDONE RTS
               529
CAE6: A8
               530 ESCNOW
                             TAY
CAE7: B9 31 CB 531
                             LDA XLTBL-$C9,Y
CAEA: 20 F1 C8 532
                             JSR ESC1
CAED: 20 44 C8 533 ESCNEW
                            JSR RDKEY
```

```
CAFO: C9 CE
                534
                               CMP
                                     #$CE
CAF2: B0 08
                535
                               BGE
                                     ESC2
CAF4: C9 C9
                536
                               CMP
                                     #$C9
CAF6: 90 04
                537
                               BLT
                                     ESC<sub>2</sub>
CAF8: C9 CC
                538
                               CMP
                                     #$CC
CAFA: DO EA
                539
                               BNE
                                     ESCNOW
CAFC: 4C F1 C8 540
                     ESC2
                               JMP
                                     ESC1
CAFF: EA
                               NOP
                541
                542
                543
                544
                545
                546
                547
                      * BASIC INITIAL I/O ENTRY POINT
                548
                549
CB00: 2C CB FF 550
                               BIT
                                     IORTS
                                                 ; SET VFLAG ON INITIAL ENTRY
CB03: 70 31
                551
                               BVS
                                     ENTR
CB05: 38
                552
                     INFAKE
                               SEC
                                                 ; FAKE INPUT ENTRY C=0
CB06: 90
                553
                               HEX
                                     90
CB 07: 18
                554
                      OUTENTR
                               CLC
                                                 : OUTPUT ENTRY C=1
C808: B8
                555
                               CLV
CB09: 50 2B
                556
                               BVC
                                     ENTR
CB0B: 01 82
                557
                               HEX
                                     0182
CB 0D: 11
                558
                               DF8
                                     INIT
C80E: 14
                559
                               DFB
                                     READ
CBOF: 1C
                560
                               DFB
                                     WRITE
CB10: 22
                               DFB STATUS
                561
                562
CB11: 4C 00 C8 563
                     INIT
                               JMP
                                     SETUP
                564
CB14: 20 44 CB 565
                     READ
                               JSR
                                    RDKEY
CB17: 29 7F
                566
                               AND
                                     #$7F
CB19: A2 00
                567
                               LDX
                                     #$00
CB1B: 60
                568
                               RTS
                569
CB1C: 20 A7 C9 570
                     WRITE
                               JSR
                                    PSOUT
CB1F: A2 00
                571
                               LOX
                                     #$00
CB21: 60
                572
                               RTS
                573
CB22: C9 00
                574
                     STATUS
                               CMP
                                     #$00
CB24: F0 09
                575
                               BEQ
                                    STEXIT
CB26: AD 00 CO 576
                               LDA
                                    KBD
CB29: 0A
                577
                               ASL
CB2A: 90 03
                578
                               BCC
                                    STEXIT
CB2C: 20 5C C8 579
                               JSR
                                    KEYSTAT
CB2F: A2 00
                580
                     STEXIT
                               LDX
                                    #$00
CB31: 60
                581
                               RTS
                582
                     * BASIC INPUT ENTRY POINT
                583
                584
CB32: 91 28
                585
                      INENTR
                               STA
                                    (BASL), Y
                                                ; REPLACE FLASHING CURSOR
CB34: 38
                586
                               SEC
CB35: B8
                               CLV
                587
CB36: 8D FF CF 588
                     ENTR
                               STA $CFFF
                                                 ; TURN OFF CO-RESIDENT MEMORY
                589
                590
                591
                592
                     * SAVE REGISTERS , SET UP NO AND CN
                593
```

```
594 *
CB39: 48
               595 WHERE
                            PHA
                                            ; SAVE REGISTERS ON STACK
                             STA XSAVE
CB3A: 85 35
               596
CB3C: BA
               597
                             TXA
CB3D: 48
               598
                             PHA
CB3E: 98
               599
                             TYA
CB3F: 48
               600
                             PHA
CB 40: A5 35
               601
                            LDA
                                 XSAVE
                                            ; SAVE CHARACTER
CB42: 86 35
               602
                            STX XSAVE
                                            ; SAVE INPUT BUFFER INDEX
CB44: A2 C3
               603
                             LDX
                                  #$C3
CB46: 8E 78 04 604
                            STX
                                  CRFLAG
CB49: 48
               605
                             PHA
CB4A: 50 10
               606
                             BVC
                                 In
                                            ; GO TO IO IF NOT INITIAL ENTRY
               607
               803
                   * BASIC INITIALIZE
               609
               610
               611
CB4C: A9 32
               612
                            LDA # (INENTR ; SET UP INPUT AND OUTPUT HOOKS
CB4E: 85 38
               613
                            STA KSWL
CB50: 86 39
               614
                            STX KSWH
CB52: A9 07
               615
                            LDA
                                 #<OUTENTR
CB54: 85 36
               616
                            STA CSWL
                            STX CSWH
CB56: 86 37
               617
CB58: 20 00 CB 618
                            JSR
                                           ; SET UP CRTC
                                 SETUP
CB58: 18
               619
                            CLC
               620 *
               621 *
CB5C: 90 6F
               955 ID
                            BCC BASOUT
               623
               624
                   * BASIC INPUT ROUTINE
               625
               626
               627
CB5E: 68
              628 BASINP
                            PLA
                                            ; POP STACK
CB5F: A4 35
              629
                            LDY XSAVE
                                           ; GET INPUT BUFFER INDEX
CB61: F0 1F
              430
                            BEQ GETLN
                                            ; IF ZERO ASSUME GETLN
C863: 88
               631
                            DEY
CB64: AD 78 06 632
                            LDA DLDCHAR
                                            ; GET LAST CHARACTER FROM GETLN
CB67: C9 88
              633
                            CMP
                                #$88
                                            ; IF 8S ASSUME GETLN
CB69: FO 17
               634
                            BEQ GETLN
CB6B: D9 00 02 635
                            CMP
                                 IN, Y
                            BEQ GETLN
CB6E: F0 12
               636
CB70: 49 20
               637
                            FOR
                                #$20
CB72: D9 00 02 638 SKIP
                            CMP IN, Y
                                            ; IF SAME AS CHARACTER IN INPUT
CB75: DO 3B
                            BNE NTGETLN
               639
                                           ; BUFFER THEN ASSUME GETLN
CB77: AD 78 06 640
                            LDA OLDCHAR
                                            ; GET LAST CHARACTER FROM GETLN
CB7A: 99 00 02 641
                            STA IN, Y
                                           ; FIX INPUT BUFFER
CB7D: B0 03
               442
                            BGE GETLN
                                           ; GO TO GETLN
CB7F: 20 ED CA 643 ESC
                            JSR
                                ESCNEW
                                           : PERFORM ESCAPE FUNCTION
CB82: A9 80
              644 GETLN
                            LDA
                                #$80
                                           : SET GETLN FLAG
CB84: 20 F5 C9 645
                            JSR FLGSET
CB87: 20 44 C8 646
                            JSR
                                RDKEY
                                            : GET CHARACTER FROM KEYBOARD
CB8A: C9 9B
               647
                            CMP
                                #$98
                                            ; CHECK FOR ESCAPE
CB8C: F0 F1
              648
                            BEQ ESC
CB8E: C9 8D
              649
                            CMP
                                 #$8D
                                            ; CHECK FOR CR
CB90: D0 05
                           BNE NOTCR
              650
                                            ; IF NOT SKIP
CB92: 48
                           PHA
                                            ; SAVE CHARACTER
              651
CB93: 20 01 C9 652
                           JSR CLREOL
                                           : CLEAR TO END OF LINE
CB96: 68
                           PLA
              653
                                            ; RECOVER CHARACTER
```

```
CB97: C9 95
              654 NOTCR
                             CMP #$95
                                           ; CHECK FOR PICK
                                           ; IF NOT SKIP
CB99: DO 12
              655
                             BNE NOTPICK
CB9B: AC 7B 05 656
                                           ; GET CURSOR HORIZONTAL POSITION
                   CHRGET
                             LDY CHORZ
JSR PSNCALC
CB9E: 20 59 CA 657
                                            ; SET UP SCREEN ADDRESS
CBA1: B0 05
                             BCS READ1
                                             ; READ CHARACTER FROM SCREEN
               658
CBA3: 8D 00 CC 659
                             LDA DISPO.X
CBA6: 90 03
                             BCC RSKIP
               660
CBA8: 8D 00 CD 661 READ1
                             LDA DISP1, X
                                           ; SET HIGH BIT
CBAB: 09 80
                             DRA #$80
               662 RSKIP
                                           ; SAVE CHARACTER IN OLDCHAR
CBAD: 8D 78 06 663
                   NOTPICK
                             STA
                                 OLDCHAR
CBB0: D0 08
               664
                             BNE
                                 DONE
                                            ; EXIT
C882: 20 44 C8 665 NTGETLN JSR ROKEY
                                            ; GET CHARACTER FROM KEYBOARD
CBB5: A0 00
                             LDY #$00
               666
                                            ; CLEAR OLDCHARACTER
CBB7: 8C 78 06 667
                             STY OLDCHAR
               4 866
CBBA: BA
               669 DONE
                             TSY
                                            ; PUT CHARACTER INTO STACK
C888: E8
               670
                             INX
CBBC: E8
                             INX
               671
CBBD: E8
               672
                             INX
CBBE: 9D 00 01 673
                             STA $100, X
CBC1: A9 00
               674 DUTDONE1 LDA #$00
                                            ; SET CH = 00
CBC3: 85 24
               675 DUTDONE STA CH
                            LDA CVERT
                                           : SET CV = CVERT
CBC5: AD FB 05 676
CBC8: 85 25
               677
                             STA CV
CBCA: 4C 2E C8 678
                             JMP
                                 EXIT
               679
               083
                   * PRIMARY BASIC DUTPUT ROUTINE
               681
               682
               683
CBCD: 68
               684 BASOUT
                             PLA
                                            ; RECOVER CHARACTER
CBCE: AC FB 07 685
                            LDY FLAGS
                                            ; CHECK GETLN FLAG
CBD1: 10 08
               686
                             BPL
                                 BOUT
                                            : IF CLEAR THEN SKIP
CBD3: AC 78 06 687
                            LDY OLDCHAR
                                            ; GET LAST CHARACTER FROM GETLN
CBD6: C0 E0
                             CPY #$E0
                                            ; IF IT IS LOWER CASE THEN USE IT
               688
CBO8: 90 01
               689
                             BLT BOUT
CBDA: 98
               690
                             TYA
CBOB: 20 B1 C8 691 BOUT
                             JSR BASOUT1
                                           ; OUTPUT CHARACTER
CBDE: 20 CF CA 692
                             JSR STPLST
CBE1: A9 7F
              693
                             LDA
                                 #$7F
                                            ; CLEAR THE GETLN FLAG
                             JSR FLGCLR
CBE3: 20 A0 C9 694
CBE6: AD 78 05 695
                                            ; GET CURSOR HORIZONTAL
                            LDA
                                 CHORZ
CBE9: E9 47
                             SBC
                                 #$47
               696
C8EB: 90 D4
              697
                             BCC
                                 DUTDONE 1
CBED: 69 1F
               698
                             ADC
                                 #$1F
CBEF: 18
               699 FIXCH
                            CLC
CBF0: 90 D1
              700
                            BCC OUTDONE
               701
CBF2: 60
               702 ESCTBL
                            DFB CLSCRN-1
CBF3: 38
               703
                            DFB
                                 ADVANCE-1
CBF4: 71
               704
                            DFB BS-1
CBF5: B2
                            DEB LE-1
              705
CBF6: 7B
              706
                            DF8 UP-1
CBF7: 00
               707
                            DFB CLREOL-1
CBF8: 48
               708
                            DFB CLREOP-1
CBF9: 66
                            DFB HOME-1
              709
              710
CBFA: C4 C2 C1
CBFD: FF C3
                          HEX C4C2C1FFC3
              711 XLTBL
              712 *
```

CBFF: EA 713 NOP 714 *

CC00: 8D FF CF 715 RDMSH STA \$CFFF CC03: 8D 00 C3 716 STA \$C300 CC06: 60 717 RTS

--ENO ASSEMBLY--

ERRORS: 0

1031 BYTES

SYMBOL TABLE - ALPHABETICAL ORDER:

| | ADVANCE | | | ASAV1 | =\$04F8 | | BADX | =\$CAC7 | • | BADY | =\$CABD |
|---|---------|---------|---|-----------------|---------|---|----------------|---------|---|----------------|---------|
| | BASCLC1 | | | BASEH | =\$04FB | | BASEL | =\$047B | ? | BASINP | =\$CB5E |
| | BASL | =\$28 | | BASOUT | =\$CBCD | | BASOUT1 | | | BELL | =\$0919 |
| | BELL1 | =\$C918 | | BELL2 | =\$C91D | | BOUT | =\$CBD8 | _ | 85 | =\$C972 |
| | BYTE | =\$067B | | CH | =\$24 | | CHORZ | =\$057B | ? | CHRGET | =\$CB9B |
| | CHRPUT | =\$CA71 | | CLEOL 5 | =\$C906 | | CLEOLZ | =\$C904 | | CLEOP 1 | =\$C94F |
| | CLREOL | =\$C901 | | CLREOP | =\$C949 | | CLSCRN | =\$C961 | | CR | =\$CA27 |
| | CRFLAG | =\$0478 | | CRLF | =\$C9B0 | | CSRMOV | =\$C8D1 | | CSWH | =\$37 |
| | CSWL | =\$36 | | CTLTBL | =\$CA40 | | CV | =\$25 | | CVERT | =\$05FB |
| | CVOK | =\$C8C1 | | DEV0 | =\$C0B0 | | DEV1 | =\$C0B1 | | DISPO | =\$CC00 |
| | DISP1 | =\$CD00 | | DONE | =\$C88A | | ENTR | =\$CB36 | | ESC | =\$CB7F |
| | ESC1 | =\$C8F1 | | ESC 2 | =\$CAFC | | ESCNEW | =\$CAED | | ESCHOW | =\$CAE6 |
| | ESCTBL | =\$CBF2 | | EXIT | =\$C85E | ? | FIXCH | =\$CBEF | | FLAGS | =\$07FB |
| | FLGCLR | =\$C9A0 | | FLGSAV | =\$C9A3 | | FLGSET | =\$C9F5 | | GETLN | =\$CB82 |
| ? | GOTOXY | =\$CAA8 | | GOXY1 | =\$C915 | | COXY2 | =\$CACA | | GOXY3 | =\$CAA4 |
| | HILITE | =\$C9F3 | | HOME | =\$C967 | | IN | =\$0200 | | INDONE | =\$C898 |
| | INENTR | =\$CB32 | ? | INFAKE | =\$CB05 | | INIT | =\$CB11 | | 10 | =\$CB5C |
| | IORTS | =\$FFCB | | JSTOADV | =\$CA01 | | JVTAB | =\$C984 | | KBD | =\$C000 |
| | KBDSTRB | =\$C010 | | KEYIN | =\$C847 | | KEYIN2 | =\$C84D | | KEYSTAT | =\$C85C |
| | KSWH | =\$39 | | KSWL | =\$38 | | LEAD | =\$CA9D | | LEADIN | =\$C90F |
| | LF | =\$C9B3 | | LOLITE | =\$C99E | | LOOP | =\$C81B | ? | MSLOT | =\$0778 |
| ? | NO | =\$06F8 | | NOKEY | =\$C857 | | NORMOUT | =\$C83E | | NOSHIFT | =\$C896 |
| | NOTO | =\$C9FA | | NOT1 | =\$C99A | | NOT2 | =\$C9EF | | NOT81 | =\$C933 |
| | NOTE | =\$C88C | | NOTCR | =\$CB97 | | NOTGOXY | =\$C987 | | NOTK | =\$C862 |
| | NOTPICK | =\$CBAD | | NTGETLN | =\$C8B2 | | NTSHFT | =\$C870 | | OLDCHAR | =\$0678 |
| | DUTDONE | =\$CBC3 | | OUTDONE! | =\$CBC1 | | OUTENTR | =\$CB07 | | OUTPT1 | =\$CA89 |
| | POFF | =\$077B | | PSAVE | =\$C911 | | PSCLOUT | =\$C8CB | | PSNCALC | =\$CA59 |
| | PSOUT | =\$C9A7 | | RDKEY | =\$C844 | | READ | =\$C814 | | READ1 | =\$CBA8 |
| | RESTART | =\$C809 | | RNDH | =\$4F | | RNDL | =\$4E | ? | ROMSW | =\$CC00 |
| | RSKIP | =\$CBAB | ? | RTS2 | =\$CA22 | | RTS3 | =\$C914 | | RTS4 | =\$CA3F |
| | RTS6 | =\$C8F0 | | RTS8 | =\$C948 | | SETEXIT | =\$C82A | | SETUP | =\$C800 |
| ? | SKIP | =\$CB72 | | SPKR | =\$C030 | | START | =\$06FB | | STATUS | =\$CB22 |
| | STEXIT | =\$CB2F | | STDADV | =\$C927 | | STPDONE | =\$CAE5 | | STPLOOP | =\$CAD9 |
| | STPLST | =\$CACF | | TABLE | =\$C8A1 | | TEMPX | =\$05F8 | | UP | =\$C97C |
| | VDOUT1 | =\$CA2D | | VIDOUT | =\$CA23 | | VTAB | =\$CA04 | | VTABZ | =\$CA07 |
| ? | WHERE | =\$CB39 | | WRITE | =\$CB1C | | WRITE1 | =\$CA85 | | WSKIP | =\$CA88 |
| | XLTBL | =\$CBFA | ? | XSAV1 | =\$0578 | | XSAVE | =\$35 | | ZERO | =\$C894 |
| | | | | | | | | | | | |

SYMBOL TABLE - NUMERICAL ORDER:

| CH | =\$24 | CV | =\$25 | BASL | =\$28 | XSAVE | =\$35 |
|------|-------|------|-------|------|-------|-------|-------|
| CSWL | =\$36 | CSWH | =\$37 | KSWL | =\$38 | KSWH | =\$39 |

| | RNDL | =\$4E | | RNDH | =\$4F | | IN | =\$0200 | | CRFLAG | =\$0478 |
|---|---------|---------|---|--------------|---------|---|---------|---------|---|---------|---------|
| | BASEL | =\$047B | | ASAV1 | =\$04F8 | | BASEH | =\$04FB | ? | XSAV1 | =\$0578 |
| | CHORZ | =\$057B | | TEMPX | =\$05F8 | | CVERT | =\$05FB | | OLDCHAR | =\$0678 |
| | BYTE | =\$067B | ? | N0 | =\$06F8 | | START | =\$06FB | ? | MSLOT | =\$0778 |
| | POFF | =\$077B | | FLAGS | =\$07FB | | KBD | =\$C000 | | KBDSTRB | =\$C010 |
| | SPKR | =\$C030 | | DEV0 | =\$C0B0 | | DEV1 | =\$C0B1 | | SETUP | =\$C800 |
| | RESTART | =\$0809 | | LOOP | =\$C81B | | SETEXIT | =\$C82A | | EXIT | =\$C82E |
| | NORMOUT | =\$C83E | | ROKEY | =\$C844 | | KEYIN | =\$C847 | | KEY IN2 | =\$C840 |
| | NOKEY | =\$C857 | | KEYSTAT | =\$C85C | | NOTK | =\$C865 | | NTSHFT | =\$C870 |
| | NOTE | =\$C88C | | ZERO | =\$C894 | | NOSHIFT | =\$C896 | | INDONE | =\$C898 |
| | TABLE | =\$C8A1 | | BASOUT1 | | | CYOK | =\$C8C1 | | PSCLOUT | =\$C8CB |
| | CSRMOV | =\$C8D1 | | RTS6 | =\$C8F0 | | ESC1 | =\$C8F1 | | CLREOL | =\$C901 |
| | CLEOLZ | =\$C904 | | CLEOF5 | =\$C906 | | LEADIN | =\$C90F | | PSAVE | =\$C911 |
| | RTS3 | =\$C914 | | GOXY1 | =\$C915 | | BELL | =\$C919 | | BELL1 | =\$C918 |
| | BELL2 | =\$C91D | | STOADV | =\$C927 | | NOT81 | =\$C933 | | ADVANCE | |
| | RTS8 | =\$C948 | | CLREOP | =\$C949 | | CLEOP 1 | =\$C94F | | CLSCRN | =\$C961 |
| | HOME | =\$C967 | | BS | =\$C972 | | UP | =\$C97C | | JVTAB | =\$C984 |
| | NOTGOXY | | | NOT1 | =\$C99A | | LOLITE | =\$C99E | | FLGCLR | =\$C9A0 |
| | FLGSAV | =\$C9A3 | | PSOUT | =\$C9A7 | | CRLF | =\$C9B0 | | LF | =\$C9B3 |
| | NOT2 | =\$C9EF | | HILITE | =\$C9F3 | | FLGSET | =\$C9F5 | | NOT 0 | =\$C9FA |
| | JSTOADV | | | VTAB | =\$CA04 | | VTABZ | =\$CA07 | | BASCLC1 | =\$CA12 |
| 1 | | =\$CA22 | | TUDGIV | =\$CA23 | | CR | =\$CA27 | | VDOUT1 | =\$CA20 |
| | RTS4 | =\$CA3F | | CTLTBL | =\$CA40 | | PSNCALC | | | CHRPUT | =\$CA71 |
| | WRITE1 | =\$CA85 | | WSKIP | =\$CA88 | | OUTPT1 | =\$CA89 | | LEAD | =\$CA9D |
| | COXY3 | ≈\$CAA4 | ? | COTOXY | =\$CAA8 | | BADY | =\$CABD | | BADX | =\$CAC7 |
| | GOXY2 | =\$CACA | | STPLST | =\$CACF | | STPLOOP | =\$CAD9 | | STPDONE | =\$CAES |
| | ESCNOW | =\$CAE6 | | ESCNEW | =\$CAED | | ESC2 | =\$CAFC | ? | INFAKE | =\$CB05 |
| | OUTENTR | | | INIT | =\$C811 | | READ | =\$CB14 | | WRITE | =\$CB1C |
| | STATUS | =\$CB22 | | STEXIT | =\$CB2F | | INENTR | =\$CB32 | | ENTR | =\$CB36 |
| 1 | WHERE | =\$CB39 | | 10 | =\$CB5C | , | BASINP | =\$CB5E | ; | SKIP | =\$CB72 |
| | ESC | =\$CB7F | | GETLN | =\$C885 | | NOTCR | =\$CB97 | ? | CHRGET | =\$CB9B |
| | READ1 | =\$CBA8 | | RSKIP | =\$CBAB | | NOTPICK | =\$CBAD | | NTGETLN | |
| | DONE | =\$CBBA | | OUTDONE | | | OUTDONE | | | BASOUT | =\$CBCD |
| | BOUT | =\$CBD8 | ? | FIXCH | =\$CBEF | | ESCTBL | =\$CBF2 | | XLTBL | =\$CBFA |
| | DISP0 | =\$CC00 | ? | ROMSW | =\$CC00 | | DISPI | =\$CD00 | | IORTS | =\$FFCB |
| | | | | | | | | | | | |

Theory of Operation

While reading this section, you should make frequent reference to the labelled photograph of the VIDEOTERM on page A-4 and the schematic of the board included as a fold-out end-paper. Also, you should refer to the description of the board components on page A-3.

In the middle of the schematic and on the left of the board are four chips labelled U-10 to U-14, inclusive. These are the four static Random Access Memory chips which hold the screen display information. Due to their low power needs, they stay relatively cool during board operation and greatly reduce the power needed to drive the VIDEOTERM.

Information may be placed in VIDEOTERM memory by either the user from the Apple II keyboard or by the VIDEOTERM on-board logic. The determination of which has control of memory at any moment is made by the Multiplexer logic, which consists of the three chips labelled U-14, U-15 and U-16. These are located directly below the RAM on the schematic drawing and directly below the CRTC (the largest chip) on the board.

At the heart of the VIDEOTERM is the Hitichi HD 46505SP CRT Controller which has been described more fully in the preceding chapter, pages 5-1 to 5-8. It appears on the right in the schematic and as U-19 in the photograph. It is located, more or less, in the center of the board. The signal from the CRTC drives the 2716 EPROM Character Generator, U-20 in the photograph and in the upper right corner of the schematic. It contains the standard ASCII character set and some special graphics symbols in each of two

character matrix sizes. Accessed by a single 8 bit code, the generator produces a character signal 8 bits long by 16 lines for definition of an upto 8 by 16 character matrix. Next to the character generator is a parallel to serial shift register chip, unit U-21, which is used to actually generate the character matrix dots. When the graphics characters are used, cell 1 contents are copied into cell 0, since the VIDEOTERM actually uses a 9 by 9 character matrix size (9 by 12 with the optional character set).

The 2708 EPROM, labelled U-3 in the photograph located at the upper left in the schematic, is the firmware chip which holds the VIDEOTERM software listed in the Firmware section starting on page activated, this software controls the 5-15. When VIDEOTERM's response to your keyboard input and data written to it by the Apple II. The 2708 EPROM labelled U-17 in the photograph and located directly above the RAM in the schematic, contains optional second character set of 64 characters or 128 characters if you are using a 2716 EPROM. tri-state inverting buffer, U-24 in photograph and located in various portions of the schematic, is the optional character set EPROM enable/disable logic circuit.

When the I/O select enables the VIDEOTERM, the address is accessed by the software as well as by The incoming data is made multiplexer. available to either the CRTC or the memory depending on the state of the latch circuit, U-5 in the photograph and located next to the EPROM firmware in upper left corner of the schematic. Thus, only of the two can be accessing memory at any one one time: the Apple II data bus or the VIDEOTERM display Part of the two to four line decoder, U-9 in the photograph and near U-5 on the schematic, is used to generate the write enable signal for the memory, allowing information to be stored. other part of this chip's circuit is used to

generate a blank display on the screen while the Apple II is writing into the VIDEOTERM memory.

Two CMOS flip-flop chips, U-7 and U-8 in the photo and located near the bottom of the schematic, control which page of memory (of the four available) is currently being addressed within the range \$CC00 to \$CDFF, and if the VIDEOTERM has been activated or inactivated by addressing within the \$C800 to \$CFFF range (according to Apple II Reference Manual specifications; also see pages 5-10 and 5-12ff).

the VIDEOTERM generated only one character time and did the entire job for each one, it would operate at an intolerably slow speed. Thus, a pipeline architecture has been used in the board In effect, the board displays the last character while it is setting up for the current The data latch, U-18 in the photograph character. and in the upper right next to the character generator on the schematic, operates in conjunction with the data latch U-5 to control the access timing to the memory. A delay shift register, U-22 in the photograph and to the right of the CRTC in the schematic, operates within this pipeline correctly delay and coordinate character attribute information. This chip also handles the cursor and display enable signal generated by the CRTC.

In order to drive the board's logic, an on-board clock circuit, entirely separate from the Apple II's clock, is used. This low power circuit is responsible for the VIDEOTERM's excellent character generation. Part of the chip labelled U-4, the chip U-23 and the crystal contained in the aluminum can compose the clock circuit.

The chip labelled U-1 in the photograph allows the cursor to flash on top of another character. Part of this chip is also used for general buffer purposes. Chips U-2 and U-6 are used for general logic circuit purposes.

Shift Wire Mod

The Shift Wire Mod is a hardware modification which allows the shift key to be used normally, provided it has supporting software, such as the firmware in the Videoterm.

Installation of the Shift Wire Mod

Run a wire from pin 24 of the keyboard connector (the pin second farthest away from the power supply on the wire comb which connects the encoder board to the keyboard) to pin 1 of chip location H-14 on the motherboard (which is electrically the same as pin 4 of the game I/O socket (J-14)).

Use of the Shift Wire Mod

The shift wire mod cannot be used in 40 columns without the use of special software. In 80 columns, the Control-A is used to enter the lower case mode (another Control-A will return you to upper case mode). In lower case mode, characters are lower case unless the shift key is used.

The following special characters are also available:

| Character | Mode | Description |
|---------------|--------------|----------------|
| Left Bracket | Shift Lock | Control-K |
| Right Bracket | Shift Lock | Shift-M |
| Left Brace | Shift Unlock | Control-K |
| Right Brace | Shift Unlock | Shift-0 (zero) |

The Soft Video Switch.

The Soft Video Switch is an automatic version of the Switchplate assembly. It will automatically switch to 80 columns when any character is sent to the Videoterm. If any color graphics mode is active, the Soft Video Switch will automatically switch to the 40 column video signal. When the graphics mode is deselected the Soft Video Switch returns to the previous mode.

Installation and checkout of the Soft Video Switch.

- 1) Turn the Apple] [off and remove the cover.
- 2) Locate the I. C. chip F-14 on the motherboard. It is the second chip down from the game I/O socket. The chip is either a 9334 or a 74LS259. Carefully remove this chip with an IC puller or a small flat bladed screwdriver. Set this chip aside.
- 3) Plug the Soft Video Switch into the F-14 socket. The five prong molex connector should face the keyboard. Be sure that all of the pins go into the socket.
- 4) Place the chip that you removed from the F-14 socket into the socket on the Soft Video Switch. The notched end should point toward the keyboard (the same direction as before).
- 5) Plug the three wire cable from the Soft Video Switch onto the four prong video connector on the Apple] [motherboard. The cable should be oriented so that the two empty holes at the top of the plug are to the right of the Apple] [(i.e. away

from the power supply). Please note the four prong video connector on the Soft Video Switch. This connector is a direct replacement of the video connector on the motherboard (for RF modulators).

- 6) Plug the two wire cable from the Soft Video Switch onto the five pin video connector on the Videoterm.
- 7) Plug the cable supplied with the Videoterm onto the five prong video connector on the Soft Video Switch. This cable should be connected to a monochromatic video monitor.
- 8) Turn your Apple on. If the speaker does not beep upon power up, turn your Apple off and re-check your installation. Pay particular attention to step 4.
- 9) If you have an Autostart ROM, Apple Language Card, or an Apple][plus, goto step 10. Otherwise, your display will probably be blank. If so type the following:

C058 (CR)

10) Adjust the 40 column video level adjustment (a little turn dial on the Soft Video Switch) so that you can see the 40 column screen. You should adjust this to be the same strength as the Videoterm's output signal.

Soft Video Switch Theory of Operation.

The Soft Video Switch is controlled by two conditions: the state of annunciator zero and the color killer signal. If the color killer is off,

the Apple] [is in its color graphics mode and the Soft Video Switch will always display 40 columns (i.e. graphics). If the color killer is on, the Soft Video Switch follows the state of annunciator zero (set to off by Autostart on power up and reset). If the annunciator is off, the Soft Video Switch displays 40 columns. If the annunciator is on, 80 columns is displayed. The firmware on the Videoterm sets annunciator zero on as EACH character is output. To turn annunciator zero on, a memory reference to \$C058 (-16296) must be made. To turn it off, \$C059 (-16295).

Use of the Soft Video Switch.

To enter 80 columns, type:

PR#3 (CR)

To go back to 40 columns, hit Reset or type a control Z immediately followed by a "1". A control X should be used to prevent an error message in immediate mode. A return is not required.

| | _ — — — | | | | | | | | | | | | _ |
|-----------------|-------------------|-----|------------|------------|----------|----------|--|------|---------------|----------|---------------|----------|---------------|
| 240 \$F0 | рдн | S | 'n | ם > | 3 | × | ^ | . 17 | ~ | _ | ^ | | rub |
| 224 \$E0 | , a b | ပ | ъ | e 4 | i 60 | Ч | Ŧ | ۳. | ᅩ | Н | Ħ | ជ | 0 |
| 208 \$D0 | 408 | S | ₽; | o > | Z | × | Y | 2 | | _ | _ | (| ١ |
| 192 \$C0 | ବ ୟ ස | ၁ | Ω, | সাদ | Ď | Ħ | ĭ | J | × | 1 | Σ | Z | 0 |
| 176 \$B0 | 0 1 2 | 3 | 4 1 | ر م | 7 | 8 | 6 | | •• | v | II | ^ | ٠, |
| 160 \$A0 | = | # | ∽ 8 | PC 45 | | <u> </u> | <u> </u> | * | + | • | 1 | | \ |
| 144 \$90 | Dle Dcl Dc2 | Dc3 | Dc4 | Nak Svn | Etb | Can | Em | Sub | Esc | Fs | Gs | Rs | Us |
| - C | 464 | S. | ₹ ; | - } | M | × | 7 | Z_ | , | ~ | 7 | (| ١, |
| 128 \$80 | Nul Soh Stx | Etx | Eot | Enq Ack | Bel | Bs | Ht | Lf | Vt | F£ | $C\mathbf{r}$ | So | $\mathbf{S}1$ |
| \$ | ^ A ^B ^B | ၁င | ₽ { | , H | 5 | Ŧ | ĭ | Ĵ. | ¥ | 건 | Σ, | , | 0 |
| | | | | | | - | <u>. </u> | _ | -, | - | _ | | _ |
| mal: Hex: | \$0 \$1 \$2 | \$3 | \$4 | ده 86 | \$7 | \$8 | 6\$ | ŞΑ | \$B | şc | βD | ŞE | ŞF |
| Decimal: Hex | 0 | ო | 4 - | n vo | 7 | 80 | 6 | 10 | 11 | 12 | 13 | 14 | 15 |

APPENDIX

ASCII CHARACTER CODE CHART

| b ₇ | 0 | 0 | 0 | 0 | 0 | 0 | | I I 0 | 1 |
|---|-----|-----|----|---|---|---|---|-------------|-----|
| BITS 04 0 3 2 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 | 0 | ı | 2 | 3 | 4 | 5 | | 6 | 7 |
| 00000 | NUL | DLE | SP | 0 | Q | Р | | | Р |
| 00011 | SOH | DCI | ! | 1 | Α | Q | | a | 9 |
| 0010 2 | STX | DC2 | " | 2 | В | R | | _ b | r |
| 00113 | ETX | DC3 | * | 3 | С | S | | С | 5 |
| 0100 4 | EOT | DC4 | \$ | 4 | D | T | | d | t |
| 0 1 9 1 5 | ENO | NAK | % | 5 | Ε | U | | е | u |
| 0 1 1 0 6 | ACK | SYN | 8 | 6 | F | V | | f | V |
| 0 1 1 1 7 | BEL | ETB | ' | 7 | G | W | | g | W |
| 1000 8 | 88 | CAN | | 8 | Н | X | | h | X |
| 1001 9 | HT | EM | | 9 | 1 | Y | | | у |
| 1010 10 | LF | SUB | * | : | J | Z | | | Z |
| 1011 11 | VT | ESC | + | ; | K | [|] | k | |
| 1 1 0 0 12 | FF | FS | | < | L | \ | | | : |
| 1 1 0 1 13 | CR | GS | _ | = | М |) |] | m | } |
| 1 1 1 G 14 | SO | RS | | > | N | ^ |] | n | ~ |
| 1 1 1 1 15 | ŞĮ | UŞ | / | ? | 0 | _ |] | 0 | DEL |

Notes

TECHNICAL SUMMARY

Board Description

Consult Figure 10, page A-4, for the location of each IC on the VIDEOTERM board. Function of each chip is described in the Theory of Operation section, page 6-1.

| Unit No. | Description |
|--------------|---|
| ** 1 | 7/7.00/ 7 1 1 1 0 0 0 0 0 0 0 0 0 0 0 0 0 0 0 0 |
| U-1 | 74LS86 Exclusive OR gate, general use |
| U-2 | S |
| U-3 | 0 |
| U-4 | 74LS04 Partly used for clock circuit |
| U - 5 | , |
| | choice |
| U - 6 | 75LS00 Four NAND gates |
| U-7 | |
| U-8 | |
| U - 9 | |
| U-10 | 2114 Static RAM organized as 4 bits |
| | x 1K words (low-power) |
| U-11 | 2114 Static RAM |
| U-12 | 2114 Static RAM |
| U-13 | 2114 Static RAM |
| U-14 | 74LS157/74LS158 Multiplexer logic use |
| | 74LS157/74LS158 Multiplexer logic use |
| U-16 | 74LS157/74LS158 Multiplexer logic use |
| | 2708 or 2716 EPROM containing optional |
| | character set, organized either |
| | as 8 or 16 bits x 1K words |
| U-18 | 74LS273 (Std.) or 74LS374-Factory choice |
| U-19 | Hitachi HD46505SP/Motorola MCM6845 |
| | CRT Controller |
| U-20 | 2716 EPROM Character generator |
| U-21 | 74LS166 Parallel to serial shift register |
| | 74LS175 Delay shift register |
| | 74LS161 System timing clock generator |
| | 74LS368 Tri-state inverting buffer |
| | |






Figure 10: VIDEOTERM Board Photograph





Notes

Index

| Applesoft ASCII chart | 4-3, 4-22 A-1 |
|---|---|
| Character Sets Control Characters CRTC Cursor | 4-38 thru 4-41 3-4, 3-5, 3-6 thru 3-10 5-1 thru 5-11 1-7, 5-5, 5-7 |
| Escape Codes | Errata, 3-9 |
| Firmware | Errata, 5-15 |
| Graphics | 3-4, 4-3, 4-4, 4-37, 6-1 |
| Integer BASIC Inverse | 4-2, 4-13 Errata, 3-4 |
| Listing (Firmware) | 5-15 |
| Memory mapping Memory usage Micro Modem | 5-12 thru 5-14 3-2, 4-8 4-31 thru 4-34 |
| Normal video | Errata, 3-4 |
| Parts list Pascal Printers | A-3 4-4, 4-28 4-9 thru 4-12 |
| Registers | 5-2 thru 5-10 |
| Schematic Scratch Pad Usage Shift Mod Soft Video Switch Softcard Switchplate | A-5 3-2 6-4 Errata, 6-5 4-31 Errata, 2-5 |

Theory of Operation 6-1 thru 6-3

RMA # RMA Form for Videoterm VT6(5) Serial # _____ Call (503-758-0521) for RMA# Previous Service RMA Name_____ Shipping Address: Name_____ Organization _____ Addr. _____ Addr. _____ Shipping Instr. Phone # (days)_____ Phone # (evenings)_____ Date purchased _____ Received _____ System Configuration: Old Monitor ROM ☐ Autostart ☐ Apple If □ Apple][plus Resident Language: AppleSoft Integer Number of disc drives: List on the back of the page all products installed in the Apple at the time the failure occurred, and any software that was in use. For problems that occurred during installation, did you get a: ☐ Display? power light?

Were there any installation errors?

□ power-up beep?

| Describe, in detail, the nature of the problem. |
|--|
| |
| |
| |
| Describe, in detail, the circumstances under which the problem occurred. |
| |
| |
| |
| Does the problem occur only several minutes after powerup? ☐ Yes ☐ No |
| COMMENTS: |
| |
| |



Corvallis, Oregon 97330 503/758-0521